





ITTTTTTTTTTTT

MAINTENANCE MANUAL Models PS/PR-7036

CONTENTS

CONTENTS
SECTION 1 - General Information PAGE
Important Safety Notice
Safety Precautions
Axle Identification
Gear Set Identification
Servicing Components not Covered in this Manual
Vehicle Storage or Prolonged Inoperation
Submersion or Deep Water Fording
Axie Lubricant Change Schedule
General Precautions for Assembly and Disassembly
SECTION 2 - Planetary Wheel End, Wheel End Brakes, Axle Shaft,
Steering Knuckle, Steering Cylinder, and Te Rod
3 SED Drive Elange
Wheel End 3 650 Beduction
Wheth Lisc Brake Wheel End 3 650 Beduction
Tie Bod and Steering Cylinder Mounting
Axle Steering Joints
Wheel End Disc Brake
Removal of Planetary Drive Flange Assembly
Disassembly of 3.650 Drive Flange
Disassembly of Wheel End Hub
Disassembly of Wet Disc Brake Wheel End
Removal and Disassembly of Spindle and Axle Shatt.
Removal of Steering Cylinder and Tie Hod Assemble 4.
Disassembly of Steering Knuckles
Installation of Tie Bod and Steering Cylinde Assemblies
Assembly and Installation of Axle Shaft an Spirile
Assembly of Wheel End Hub
Assembly of Wet Disc Brake When End
Assembly of 3.650 Drive Flanger
Steering Cylinder Disassembly an Argemony
Disassembly and Assembly of Wheel End Disc Brake
SECTION 3 - Carrier, semble Limite, Slip Differential Option,
Pinion Ma Nic 7 Dry Disc Parking Brake Option
Carrier Assembly
Bemoval of Carber Er in Axle Nousing
Removal r Difference al From Carrier
Differential Disasser bly
Pinice Disassembly
Differen iak ssembly
n Polition and Assembly
Differential resultation
Hip theat and Pinion Tooth Contact Pattern
isian Aurora Dry Dice Parking Brake
Horn Mounted Div Disc Taking Drake
Parking Brake — Disassembly/Assembly.
Parking Brake — Bleeding/Trouble Shooting
Inspection and Failure Analysis
SECTION 4 - Specifications
Spicer Axle Lubricant Recommendations
Fastener Strength Identification
Wrench Tightening Torque Specifications
Bearing Preload Specifications
Drive Pinion Ring Gear Backlash Specification

SECTION 1 GENERAL INFORMATION

IMPORTANT SAFETY NOTICE

Should an axle assembly require component parts replacement, it is recommended that "Original Equipment" replacement parts be used. They may be obtained through your local service dealer or othe original equipment manufacturer parts supplier. CAUTION: THE USE OF NON-ORIGINAL EQUIPMENT REPLACEMENT PARTS IS NOT RECOMMENDED AS THEIR USE MAY CAUSE UNIT FAILURE AND/OR AFFECT CHILD EL AFETY. Proper service and repair is important to the safe, reliable operation of all motor vehicles or o ving axles whether they be front or rear. The service procedures recommended and described in this service manufal are effective

they be front or rear. The service procedures recommended and described in this service manual are effective methods for performing service operations. Some of these service operations to price use of tools specially designed for the purpose. The special tool should be used when and as recommended.

CAUTION: EXTREME CARE SHOULD BE EXERCISED WHEN WORKING ON COMPONENTS UTILIZING SNAP RINGS OR SPRING LOADED RETENTION DEVICES. FOR PERS NAL SALETY, IT IS RECOMMENDED THAT INDUSTRIAL STRENGTH SAFETY GOGGLES OR GLASSES BE WORK WHENEVER REPAIR WORK IS BEING DONE ON ANY VEHICLE OR VEHICLE COMPONENTS.

It is impossible to know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. coordingly, anyone who uses a service procedure or tool which is not recommended must first satisfy him can horoughly that neither his safety or vehicle safety will be jeopardized by the service methods he selects.

WARNING

Some vehicle manufacturers may require the assumbly of brake components on Dana axles that utilize materials containing asbestos fibers.

BREATHING ASBESTOS DUST MAY DE HALARDOUS TO YOUR HEALTH AND MAY CAUSE SERIOUS RESPIRATORY OR OTHER BODILY HARM

Follow O.S.H.A. standards for proper protective devices to be used when working with asbestos materials.

SILICONE PUBLIC STALLAT (RTV) AND LUBRICATING GREASE AND OILS

Silicone rubber sealant is used as a gasket material on some Dana axles, as well as various lubricants and other materials. Before us to any or these materials, one should become familiar with and follow all safety precautions as recommended by the product manufacturer/supplier. All personnel involved with these materials should follow tood a dustrial hygiene practices (e.g. before eating, hand and face should be thoroughly washed. Erang, drinking and smoking should be prohibited in areas where there is potential for significant exposure to these materials).

When discurding any owne materials, observe all local, state, and federal laws and regulations for proper disposal procedures.

fety Precautions

This symbol warns of possible personal injury.

A serious or fatal injury can occur ...

- if you lack proper training
 - · if you fail to follow proper procedures
 - if you do not use proper tools and safety equipment

- if you assemble components improperly
- if you use incompatible components
- if you use worn-out or damaged components
- if you use components in a nonapproved application

SAFETY GLASSES SHOULD BE WORN AT ALL TIMES WHEN WORKING ON VEHICLES OR VEHICLE COMPONENTS.



A A A A A A

Axle Identification

-

....

-

0



The identification tag located on the rear of the axle housing contains the axle assembly number, the serial number and the build date. It is recommended then referring to components of the axle assembly, the all the information recorded on this tag be obtained to aid in the correct identification.

Gear Set Identification

Manufacturer's date—date gear set was made. Dana—Dana name—and location of manufacturing. 572199C91—part number of ring gear. (Typical)

Tooth combination (i.e. 37-6)—indicates the pinion has 6 teeth and the ring gear 37 teeth which results in a 6.17:1 ratio.

Matched set number—Spicer ring and pinions are manufactured as a matched set. Both pieces are marked with a corresponding number (i.e. 268) and indentifies them as a matched set.

A gear set that does not have the same matching numbers should not be run together. If e her wring gear or pinion require replacement they must be replaced as a matched set.





Servicing Components Not Covered In This Manual

Service procedures for some components may not be covered in this manual because they are unique to the vehicle application. Refer to the vehicle manufacturer's service manual for servicing those components.

Vehicle Storage Or Prolonged Inoperation

If the vehicle has not been operated on a regular daily basis, it is recommended that the vehicle be operated that the vehicle be operated to the least once every two weeks. The vehicle should be moved far enough to cause the drivetrain components to make several complete revolutions. This procedure will help assure that all internal components because adequate amount of lubrication to help reduce component deterioration caused by an undesirable environment (r.g. high humidity).

Submersion Or Deep Water Fording

If the vehicle is exposed to water deep enough to cover the hubs, it is recommended in the wheel ends be disassembled and inspected for water damage and/or contamination.

In the event the carrier housing should become submerged in trater, particularly if over the breather, it is recommended that the hypoid gear lubricant be drained and interval parts to inspected for water damage and/or contamination.

Clean, examine, and replace damaged parts if necessary, prior to assumbling and refilling with the specified lubricants.

NOTE: If the hubs are exposed to deep water, it is nos the instearing axles that the water could enter the carrier at the point the inner axle shaft enters the ane housing. This could also necessitate the draining of the hypoid lubricant as described above.

It is recommended that whenever bearings an removed, they be replaced with new ones, regardless of mileage.

Axle Lubricant Charge Schedule

The following schedule is a suggested lubricant change schedule. Lubricant in your vehicle may require more frequent changes depending on the environment in which it is operated. Contact your local authorized service dealer or refer to your wher's minual for obtaining the proper lubricant change schedule for your vehicle.

BREAK IN

After 100 hours a operation, the lubricant should be drained and replaced with fresh lubricant to the correct level and of the type specified.

JE WICL

It is recommended that the lubricant be changed at 2000 nears of operation. When yearly usage is less than 4000 hours, the lubricant should be changed to be yearly.

AFTER OVERHAUL

When refilling the axle assembly or planetary hub assembly after it has been disassembled for service, the lubricant should be filled to the bottom of the fill hole located in the bowl of the axle housing or the planetary drive flange. After 24 hours of operation recheck the lubricant level and bring it up to the bottom of the fill hole again, if necessary. This procedure is recommended to replenish the small amount of lubricant that is retained in the differential support case or planetary gearing during initial operation of the axle immediately following an overhaul.



IMPORTANT

READ THIS SECTION BEFORE STARTING THE DETAILED ASSEMBLY OR DISASSEMBLY PROCEDURES.

USE ONLY GENUINE REPLACEMENT PARTS FOR SATISFACTORY SERVICE.

NOTE: The photos or pictures contained herein are for illustrative and instructional purposes only. The appearance of your axle assembly and/or components may vary from that shown. However, the service procedures described will apply.

If it becomes necessary to disassemble any parts inside the carrier, it is suggested that the entire axle be removed from the vehicle and held tight in a stand or rack.

All dimensions are in inches unless otherwise stated.



-

WARNING: When removing axle assembly, make sure vehicle is properly supported. Improperly supported vehicle can cau serious injury or death. Follow vehicle manufacturers recommendation for prope axle assembly removal processives.

Safety Glasses should be worn

at all times when

assembling resassembling.

CLEANL' LESS

The axe assessoly should be steam cleaned prior to disassenable Seal at openings before steam cleaning to prevent entry or dirt and water which can damage service able parts.

The sugnition all parts just prior to assembly.

REBALD FACILITIES

If the axle assembly is removed from the vehicle, it must be safely supported at three points on the housing. If the axle is to remain in the vehicle, use the OEM recommended support method.

A suitable holding fixture should be used rebuilding the carrier assembly. A lifting device should be used to relocate the carrier assembly and to install or remove the ring gear and support case assembly.

END YOKES AND FLANGES

CAUTION: Hammering on end , akes or flames to remove or install them is not only desumate to the voke or flange itself, the mails cause serious internal damage. A mmering on end yokes can close in the sonring bores or misalign yoke lugs and result in each fanores of journal needle bearings of other driveline components. Serious damage can also be done internally to the ring and rinion set on the boot bearings by hammering on external parts. End yokes or flang s should be removed or installed using a recome readed method such as that described in.

BEARIN

se suif the pullers for bearing removal. Clean, inspect, and lubricate all bearings just prior to eassembly.

NOTE: It is recommended that whenever bearings are removed, they are (regardless of mileage) to be replaced with new ones.

NOTE: If replacement of a damaged bearing cup or cone is necessary, the cup and cone must be replaced as a set.

OIL OR GREASE SEALS

Whenever it becomes necessary to remove an oil or grease seal to gain access to an adjacent component for replacement or repair, that seal is to be discarded because of possible damage.

CLEANING

Parts with machined or ground surfaces such as gears, bearings, and shafts should be cleaned with emulsion cleaners or petroleum based cleaners. Steam cleaning of internal components and the interior of the planetary hub and axle housing is not recommended. Water can cause corrosion of critical parts. Rust contamination in the lubricant can cause gear and bearing failure.

Clean all surfaces of old gasket material.

DRYING

Use clean lintless towels to dry components after cleaning. DO NOT dry bearings by spinning with compressed air. This can damage mating surfaces due to lack of lubrication.

After drying, components should be lightly coated with oil or rust preventive to protect them from corrosion. If components are to be stored for a prolonged period they should be wrapped in wax paper.

INSPECTION

Prior to reassembly, inspect parts for signs of wear or damage.

Bearing surfaces should be inspected for pitting, wear, _____ or overheating.

Inspect, all bearings, cups, and cones, and replace if worn, pitted or damaged. When replacing bearings, use a suitable puller or pressing fixture to remove them. Avoid using drifts and hammers which may mutilate or distort component parts.

Inspect planetary and carrier components for wear or damage. Replace if the following conditions are found.

- · Worn, chipped, pitted or scored gears.
- Worn, pitted, or scored thrust washers.

- Worn or scored planet gear or differential pinion gear shafts.
- Axle shafts or worn splines, bends, cracks, or for torsional fractures or other indications of impending failure.
- BOLTS: Make sure all bolts are torqued to the recommended specifications.

• LUBRICATION: Coat bearings, sealed and solines with lubricant to provide initial lubrication and powent damage during assembly.

• BEARINGS: Bearing drivers which apply equal forces to both races of the bearing are recommended. If another type of driver is used, his invariant that the driving force not be transmosted through the rollers.

USE A PRESS WHEN POSSIBLE WHEN ASSEMBLING COMPONINT PARTS WHICH REQUIRE AN UTERFER INCE FIT.

Dana Corporation, oncer Off-Highway Axle Division, reserves the right to make changes from time to time, without notice or obligations, in specifications descriptions, and illustrations, and to discutive models or revise designs.

SECTION 2 Planetary Wheel End, Wheel End Brakes, Axle Shaft, Steering Knuckle Steering Cylinder, Tie Rod

3.650 Drive Flange

1 Capscrew—Self Locking Flange Mounting

2

- 2 Pipe Plug or Vent
- 3 Recessed Drive Pipe Plug (Magnetic)
- 4 Planetary Drive Flange
- 5 Planetary Gear Shaft
- 6 Roll Pin
- 7 Drive Flange Washer (Thrust Washer)
- 8 Flat Spacer (Thrust Washer)
- 9 Needle Roller Bearing
- 10 Spacer Ring-Bearing
- 11 Planetary Spur Gear
- 12 Plate—Lining Stop (Wheel End Wet Disc Brake Use Only)











Removal of Planetary Drive Flange Assembly

NOTE: The following procedures are the same for both rigid and steer axles.

1. Rotate hub so drain plug is down. Remove plug and drain oil.

000000

りりりりり

00



3. Tap drive flat the with soft faced hammer to break loose from tub. In move drive flange from hub.

Disassembly of 3.650 Drive Flange



1. Using a hammer and punch, drive roll pins out of planet gear shafts. Remove lining stop plate for wheel end wet disc brake if used.



2 Insertory bar into groove in planet gear shaft and repove 5 ar shaft.



3. Remove planet gears and thrust washers.



4. The planet gears are supported on the planet shafts by two rows of needle bearings divided by a spacer ring and a thrust washer on each end.
5. Inspect the thrust button located in the center of the drive flange. If worn, replace.

WARNING: Keep the groove under the thrust button open. It is the access to the air vent if used.



Disassembly of Wheel End Hub

NOTE: the following procedure is the same for both rigid and steer axles.



1. Insert small screwdriver under end and remove locking ring from end of axle shaft by rotating around shaft.





4. Remove the wheel bearing adjusting neurosing a three pin spanner wrench. Some teol. (451125) NOTE: If axle is equipped with wheel and disc brakes, remove the caliple as embly at this time as outlined in the disc brake section of this manual.



2. Remove sun rear and spacer from axle shaft.



3. Remove ring gear. Use a suitable puller if necessary. NOTE: DO NOT pilot puller on axle shaft. This may damage the inboard axle seal.



5. Remove the outer wheel bearing while supporting the hub assembly.



6. With the hub supported, carefully remove it from the spindle.

NOTE: A lifting device is recommended for assemblies having a rotor attached.



7. If the axle is equipped with disc brakes the rotor can be removed at this time.

8. Rest hub on drive flange mounting face and remove the hub seal and inner wheel bearing.

9. Inspect wheel bearings and cups and replace if necessary. Remove cups with a suitable puller.

NOTE: It is recommended that whenever bearings are removed, they are (regardless of mileage) to be replaced with new ones.

NOTE: If replacement of a damaged bearing cup or cone is necessary, the cup and cone much be replaced as a set.

NOTE: Whenever it becomes incessary to remove an oil or grease seal to gain accurs to an adjacent component for replacement or replacement seal is to be discarded because of possible damage.

Disassembly of Wet Disc Brake Wheel End

NOTE: the following procedure is the same for both rigid and steer axles.



1. Insert small screwdriver under locking ring on axle shaft and remain by rotating around shaft.



2. Remove sun gear from axle shaft.



3. Remove brake plates and discs. Check friction material thickness on discs. If groove depth is less than .005" they must be replaced.

Inspect stationary plates for warpage with a straight edge. If warpage is observed they must be replaced. Inspect all plates and discs for heat damage. Replace if necessary.

NOTE: If any of the above conditions exist it is necessary to replace all discs and plates together as a set. Piston O-rings should also be replaced at this time.

If brake discs and plates are within specifications and brake was operating properly it is not necessary to remove brake piston or replace piston O-rings.

SPECIAL SERVICE NOTE: If the service procedure being performed does not require replacement of piston or wheel retainer O-rings the hub assembly may be removed using the following steps. A. Safely support hub assembly with lifting device.



B. Remove wheel retainer cap-screws.

5

E. Skip following steps #4 thru #9. Continue disassembly with step #10.



4. Remove brake a ston from wheel end. NOTE: Use of a special picton remover/installer tool, (Dark tool #45 no-7, is recommended to prevent damage to the piston.



C. Remove planetary ring gear, take place, and wheel retainer as one unit



5A. Remove outer diameter piston O-ring. Discard and replace with new.



5B. Remove inner diameter piston O-ring. Discard and replace with new.



D. Remove oil passage O-rings from grooves on inboard face of wheel retainer. If damaged, replace. If ok, save for re-assembly.



6. Safely support hub assembly with a lifting device. Remove wheel retainer capscrews. Remove wheel retainer and preload shims. Wire shims to retainer to facilitate re-assembly.



9. Remove planetary ring, per from wheel end.
Inspect outboard wheel be ring. Replace if necessary.
10. With hub supraneous pare. By remove it from the spindle.







8. Remove and inspect outer diameter O-ring on inboard side of wheel retainer. Replace if necessary.



11. Inspect wheel bearings, cups and seal. Replace if necessary.

NOTE: It is recommended that whenever bearings are removed, they are (regardless of mileage) to be replaced with new ones.

NOTE: If replacement of a damaged bearing cup or cone is necessary, the cup and cone must be replaced as a set.

NOTE: Whenever it becomes necessary to remove an oil or grease seal to gain access to an adjacent component for replacement or repair, that seal is to be discarded because of possible damage.

Removal and Disassembly of Spindle and Axle Shaft



1A. Remove spindle mounting nuts and flat washers. On planetary equipped with disc brake, the caliper mounting bracket can be removed when the spindle mounting nuts are removed.

000000



1B. On planetary equip, ed with web disc brake wheel ends remove brace inlet noing and bleeder screw. Remove spindly mounting non-washers, and (if used) the fitting/bleede or ards.



2. Tap spindle with soft faced hammer to loosen from steering knuckle or housing flange. Remove spindle.



3. The spindle in many applications, contains an outer shaft of seal and bronze bushing in the spindle bore. The e should be replaced if necessary.

NOTE: innerent it becomes necessary to remove an oil or regulate seal to gain access to an adjacent component for replacement or repair, that seal is to be obscarded because of possible damage.

NOTE. Inspect the spindle mounting studs in steer knuckle or axle housing (rigid axle) for damage and replace if necessary.



 To remove axle shaft assembly on the steering axle, hold shaft level and pull straight out to avoid damaging inner shaft oil seal.

NOTE: To remove axle shaft on rigid axles, pull shaft straight out.



5. To separate inner and outer axle shafts, on steering axle, first remove all bearing cap retaining rings.



6. Next, press out u-joint bearing trops and remove cross.7. Inspect u-joint bearing cars and cross and replace

722252525252525257

if necessary.

Removal of Steering Cylinder and Tie Rod Assemblies

1. Disconnect the hydraulic hoses to the steering cylinders. Plug the open fittings.



Semule the cotter pins from the steering cylinder sortet assumblies.



3. Remove the slotted hex nuts that fasten the cylinder socket assemblies to the anchor points on the carrier and steering knuckle. Tap the threaded end of socket assembly lightly with a soft faced hammer to unseat them. Carefully remove steering cylinder assemblies. Mark cylinder assemblies "rightside" "leftside" to aid reassembly.

CAUTION: Protect chrome finish on rod at all times. Damage to surface of rod can cause premature seal failure.

NOTE: Refer to steering cylinder disassembly and assembly section of manual if further disassembly of cylinder assembly is required.



4. Remove the cotter pins from the tie rod socket assemblies.



5. Remove the slotter does not a that fasten the tie rod socket assemblie to the sperior knuckle anchor points. Tap the threaded end of the socket assembly lightly with a soft faced har her to unseat them. Remove the tie rod observaly. Match marked tie rod end any steering knuckle to aid in reassembly. NOT : Do not alter the tie rod adjustment unless further repair is required to tie rod components. In epair is required or tie rod adjustment is inadverted by changed it will require the resetting of this adjustment for proper "toe-in".

Disassembly of Steering Knuckles

1. Remove the wheel end components upindle baxle shaft, steer cylinder, and tie rod prior to lise sembly of steer knuckle components.



2. emove bearing cap bolts and washers from both upper and lower bearing caps.



3. Remove both upper and lower bearing caps and shims. Wire shims together with their respective bearing caps to facilitate reassembly.



4. Tip the steering knuckle slightly and remove from housing yoke.



6. Inspect axle seal and bushing. If replacement is necessary, replace we supplie puller.





7. Inspect bearing cup and seal; replace if necessary.

NOTE: It is recommended that whenever bearings are removed, they are (regardless of mileage) to be replaced with new ones.

NOTE: If replacement of a damaged bearing cup or cone is necessary, the cup and cone must be replaced as a set.

NOTE: Whenever it becomes necessary to remove an oil or grease seal to gain access to an adjacent component for replacement or repair, that seal is to be discarded because of possible damage.

Assembly of Steering Knuckles

1. Install inner axle shaft bushing and seal into housing yoke bore.

2. Apply #2 Permatex to grease retainers. Install grease retainers and king pin bearing cups into housing yoke.

NOTE: The grease retainer must be installed with its "dished" portion positioned toward the inside of the axle housing yoke. Installed opposite, the retainer would restrict the bearing cup from seating properly in the housing bore and clamp against the bearing cone cage restricting movement.



6. Place original sums in positic, on knuckle or king pin cap.

Install pregreased king pin braring ones in bearing cups.
 Install king pin seals.
 NOTE: Inspect the spindle mounting studs in steer knuckle for damage and replace if necessary.



5. Place knuckle in position over housing yoke.



7. Install bearing caps, washers, and bolts. Torque to 80-90 ft. lbs.



8. To check king pin bearing preload, turn knuckle all the way to the right. Place torque wrench on one of the king pin cap bolts. Rotate knuckle through complete turn angle. Torque reading should be 8-15 ft. lbs. Measurement is made less hub components, axle shaft, tie rod, and steering cylinder.

To increase preload, remove shims from top or bottom king pin bearing. To decrease preload, add shims to top or bottom king pin bearing. Keep top and bottom shim packs as equal as possible.

Installation of Tie Rod and Steering Cylinder Assemblies

NOTE: The carrier assembly and steering knuckles are to be installed prior to proceeding with the installation of these components.



1. Connect the tie rod assembly make steering knuckle anchor points, arque the nocket assembly slotted nuts to 140 ftees, minimum. Check to make sure the position of the officet in the tie rod clears the carrier assembly in full the position (both directions). The tie rod an embly should be switched around end for end if full the clearance is not found and the slotted may retorged.

NOTE if the de roo adjustment (toe-in) has been change Li will be necessary to readjust it. Loosen is a d comparisembly bolt and nut. Position the stee ing knowles in a straight ahead (0° turn and comparisembly bolt and nut. Position the stee ing knowles in a straight ahead (0° turn and comparised of the steering knowles. Masure across them on the carrier side and cover side of the axle housing and compare readings. Remove tie rod, adjust the overall socket to socket length (in or out), reinstall the tie rod assembly and remeasure. Repeat this procedure until equal measurements are attained (zero toe-in) or the toein specified by the vehicle manufacturer is attained. Retorque slotted nuts to 140 ft. lbs. minimum. Torque the tie rod clamp assembly bolts and nuts to 60-70 ft. lbs.



Institute cotton pins and bend the pin over to lock it in place.
 NOTI If cotter pin cannot be installed after

NOT If cotter pin cannot be installed after minipum torque is attained, the nut must be advanced until the cotter pin can be installed.



3. Connect the steering cylinder assemblies to the carrier and steer knuckle anchor points. Torque the socket assembly slotted nuts to 140 ft. lbs. minimum. NOTE: If repairs were made to or the retracted length of the steering cylinder assembly was inadvertently changed the retracted length of the assembly will require resetting as follows:

A. Remove slotted nuts from and remove rod end socket assemblies from steer knuckles. Push in or use air pressure retract the rod into the barrel assembly of both cylinders.



B. Turn steering knuckle to full inside turn position on either the right or left hand side.

C. Adjust the socket assembly position in or out on the rod end and also barrell end, if required, such that its retracted length matches the length required for assembly to its steer knuckle. CAUTION: Protect the rod from damage while adjusting socket position.

Reconnect the cylinder assembly as noted in step #3. Torque the cylinder socket clamp bolts and nuts to 60-70 ft. lbs.

D. Turn the other steer knuckle to its full inside turn position. Adjust its steer cylinder retracted length as noted in step C.



4. Install cotter pine and band the pin over to lock it in place.

NOTE: If cotter per cannot be installed after minimum torque is trained, the nut must be advanced until the cotter pin can be installed.

5. Connect the hydraulic hoses to the steering cylinds and "blood" the system.

Assembly and Installation of Axle Shaft and Spindle



1. To assemble inner and outer axle shafts, insert u-joint ross into yoke of outer shaft and press in bearing c.r.s. Repeat with center yoke and inner shaft.



2. Install all bearing cap retaining rings. Grease u-joint.



3. Support shaft assembly and slide into axle housing and engage in differential side gear. Care should be taken when installing shaft as not to damage axle shaft oil seal.

NOTE: On rigid axles, install the axle shaft into the axle housing until it engages the differential side gear.



4. Install new bushing and seal in spindle if required.



5. Install spindle over the axle shaft and onto knuckle or housing flange studs.

NOTE: Care should be taken when slidh mane spindle over the end of the axle cost so as not to damage the outer shafe sear and bushing if so equipped.

NOTE: On planetal per apped with wet disc brake wheel ends the spinol is to be assembled to the mounting stads with the blake bleeder port positioned a the cop (12 o'clock position) and the brake inter portion the carrier side of the axle houring.





6A. On planetary equipped with disc brake, install the caliper mounting fraction be mounting studs. The bracket is to be positioned such that when the brake caliper assembly is install, d it will be on the cover side of the axle housing (3 or 1 o'clock position). Also, the support key and spinning of the bracket is to be on the top side. Install the mounting washers and nuts an torque to 80-100 ft. lbs.



6B. On planetary equipped with wet disc brake wheel ends proceed as follows:

1) Install the fitting/bleeder guards, if used, on the mounting studs. Guards are not to be installed in the area between the bleeder and inlet ports but just outside of that area and such that they will not interfere with the installation of the bleeder screw and inlet fitting.

2) Install the mounting washers and nuts and torque to 80-100 ft. lbs.

3) Install the bleeder screw in the top port and tighten until it is seated properly.

4) Install the brake inlet fitting in the other port and tighten until it is seated properly.

Assembly of Wheel End Hub

1. Install inner and outer bearing cups into hub. Install inboard bearing and hub seal.

2. Install hub onto spindle.

0000000000

EE

-

-

0

-

3

0000000000

NOTE: A lifting device is recommended for assemblies having a rotor attached.



3. Install outer bearing cone.





6. Install ring gear. The roll run on the back face of the ring gear must be locked into the bearing adjusting nut hole. Une punch mark on front of ring gear as an alignment aid



4. Install bearing adjusting nut forque to 200-250 ft.lbs. Back nut off 1/8 turn and a the any hole in nut with a major spline on the spindle. Lake sure hub rotates freely. (Use Data Too!) #45112.)





5. As an aid, mark the end of the aligned spline. NOTE: If axle is equipped with wheel end disc brakes, the brake caliper assembly can be installed at this time as outlined in the disc brake section of the manual.

7. Install spacer and sun gear on shaft.



8. Install snap ring onto axle shaft.

Assembly of Wet Disc Brake Wheel End



1. Install inner and outer bearing cups into hub. Install inboard bearing and seal and deflector.

2. Using a suitable lifting device, install hub assembly onto spindle.

SPECIAL SERVICE NOTE: If the planetary ring gear, brake piston, and wheel retainer were removed as a unit, (described in disassembly section), and it was not necessary to replace wheel bearings or cups, use the following lettered steps for reassembly. Otherwise proceed run steps #3.



A consert both oil passage O-rings into grooves on mboard face of wheel retainer using a small amount of petroleum jelly to hold them in place and facilitate a sembly.



B. Install ring c ar/pisto assumbly onto spindle spline making sure of passage tole in ring gear is to bottom of axle at 6 o'c, ck position. Mounting holes in wheel retainer will align plugge way.



C. Install wheel retainer capscrews with Loctite[®] 271 compound applied to the threads and torque to 45 ft. lbs.

D. Skip following steps 3 thru 10 and continue assembly with step 11.



3. Install outboard wheel bearing onto planetary ring gear.



4. Install planetary ring gear onto spindle spline making sure oil passage hole in ring gear is to bottom of axle at 6 o'clock position.



5. Lubricate and install outer clamete O-ring into groove around inboard side on the rotation.



6. Insert both oil passage O-rings into grooves on inboard face of wheel retainer. Use a small amount of petroleum jelly to hold them in place and facilitate assembly.



2. Place original wheel pre-load shims onto inboard side of where retainer and install into planetary ring gear. Make sure bleeder tube in retainer is to top of axle at 2 o'clock position.



8. Install wheel retainer capscrews with Loctite[®] 271 compound applied to the threads. Gradually increase torque value on capscrews using a crossing pattern until 45 ft. lbs. is achieved on each capscrew.

NOTE: At this point check wheel bearing preload. Torque to rotate wheel should be 50-80 in. lbs. when measured with a torque wrench from the center of the hub. If a spring scale is used, wrap a cord around the wheel pilot diameter. Readings taken with this method should be 10-15 lbs. Pull while the hub is rotating.

To increase preload add shims. To decrease preload subtract shims.



9. Lubricate and install outer and inner diameter piston O-rings.



10. Install brake piston. NOTE: Use of a special picton re nover/n staller tool, (Dana tool #451164), precommended to prevent damage to the piston



11. Install sun gear onto outer axle shaft.



12. Install snap ring into proove on outboard end of outer shaft.



13. Push inward on end of axle shaft to seat sun gear against wheel retainer. This will prevent rotating disc from dropping behind gear during installation.



AAAAAAAAAAAA

14. Install brake plates and discs into wheel end (4 each). Start with a steel stationary plate first, then a grooved friction disc (shown) second. Alternate until 4 of each are in place.

NOTE: If new discs are installed, presoak in the correct lubricant as recommended by the vehicle manufacturer for a minimum of 15 minutes prior to assembly.

Assembly of 3.650 Drive Flange

1. Install thrust button and vent into drive flange.



2. Grease inside of planet gear. Install two rows of needle bearings (25 per row) separated by spacer ring.

......

3



3. Place thrust washer on. drive flange.



4. Install planet gear and remaining thrust washer.



5. Install planet war shaft into drive flange. If equipped with we disc brokes install lining stop plate. Align bries and instantion pins.



6. Apply small bead of Permatex #2 gasket sealer around drive flange. NOTE: DO NOT use silicone sealer on drive flange. It can cause flange to loosen.



7. Align gears and install drive flange into hub. Rotate hub to align bolt holes.

8. Install and torque bolts 90-100 ft. lbs.



ASSEMBLY

-

PPP

-

PP

-

-

-

PP

eterererer

-

1. Install all seals. Do not over stretch seals to facilitate easier installation.

2. Make sure all seals are not twisted or distorted in grooves.



3. Install gland on rod with inner seal facing exposed section of rod.



4. Install piston on rod turn down.

humun

5. Install locknut and torque to 90-100 ft. lbs. NOTE: Two (2) jam nuts can be used in opposend of shaft to hold while torquing 6. Lubricate all parts and inside of cylinder with hydraulic oil.

7. Push the piston into the cylinder bore with a steady, even pressure.

8. Push gland bore until shoulder of gland burs up to the barrel.

9. Locate drilled tole in grand through milled slot in the barrel and inser lockwire, then rotate the gland 360° to install lockwire.

10. Install the socks percemblies on the steering cylinder. Install the socket clamp bolt and nut (finger tight only).

tight only). NOT to the final socket to steer cylinder aujust, ents will be made when steering cylinder assemblic, are installed on the axle assembly.

Disassembly and Assembly of Wheel End Disc Brake



MAINTENANCE GENERAL

It is difficult to determine an exact maintenance interval (time and mileage), since vehicles will be used in a wide variety of applications and conditions.

A regular schedule for periodic inspection should be established based on past experience and type of operation.

Disc brakes do not require adjustment since to pa clearance is maintained by movement of ne can and piston.

BRAKE PADS

To inspect brake pads for wear, rais, while onto floor stands and remove wheel. Sually espect pad linings nto floor at each visible end and through pening in caliper assembly. Replace parts if the trinnest point is less than 3/16" (4.76 mp.

It is recommended to the probability of braketpads be replaced at the same time to man tain balanced braking of the axle.

Moderate erospector pitting is a normal characteristic or sent-metallic and lining material which does not require replacements Should erosion reduce the polished contact area to less than 20% of total surface a, re lace ads.

IPERS

isually inspect calipers for defects or brake fluid akage. If necessary, follow repair procedures in the Pad and Caliper portion of this section.

BRAKE FLUIDS

The Bendix disc brake is designed to use either a standard brake fluid or petroleum base mineral oil. 1. If brake fluid is used the brake must have black colored seals and dust boots. Brake fluid must meet SAE 1703 or Super Heavy Duty DOT-3 brake fluid specifications.

2. If petroleum based mineral oil is used the brake must have green colored seals and dust botts. Petroleum based mineral oil must meet Mil bec Mil-H-5606 requirements.

SERVICE PRECAUTIONS

1. When the vehicle is raised for inspection or

a. When the vehicle is raised to inspection or servicing use floor stands for additional support.
2. Check fluid level in the fluid reservoir nor to servicing the brakes. If the reservoir is call when the caliper pistons are retrained and the reservoir with a sinhon and discord. siphon and disc ıd.

CAUTION: Ave d containing the caliper and other brake parts while ervicing the brake. Handle parts ca. fully to prevent damage.

3. The caliper assembly must be removed before noving the hub and disc assembly. re

4. iston reals

5. If the original brake pads are to be reused, mark them n some manner so they can be installed in the same location.

 After any brake service, be sure to test brakes prior to returning vehicle to service. A firm pedal should be felt during brake application.

CAUTION: DO NOT move vehicle until a firm brake pedal is obtained.

SERVICE PROCEDURES CALIPER AND PADS REMOVAL



1. Position vehicle on floor stands and remove wheel. 2. Inspect master cylinder fluid level and remove fluid if necessary.

3. Pry the caliper outboard retracting the caliper pistons into the cylinder bore.



Remove support key retaining screw.

e e e e e e



5. Using a hammer and drift arive out caliput support key and spring.

6. Disconnect hydraulic hose if hypoving caliper to service other than brake pros.



7. Remove caliper from mounting bracket. Do not let caliper hang on brake hose.



8. Remove inboard part from saliper mounting bracket. Inspect caliper for leakage Requild if necessary. NOTE: If the caliper does not require rebuilding, retract the pistors into the caliper to obtain necessary clearance for reassembly over the rotor. Position a metal bar over both pistons, then use a "Coclamp to force both pistons into the caliper.

CALIPER JISASSEMBLY

1. Disconnect brake hose from caliper inlet. Cap the hose and inlet to prevent brake fluid leakage. Avoid going grease or brake fluid on brake pads.

- 2. Clean exterior of caliper in denatured alcohol.
- Remove pistons from caliper.

NOTE: It may be necessary to use compressed air to aid in removal of pistons.

CAUTION: Use no more than 15 PSI air pressure to ease pistons from bore. Stay clear of area between piston and caliper housing to avoid personal injury. Avoid spray of brake fluid as pistons are dislodged from bores. Use shop towels to restrict piston travel and prevent damage to the pistons. NOTE: If the piston becomes seized or cocked, release the air pressure and realign the piston, tapping with a soft faced hammer. Reapply air pressure to remove the piston.

4. Remove boot from piston and seal from caliper bore. Discard boot and seal.

CLEAN AND INSPECT CALIPER COMPONENTS

1. Remove any rust or corrosion from the external machined surfaces of the caliper housing. DO NOT use any abrasive material in the piston bores.

2. Remove any rust or corrosion from the machined surfaces on the caliper mounting bracket.

3. Clean the caliper housing and piston bores using denatured alcohol. Use dry compressed air to clean and dry all grooves and passages.

NOTE: Make sure all alcohol is completely removed before reassembly.

4. Inspect the piston bore, boot groove, seal groove, and piston for damage for excessive wear. Replace piston if it is pitted, scored or worn. Remove any corrosion that may be present in the piston bores and grooves with a fiber brush.

5. Inspect caliper support spring and key. Replace if necessary.

CALIPER REASSEMBLY

1. Lubricate piston seal and piston bore with brake fluid (Refer to BRAKE FLUID SECTION), and install seal in groove in piston bore. Be sure seal is fully seated and not twisted.

2. Coat outside of piston and dust boot lips with brakefluid. Slide dust boot over the piston and position it at bottom (closed end) of piston.

3. Position piston and boot over piston bore and install lip of boot into groove near top of bore. Be sure boot lip is fully seated.

4. Press straight in on piston until it bottoms in bore.

5. Assemble other parts on caliper and install as outlined in the Pad and Caliper Installation section.

CLEANING AND INSPECTION OF ROTOR AND PARTS

1. Measure lining thickness. If any point is less than 3/16" (4.76 mm), new pads should be installed on both wheels of that axle.



If lining naterial shows sign of excessive cracking, the pads must be replaced.

Replice trake pads as a set on an axle. Never replace pads one wheel at a time.

Replace since pads contaminated with oil, grease, or an empty and a clean rag.



Examine the pads for flatness of the control surface. Any shoe found with a concave or convex bend more than 0.015" (0.381 mm), should be replaced. 2. Inspect rotors. While rotors are mounted on wheel end, use dial indicator to check for warpage of braking surface. If surface varies more than .003 (.076 mm), it will be necessary to machine rotor to acceptable tolerance (Use standard automotive procedures). Rotors with cracks or burnt spots must be replaced.

NOTE: The minimum allowable thickness of the rotor braking surfaces is 1.320 inch (This value is cast on the rotor). If the amount of cleanu machining to eliminate warpage decreases for will decrease the thickness to less than the minimum specified, the rotor must be replaced.

Before reassembling the rework of or new rotor on the hub make sure the rotor and the bub mounting surface and pilot diameter for hare oclean. Position the rotor on the hub, much the mounting bolts and torque time to 74-191 ft. lbs.

Recheck the braking surfact runout to make sure it is acceptable.

PADS AND CALIPER INSTALLATION



 Position the inboard (smaller) pad into the caliper mounting bracket with lining towards rotor.

2. Be sure the caliper piston is fully bottomed in the piston bore.

3. Position outboard pad on caliper.

4. Apply a small amount of special lubricant (NLG-2 extreme temperature lithium grease), to the machined surfaces of the caliper vee-way grooves and caliper mounting bracket rails which are in contact during the sliding action of the caliper.



5. Position caliper into caliper mounting bracket. Avoid cutting piston dust boots.

erererererere

FFF

000

-

555

50



7. Install key retaining screep and torque to 12-18 ft. lbs.
8. Install line fitting in being port and bleeder fitting in top port.

9. Connect brakeline hose removed.

BLEED' IG INSTRUCTION

Refere VENICLE SERVICE MANUAL CAUCION OBTAIN FIRM PEDAL BEFORE MOVING MEHICLE.



6. Hold caliper in position and install, upport and support key between calipere to bracket. Use a soft faced hammer to drive the key on spring assembly into position.



- reerererererererererererer
- 1 Nut-Pinion 2 Washer-Pinion Nut
- 3 Pinion End Yoke Assembly (Includes Item 4 and 5)
- 4 End Yoke or Companion Flange
- 5 Deflector
- 6
- Oil Seal—Pinion Washer—Bearing Thrust 7
- 8 Outer Bearing Cone
- 9 Outer Bearing Cup
- 10 Shim—Pinion Bearing Preload Adjusting
- 11 Spacer-Flat
- 12 Capscrew—Carrier Mounting
- 13 Washer-Flat
- 14 Carrier
- 15 Cap-Differential Carrier
- 16 Washer-Flat
- 17 Capscrew—Bearing Cap Mounting
- 18 Lock-Bearing Adjusting Nut
- 19 Washer-Flat
- 20 Capscrew—Lock Mounting
- 21 Shim—Pinion Position (.003, .005, .010 Thick)
- 22 Inner Bearing Cup
- 23 Inner Bearing Cone
- 24 Gear and Pinion (Matched Set)
- 25 Side Bearing Cone
- 26 Side Bearing Cup
- 27 Adjusting Nut-Differential Side Bearings

- 28 Shaft-Differential 29 Pinion-Differential 30 Thrustwasher—Differential Pinion 31 Side Gear—Differential 32 Thrustwasher-Differential Side Gear 33 Lock-Differential Shaft 34 Case-Differential (Standard) 35 Capscrew—Drive Gear Mounting 36 Capscrew—Brake Mounting (Optional) Parking Brake (Optional) 37 38 Flange Half-Limited Slip Differential Case 39 Cap Half-Limited Slip Differential Case 40 Shaft—Differential 41 Pinion—Differential 42 Side Gear—Differential 43 Ring-Differential Side Gear 44 Plate-Differential 45 Disc-Differential 46 Disc-Differential (Dish. 47 Plate-Differential (Dishes 48 Capscrew—Differentia Case Mounting 49 Housing—Axler (Housing) configurations May Vary from Ster to Rigid) 50 Vent 51 Pin-Dowel 52 Plus-Pipe (Drain and Fill/Level) 53
- Ushing Axle Pivot 54

Removal of Carrier from Axe Housing

NOTE: Use of safety glasses during disast assembly procedures is recommended

1. If it becomes necessary to disassemble any pan inside the carrier, it is suggested that e entite axle be removed from the vehicle and held tight stand or rack.



rerererer

WARNING: When renoving axle assembly, make sure vehicle is reperly supported. Improperly supported whicle can cause serious injury or d ath. Fillow vehicle manufactures recommendations for proper tale assembly emoval procedures.

2. Remove durin plugs and train lubricant from planetarize and tarier housing.

3. At this time remark wheel ends, and axle shafts. Follow procedures outlined in Wheel-End section of anua

If http://steering axle skip steps #4 and #5 seed with step #6. NO E: If h. ar

Disconnect hydraulic lines to and remove steering cylinder assemblies from the steer knuckle and carrier anchor points.

5. Remove the tie rod assembly from the steer knuckle anchor points.

NOTE: Do not alter the tie rod adjustment.

NOTE: If axle assembly is still in vehicle, be sure carrier assembly is securely supported before it is separated from housing.

If axle assembly has been removed from vehicle, be sure it is set securely in support stands with carrier pinion positioned up.

6. Remove mounting bolts and washers from carrier flange. Carrier assembly and axle housing is aligned with dowel pins.

7. Remove carrier assembly from housing and mount in suitable holding fixture such as a carrier repair stand.

Removal of Differential from Carrier



1. Remove adjusting nut lock from bearing caps.



2. Match mark one differential paging cap and leg of carrier with center punch or chise, for correct reassembly.



Remove bearing cap retaining bolts.
 Remove bearing caps.



5555555

5. Rem ve adjusting nuts.



6. Carefully lift the ring gear and differential subassembly out of carrier.

NOTE: Prevent bearing cups from falling as you remove differential.

Use care to avoid damage to ring and pinion gears. If either is damaged, it must be replaced as part of a matched set.

NOTE: If replacement of a damaged bearing cup or cone is necessary, the cup and cone must be replaced as a set.



Differential Disassembly

A. Ring Gear and/or Differential Side Bearing Cones



1. If replacement of differential bearings is required, remove differential bearings with a puller as shown.

errerrerrerrerrerrerrerrer

-

-

000

NOTE: It is recommended that whenever bearings are removed, they are (regardless of milea, the be replaced with new ones.

NOTE: If replacement of a damaged pearing cup cone is necessary, the cup and continuous be replaced as a set.



2. If removal of ring gear from case is required, place a few shop towels over the vise to prevent the ring gear teeth from being nicked after it is free from the case. Place case in vise. Remove ring gear screws and discard them.

Ring gear screws are to be replaced with new ones at time of reassembly.



3. Tap ring gear with a new to have the free it from the case. Remove case an tring gear from vise.

NOTE: If ring gen and a pin on shaft needs to be replaced, ring year and p nion shaft must be replaced as a natched so.

B. Standard Differential One-Piece Case)



1. Place holding fixture into vise. Place case onto holding fixture as shown. Drive out lock pin.



2. Reposition case on holding fixture as shown. Drive out cross pin using a drift and hammer.

3. Rotate gears until the pinion mate gears (small gears) enter the large opening of the case. Remove pinion mate gears and spherical washers. After removal of the pinion mate gears, the side gears and thrust washers can be easily removed. Inspect and replace components as required.

NOTE: Always replace gears as a complete set. Do not mix new gears with old gears, as this may cause uneven wear and short gear life.

C. Limited Slip Differential

- Large Section of Case 1 2
 - **Dished Plate**
- 3 Dished Disc
- 4 Flat Plate
- 5 Flat Disc 6 Clutch Ring
- 7 Side Gear
- 8 Pinion Gear
- 9 Cross Shaft
- 10 Small Section of Case
- 11 Bolt and Tapered Sleeve

11

unchmark both sections of differential case to sure proper reassembly. Also mark end of the cross short nearest the differential case punch marks.

2. Remove the small section of differential case, side gear, clutch ring, plates, and discs.

3. Remove pinion gears, cross shafts, side gear, clutch ring, plates, and discs from large section of differential case.

NOTE: The differential has a serial number stamped on the small case section. When ordering parts, always include the complete part number.

NOTE: If any plates or discs are scored or worn, entire set must be replaced on both sides.

.10

NOTE: Clutch rings must be replaced in sets.

NOTE: Side gears or pinion gears showing wear must be replaced in sets.

NOTE: If cross shaft shows signs of wear, replace in sets.

NOTE: If wear is evident at "V" notch for the cross shaft on either small or large case section, replace as a set.

Pinion Disassembly

NOTE: If carrier has optional pinion mounted parking brake refer to pinion parking brake section of manual for removal of brake assembly from carrier.

00000000000

-

-

-

9



1. Hold end yoke or flange with tool similar to the one shown, and remove pinion nut and washer. Discard nut as new one should be used at reassembly.



2. Remove end yoke or lange with tools similar to that shown. If yoke or lange shows what in the area of the seal contact, it mould be reported.



3. Remove pinion by tapping with a rawhide hammer. Catch the pinion with your hand to prevent it from falling to the ground and being damaged.



WARNING: Gear teeth may have sharp edges. When handling gears, use care to avoid personal injury.

NOTE: On the spline end of the pinion, there are bearing preload shims. These shims may suck to the bearing—pinion—or even fall out. The spims are to be collected and kept together such they will be used later in assembly. Try not to mutuate shims. If shims are mutilated, replace with new ones; shims are available in thicknesses of .003", .005", .010". and .030".

NOTE: If ring gear and/or pinion thaft, eeds to be replaced, ring gear and pinion. It must be replaced as a matched set.



4. Pull out pinion seal with puller as shown. **DISCARD SEAL.** Replace with new seal at time of assembly. Remove bearing cone and outer pinion oil slinger.



5. Remove the inner bearing cup, if necessary, with tools as shown.

NOTE: Shims are located between the bearing cup and carrier bore and may also include an oil baffle, depending upon the application. If shims and baffle are bent or nicked, they should be replaced at time of assembly. Wire the stacks together and measure each. If stack has to be replaced, replace with the same thickness.

NOTE: The front and rear axle carrier section may vary in pinion bore depth due to the possibility of the need for either a baffle or slinger or both.

The baffle serves the same purpose of assisting the lube to flow up through the oil channels to lubricate the pinion bearings. If used, they are part of the pinion setting adjustment.



6. Turn nose of carrier down. Remove outer pinion bearing cup as shown. Locate driver on back edge of cup; drive cup out of carrier if necessary. CAUTION: Do not nick carrier bore.

Differential Assembly



7. Remove inner pinion bearing co. a. if Nocessary, with tools as shown.

WARNING second allow gear to fall. It can strike less or fee and may cause serious injury. Gear teeth may have sharp edges. When handling, use care to avoid cutting hands. NOTE Both baffle and slinger are part of the pint in adjustment shims and are to be kept intact for as publy.

NOTE: his recommended that whenever bearings are removed, they are (regardless of mileage) to be replaced with new ones.

NOTE. If replacement of a damaged bearing cup or cone is necessary, the cup and cone must be replaced as a set.

A. Standard Differential (One-Piece Case)

1. Apply a small amount of grease in both side gear hubs. Assemble new prust rashers into side gears.



2. Assemble both side gears into case. Hold top side gear up with your fingers. Assemble one pinion mate gear. Rotate gears until pinion mate gear is directly in

the center of the small opening of the case. Line up the other pinion mate gear with the gear which has just been assembled. Rotate gears until the holes of pinion mate gears are in direct line with the holes of the differential case.



3. After making sure the gears are in alignment, apply a small amount of grease to the new spherical

washers. Assemble washers between the gears and case. Also line up the holes of the washers with those of the gears and case. 4. Assemble cross pin. Make sure lock pin hole of the 5. Assemble lock in. Peen etal of case over pin to cross pin is in a vertical position and lined up with the lock in place. lock pin hole of the case. Drive cross pin into case with a hammer until the cross pin hole is in alignment with the hole of the case. **B. Limited Slip Differential** 1 Large Section of Case 2 Dished Plate 3 Dished Disc Flat Plate 4 Flat Disc 5 6 Clutch Ring Side Gear 7 **Pinion Gear** 8 9 **Cross Shaft** 10 Small Section of Case 11 Bolt and Tapered Sleeve 11 g 10

ubricate all internal parts with axle lubricant be, re assembly.

2. Alternately install plates and discs into large section of case as illustrated.

NOTE: Install dished plate and disc with concave surface toward case section.

3. Install clutch ring and side gear. Engage splines of discs and clutch ring on side gear.

4. Assemble pinion gears on cross shafts. Assemble cross shafts together.

5. Install cross shafts to large section of case so "V" portion of cross shaft mates with "V" cut out in case.

6. Assemble side gear, clutch ring and clutch discs for small case section on spider assembly as it sits on work bench. Install case section being sure it seats fully.

7. Tighten case section bolts to 95-100 ft. lbs.

NOTE: Match case halves together by punch marks.

C. Ring Gear and/or Differential Side Bearing Cones



1. Place case assembly in a vise. Be sure flange face of the case is free of nicks or burrs. Assemble ring gear to case. Line up holes of the ring gear with those of the case. Use new ring gear screws. Draw up screws alternately and evenly. Torque ring gear screws to 120-140 ft. lbs.



2. Place bearing one on h o of case. Use bearing installer to seat bearing one as shown. Be surfithey are fully seated. NOT :: Be dire bearing cone and case bearing journ. Use clear prior to assembly.

Pinion Position and Assembly

A. Pinion Position

RING GEAR & PINION TOOTH PATTELIN INTERPRETATION

When setting the pinion position, many of the service manuals required a final pinion position check by using gauges that verified the dimensional much the central rine of the differential carrier (center line of ring gear) to the face of the pinion (button).

This surface (button) is not used on all engears for verifying the pinion position. The service tools will be used to establish the proper amount of such required prior to installing the pinion gear. The final pinion position will be verified by using the GEAR CONTANT PATTERN METHOD, as described in this manual.



View of ring and pinion set.

Ring gears and pinions are supplied in matched sets only. Matching numbers on both the pinion and ring gear are etched for verification. If a new gear set is being used, verify the numbers of each pinion and ring before proceeding with assembly. The distance from the centerline of the ring gear to the button end of the pinion for the Model 70 (Front and Rear) axle is 3.500 inches approx.

On the button end of each pinion there is etched a plus (+) number, a minus (-) number, or a zero (0) number, which indicates the best running position for each particular gear set. This dimension is controlled by the shimming behind the inner bearing cup.

For example: If a pinion is etched +3, this pinion would require .003" less shims than a pinion etched "0". This means by removing shims, the mounting distance of the pinion is increased to 3.503" which is just what a +3 indicates. Or if a pinion is etched -3, we would want to add .003" more shims than would be required if the pinion were etched "0". By adding .003 shims the mounting distance of the pinion was decreased to 3.497" which is just what a -3 etching indicated.

If the old ring and pinion set is to be reused, measure the old shim pack and build a new shim pack to this 3

-

5

same dimension. If a baffle is in the axle assembly, it is considered as part of the shim pack.

To change the pinion adjustment, shims are available in thicknesses of .003", .005", and .010".

NOTE: If baffle or slinger is bent or mutilated, it should be replaced.

Measure each shim separately with a micrometer and add together to get total shim pack thickness from original build up.

If a new gear set is being used, notice the (+) or (-) etching on both the old and new pinion and adjust the thickness of the new shim pack to compensate for the difference of these two figures.

For example: If the old pinion reads (+) 2 and the new pinion is (-) 2, add .004" shims to the original shim pack.

The above procedures also apply to pinion adjustment on the front axle which includes the oil slinger between the inner bearing cone and pinion, and to file between the inner bearing and carrier.

Old Pinion Marking	New Pinion Marking								
	-4	-3	-2	-1	0	+1	+2	+3	+4
+4	+0.008	+0.007	+0.006	+0.005	+0.004	+0.003	+6 72	+0.001	0
+3	+0.007	+0.006	+0.005	+0.004	+0.003	+0.00	+0.0	0	-0.001
+2	+0.006	+0.005	+0.004	+0.003	+0.002	+0.001		-0.001	-0.002
+1	+0.005	+0.004	+0.003	+0.002	+0.001	0	-0.001	-0.002	-0.003
0	+0.004	+0.003	+0.002	+0.001	0	0.001	-0.002	-0.003	-0.004
-1	+0.003	+0.002	+0.001	0	-0.001	-0.0	-0.003	- 0.004	-0.005
-2	+0.002	+0.001	0	-0.001	-0.002	.003	-0.004	-0.005	-0.006
-3	+0.001	0	-0.001	-0.002	-0.003	-0.004	-0.005	-0.006	-0.007
-4	0	-0.001	-0.002	-0.0	-0.004	-0.005	-0.006	-0.007	-0.008

Pinion setting char shown Use this chart as a guideline to set pinion.

B. Pinion Assembly



1. Measure each shim separately with a micrometer and add together to get total shim pack thickness. If baffle is required, it is to be included in the shim pack. If slinger is used between the inner bearing cone and thrust face of pinion, the slinger is also to be measured and included as a part of the total shim pack.



2. Place the required amount of shims (and baffle if used) in the inner bearing bore; drive the inner bearing cup into carrier with tools as shown.



3. Assemble the outer pinion bearing cup into carrier as shown.



5. Install pinion into carrie Assemble outer vision bearing cone, (slinger if used) and end yoke onto purion spline. NCLE: Do not assemble preload shims or pinion o seal at this time **金 金 金 金 金 金 金**

Use the installer (as shown) to assemble end yoke onto spine of pinion.



6. Assemble washer and pinion nut. Torque nut until it requires 10 lbs. inch to rotate pinion. Rotate pinion several times before checking pinion position. This is to seat the bearings and assure a more accurate indication of the pinion position.

NOTE: The reason for not assembling preload shims and new pinion oil seal at this time is due to the possibility of having to adjust pinion preload or pinion adjustment. It would be necessary to again remove the seal, and as mentioned, whenever seals are removed, they are to be discarded because of possible damage.

7. Install the differential assembly into the carrier. Refer to the ring gear/pinion tooth contact pattern and differential installation sections of manual to properly set the pinion position and backlash.



on pinion place pearing installer over pinion shaft as shown Drive being on shaft until it is completely sea d.

Differential Installation



1. Install ring gear and differential assembly into carrier housing.

CAUTION: Care should be used when installing ring gear and differential into carrier housing so damage to ring gear, pinion, bearings, or bearing bores do not occur.



2. Install adjusting nuts implace. Spread in adjusting nuts until all slack is removed between bearing cups and bearings.

NOTE: Adjusting nuts hats be installed with side of nut having the depper necess facing the bearing. Installed opposite, the adjusting nut would clamp against the bearing cage restricting movement.



1. Bearing Cup 2.

2. Adjusting Nut

*.



3. Be sure bearing conside seated on bearing cones and astemble differential bearing caps. Install bearing capitolts (finger tight only) so adjusting nuts can still be to ser

TTE: Take dre the "match marked" bearing cap and leg of the carrier are on the same side for correct reassembly.



1. Dial Indicator 2. Adjusting Nut 3. Notch

4. Position a dial indicator on housing lip and index indicator dial to back face of the ring gear. Zero the indicator.

Turn adjusting nut on the backside of the ring gear in until the indicator stops moving.

5. Next tighten adjusting nut on tooth side of ring gear until bearing cup is seated.

Checking backlash

6. Position dial indicator on lip of differential housing and indicate to side of one tooth on ring gear.

7. Move ring gear as far as it will go in one direction before it moves the pinion.

8. '0' the dial on the indicator face.



9. Force the ring gear in the opposite direction until it contacts the pinion gear and observe the dial face. This figure is your backlash setting. Backlash should be .005-.009-inch with no more variation around gear than .003 inch.

A reading larger than .009 in. is corrected by moving ring gear closer to pinion. A reading smaller than .005 in. is corrected by moving ring gear away from pinion. Move the ring gear by tightening and loosening the adjusting nuts. Both adjusting nuts must be moved the same amount. A ¹/₄ turn 'in' with one nut should be accompanied by a ¹/₄ turn 'out' for the opposite nut.

10. When backlash is adjusted properly, rotating torque at the pinion shaft nut should be 5-10 inch lb. higher than the torque you had when setting pution shaft bearing preload.

Tighten adjusting nuts until adjusting nut locks can be installed.

11. Torque the bearing cap bolts 180 of ft. lbs.

Ring Gear and Pinion Toeth Contact Pattern



Gear tooth nomenclature

The **toe** of the gear tooth is the partion of the tooth surface at the end towards the centre.

The **heel** of the gear both in the portion of the tooth surface at the outer ender

The **top land** *t* a gear too vie the surface of the top of the tooth.



1. Paint ring gear teeth with marking compound and rotate with pinion to obtain contact pattern.



2. The tooth contact patterns should have the same general shape and position as the ring gear teeth shown above.



3. If the pattern is concentrated more toward the heel (as shown above), backlash must be reduced.

B

-

0

-

PP

00000

00

000

0

0

0

0

000000

Recheck backlash as described in differential installation section of manual. To reduce backlash, loosen the right side adjusting ring until the measured backlash is within specification. The tooth contact pattern should now have the same general shape and location as shown in step 2. If the contact pattern still does not conform, less backlash than normal is required. To avoid reducing differential bearing preload excessively, further loosening of the right hand adjusting ring should be accompanied by equal tightening of the left hand adjusting ring. Place a dial indicator directly on each adjusting ring to measure the exact amount of additional adjustment. Decreasing backlash moves the ring gear toward the pinion.



4. If the pattern is concentrated at the toe (as shown above), more backlash is required. Recheck back of To increase backlash, tighten the right side a dusting ring further until the measured backlash is athin specification. The tooth contact pattern should how spread across the ring gear tooth as in step for the contact pattern still does not conform, more socklarin than normal is required. To avoid increasing differential bearing preload excessively, further tick on an of the right hand adjusting ring should be a companied by equal loosening of the left hand adjusting ring. Place a dial indicator directly on each adjusting ring to measure the exact mount of the arditional adjustment. Increasing back showes the ring gear away from the pation.



5. If a pattern is concentrated at the ring gear tooth root as shown above, the pinion is too close to the ring gear. It must be moved out and away to establish its

proper mounting distance and contact pattern as shown in step 2. This is accomplished by decreasing the thickness of the inner pinion bearing shim pack as described in the pinion assembly and position sections of manual. Readjust pinion-to-ring gear backlash, as required, once proper pinion mounting distance has been established.



6. If pattorn is concentrated at the tooth top land (as shown above, the pinion is too far away from the ring gear as thrust be hoved closer to the ring gear to bacolish to proter mounting distance and tooth contact pattor. This is accomplished by increasing the thick ess of the inner pinion bearing shim pack as described in the pinion assembly and position sections of an all. Readjust pinion-to-ring gear backlash as required once proper mounting distance has been btablished.

NOTE: When making changes, note that two variables are involved. Example: If you have the backlash set correctly to specifications and you change the pinion position shim, you may have to readjust the backlash to the correct specification before checking the pattern. Refer to patterns as shown.

PATTERN MOVEMENTS SUMMARIZED

 Decreasing backlash moves the ring gear closer to the pinion.

Drive pattern (convex side of gear) moves slightly lower and toward the toe. Coast pattern (concave side of gear) moves lower and toward the toe.

(2) Increasing backlash moves the ring gear away from the pinion. Drive pattern moves slightly higher and toward the hel.

Coast pattern moves higher and towards the heel.

(3) Thicker pinion position shim with the backlash constant moves the pinion closer to the ring gear. Drive pattern moves deeper on the tooth (flank contact) and slightly toward the toe. Coast pattern moves deeper on the tooth and toward the heel.

(4) Thinner pinion position shim with the backlash constant moves the pinion further from the ring gear.

Drive pattern moves toward the top of the tooth (face contact) and toward the heel. **Coast pattern** moves toward the top of the tooth and slightly toward the toe.

7. After the proper pinion position is determined, temporarily remove the differential assembly from the carrier for the proper setting of pinion bearing preload.

8. Remove pinion nut, washer, end yoke, slinger, and bearing cone. Assemble preload shims (which were removed during disassembly) onto pinion. Assemble bearing cone, slinger.

NOTE: If carrier has optional pinion mounted parking brake refer to pinion parking brake section of manual for installation of brake assembly, pinion input yoke, washer, and nut to the carrier.



9a. Apply a light coat of hyport lubric time the lip of the pinion seal and assemble inconousing.9b. If pinion parking back is used, astall brake cover plate and inner pinion seal or this time.



10. Assemble end yoke, washer, and new pinion nut. Torque nut to 240-300 lbs. ft.



11. Using an inc. (b. torque wreach as shown, rotate pinion. Torque of pinion should read between 20-40 lbs. inch (with new bearing).

To increase preload, remove shims; to decrease preload, add shims.

12. Up in a parking brake is used remove pinion nut, upshearend youe. Refer to parking brake section of manual to complete the installation of the brake assembly to the carrier.

13. Repeatall the differential assembly into the carrier. to the differential installation section of manual to properly set the ring gear/pinion backlash. Torque the differential bearing cap bolts to 180-200 ft. lbs.



14. Install adjusting nut locks, mounting bolts, and washers. Torque mounting bolts to 15-17 ft. lbs.

Installation of Carrier Assembly into Axle Housing

1. Thoroughly clean inside of axle housing. Stone the housing mounting surface if necessary to remove burrs or nicks.



2. Apply Permatex #2 gasket sealer to axle housing at carrier mounting flange. A 1/4 inch bead around the outside of all carrier mounting dowels and each bolt hole is required.

3. Install carrier assembly into axle housing. Install washers. Torque bolts to 100-115 ft. lbs. Bolts must be

cleaned and threads coated with Loctite #271, or its equivalent.

4. Assemble axle shafts and wheel end the morents at this time following procedures outlined in the weel end section of manual.

5. Clean Drain plugs and install he plane arise and carrier housing. Fill with proper lubit part and to required levels for planetaic where the carrier housing. Inspect wheel ends and housing for oil leaks. Take corrective action if leaks an incountered.

NOTE: If steering axle, at this time install tie rod and steering cyline r assumblies following procedures outline in mose specific sections of the minual for them.

Pinion Mounted Dry Disc Parking Brake



Parking Brake—Removal/Installation



REMOVAL INSTRUCTIONS

- 1. Disconnect driveline from yoke shaft (6) and position away from orake.
- 2. Disconnect hydraulic pressure line used for releasing brake
- Become ut (8) and washer (7) which retains yoke shaft (6) to black pircon shaft on axle. Discard nut (8).
 Remove four 1/2-13 UNC socket head cap screws (5) your, attactes black module (4) to cover plate (1).
 Pull brake module (4) and yoke shaft (6) assembly avay from cover nate (1).

- 6. Remove snap ring (3) from yoke shaft (6) and remove yoke shap (6) from brake module (4).
 7. Remove eight 9/16-18 UNF hex bolts (2) which another yer place (1) to carrier pinion input flange. Remove cover plate (1) from axle.

INSTALLATION INSTRUCTIONS

- 1. Insert yoke shaft (6) into brake module (4) thrus pal, bearing, and internal hex of spline ring.

- Insert yoke shart (b) into brake modul (4) third stati, bearing, and internal nex of spinle ring.
 Attach snap ring (3) in groove on y ke shart (6) to etain spline ring.
 Install cover plate (1) on carrier pinic sing at flance. Apply sealant between flange and cover plate surfaces.
 Attach cover plate (1) to axle your eigt 9/16 of UNF hex bolts (grade 5) and torque evenly to 90-100 ft. lbs.
 Install brake module (4) and yoke thaft (consembly into cover (1) engaging internal yoke shaft spline with pinion spline. Orient brake module that mounting bolt holes are in alignment and brake module seats e pressure and bleeder ports are facing up.
- properly on cover flance. Becare pressure and bleeder ports are facing up. 6. Insert four 1/2-13 Up of socket had cap screws (5) thru brake module (4) and into cover plate (1). Torque screws evenly to 85 ft. lbc
- we nut (8) on threaded end of spline shaft which engages yoke shaft (6). Torque nut (8) 7. Install washer (7) and to 240-300 f lbs.
- 8. Reattach veling on you shaft (6).
- 9. Connect preside line to brake, bleed system, and test operation of brake on vehicle.



Parking Brake—Disassembly/Assembly



18

* NOTE: Earlier brakes do not have additional dowe pins (10) installed. The plate stack (7, 8 & 9) is retain only by shoulder bolts (5).

DISASSEMBLY

recteresses and the second of the second of

1. Remove case gasket (3) from cover (1).

11

2. Press out oil seal (2) from cover (1) if replacement required.

14 15 16

3. Remove outer spline (4) from brake module.

4. Remove four socket head shoulder bolts (5). A suitable holding fixture is useful to hold brake in position.

CAUTION: Do not remove shoulder bolts without pressurization of brake (approx. 300 psi) or damage may result.

5. Remove primary disc (7), seven rotor discs (8) and sev stator discs (9).

NOTE: Primary disc (7) is offset from other state discs (9). Reinstall new plates in same sequence.

6. Remove four (4) socket head cap rews 6) wh ach spring plate (11) to pressure plate (3).

- 7. Remove spring plate (11) from pro su
- 8. Remove case gasket (3) from spring vate (11).
- 9. Remove springs (12) from pistor (13).

10. Remove piston (12) by archally exerting hydraulic pressure through broke release port or pressure plate (18). 11. Remove o-rines (15 247) and ack-up rings (14 & 16)

from piston (13).

CAUTION: are must be taken so as not to scratch or mar piston.

seal (21) from pressure plate (18). 12. Rem. a ci

nove pap rig (20) and press bearing (19) from 13 essu plate

precial removal tool with a diameter tolerance NOTE J90/2.980 is required to press bearing from bore. The fore the bearing should be removed only if replatment is required.

ASSEMBLY

LUBRICATE ALL RUBBER COMPONENTS FROM REPAIR KIT WITH CLEAN TYPE FLUID USED IN THE SYSTEM. 1. Clean all parts thoroughly before assembling.

2. If removed, press new bearing (19) in pressure plate bore (18). Insert snap ring (20).

3. Press seal (21) into pressure plate (18) until flush with end of pressure plate.

4. Ins. "bar -up rings (14 & 16) on piston (13) toward spring pu ets.

ston

p Ring

ack-up Ring

18 Pressure Plate 19 Bearing

20 Retaining Ring

21 Oil Seal

5. Install o-15 & 17) on piston (13). Be sure o-rings are flat and an wists removed.

CAUTION Care must be taken so as not to scratch or ar pis ۵n.

6. Lupricate pressure plate piston bore (18) with type fluid sed in system. Carefully press piston (13) into pressure hate (18). Be sure piston is oriented such that threaded holes in piston are in alignment with thru holes in spring plate (11) when installed. Press piston until it bottoms on pressure plate (18).

7. Install twelve springs (12) in piston (13).

8. Install case gasket (3) on spring plate (11).

9. Install spring plate (11) on pressure plate (18). Compress springs (12) until spring plate bottoms on pressure plate. 10. Install four socket head cap screws (6). SEE NOTE

BELOW. Torque bolts to 55 ft. lbs. A suitable holding fixture is useful to hold brake in position.

11. Install stator discs (9) and rotor discs (8). Begin with a stator disc (9) and alternate with rotor discs (8).

CAUTION: Slots in stator discs (9) should engage with fixed dowel pins (10) in spring plate (11).

12. Install primary disc (7) offset from other stator discs (9). 13. Align tabs on primary disc (7) with thru holes in spring plate (11) and partially screw in four socket head shoulder bolts (5) into piston (13). SEE NOTE BELOW.

14. Using outer spline (4) align and center rotor discs (8) in brake module. Be certain outer spline (4) is installed with counterbored end towards bearing in brake.

15. Pressurize brake release port (approx. 300 psi) to completely release discs. Torque shoulder bolts to 18 ft. lbs. and release pressure. A suitable holding fixture is useful to hold brake in position.

16. Press oil seal (2) into cover (1). Note direction of seal during installation.

17. Install case gasket (3) in cover (1).

NOTE: Bolts should have Loctite applied. Place one or two drops of Loctite to the threads.

Parking Brake — Bleeding / Trouble Shooting

BLEEDING

1. Install brake in system and connect pressure lines.

2. Bleed pressure release section of brake by pressurizing side inlet port and allowing air to escape from top port. Pressure should not exceed 100 psi during bleeding.

SERVICE DIAGNOSIS

3. Apply sufficent pressure to release brake and check for proper operation in system.

0 1

PROBLEM	CAUSE	EXPLANATION	ACTION
Brake slips	A. Excessive pressure in hydraulic system	If there is back pressure in the brakes actuation line, the holding torque of the brakes is reduced.	Check filters hose size, netricul prim other hyo, pulic components.
	B. Oil in brake if de- signed for dry use	Dry linings generate 50% more torque than linings saturated with of in the brake has oil in it, check the type of o hydraulic or gearbox. 1. Gearbox oil 2. Hydraulic oil	Replace oil seal in brake Check motor seal Check piston seals Note: Internal compo- nents will need to be inspected, cleaned and replaced as required.
	C. Disc plates worn	The thickness of the disc stack set the torque level A this stack aduces torque.	Check disc thickness
	D. Springs broken or have taken a perma- nent set.	Broken or set springs can cause re- dured turque — rare occurence.	Check release pressure
Brake drags or runs hot	A. Low actuation pressure	method should be pressurized to ninimum of 20 psi over the specified remase pressure under normal operat- ing conditions. Lower pressures will ause the brake to drag thus generat- ing heat.	Place pressure gauge in bleed port & check pressure with system or
	B. Bearing fail to	If the bearing should fail, a large amount of drag can be generated.	Replace bearing
Brake will not release	. Stuck valve or clugged	Brakes are designerd to come on when system pressure drops below stated re- lease pressure. If pressure cannot get to brake, the brake will not release.	Place pressure gauge in bleed port — check for adequate pressure — Replace defective line or component
	B. Bad o-rings	If release piston will not hold pressure, brake will not release.	Replace o-rings
2~	C. Discs frozen	Brakes are designed for only limited dynamic braking. A severe emergency stop or prolonged reduced release pressure operation may result in this type of damage.	Replace disk stack

Inspection and Failure Analysis

This section is intended to serve as a guide for describing and explaining commonly encountered axle problems or failures, and for recommending appropriate repair procedures.

FAILURE MODE	PROBABLE CAUSE	RECOMMENDED REPAIR		
Fracture of ring gear teeth at the tooth heel.	 Excessive loading of the gear beyond design intent. Incorrect gear adjustment (excessive backlash). 	Replace ring gear and pinion as matched set. Carefully follow the recommended procedures for adjusting ring gear and pinion backlash and tool, pattern.		
Fracture of ring gear teeth at the tooth toe.	 Shock impact loading. Incorrect gear adjustment (insufficient backlash). 	Replace ring gear and pinion as matche set. Carefully follow the recommended procedure for adjusting ring gear and pinion hacklash poth pattern.		
Scored and/or scuffed ring and pinion gear teeth.	 Insufficient lubrication. Contaminated lubricant. Wrong lubricant or lubricant with depleted additives. Worn pinion bearings which result is pinion end play and incorrect ring and pinion tooth contact. 	Replace ring geal and pinion as a matched set. Replace pinion bearings taking care to set ring and pinion position and bearing preloads properly. Use correct lubricant, fill to proper level and change at recommended intervals.		
Overheated ring and pinion gear teeth. Look for discoloration of the gear teeth.	 Prolonged operation at excessive temperatures. Incorrect lubricant Low oil level. Contaminate rlubricent. All of the above cancesume inadequate lubricant film between tooth surfaces which causes or faces to overheat due to excessive friction. 	Replace ring and pinion as a matched set. Use correct lubricant, fill to specified level and change at recommended intervals.		
Pitted drive pinion teeth.	 1. Lettremon, and are service. 2. Insuficient lubrication. 	Replace ring gear and pinion as a matched set. Use correct lubricant, fill to proper level and change at recommended intervals.		
Bent axle housing	 Venicle overloading. Vehicle accident. Shock loading. 	Replace axle housing.		
Worn or inited bearing.	 Insufficient lubrication. Contaminated lubricant. Very severe service. Normal wear. 	Replace bearing cups and cones in matched sets. Check roller ends for excessive wear by comparing used rollers with a new bearing. Use correct lubricant, fill to proper level and change at recommended levels.		
Leakin, oil seal.	 Prolonged operation at excessive oil temperatures. Scored or dented yoke wear surface. Improperly installed oil seal. Nicked or cut seal lip. Contaminated lubricant. 	Replace the oil seal and mating surface if damaged. Use correct lubricant, fill to proper level and change at the recommended intervals.		

FAILURE MODE	PROBABLE CAUSE	RECOMMENDED REPAIR
Excessive end yoke spline ooseness.	 Severe service. Loose pinion nut. Pinion endplay. 	Replace the end yoke. Check the pinion spline for excessive wear. Replace the ring gear and sinion as a matched set if necessary.
Fatigue fracture of the pinion gear teeth. Look for clear-cut, wavy fracture lines (beachmarks).	Severe service	Replace the ring gear and potion as a matched set.
Fracture of differential side gears and pinion mates.	Shock loading of differential components.	Replace differential solv gears, pinion mates and heross, shaft as a set.
Scoring and/or seizure of cross shaft arms and pinion mate gears.	 Excessive wheel spinning. Inadequate lubrication. Extremely severe service. Unequal tire pressures. 	Peoloce offerential side gears, pinion mates, prost shaft and thrust washers as a set. Use correct lubricant, fill to proper level and change at recommended intervals.
Worn side gear splines. (Excessive backlash).	Severe service.	Replace differential side gears and pinion mates as a set. Replace worn axle shafts.
Scored or worn thrust washer surfaces.	 Insufficient lubrication. Improper lubrication. Contaminated ubricant. 	Replace any scored washer and any washer that is .005 inch thinner than a new one. Use correct lubricant, fill to proper level and change at recommended intervals.
Worn pinion roller bearing retainer bore.	 Severe service. Eccessive pint n end play. In adequate lubrication. Contaminated lubricant. 	Replace carrier housing. Check pinion for excessive endplay. Use correct lubricant, fill to proper level and change at recommended intervals.
Twisted or broken axle shaft.	S vere veuicle operation.	Replace the shaft.
Fractured axle short at the flange.	 Loose wheel bearing. Bent axle housing. Loose shaft to wheel hub bolts. 	Replace the shaft. Check housing distortion. Make certain that wheel bearings are not worn or misadjusted.
Noise on triu	 Excessive pinion to ring gear backlash. Worn pinion and ring gear. Worn pinion bearings. Loose pinion bearings. Excessive pinion end play. Worn differential bearings. Loose differential bearings. Excessive ring gear run-out. Low lubricant level. Wrong or poor grade lubricant. Bent axle housing. 	 Adjust Replace Replace Adjust Adjust Replace
Noise on Coast 1. Axle noises heard on drive usually be heard on coast not as load. 2. Pinion and ring gear too ti (audible when decelerating dispapears when driving dispapears when drispapears when driving dispapears when drispapears whe		 Adjust or replace (See above) Adjsut



FAILURE MODE	PROBABLE CAUSE	RECOMMENDED REPAIR
Intermittent Noise	 Warped ring gear. Loose differential case bolts. 	1. Replace 2. Tighten
Contant Noise	 Flat spot on pinion or ring gear teeth. Flat spot on bearings. 	1. Replace
	3. Worn pinion splines.	2. Replace
	4. Bent axle shaft.	3. Replace
		4. Replace
Noisy on Turns	 Worn differential side gears and pinions. 	1. Replace
	2. Worn differential spider.	2. Replace
	Worn differential thrust washers.	3. Replace
	4. Worn axle shaft splines.	4. Replace

SECTION 4 Specifications

Spicer Axle Lubricant Recommendations

IMPORTANT: Motor vehicles are operated under various requirements, conditions, and environments. This manual specifies the minimum requirements that the luccicants s ould meet. However, it is recommended that the lubricants specified by the vehicle manufacturer in user. They may provide additional lubricating characteristics which may be required for your vehicle, operation. Contact your local service dealer or refer to your owner's manual for obtaining provide additional type to provide a specification.

To ensure proper lubrication and operating temperature in Spicer Axles, it is importany that proper lubricants be used and correct lubricant level be maintained.

RECOMMENDED LUBRICANTS

Multi-purpose gear lubricarts meeting MIL Spec L-2105C and suitable for aPI service constitution GL-5 are suggested as a minimum requirement for Spicer Industrial axis. Report to the chart below for SAE viscosity grade versus as biant air temperature range recommendations.



LIMITEL SLIP JFFERENTIAL LUBRICATION

Limit of Slip etfferencials impose additional requirements on lubricants which may not be covered by the above specific tions. May vehicle manufacturers find it necessary to specify a special lubricant or limited slip additive for use with Limited Slip Differentials. If required, these special lubricants are normally available through the original explanent manufacturer.

KINC PIN BEARING LUBRICATION

King pin bearings are lubricated by packing with grease. For grease packing it is recommended that a No. 2 lithium EP grease suitable for automotive wheel bearings be used. Contact your local vehicle service dealer or refer to your owner's manual for obtaining the proper lubricant specification, and maintenance schedule.

WHEEL END WET DISC BRAKE LUBRICATION

Wheel end wet disc brakes impose additional requirements on lubricants which may not be covered by the above specifications. Many vehicle manufacturers find it necessary to specify a special lubricant or additive for use with them. Contact your local vehicle service dealer or refer to your owner's manual for obtaining the proper lubricant specification.

FASTENER STRENGTH IDENTIFICATION

IMPORTANT: Whenever fasteners are replaced, it is very important that the fastener be replaced with one of equal or higher grade and quality. Fasteners should be torqued as recommended or specified for the application.

WARNING: If fasteners of a lower grade or class are torqued to the requirements of a higher grade or class fastener, it may result in component failure. (e.g. Grade 5 fastener torqued to the requirements of a grade 8 fastener).



WRENCH TORQUE (FT. LBS.)

represent increasing strength.

Inch grade fasteners can be identified by the radial lines embossed upon the head of the fastener and will correspond to the fastener strength by two-lines less than actual grade (i.e. grade a fastener will display 6 radial lines on the head).

NOTE: Male and female threads should be dry and unlubricated unless purchased new as such), clean and free from scale and dirt.

WRENCH TIGHTENING TORQUE SPECIFICATIONS

Ρ	0	S	Τ	10	N	

Drive Pinjon Nut	240-300
Differential Rearing Can Canscraws	180-200
	120 140
Hing Gear Capscrews	
Limited Slip Differential Capscrews	
Carrier Assembly Mounting Capscrews	
Pinion Parking Brake Cover Plate Carscrew	
Pinion Parking Brake Module Capscharger, A	
King Pin Cap Capscrews	
Tie Rod and Steer Cylinder Socket ssen, Stud Nuts	140 Min. (Note A)
Tie Rod and Steer Cylinder Socker transmby Clamp Nuts	60-70
Spindle Mounting Nuts	
Brake Botor Mountine capscrew	
Wet Disc Brake Wheel Reference ascrews	
Drive Flange Mountik, Capscrees	
A) If cotter pir cannot be installed after minimum torque is attained, the nut must be advanced be installed.	l until cotter pin can
BEAPING PRELIDAD SPECIFICATIONS	
Pinen Torgae to Rotate (New Bearings Only)	

BACKLASH SPECIFICATIONS

	005009 in
--	-----------



APPLIC ATION POL, Y Cap allity reflags, features and specifications vary depending upon the model type of service. Applications approvals must be obtained from sign Off-Highway Products Division. We reserve the right to change or modify our product specifications, configurations, or givens, is at ar time without notice.



> SPICER OFF-HIGHWAY PRODUCTS DIVISION

1293 Glenway Drive Statesville, NC 28625 Tel: 704-873-2811 Fax: 704-878-5616

> MM7036-3/99 Excel/Parro

O