



Parts Manual

Serial Number Range

GTH-4010 AU.2

from SN 16125 to 19119

Part No. 645010

Rev D

May 2010

Technical Publications

Genie has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy. Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement.

All communications will be carefully considered for future printings of this and all other manuals.

Contact Us:



www.genieindustries.com


e-mail: awp.techpub@terex.com

The technical data contained in this document is indicative and not binding, insofar as TEREXLIFT S.r.l reserves the right to make modifications and improvements to its products at any time in order to enhance the quality thereof.

57.0411.0022 Rev 0 March 2006
First Edition, First Printing

Chassis serial number

(The chassis serial number is punched on the front right part of the chassis side member)

**Machine data plate**

(On machines destined for the Italian market, the machine data plate is installed in the driving cab, on the right, and is well-visible when the door is opened. On the machines destined for foreign markets, the data plate is applied on the front right side of the chassis)

TEREX^{LIFT} s.r.l.	
ZONA INDUSTRIALE - 06019 UMBERTIDE (PG) - ITALY Tel. +39 075 941.811 Fax +39 075 941.53.82	
MODELLO - MODEL - MODELE - TYP - MODELO	
ANNO DI COSTRUZIONE - YEAR OF CONSTRUCTION - ANNEE DE CONSTRUCTION BAUJAHR - AÑO DE FABRICACIÓN	
MATRICOLA - SERIAL N. - N. DE SERIE - FZ.-IDENT NR. - NO. DE SERIE	
PESO MAX ASSALE ANT. - MAX FRONT AXLE WEIGHT - POIDS MAX ESSIEU AVANT ZUL. ACHSLAST VÖ. N. ST VZO - PESO MAX EJE ANTERIOR	kg
PESO MAX ASSALE POST. - MAX REAR AXLE WEIGHT - POIDS MAX ESSIEU ARRIERE ZUL. ACHSLAST HI. N. ST VZO - PESO MAX EJE POSTERIOR	kg
PESO TOTALE - TOTAL WEIGHT - POIDS TOTAL - ZUL. GESAMTGEWICHT N. ST VZO PESO TOTAL	kg
MATRICOLA MOTORE TERMICO - ENGINE SERIAL N. - N. MOTEUR THERMIQUE FABRIK NR. DIESEL MOTOR - NO. DE SERIE MOTOR TERMICO	
POTENZA MOTORE TERMICO - ENGINE POWER - PUISSANCE MOTEUR MOTORLEISTUNG - POTENCIA MOTOR	kW
CARICO STATICO VERT. GANCIO DI TRAINO-MAX.VERTICAL LOAD ON THE COUPLING HOOK-EFFORT VERTICAL MAXIMAL SUR LE CROCHET D'ATTACHE MAXIMALE STUTZLASTBEANSPRUCHUNG DES ZUGHAKENS IN VERTIKALER RICHTUNG- ESFUERZO VERTICAL SOBRE EL GANCHO DE TRACCION	kg
MASSA MAX. RIMORCHIABILE - MAX.DRAWBAR PULL AT THE COUPLING HOOK EFFORT THE TRACTION - MAXI AU CROCHET D'ATTACHE-MAXIMALE ZUGBEANSPRUCHUNG AM ZUGHAKEN-MAXIMO ESFUERZO DE TRACCION EN EL GANCHO DE TRACCION	kg
OMOLOGAZIONE	
FABBRICATO IN ITALIA - MADE IN ITALY	
CE	

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genieindustries.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genieindustries.com.

How to Read Your Serial Number.....	3
Parts Stocking List.....	7
How to Order Parts.....	8
Service Parts Fax Order Form.....	9

Electronic Version

Click on any page number to view the figure.

100 Cab and Control Place Unit

101.1 604858 Cab, View 1.....	10
102.1 604859 Cab, View 2.....	14
103.1 604860 Dashboard.....	16
104.1 604861 Cab Heater.....	18
105.1 604873 Overload Warning System.....	20
106.1 604875 Instruments And Lights Panel.....	22

200 Frame Unit

201.1 604857 Hydraulic System - Outriggers.....	24
202.1 604876 Frame.....	26
203.1 604877 Rear Frame Unit.....	28
204.1 604900 Label - Name Plate.....	30
205.1 604901 Label - Name Plate.....	32

300 Transmission Unit

301.1 604863 Transmission And Wheels.....	34
302.1 604867 Hydraulic System - Gear Box.....	36
303.1 604868 Power Steering System.....	38
304.1 604872 Hydraulic System - Transmission.....	40
305.1 604878 Hydraulic System - Service Brake.....	42
306.1 604879 Hydraulic System - Parking Brake.....	44
307.1 604880 Front Axle - Differential Case.....	46
308.1 604881 Front Axle - Differential Gear.....	48
309.1 604882 Front Axle - Steering Axle.....	50
310.1 604883 Front Axle - Brake.....	52
311.1 604884 Front Axle - Reduction Gear.....	54
312.1 604885 Front Axle - Steering Cylinder.....	56
313.1 604886 Rear Axle - Differential Case.....	58
314.1 604887 Rear Axle - Differential Gear.....	60
315.1 604888 Rear Axle - Steering Axle.....	62
316.1 604889 Rear Axle - Brake.....	64
317.1 604890 Rear Axle - Steering Cylinder.....	66
318.1 604891 Front Axle - Support.....	68

400 Telescopic Boom Unit

401.1 604856 Forks.....	70
402.1 604892 Arm.....	72

403.1 604893 Hydraulic System - Tilting.....	74
404.1 604894 Hydraulic System - Boom Extension.....	76
405.1 604895 Hydraulic System - Auxiliary Circuit.....	78
406.1 604896 Hydraulic System - Fork Balancing.....	80
407.1 604897 Hydraulic System - Implement Locking.....	82
408.1 604898 Hydraulic System - Lifting.....	84
409.1 604899 Coupling Unit.....	86

500 Diesel Engine Unit

501.1 604864 Diesel Engine - Hydraulic Pump.....	88
502.1 604865 Diesel Engine - Engine Cooling System.....	90
503.1 604866 Diesel Engine - Exhaust System - Accelerator.....	92
504.1 604869 Hydraulic System - Oil Cooler.....	94
505.1 604871 Suction System Hydraulic Pumps.....	96

600 Electric Installation Unit

601.1 604862 Fuse Box.....	98
602.1 604870 Electric Installation.....	100
603.1 604874 Electric Installation.....	102

Indices

Part Number Index.....	104
Part Description Index.....	108

Cross References

This Page Intentionally Left Blank

[illegible]

The following parts are required to perform maintenance procedures as outlined in the GTH 4010 AU.2 Operator's and Service Manuals.

Description	Part No.
Diesel Fuel Filter.....	07.4501.0068
Engine Oil Filter.....	07.4501.0067
Hydraulic Oil Filter Cartridge	07.0700.0000
Oil Filter Immersed in the Tank.....	09.4604.0004
Engine Air Filter Primary Cartridge	640885
Engine Air Filter Secondary Cartridge	07.0700.0041

Used Varnishes

Description	Type
Terex Grey	RAL 7012
Terex White	RAL 1013
Terex Matte Black for Cylinders.....	RAL 9005
Genie Blue.....	
Genie Grey	
Genie Mat Black for Cylinders	RAL 9005

Manuals

Terexlift offers the following support documents for these models:

Title	Part No.
Genie GTH 4010 AU.2 Operator's Manual, 1 st edition (English)	57.0006.2200

Part list abbreviations

ZN	Zinc-plated
RNFT	Reinforced
FLNG	Flanged
PSNT	Heavy type
OC	Eye
PSRT	Through-coupling
CNTF	Hole centre

How To Order Parts

Please be prepared with the following information when ordering replacement parts for your Genie product:

- ☒ Machine model number
- ☒ Machine serial number
- ☒ Genie part number
- ☒ Part description and quantity
- ☒ Purchase order number
- ☒ "Ship to" address
- ☒ Desired method of shipment
- ☒ Name and telephone number of the authorized Genie Distributor in your area

Use the Service Parts Fax Order Form on the next page and fax your order to our Parts Department.

If you don't know the name of your authorized distributor, or if your area is not currently serviced by an authorized distributor, please call Genie Industries.

Machine Information

Model

Serial Number

Date of Purchase

Authorized Genie Distributor

Phone Number

Genie North America

Telephone (425) 556-6551

Toll Free (877) 367-5606 in U.S.A. and Canada

Fax (425) 556-8659

Genie UK

Parts Telephone (44) (0) 1476 584352

Parts Fax (44) (0) 1476 584340

Genie Australia

Parts Telephone (617) 03375 1660

Parts Fax (617) 03375 1002

Genie France

Parts Telephone (33) (0) 237 26 09 99

Parts Fax (33) (0) 237 31 50 10

Genie Germany

Parts Telephone (49) (0) 4202 885223

Parts Fax (49) (0) 4202 885225

Genie Scandinavia

Parts Telephone (46) (31) 3409612

Parts Fax (46) (31) 3409613

Genie Iberica

Parts Telephone (34) (93) 5795042

Genie Brazil

Parts Telephone (55) (114) 1665755

Parts Fax (55) (114) 1665754

Genie Japan


Parts Telephone (81) (33) 4536082

Parts Fax (81) (33) 4536083

Genie China

Parts Telephone (86) (215) 3852570

Parts Fax (86) (215) 3852569



Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0066	Filter.....	1	41	07.0740.0098	Tank.....	1
2	07.0740.0067	Grate.....	1	42	07.0740.0099	Glass.....	1
3	07.0740.0068	Ball-Grip.....	2	43	07.0740.0100	Stop.....	1
4	07.0740.0069	Seal.....	1	44	07.0740.0101	Guard.....	1
5	07.0740.0070	Sheet.....	1	45	07.0740.0102	Washer.....	1
6	07.0740.0026	Washer.....	12	46	07.0740.0103	Nut.....	1
7	07.0740.0071	Screw.....	18	47	07.0740.0104	Door Stop.....	1
8	07.0740.0072	Wiper Motor.....	1	48	07.0740.0105	Screw.....	3
9	07.0740.0073	Glass.....	1	49	07.0740.0106	Seal.....	1
10	07.0740.0074	Glass.....	1	50	07.0740.0028	Hex Cap.....	6
11	07.0740.0246	Glass.....	1	51	07.0740.0006	Washer.....	10
12	07.0740.0052	Seal.....	1,5	52	07.0740.0005	Stop Nut.....	3
13	07.0740.0076	Handle.....	2	53	07.0740.0107	Frame.....	1
14	07.0740.0217	Split Pin.....	2	54	07.0740.0178	Support.....	1
15	07.0740.0078	Hinge.....	2	55	07.0740.0114	Lock.....	1
16	07.0740.0079	Screw.....	7	56	07.0740.0115	Bracket.....	1
17	07.0740.0046	Stop Nut.....	7	57	07.0740.0116	Screw.....	4
18	07.0740.0014	Hex Cap.....	7	58	07.0740.0117	Washer.....	4
19	07.0740.0080	Rubber.....	2	59	07.0740.0247	Kit.....	1
20	07.0740.0081	Washer.....	3	60	07.0740.0202	Driving Mirror.....	1
21	07.0740.0082	Loadspeaker Frame.....	2	61	07.0740.0157	Wiper Blade.....	1
22	07.0740.0083	Screw.....	8	62	07.0740.0158	Wiper Motor.....	1
23	07.0740.0084	Roof Lamp.....	1	63	07.0740.0210	Rubber.....	1
24	07.0740.0064	Screw.....	2	64	07.0740.0211	Spacer.....	1
25	07.0740.0085	Glass.....	1	65	07.0740.0212	Screw.....	2
26	07.0740.0009	Rubber.....	3	66	07.0740.0213	Bushing.....	2
27	07.0740.0086	Rubber.....	1	67	07.0740.0214	Rubber.....	2
28	07.0740.0032	Washer.....	1	68	07.0740.0035	Rubber.....	2
29	07.0740.0087	Glass.....	1	69	07.0740.0215	Spacer.....	2
30	07.0740.0088	Wiper Arm.....	1	70	07.0740.0156	Wiper Arm.....	1
31	07.0740.0089	Wiper Blade.....	1	71	07.0740.0209	Kit.....	1
32	07.0740.0090	Through Coupling.....	1	72	07.0740.0156	Wiper Arm.....	1
33	07.0740.0091	Seal.....	1,5	73	07.0740.0163	Screw.....	2
34	07.0740.0092	Lock.....	1	74	07.0740.0117	Bushing.....	2
35	07.0740.0012	Washer.....	16	75	07.0740.0248	Wiper Blade.....	1
36	07.0740.0093	Storage Pocket.....	1	76	07.0740.0016	Rubber.....	2
37	07.0740.0094	Screw.....	4	77	51.0901.6900	Grate.....	1
38	07.0740.0095	Screw.....	4	78	01.0001.0094	Screw.....	2
39	07.0740.0096	Stop Nut.....	2	79	01.0001.0071	Spring Washer.....	2
40	07.0740.0097	Arm.....	2	80	09.0803.0359	Magnet.....	1


101.1 604858 Cab, View 1
(continued)

Item	Part No.	Description	Qty.
81	09.0803.0358	Rope.....	1
82	01.0031.0056	Washer.....	2
83	01.0001.0505	Screw.....	2
84	01.0001.0072	Spring Washer.....	2
85	01.0031.0057	Washer.....	2

This Page Intentionally Left Blank


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0000	Pin.....	3	41	07.0740.0063	Washer.....	2
2	07.0740.0001	Split Pin.....	3	42	07.0740.0128	Screw.....	4
3	07.0740.0002	Grease Nipple.....	3	43	07.0740.0009	Rubber.....	1
4	07.0740.0003	Seat.....	1	44	07.0740.0060	Screw.....	1
5	07.0740.0004	Screw.....	2	45	07.0740.0231	Plug.....	1
6	07.0740.0005	Stop Nut.....	2	46	07.0740.0062	Washer.....	1
7	07.0740.0006	Washer.....	2	47	07.0740.0027	Plug.....	4
8	07.0740.0007	Screw.....	4	48	07.0740.0028	Hex Cap.....	2
9	07.0740.0275	Screw.....	4	49	07.0740.0250	Lower Door.....	1
10	07.0740.0274	Coating.....	1	50	07.0740.0373	Upper Door Complete.....	1
11	07.0740.0010	Support.....	1	51	07.0740.0029	Handle.....	1
12	07.0740.0011	Screw.....	2	52	07.0740.0030	Pin.....	1
13	07.0740.0012	Washer.....	4	53	07.0740.0228	Rubber.....	6
14	07.0740.0013	Stop Nut.....	2	54	07.0740.0227	Screw.....	2
15	07.0740.0014	Hex Cap.....	8	55	07.0740.0047	Label.....	1
16	07.0740.0015	Rubber.....	1	56	07.0740.0279	Glass.....	1
17	07.0740.0016	Washer.....	2	57	07.0703.0125	Key.....	1
18	07.0740.0017	Nut.....	1	58	07.0740.0276	Hinge.....	2
19	07.0740.0018	Non-Skid Coating.....	0,7	59	51.0811.4092	Reinforcement.....	1
20	07.0740.0235	Rubber Platform.....	1	61	07.0740.0223	Washer.....	6
21	07.0740.0020	Coating.....	1	62	07.0740.0272	Handle.....	1
22	07.0740.0021	Coating.....	1				
23	07.0740.0022	Adhesive Profile.....	1				
24	07.0740.0054	Stop Belt.....	1				
25	07.0740.0024	Support.....	1				
26	07.0740.0025	Screw.....	2				
27	07.0740.0026	Washer.....	6				
28	07.0740.0048	Seal.....	1				
29	07.0740.0049	Seal.....	1				
30	07.0740.0050	Handle.....	1				
31	07.0740.0051	Lever-Fitted Lock.....	1				
32	07.0740.0052	Seal.....	3,5				
33	07.0740.0273	Panel.....	1				
34	07.0740.0035	Bushing.....	1				
35	07.0740.0055	Bushing.....	1				
36	07.0740.0249	Frame.....	1				
37	07.0740.0236	Sun Visor.....	1				
38	07.0740.0058	Seal.....	1				
39	07.0740.0059	Screw.....	2				
40	07.0740.0061	Nut.....	2				

103.1 604860 Dashboard




Item	Part No.	Description	Qty.
1	07.0740.0139	Dashboard.....	1
2	07.0740.0220	Dashboard.....	1
3	07.0740.0141	Lock.....	1
4	07.0740.0142	Cover.....	1
5	07.0740.0116	Screw.....	15
6	07.0740.0117	Washer.....	15
7	07.0740.0037	Washer.....	3
8	07.0740.0143	Cover.....	1
9	07.0740.0144	Screw.....	3
10	07.0740.0145	Washer.....	3
11	09.4610.0001	Bubble Level.....	1
12	07.0740.0154	Spring.....	3
13	07.0703.0490	Glass.....	1
14	07.0703.0494	Switch.....	2
15	07.0703.0417	Turn Signals Lever.....	1
16	07.0703.0418	Speed Lever.....	1
17	07.0703.0420	Security Switch.....	1
18	07.0740.0062	Rivet.....	3
19	07.0703.0441	Emergency Button.....	1
20	07.0703.0423	Plug.....	1
21	07.0740.0152	Ball-Grip.....	1
22	07.0703.0489	Plug.....	6
23	07.0703.0532	Contact.....	1
24	07.0703.0531	Contact.....	1
25	07.0740.0251	Panel.....	1
26	07.0703.0017	Glass.....	1

104.1 604861 Cab Heater



Item	Part No.	Description	Qty.
1	07.0740.0119	Heater.....	1
2	07.0740.0120	Paper Piping.....	0,75
3	07.0740.0120	Paper Piping.....	0,65
4	07.0740.0120	Paper Piping.....	1,55
5	07.0740.0120	Paper Piping.....	0,33
6	07.0740.0120	Paper Piping.....	0,32
7	07.0740.0120	Paper Piping.....	0,4
8	07.0740.0121	Pipe Fitting.....	1
9	07.0740.0122	Rubber Hose.....	6
10	07.0740.0122	Rubber Hose.....	0,8
11	07.0740.0122	Rubber Hose.....	5
12	07.0740.0123	Clamp.....	4
13	07.0740.0124	Screw.....	4
14	07.0740.0125	Air Inlet.....	5
15	07.0740.0126	Reduction.....	5
16	07.0740.0127	Clamp.....	8
17	07.0740.0128	Screw.....	2
18	07.0740.0129	Air Inlet.....	1
19	07.0740.0006	Washer.....	1
20	07.0740.0005	Stop Nut.....	1
21	07.0740.0028	Hex Cap.....	1
22	07.0740.0120	Ball-Grip.....	1
24	07.0740.0118	Screw.....	2
25	07.0740.0016	Washer.....	2
26	07.0740.0132	Support.....	1
27	07.0740.0012	Washer.....	2
28	07.0740.0071	Screw.....	2
29	07.0740.0133	Rubber.....	2
30	07.0740.0218	Tap.....	1
31	07.0740.0219	Name Plate.....	1


105.1 604873 Overload Warning System



105.1 604873 Overload Warning System

Item	Part No.	Description	Qty.
1	56.0016.0022	Display.....	1
2	09.0802.0018	Load Cell.....	1
3	09.0803.0225	Screw.....	2
4	09.0803.0226	Washer.....	2
5	55.0602.0129	Wiring Harness.....	1
6	01.4032.0002	Spring Washer.....	2
7	01.0001.0156	Screw.....	2


106.1 604875 Instruments And Lights Panel



106.1 604875 Instruments And Lights Panel

Item	Part No.	Description	Qty.
1	07.0703.0424	Board With Led'S.....	1
2	07.0703.0425	Indicator.....	1
3	07.0703.0613	Indicator.....	1
4	07.0703.0427	Indicator.....	1
5	07.0703.0029	Starting Switch.....	1
6	07.0703.0428	Hour Meter.....	1
7	638226	SWITCH,SELECTOR,3 POSITION.....	1
8	07.0703.0429	Selector.....	1
9	07.0703.0430	Switch.....	1
10	07.0703.0007	Glass.....	1
11	07.0703.0431	Switch.....	1
12	07.0703.0032	Glass.....	1
13	07.0703.0423	Plug.....	3
14	07.0703.0432	Glass.....	1
15	07.0703.0433	Switch.....	1
16	07.0703.0434	Glass.....	1
17	07.0703.0435	Switch.....	1
18	07.0703.0010	Glass.....	1
19	07.0703.0011	Control Panel.....	1
20	07.0703.0125	Key.....	1
21	07.0703.0572	Switch.....	1


201.1 604857 Hydraulic System - Outriggers



201.1 604857 Hydraulic System - Outriggers

Item	Part No.	Description	Qty.
1	51.0500.0900	Stabilizer.....	2
2	51.0500.0100	Road Pad.....	2
3	54.0000.0146	Pin.....	4
4	54.0000.0008	Pin.....	2
5	54.0000.0145	Pin.....	2
6	53.0800.0400	Cylinder.....	1
7	09.0801.0000	Bushing.....	4
8	53.0800.0500	Cylinder.....	1
9	640537	Joint Kit.....	2
10	04.0607.0163	Pipe Fitting.....	8
11	04.4239.0007	Valve.....	2
12	09.0801.0021	Bushing.....	4
13	04.0605.0319	Flexible Hose.....	4
14	01.0001.0308	Screw.....	2
15	56.0012.0009	Proximity Switch.....	2
16	01.0023.0055	Nut.....	2


202.1 604876 Frame



202.1 604876 Frame

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	51.0108.0000	Frame.....	1	40	01.0001.0156	Screw.....	8
2	51.0800.0400	Plate.....	2	41	01.4006.0016	Screw.....	3
3	01.4001.0000	Screw.....	8	42	09.0803.0012	Spring Washer.....	12
4	01.0031.0062	Plain Washer.....	8	43	51.0800.1000	Support.....	1
5	01.4023.0000	Stop Nut.....	8	44	01.0023.0053	Nut, M6.....	12
6	51.0806.7300	Support.....	2	45	01.4032.0003	Spring Washer.....	12
7	09.0803.0177	Mud-Guard.....	2	46	09.4610.0011	Cylinder.....	1
8	07.0726.0065	Hatch.....	1	47	51.0810.2800	Support.....	1
9	51.0800.1100	Support.....	1	48	51.0807.4200	Support.....	1
10	52.1100.6200	Guard.....	1	49	01.0001.0306	Screw.....	6
11	51.0909.5800	Guard.....	1	50	01.0031.0301	Plain Washer.....	12
12	09.0803.0005	Handle.....	1	51	09.0803.0011	Spring Washer.....	8
13	51.0901.5500	Guard.....	1	52	01.4006.0004	Screw.....	8
14	09.0803.0245	Seal.....	2,1	53	01.0023.0055	Stop Nut.....	10
15	09.4610.0002	Driving Mirror.....	1	54	01.4032.0007	Plain Washer.....	4
16	51.0901.8100	Guard.....	1	55	01.0001.1493	Screw.....	8
17	51.0901.8700	Guard.....	1	56	01.4032.0006	Plain Washer.....	16
18	09.4670.0006	Insulator.....	4	57	01.0001.0657	Screw.....	4
19	01.0001.0357	Screw.....	8	58	01.0031.0061	Plain Washer.....	4
20	01.4031.0001	Plain Washer.....	4	59	01.4001.0001	Screw.....	4
21	54.0100.0020	Protection.....	4	60	01.0023.0060	Stop Nut.....	4
22	01.0031.0058	Plain Washer.....	8				
23	01.0023.0057	Stop Nut.....	16				
24	09.4670.0004	Insulator.....	4				
25	01.0001.0356	Screw.....	16				
26	01.0023.0055	Stop Nut.....	16				
27	01.4001.0012	Screw.....	4				
28	01.4032.0004	Plain Washer.....	32				
29	07.0726.0083	Hatch.....	1				
30	09.0803.0023	Lock.....	1				
31	09.0803.0024	Hook..... Latch	1				
32	09.0803.0000	Hinge.....	2				
33	01.0001.0256	Screw.....	22				
34	01.0031.0299	Plain Washer.....	10				
35	01.0023.0054	Stop Nut.....	21				
36	51.0806.7200	Support.....	2				
37	09.0803.0178	Mud-Guard.....	2				
38	01.0006.0033	Screw.....	8				
39	01.0031.0055	Washer.....	43				


203.1 604877 Rear Frame Unit



203.1 604877 Rear Frame Unit

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	09.0805.0000	Rubber Hose.....	3	41	01.0001.0007	Screw.....	2
2	04.0227.0051	Clamp.....	4	42	01.0023.0054	Stop Nut.....	2
3	09.0805.0000	Rubber Hose.....	0,6	43	01.0001.0086	Screw.....	2
4	01.0032.0054	Spring Washer.....	2	44	09.4661.0021	Airinlet.....	1
5	01.4001.0018	Screw.....	2	45	09.4661.0022	Chain.....	1
6	01.4032.0006	Spring Washer.....	6	46	06.0442.0103	Washer.....	1
7	51.0800.3800	Tie Rod.....	1	47	04.0220.0055	Plug.....	1
8	01.0001.0651	Screw.....	2	48	01.0001.0905	Screw.....	2
9	01.0031.0059	Washer.....	2	49	51.1000.4100	Counterweight.....	1
10	54.0000.0027	Pin.....	1	50	01.0001.0503	Screw.....	1
11	09.0803.0026	Spring Split Pin.....	1	51	51.1000.3000	Counterweight.....	2
12	51.0901.9600	Guard.....	1	52	01.0001.1119	Screw.....	3
13	09.0803.0278	Hinge.....	2	53	51.0800.2500	Bracket.....	1
14	09.0803.0002	Handle.....	1	54	56.0012.0000	Proximity Switch.....	1
15	01.0003.0203	Screw.....	2				
16	01.0031.0299	Plain Washer.....	2				
17	01.0023.0054	Nut.....	2				
18	51.0806.8200	Rod.....	1				
19	51.0600.4300	Diesel Oil Tank.....	1				
20	01.0001.0254	Screw.....	1				
21	09.0803.0013	Clip.....	1				
22	01.0001.0204	Screw.....	1				
23	04.4227.0006	Clamp.....	1				
24	01.0003.0110	Screw.....	4				
25	01.0031.0054	Plain Washer.....	8				
26	09.4670.0000	Retainer.....	1				
27	01.0001.0154	Screw.....	1				
28	01.0031.0054	Washer.....	1				
29	09.0805.0000	Rubber Hose.....	3				
30	09.4661.0020	Plug.....	1				
31	56.0013.0001	Fuel Gauge.....	1				
32	01.4001.0006	Screw.....	6				
33	01.0023.0053	Nut, M6.....	4				
34	51.1000.3800	Left Counterweight.....	1				
35	51.1000.3700	Right Counterweight.....	1				
36	01.0023.0055	Stop Nut.....	1				
37	01.0001.0556	Screw.....	2				
38	01.0023.0053	Nut, M6.....	2				
39	01.0031.0058	Plain Washer.....	6				
40	01.0031.0295	Plain Washer.....	6				




204.1 604900 Label - Name Plate



204.1 604900 Label - Name Plate

Item	Part No.	Description	Qty.
1	09.4618.0242	Label.....	1
2	09.4618.0289	Label.....	2
3	09.4618.0243	Label.....	1
4	09.4612.0212	Label.....	2
5	09.4618.0227	Label.....	1
6	09.4618.0540	Label.....	1
7	09.4618.0657	Label.....	1
8	09.4618.0010	Label.....	1
9	09.4618.0261	Label.....	4
10	09.4618.0022	Label.....	1
11	09.4618.0034	Label.....	1
12	09.4616.0040	Label.....	1
13	09.4618.0230	Label.....	-
14	09.4618.0241	Label.....	1
15	09.4618.0288	Label.....	2
16	09.4618.0361	Label.....	2
17	09.4618.0563	Label.....	1
18	09.4618.0271	Label.....	1
19	09.4618.0784	Label.....	1


205.1 604901 Label - Name Plate



205.1 604901 Label - Name Plate

Item	Part No.	Description	Qty.
1	09.4616.0230	Label.....	1
2	09.4618.0068	Name Plate.....	1
3	09.4618.0053	Name Plate.....	1
4	09.4618.0652	Label.....	1
5	09.4618.0030	Label.....	1
6	09.4618.0026	Label.....	1


301.1 604863 Transmission And Wheels



301.1 604863 Transmission And Wheels

Item	Part No.	Description	Qty.
1	09.4632.0016	Rear Axle.....	1
2	09.4632.0058	Front Axle.....	1
3	09.4635.0024	Cardan Shaft.....	1
4	07.0738.0000	Star Wheel.....	2
5	09.4635.0014	Cardan Joint Assembly Kit.....	4
6	55.0403.0047	Wheel.....	4
7	09.4629.0019	Rim.....	4
8	09.4627.0017	Tyre.....	4
9	09.4635.0039	Cardan Shaft.....	1
10	01.4001.0011	Screw.....	6
11	01.0031.0057	Plain Washer.....	6
12	01.0023.0056	Stop Nut.....	6
13	56.0013.0015	Proximity Switch.....	1
14	09.4633.0026	Reduction Gear.....	1


302.1 604867 Hydraulic System - Gear Box



302.1 604867 Hydraulic System - Gear Box

Item	Part No.	Description	Qty.
1	04.0607.0114	Pipe Fitting.....	4
2	04.0605.0177	Flexible Hose.....	2
3	04.4240.0053	Solenoid Valve.....	1
4	07.0728.0007	Solenoid.....	2
5	07.0728.0006	Joint Kit.....	1
6	01.0001.0257	Screw.....	2
7	01.0031.0055	Spring Washer.....	2
8		604872 pos. 59	
9	04.0607.0153	Pipe Fitting.....	2
10	04.0607.0117	Pipe Fitting.....	1
11	04.0605.0272	Flexible Hose.....	1
12	04.0600.0013	Pipe Fitting.....	1
13	06.0442.0105	Washer.....	1


303.1 604868 Power Steering System



303.1 604868 Power Steering System

Item	Part No.	Description	Qty.
1	07.0740.0135	Steering Wheel.....	1
2	07.0740.0136	Steering Column.....	1
3	01.0001.0256	Screw.....	4
4	01.0032.0054	Washer.....	4
5	01.0001.0355	Screw.....	4
6	01.0032.0055	Washer.....	4
7	09.4636.0014	Power Steering.....	1
8	07.0728.0007	Solenoid.....	2
9	04.0607.0110	Pipe Fitting.....	2
10	04.0605.0310	Flexible Hose.....	1
11	04.0607.0117	Pipe Fitting.....	4
12	992989	SEAL KIT.....	1
13	01.0003.0210	Screw.....	2
14	04.4240.0044	Solenoid Valve.....	1
15	04.0607.0137	Pipe Fitting.....	4
16	01.4032.0003	Spring Washer.....	2
17	04.0605.0311	Flexible Hose.....	1
18	04.0605.0323	Flexible Hose.....	1
19	04.0605.0254	Flexible Hose.....	1
20	04.0605.0255	Flexible Hose.....	1
21	07.0728.0006	Joint Kit.....	1


304.1 604872 Hydraulic System - Transmission



304.1 604872 Hydraulic System - Transmission

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	04.4224.0000	Tap.....	1	41	01.0003.0157	Screw.....	2
2	06.0442.0111	Washer.....	1	42	04.0607.0103	Pipe Fitting.....	4
3	04.0600.0057	Pipe Fitting.....	1	43	04.4235.0023	Hydraulic Motor.....	1
4	04.0600.0042	Pipe Fitting.....	1	44	01.0031.0059	Plain Washer.....	4
5	06.0442.0109	Washer.....	2	45	04.0607.0129	Pipe Fitting.....	1
6	07.0701.0007	Solenoid.....	2	46	07.0701.0196	Solenoid Valve.....	1
7	07.0700.0000	Cartridge.....	1	47	04.0607.0104	Pipe Fitting.....	1
8	07.0700.0001	Indicator.....	1	48	04.0607.0114	Pipe Fitting.....	3
9	04.0600.0044	Pipe Fitting.....	1	49	01.4032.0007	Spring Washer.....	1
10	04.0602.0490	Flexible Hose.....	1	50	04.0605.0315	Flexible Hose.....	1
11	04.0600.0045	Pipe Fitting.....	1	51	04.0600.0068	Pipe Fitting.....	1
12	04.0600.0053	Sleeve.....	1	52	06.0442.0055	Plain Washer.....	1
13	04.0607.0127	Pipe Fitting.....	1	53	04.4210.0003	Pressure Tube.....	1
14	04.0605.0195	Flexible Hose.....	1	54	51.0806.3000	Support.....	1
15	04.0607.0143	Pipe Fitting.....	1	55	01.0031.0299	Plain Washer.....	4
16	04.0600.0159	Pipe Fitting.....	2	56	01.4031.0004	Plain Washer.....	4
17	04.0600.0021	Pipe Fitting.....	1	57	01.0001.0256	Screw.....	2
18	06.0401.0214	Seal.....	2	58	01.4032.0003	Spring Washer.....	2
19	04.4223.0004	Flange.....	4	59	04.0605.0621	Flexible Hose.....	1
20	01.4032.0004	Washer.....	8	60	04.0607.0120	Pipe Fitting.....	1
21	01.0003.0257	Screw.....	8	61	04.0607.0119	Pipe Fitting.....	1
22	04.4229.0047	Flexible Hose.....	1				
23	06.0401.0219	Seal.....	2				
24	04.4223.0003	Half Flange.....	4				
25	04.4229.0046	Flexible Hose.....	1				
26	04.0605.0204	Flexible Hose.....	1				
27	01.0001.0401	Screw.....	8				
28	01.4032.0005	Washer.....	8				
29	01.0001.0651	Screw.....	4				
30	04.0605.0222	Flexible Hose.....	1				
31	04.0607.0105	Pipe Fitting.....	2				
32	04.0600.0050	Pipe Fitting.....	1				
33	04.4210.0004	Pressure Tube.....	2				
34	04.0600.0038	Pipe Fitting.....	1				
35	04.4239.0013	Valve.....	1				
36	04.0605.0620	Flexible Hose.....	2				
37	04.0607.0107	Pipe Fitting.....	2				
38	04.0605.0209	Flexible Hose.....	1				
39	09.4604.0001	Complete Filter.....	1				
40	09.0803.0043	Retainer Pipe.....	1				


305.1 604878 Hydraulic System - Service Brake



305.1 604878 Hydraulic System - Service Brake

Item	Part No.	Description	Qty.
1	05.4309.0004	Pump.....	1
2	01.0003.0155	Screw.....	1
3	05.4329.0001	Pressure Switch.....	1
4	05.4329.0002	Pressure Switch.....	1
5	01.0001.1465	Screw.....	2
6	01.0023.0054	Nut.....	2
7	05.0401.0000	Pipe Fitting.....	2
8	06.0442.0054	Washer.....	8
9	06.0442.0055	Washer.....	12
10	05.0400.0000	Flexible Hose.....	4
11	09.0803.0016	Clamp.....	1
12	53.3401.7700	Pipe.....	1
13	04.0605.0312	Flexible Hose.....	1
14	05.0401.0003	Drilled Screw.....	10
15	04.0601.0003	Pipe Fitting.....	2
16	04.0607.0245	Flexible Hose.....	2
17	04.0607.0114	Pipe Fitting.....	2
18	53.3400.0600	Pipe.....	1
19	05.4329.0000	Accumulator.....	2
20	05.0401.0005	Pipe Fitting.....	4
21	05.0401.0001	Pipe Fitting.....	6
22	04.0607.0156	Pipe Fitting.....	1
23	04.0605.0113	Flexible Hose.....	1
24	04.0607.0137	Pipe Fitting.....	2
25	04.0605.0370	Flexible Hose.....	1
26	04.0600.0166	Pipe Fitting.....	2
27	04.0607.0137	Pipe Fitting.....	1
28	06.0442.0057	Washer.....	2


306.1 604879 Hydraulic System - Parking Brake



306.1 604879 Hydraulic System - Parking Brake

Item	Part No.	Description	Qty.
1	05.4315.0004	Lever.....	1
2	07.0740.0063	Washer.....	4
3	07.0740.0026	Plain Washer.....	7
4	07.0740.0095	Screw.....	4
5	09.4645.0022	Cable.....	2
6	07.0703.0492	Proximity Switch.....	1
7	900130	Snap Ring.....	2
8	07.0740.0177	Cotter Pin.....	2
9	07.0740.0170	Pin.....	1
10	07.0740.0171	Pulley.....	1
11	07.0740.0174	Screw.....	1
12	07.0740.0172	Support.....	1
13	07.0740.0011	Screw.....	1
14	07.0740.0013	Stop Nut.....	2
15	07.0740.0173	Plate.....	1
16	07.0740.0175	Washer.....	2
17	51.0808.7600	Support.....	1
18	54.0001.0000	Pin.....	2
19	02.0117.0053	Grease Nipple.....	2
20	01.0023.0056	Stop Nut.....	2
21	54.0800.0000	Spring.....	2
22	01.4032.0009	Spring Washer.....	1
23	01.0001.0902	Screw.....	1


307.1 604880 Front Axle - Differential Case



307.1 604880 Front Axle - Differential Case

Item	Part No.	Description	Qty.
1	632383	Seal.....	3
2	639668	COVER.....	1
3	07.0709.0439	Housing.....	1
4	07.0709.0084	Plug.....	1
5	639670	PLUG,BREATHER.....	1
7	07.0709.0113	Plug.....	1
8	07.0709.0371	Plug.....	1
9	07.0709.0441	Snap Ring.....	1

308.1 604881 Front Axle - Differential Gear




*28: Position kit = 6+17+18+19+20+21+27+29

308.1 604881 Front Axle - Differential Gear

Item	Part No.	Description	Qty.
1	633202	BEARING.....	1
2	640207	Stud.....	8
3	640206	Nut.....	8
4	639633	SEAL.....	1
5	639650	Screw.....	4
6	639651	Snap Ring.....	4
7	07.0709.0441	Snap Ring.....	1
8	630693	Ring Nut.....	1
9	639828	Spacer.....	1
10	639300	SPACER.....	1
10	639301	SPACER.....	1
10	639302	SPACER.....	1
10	639303	SPACER.....	1
11	634499	SPACER.....	1
11	634501	SPACER.....	1
11	639297	SPACER.....	1
11	639298	SPACER.....	1
12	626544	BEARING.....	2
13	07.0709.0216	Bevel Gear Set.....	1
14	639657	Screw.....	2
15	626544	BEARING.....	2
17	641090	Differential Side Gear.....	2
18	07.0709.0373	Differential Pinion.....	4
19	639660	Pin.....	4
20	639661	Snap Ring.....	4
21	639662	WASHER,FRICTION.....	4
23	07.0709.0057	Screw.....	12
24	639664	Ring Nut.....	2
27	641089	Differential Case.....	1
28	07.0709.0374	Differential.....	1
29	07.0709.0059	Disc.....	2

309.1 604882 Front Axle - Steering Axle




*65: Position kit = 22+12

*66: Position kit = 27+12

309.1 604882 Front Axle - Steering Axle

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	633174	Nut.....	2	44	639646	Snap Ring.....	2
2	640718	Screw.....	2	45	07.0709.0104	Screw.....	4
3	640214	Arm.....	2	46	634546	NUT,DIN439 JAM M16-2.0 P.....	4
4	07.0709.0377	Screw.....	32	49	639647	PLATE,LOCKING.....	2
6	640720	Bushin.....	2	50	07.0709.0365	Screw.....	4
7	630846	SEAL,PLANETARY.....	2	53	07.0709.0119	Stud.....	8
8	633202	BEARING.....	2	54	07.0709.0070	Nut.....	8
9	633203	Snap Ring.....	2	56	07.0709.0071	Washer.....	8
10	640216	Seal.....	2	57	640728	Thickness.....	2
11	639624	Joint.....	2	57	640729	Thickness.....	2
12	639289	Bushing.....	1	57	640730	Thickness.....	2
13	07.0709.0124	Bushing.....	2	58	07.0709.0072	Grease Nipple.....	2
14	640909	Screw.....	8	60	07.0709.0073	Support.....	2
15	07.0709.0060	Cover.....	2	65	07.0709.0219	Housing.....	1
16	638548	CAP.....	4	66	07.0709.0121	Housing.....	1
17	633176	GREASE NIPPLE.....	2				
18	07.0709.0061	Pin.....	2				
19	640908	Pin.....	2				
20	639630	SEAL.....	2				
21	639631	JOINT,ARTICULATED.....	2				
22	07.0709.0101	Housing.....	1				
23	07.0709.0215	Seal.....	2				
25	07.0709.0371	Plug.....	2				
26	07.0709.0113	Plug.....	4				
27	07.0709.0102	Housing.....	1				
28	07.0709.0205	Seal.....	2				
29	639637	Bearing.....	4				
30	07.0709.0117	Pipe Fitting.....	16				
31	07.0709.0064	Hub.....	2				
32	632383	Seal.....	2				
33	639639	RING GEAR.....	2				
34	639640	SUPPORT,RING GEAR.....	2				
35	639641	Snap Ring.....	8				
36	639642	PINION,DIFFERENTIAL.....	8				
37	639643	Bearing.....	8				
38	07.0709.0118	Nut.....	16				
40	07.0709.0065	Screw.....	4				
41	07.0709.0103	Support.....	2				
42	639645	Stud.....	16				
43	637567	Nut.....	16				

310.1 604883 Front Axle - Brake




*14: Position Kit = 4+5+6+7+8+9

310.1 604883 Front Axle - Brake

Item	Part No.	Description	Qty.
1	639674	Brake Disc.....	6
2	639675	Screw.....	6
3	07.0709.0106	Spring.....	6
4	07.0709.0424	Piston.....	2
5	639676	Spring.....	6
6	639679	Back-Up Ring.....	2
7	639695	O-RING.....	2
8	639681	Back-Up Ring.....	2
9	639682	SEAL.....	2
10	639683	BRAKE DISC,INTERMEDIATE.....	8
11	630328	BLEEDER VALVE, LONG.....	2
12	638548	CAP.....	2
13	633069	DOWEL.....	2
14	07.0709.0074	Piston.....	2


311.1 604884 Front Axle - Reduction Gear



311.1 604884 Front Axle - Reduction Gear

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	639799	O-RING.....	1	40	639816	O-RING.....	1
2	639779	PLUG,BREATHER.....	1	41	639809	ROD.....	1
3	639789	Cover.....	1	42	639810	O-RING.....	1
4	639790	Seal.....	1	43	639815	Piston.....	1
5	629733	SHIM,THICKNESS.....	1	44	639781	O-RING.....	1
5	629735	SHIM,THICKNESS.....	1	45	639814	PLATE,COVER.....	1
5	639327	SHIM.....	1	47	639813	Selector Shaft.....	1
5	639328	SHIM.....	1	48	639811	SLIDING GUIDE.....	2
5	639329	SHIM.....	1	49	639812	Selector Fork.....	1
6	633202	BEARING.....	1	50	637584	WASHER,SEALING.....	1
7	639782	COVER.....	1	52	637536	SEAL RING.....	1
9	639784	Bearing.....	1	53	633161	RING/SEAL.....	1
10	639797	SPLIT PIN.....	2	56	633208	Plug.....	1
11	639785	Dowel.....	2	57	637577	SEAL.....	1
12	640196	Housing.....	1	58	639800	Cover.....	1
13	639787	Screw.....	12	59	07.0709.0079	Flange.....	1
14	637574	SEAL.....	1	60	639802	Nut.....	1
16	639818	Washer.....	1	61	07.0709.0440	Sheet.....	1
17	07.0709.0422	Screw.....	1	65	633109	Spring Washer.....	12
18	640198	Spacer.....	1	71	639819	SHAFT.....	1
19	639792	SCREW.....	2	72	639820	Gear.....	1
21	639793	Sheet.....	1	73	639821	Gear.....	1
22	639794	Bearing.....	4				
23	640199	Shaft.....	1				
24	639796	SLEEVE.....	1				
25	639778	SCREW.....	2				
26	639798	Sheet.....	1				
27	628275	PLUG,MAGNETIC.....	1				
28	639791	Spacer.....	1				
29	07.0709.0442	Security Switch.....	1				
30	637582	Rubber Protection.....	1				
31	635594	SCREW.....	1				
32	635596	Spring.....	1				
33	07.0709.0443	Bearing.....	1				
34	07.0709.0327	Sphere.....	1				
35	639803	SCREW.....	1				
36	639804	O-RING.....	1				
37	639807	Seal.....	2				
38	639780	Cylinder.....	1				
39	639808	Plug.....	2				


312.1 604885 Front Axle - Steering Cylinder



312.1 604885 Front Axle - Steering Cylinder

Item	Part No.	Description	Qty.
1	639671	Screw.....	4
4	07.0709.0001	Cylinder.....	1
5	07.0709.0075	Articulated Tie Rod.....	2
8	640270	Joint Kit.....	1


313.1 604886 Rear Axle - Differential Case



313.1 604886 Rear Axle - Differential Case

Item	Part No.	Description	Qty.
1	632383	Seal.....	3
2	639668	COVER.....	1
3	640715	Housing.....	1
4	07.0709.0055	Cover.....	1
5	639670	PLUG,BREATHER.....	1
7	07.0709.0113	Plug.....	1
8	07.0709.0371	Plug.....	1


314.1 604887 Rear Axle - Differential Gear



314.1 604887 Rear Axle - Differential Gear

Item	Part No.	Description	Qty.
1	639352	O-RING.....	1
2	639300	SPACER.....	1
2	639301	SPACER.....	1
2	639302	SPACER.....	1
2	639303	SPACER.....	1
3	07.0709.0372	Bevel Gear Set.....	1
4	633099	Bearing.....	2
5	639664	Ring Nut.....	2
6	639650	Screw.....	4
7	639657	Screw.....	2
8	07.0709.0057	Screw.....	12
9	639684	WASHER.....	2
10	639685	GEAR,DIFFERENTIAL SIDE.....	2
11	639660	Pin.....	4
12	639661	Snap Ring.....	4
13	639662	WASHER,FRICTION.....	4
14	639659	GEAR,SATELLITE.....	4
15	639686	CASE,DIFFERENTIAL.....	1
16	626544	BEARING.....	2
17	634499	SPACER.....	1
17	634501	SPACER.....	1
17	639297	SPACER.....	1
17	639298	SPACER.....	1
18	639653	Spacer.....	1
19	630693	Ring Nut.....	1
20	633098	SEAL,DIFFERENTIAL.....	1
22	07.0709.0426	Flange.....	1
23	639802	Nut.....	1
24	639651	Snap Ring.....	4
25	640717	Differential.....	1


315.1 604888 Rear Axle - Steering Axle



315.1 604888 Rear Axle - Steering Axle

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	633174	Nut.....	2	44	639646	Snap Ring.....	2
2	640718	Screw.....	2	45	07.0709.0104	Screw.....	4
3	640719	Arm.....	2	46	634546	NUT,DIN439 JAM M16-2.0 P.....	4
4	07.0709.0377	Screw.....	32	49	639647	PLATE,LOCKING.....	2
6	640720	Bushin.....	2	50	633204	SNAP RING (CIRCLIP).....	2
7	630846	SEAL,PLANETARY.....	2	53	07.0709.0119	Stud.....	8
8	633202	BEARING.....	2	54	07.0709.0070	Nut.....	8
9	633203	Snap Ring.....	2	56	07.0709.0071	Washer.....	8
10	640216	Seal.....	2	57	640728	Thickness.....	1
11	639624	Joint.....	2	57	640729	Thickness.....	1
12	639289	Bushing.....	2	57	640730	Thickness.....	1
13	07.0709.0124	Bushing.....	2	58	07.0709.0072	Grease Nipple.....	2
14	640909	Screw.....	12	60	07.0709.0105	Support.....	2
15	07.0709.0060	Cover.....	2	65	07.0709.0219	Housing.....	1
16	638548	CAP.....	4	66	07.0709.0121	Housing.....	1
17	633176	GREASE NIPPLE.....	2	72	07.0709.0365	Screw.....	4
18	07.0709.0061	Pin.....	2				
19	640908	Pin.....	2				
20	639630	SEAL.....	2				
21	639631	JOINT,ARTICULATED.....	2				
22	07.0709.0101	Housing.....	1				
23	07.0709.0215	Seal.....	2				
25	07.0709.0371	Plug.....	2				
26	07.0709.0113	Plug.....	4				
27	07.0709.0102	Housing.....	1				
28	07.0709.0205	Seal.....	2				
29	639637	Bearing.....	4				
30	07.0709.0117	Pipe Fitting.....	16				
31	07.0709.0064	Hub.....	2				
32	632383	Seal.....	2				
33	639639	RING GEAR.....	2				
34	639640	SUPPORT,RING GEAR.....	2				
35	639641	Snap Ring.....	8				
36	639642	PINION,DIFFERENTIAL.....	8				
37	639643	Bearing.....	8				
38	07.0709.0118	Nut.....	16				
40	07.0709.0065	Screw.....	4				
41	07.0709.0103	Support.....	2				
42	639645	Stud.....	16				
43	637567	Nut.....	16				

316.1 604889 Rear Axle - Brake




*36: Position Kit = 15+16+17+18+22+23+24

*37: Position Kit = 15+17+18+22+23+24+26

316.1 604889 Rear Axle - Brake

Item	Part No.	Description	Qty.
1	639689	Lever.....	1
2	630328	BLEEDER VALVE, LONG.....	2
3	638548	CAP.....	2
4	901777	Screw.....	6
5	637574	SEAL.....	2
6	07.0709.0122	Bushin.....	2
7	639691	GRUBSCREW.....	2
8	636440	Nut.....	2
10	639692	Lever.....	2
11	630280	Spacer.....	2
12	637511	Screw.....	2
13	639683	BRAKE DISC, INTERMEDIATE.....	10
14	639693	Screw.....	6
15	07.0709.0106	Spring.....	3
16	640731	Piston.....	1
17	639679	Back-Up Ring.....	1
18	639695	O-RING.....	1
19	633069	DOWEL.....	2
20	639696	Lever.....	1
21	639676	Spring.....	6
22	637621	THREADED ELEMENT.....	2
23	639681	Back-Up Ring.....	1
24	639682	SEAL.....	1
25	639674	Brake Disc.....	8
26	640732	Piston.....	1
36	07.0709.0081	Piston.....	1
37	07.0709.0082	Piston.....	1
38	07.0709.0123	Seal.....	2


317.1 604890 Rear Axle - Steering Cylinder



317.1 604890 Rear Axle - Steering Cylinder

Item	Part No.	Description	Qty.
1	639671	Screw.....	4
4	07.0709.0001	Cylinder.....	1
5	07.0709.0075	Articulated Tie Rod.....	2
8	640270	Joint Kit.....	1


318.1 604891 Front Axle - Support



318.1 604891 Front Axle - Support


Item	Part No.	Description	Qty.
1	07.0709.0218	Bushin.....	4
2	637850	Bushing.....	2
3	07.0709.0386	Support.....	2
4	633176	GREASE NIPPLE.....	2
5	638548	CAP.....	2
6	07.0709.0387	Support.....	2

401.1 604856 Forks




Item	Part No.	Description	Qty.
1	51.1300.5300	Plate.....	1
2	51.1301.2500	Fork.....	2
3	54.0000.0083	Pin.....	1
4	54.0100.0056	Washer.....	1
5	01.0001.0409	Screw.....	1
6	01.0023.0056	Nut.....	1
7	09.0803.0055	Chain.....	0,45
8	09.0803.0026	Spring Split Pin.....	2
9	07.0726.0051	Pin.....	2
10	01.4041.0005	Security Dowel.....	2

402.1 604892 Arm



Item	Part No.	Description	Qty.
1	51.0200.7000	1st Telescopic Element.....	1
2	54.0702.0000	Sliding Guide.....	6
3	54.0200.0001	Bushing.....	8
4	54.0702.0001	Sliding Guide.....	4
5	51.0801.9000	Support.....	2
6	01.4032.0004	Spring Washer.....	16
7	01.0001.0357	Screw.....	12
8	01.0001.0304	Screw.....	4
9	54.0201.0003	Bushing.....	2
10	52.0900.0200	Spacer.....	2
11	54.0201.0004	Bushing.....	2
12	02.0117.0101	Grease Nipple.....	1
13	54.0200.0000	Bushing.....	10
14	01.0001.0353	Screw.....	2
15	54.0702.0004	Sliding Guide.....	2
16	01.4006.0005	Screw.....	4
17	01.0003.0203	Screw.....	4
18	54.0702.0005	Sliding Guide.....	2
19	51.0200.7100	2nd Telescopic Element.....	1
20	01.4032.0003	Spring Washer.....	4
21	51.0804.9000	Thickness.....	6
22	51.0809.4000	Thickness.....	4
23	51.0809.3900	Thickness.....	2
24	51.0806.3800	Thickness.....	2
25	07.0803.0357	Indicator.....	1
26	01.0003.0153	Screw.....	2


403.1 604893 Hydraulic System - Tilting



403.1 604893 Hydraulic System - Tilting

Item	Part No.	Description	Qty.
1	04.0607.0141	Pipe Fitting.....	1
2	09.0803.0043	Retainer Pipe.....	10
3	04.0605.0354	Flexible Hose.....	1
4	53.3401.7900	Pipe.....	1
5	01.0003.0157	Screw.....	20
6	06.0442.0103	Washer.....	2
7	54.0201.0017	Bushing.....	2
8	04.4239.0000	Valve.....	1
9	53.0400.1000	Forks Articulation Cylinder.....	1
10	640536	Joint Kit.....	1
11	54.0000.0143	Pin.....	1
12	04.0214.0035	Drilled Screw.....	1
13	07.4529.0073	Back-Up Ring.....	1
14	07.4529.0071	Seal.....	1
15	01.0001.0314	Screw.....	1
16	01.0023.0055	Nut.....	1
17		604896 pos. 14	
18	01.0001.0306	Screw.....	4
19	53.3400.7800	Pipe.....	1


404.1 604894 Hydraulic System - Boom Extension



404.1 604894 Hydraulic System - Boom Extension

Item	Part No.	Description	Qty.
1	53.0100.2100	Cylinder.....	1
2	07.4529.0114	Cylinder Packing Kit.....	1
3		Screw.....	2
4	54.0702.0028	Sliding Guide.....	2
5	54.0003.0101	Pin.....	1
6	01.4032.0003	Washer.....	1
7	01.0031.0299	Spring Washer.....	1
8	01.0001.0254	Screw.....	1
9	04.0605.0326	Flexible Hose.....	2
10	04.0607.0111	Pipe Fitting.....	2
11	07.4529.0073	Back-Up Ring.....	2
12	07.4529.0071	Seal.....	2
13	01.4003.0002	Screw.....	4
14	04.4239.0001	Valve.....	1
15	01.0023.0054	Nut.....	2
16	01.0001.0310	Screw.....	1
17	54.0000.0142	Pin.....	1
18	01.0023.0055	Nut.....	1
19	53.3401.8600	Pipe.....	1
20	53.3401.8500	Pipe.....	1
21	09.0803.0043	Clamp.....	2
24	01.0003.0157	Screw.....	2


405.1 604895 Hydraulic System - Auxiliary Circuit



405.1 604895 Hydraulic System - Auxiliary Circuit

Item	Part No.	Description	Qty.
1	01.0003.0164	Screw.....	12
2	04.0607.0163	Pipe Fitting.....	2
3	09.0803.0043	Retainer Pipe.....	10
4	01.0003.0157	Screw.....	8
5	04.0605.0414	Flexible Hose.....	1
6	04.0605.0413	Flexible Hose.....	2
7	53.3401.8000	Pipe.....	1
8	53.3401.8100	Pipe.....	1


406.1 604896 Hydraulic System - Fork Balancing



406.1 604896 Hydraulic System - Fork Balancing

Item	Part No.	Description	Qty.
1	04.0605.0623	Flexible Hose.....	2
2	07.0704.0075	Solenoid.....	1
3	04.0605.0261	Flexible Hose.....	2
4	04.0607.0122	Pipe Fitting.....	2
5	04.0607.0111	Pipe Fitting.....	8
6	04.4239.0003	Valve.....	1
7	07.4529.0072	Seal.....	2
8	53.0300.1500	Cylinder.....	1
9	636455	Joint Kit.....	1
10	02.0117.0119	Grease Nipple.....	2
11	54.0000.0132	Pin.....	1
12	54.0000.0123	Pin.....	1
13	04.4239.0004	Valve.....	2
14	04.0605.0260	Flexible Hose.....	2
15	635574	End Piece.....	1
16	03.0000.0005	End Piece.....	1
17	01.4001.0008	Screw.....	2
18	01.0023.0055	Stop Nut.....	2
19	01.0031.0055	Plain Washer.....	4
20	04.4236.0049	Valve.....	1
21	01.4001.0034	Screw.....	4
22	01.4032.0003	Spring Washer.....	4
23	07.0704.0155	Valve.....	1
24	07.0704.0154	Valve.....	2


407.1 604897 Hydraulic System - Implement Locking



407.1 604897 Hydraulic System - Implement Locking

Item	Part No.	Description	Qty.
1	53.3001.0500	Manifold.....	1
2	04.0600.0019	Pipe Fitting.....	1
3	04.0600.0087	Pipe Fitting.....	2
4	04.4210.0008	Female Coupling.....	2
5	04.4210.0007	Male Coupling.....	2
6	04.0607.0141	Pipe Fitting.....	2
7	04.0607.0110	Pipe Fitting.....	2
8	04.0605.0308	Flexible Hose.....	2
9	04.0607.0114	Pipe Fitting.....	3
10	01.0001.0156	Screw.....	2
11	04.0607.0112	Pipe Fitting.....	1
12	04.0605.0114	Flexible Hose.....	1
13	04.0605.0113	Flexible Hose.....	1
14	04.0605.0112	Flexible Hose.....	1
15	04.0607.0131	Pipe Fitting.....	1
16	01.4032.0002	Spring Washer.....	2
17		604895 pos. 5	
18	53.0500.0400	Cylinder.....	1
19	01.0031.0054	Plain Washer.....	2
20	01.0001.0355	Screw.....	4
21	01.0032.0055	Washer.....	4
22	01.0031.0301	Washer.....	4
23	54.0001.0001	Pin.....	2
24	04.0600.0081	Pipe Fitting.....	1
25	04.4239.0002	Valve.....	1
26	04.0607.0132	Pipe Fitting.....	1
27	01.0031.0299	Plain Washer.....	3
28	639395	Joint Kit.....	1
29	51.0901.8200	Guard.....	1
30	01.0001.0254	Screw.....	3
31	01.4032.0003	Spring Washer.....	3
32	04.0607.0163	Pipe Fitting.....	2



408.1 604898 Hydraulic System - Lifting



408.1 604898 Hydraulic System - Lifting


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	01.4236.0050	Control Valve.....	1	41	09.0803.0238	Lever.....	1
2	04.0607.0111	Pipe Fitting.....	2	42	07.0704.0162	Block.....	1
3	54.0000.0013	Pin.....	1				
4	02.0117.0101	Grease Nipple.....	2				
5	04.0605.0321	Flexible Hose.....	2				
6	04.0607.0111	Pipe Fitting.....	2				
7	04.0600.0016	Pipe Fitting.....	1				
8	04.4239.0005	Valve.....	1				
9	53.0000.2700	Cylinder.....	1				
10	07.4529.0110	Joint Kit.....	1				
11	09.0801.0016	Bushing.....	4				
12	54.0000.0126	Pin.....	1				
13	07.4529.0072	Seal.....	2				
14	04.0220.0055	Plug.....	2				
15	07.0704.0164	Seal.....	5				
16	51.0809.8400	Bracket.....	2				
17	09.0803.0275	Lever.....	2				
18	07.0704.0157	Proximity Switch.....	2				
19	09.0803.0276	Control Lever.....	1				
20	09.0704.0159	Bellow.....	1				
21	07.0704.0042	Valve.....	1				
22	07.0704.0156	Valve.....	1				
23	01.0001.0207	Screw.....	3				
24	01.0031.0055	Plain Washer.....	3				
25	06.0442.0103	Washer.....	2				
26	01.0032.0054	Spring Washer.....	3				
27	01.0001.0505	Screw.....	1				
28	01.4032.0005	Spring Washer.....	1				
29	07.0704.0106	Proximity Switch.....	1				
30	07.0704.0158	Proximity Switch.....	2				
31	07.0704.0112	Push Button.....	1				
32	07.0704.0110	Push Button.....	1				
33	07.0704.0111	Cap.....	1				
34	01.0023.0056	Stop Nut.....	1				
35	01.0001.0413	Screw.....	1				
36	07.0704.0055	Solenoid.....	1				
37	01.0001.0304	Screw.....	2				
38	01.0032.0055	Spring Washer.....	2				
39	01.0031.0056	Plain Washer.....	2				
40	09.0804.1700	Panel.....	1				

409.1 604899 Coupling Unit



Item	Part No.	Description	Qty.
1	51.0400.2600	Fork Coupling Attachment.....	1
2	01.0031.0054	Plain Washer.....	4
3	01.0023.0053	Nut, M6.....	4
4	01.0001.0104	Screw.....	4
5	54.0201.0017	Bushing.....	2
6	54.0002.0030	Pin.....	1
7	54.0002.0031	Pin.....	1
8	02.0117.0101	Grease Nipple.....	1
9	02.4102.0001	Cotter Pin.....	1
10	54.0000.0077	Pin.....	1
11	54.0001.0022	Pin.....	2


501.1 604864 Diesel Engine - Hydraulic Pump



501.1 604864 Diesel Engine - Hydraulic Pump

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	01.4001.0012	Screw.....	4	43	07.4529.0112	Joint Kit.....	1
2	01.0031.0058	Washer.....	6				
3	51.0806.7500	Support.....	1				
4	01.0031.0301	Plain Washer.....	2				
5	01.4032.0004	Spring Washer.....	2				
6	01.0001.0358	Screw.....	2				
7	01.0001.0356	Screw.....	32				
8	09.4670.0004	Insulator.....	4				
9	01.0023.0055	Nut.....	16				
10	09.0804.0100	Handwheel Arrangement.....	1				
11	01.0023.0057	Nut.....	2				
12	641124	Elastic Joint.....	1				
13	01.0032.0057	Washer.....	9				
14	07.4501.0067	Oil Filter.....	1				
15	01.0031.0099	Plain Washer.....	1				
16	01.4032.0007	Spring Washer.....	1				
17	01.0003.0405	Screw.....	1				
18	04.4238.0033	Pump.....	1				
19	640125	Protection.....	1				
20	04.4238.0030	Pump.....	1				
21	01.0032.0055	Plain Washer.....	8				
22	634981	HUB.....	1				
23	999058	WASHER.....	1				
24	07.4501.0068	Diesel Oil Filter.....	1				
25	01.0001.0357	Screw.....	1				
26	09.4601.0029	Diesel Engine.....	1				
27	54.0100.0066	Pulley.....	1				
28	01.0003.0262	Screw.....	8				
29	09.0804.1000	Snap Ring.....	1				
30	09.0804.1200	Half-Joint.....	1				
31	09.0804.0900	Elastic Joint.....	1				
32	01.0003.0208	Screw.....	6				
33	09.0804.1100	Half-Joint.....	1				
34	51.0807.9800	Support.....	1				
35	01.4032.0006	Spring Washer.....	4				
36	02.4102.0004	Split Pin.....	2				
38	01.0001.0402	Screw.....	2				
39	01.0001.0606	Screw.....	4				
40	01.0023.0056	Nut.....	2				
42	07.0722.0053	Flange.....	1				


502.1 604865 Diesel Engine - Engine Cooling System



502.1 604865 Diesel Engine - Engine Cooling System

Item	Part No.	Description	Qty.
1	01.0001.0209	Screw.....	1
2	01.4031.0004	Plain Washer.....	1
3	09.4670.0001	Rubber.....	1
4	09.0803.0245	Seal.....	1,4
5	53.3200.0022	Complete Radiator.....	1
6	01.0031.0298	Plain Washer.....	3
7	04.0607.0130	Pipe Fitting.....	2
8	01.0001.0254	Screw.....	1
9	04.0605.0215	Flexible Hose.....	1
10	04.0605.0216	Flexible Hose.....	1
11	01.4032.0003	Spring Washer.....	1
12	01.0031.0055	Plain Washer.....	2
13	07.0712.0046	Radiator Core.....	1
14	07.0712.0047	Conveyor.....	1
15	09.4670.0002	Insulator.....	1
16	51.0806.8900	Bracket.....	1
17	01.0023.0054	Nut.....	1
18	01.0031.0301	Plain Washer.....	1
19	01.0023.0055	Nut.....	1
20	07.0712.0006	Guard.....	1
21	07.0712.0048	Fan.....	1
22	01.0001.0158	Screw.....	2
23	01.4032.0002	Spring Washer.....	3
24	01.0001.0154	Screw.....	1
25	53.3302.0017	Insulation.....	1


503.1 604866 Diesel Engine - Exhaust System - Accelerator



503.1 604866 Diesel Engine - Exhaust System - Accelerator

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	09.4655.0000	Lever.....	4	42	640885	Cartridge.....	1
2	09.4656.0000	Pedal.....	1	43	53.3001.1100	Manifold.....	1
3	07.4501.0060	Precleaner.....	1	44	09.0805.0057	Rubber Hose.....	1
4	04.0227.0067	Clamp.....	3	45	01.0023.0053	Nut, M6.....	1
5	09.0805.0054	Rubber Hose.....	1	46	01.0001.0158	Screw.....	1
6	09.0803.0008	Articulation.....	1	47	01.0001.0254	Screw.....	3
7	04.4227.0000	Clamp.....	2	48	01.4032.0003	Washer.....	3
8	07.4501.0061	Proximity Switch.....	1	49	04.0227.0067	Clamp.....	2
9	01.0001.0256	Screw.....	4	50	53.3001.1800	Tube.....	1
10	01.0031.0299	Plain Washer.....	4	51	09.0803.0259	Sheath.....	1
11	09.0805.0058	Rubber Hose.....	1	52	51.0807.5700	Support.....	1
12	01.0001.0357	Screw.....	1	53	09.4645.0003	Gas Cable.....	1
13	01.0031.0056	Washer.....	2	54	09.0803.0007	Clamp.....	2
14	01.0023.0055	Nut.....	1	55	01.0001.1438	Screw.....	2
15	04.4227.0007	Retainer Pipe.....	1	56	01.0023.0052	Stop Nut.....	2
16	01.0006.0049	Screw.....	2	57	09.0803.0027	Rain Protector.....	1
17	53.3100.0033	Exhaust Muffler.....	1				
18	01.4032.0003	Nut.....	4				
19	09.0803.0109	Collar.....	1				
20	09.0805.0053	Rubber Hose.....	1				
21	01.0001.0506	Screw.....	2				
22	01.4032.0005	Spring Washer.....	2				
23	51.0900.1500	Guard.....	1				
24	01.0031.0301	Plain Washer.....	2				
25	01.4032.0004	Spring Washer.....	2				
26	01.4001.0015	Screw.....	2				
27	55.0208.0030	Manifold.....	1				
28	01.0031.0057	Plain Washer.....	2				
29	51.0807.5900	Support.....	1				
30	09.4645.0000	Cable.....	1				
31	07.4501.0042	Clamp.....	2				
32	07.4501.0041	Cartridge.....	1				
33	09.4604.0039	Complete Air Filter.....	1				
35	51.0806.2800	Bracket.....	1				
36	09.0803.0251	Spring.....	1				
37	51.0806.2700	Bracket.....	1				
38	07.0723.0194	Rubber Hose.....	0,1				
39	01.0023.0054	Nut.....	1				
40	51.0901.9500	Guard.....	1				
41	04.0227.0051	Clamp.....	2				


504.1 604869 Hydraulic System - Oil Cooler



504.1 604869 Hydraulic System - Oil Cooler

Item	Part No.	Description	Qty.
1	51.0600.4000	Oil Tank.....	1
2	07.0726.0044	Cover.....	1
3	53.3301.0002	Seal.....	1
4	01.0031.0299	Washer.....	12
5	01.0023.0054	Nut.....	12
6	56.0013.0000	Transmitter.....	1
7	06.0442.0103	Washer.....	2
8	04.0600.0046	Pipe Fitting.....	2
9	04.4239.0013	Valve.....	1
10	09.0803.0232	Insulator.....	2
11	04.0607.0120	Pipe Fitting.....	1
12	04.0607.0119	Pipe Fitting.....	1
13	01.0031.0301	Plain Washer.....	4
14	01.0023.0055	Nut.....	4
15	04.0605.0276	Flexible Hose.....	1
16	04.0607.0107	Pipe Fitting.....	1
17	04.0605.0316	Flexible Hose.....	1
18	04.0605.0279	Flexible Hose.....	1
19	04.0607.0130	Pipe Fitting.....	2
20	06.0442.0105	Washer.....	1
21	04.0600.0013	Pipe Fitting.....	1
22	04.4210.0006	Pressure Tube.....	1



505.1 604871 Suction System Hydraulic Pumps



505.1 604871 Suction System Hydraulic Pumps


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	09.4661.0016	Filter.....	1	42	04.0607.0112	Pipe Fitting.....	3
2	09.4661.0002	Level Indicator.....	1	43	04.4239.0082	Valve.....	1
3	06.0401.0842	Seal.....	1	44	01.0031.0054	Plain Washer.....	2
4	53.3000.1300	Manifold.....	1	45	01.0023.0053	Nut, M6.....	2
5	01.4032.0002	Spring Washer.....	6	46	04.0605.0369	Flexible Hose.....	1
6	01.0001.0156	Screw.....	6	47	56.0013.0028	Level Indicator.....	1
7	09.0805.0007	Rubber Hose.....	0,3	48		604878 pos. 13	
8	04.0227.0144	Clamp.....	2	49	04.0605.0314	Flexible Hose.....	1
9	53.3001.0700	Manifold.....	1	50	01.4032.0003	Spring Washer.....	2
10	09.4661.0014	Plug.....	1	51		604878 pos. 23	
11	01.0001.0154	Pipe Fitting.....	1	52	01.0001.0254	Screw.....	2
13	04.0220.0051	Plug.....	1	53	01.0031.0299	Plain Washer.....	2
14	06.0442.0101	Washer.....	1	54	07.0730.0039	Pipe Fitting.....	1
15	06.0442.0103	Washer.....	1	55	07.0730.0040	Pipe Fitting.....	1
16	04.0220.0055	Plug.....	1				
17	06.0442.0111	Washer.....	1				
18	04.0607.0235	Flexible Hose.....	1				
19	04.0605.0194	Flexible Hose.....	1				
20	01.0001.1482	Screw.....	2				
21	01.4031.0003	Plain Washer.....	4				
22	01.0023.0056	Nut.....	2				
23	09.4604.0004	Filter.....	1				
24	04.4224.0000	Tap.....	1				
25	04.0600.0055	Pipe Fitting.....	1				
26	04.0607.0147	Pipe Fitting.....	1				
27	04.0605.0206	Flexible Hose.....	1				
28	04.4223.0000	Pipe Fitting.....	1				
29	626804	Seal.....	1				
30	01.0001.0355	Screw.....	3				
31	01.0031.0056	Washer.....	3				
32	04.0607.0142	Pipe Fitting.....	1				
33	04.0607.0107	Pipe Fitting.....	1				
34	04.0607.0148	Pipe Fitting.....	2				
35	04.0607.0111	Pipe Fitting.....	4				
36	04.0607.0107	Pipe Fitting.....	1				
37	04.0605.0624	Flexible Hose.....	1				
38	04.0605.0309	Flexible Hose.....	1				
39		604878 pos. 25					
40	04.0607.0122	Pipe Fitting.....	3				
41	04.0605.0269	Flexible Hose.....	1				

601.1 604862 Fuse Box




Item	Part No.	Description	Qty.
1	637650	FUSE,3A.....	2
2	07.0703.0193	Fuse.....	1
3	634972	FUSE,7.5A.....	4
4	634974	FUSE,10A.....	15
5	634973	FUSE,15A.....	5
6	07.0703.0485	Relay.....	14
7	07.0703.0487	Relay.....	1
8	56.0021.0062	Housing.....	1
9	56.0021.0040	Relay.....	1

602.1 604870 Electric Installation



Item	Part No.	Description	Qty.
1	55.0602.0235	Wiring Harness.....	1
2	55.0602.0233	Wiring Harness.....	1
3	55.0602.0237	Wiring Harness.....	1
4	55.0602.0233	Wiring Harness.....	1
5	55.0602.0234	Wiring Harness.....	1
6	55.0602.0205	Wiring Harness.....	1
7	55.0602.0231	Wiring Harness.....	1
8	55.0602.0239	Wiring Harness.....	1
9	55.0602.0238	Wiring Harness.....	1
10	55.0601.0046	Wiring Harness.....	1

603.1 604874 Electric Installation



Item	Part No.	Description	Qty.
1	07.0703.0096	Removing Battery.....	1
2	56.0008.0002	Battery.....	1
3	07.0703.0306	Bulb.....	2
4	07.0703.0321	Bulb.....	1
5	56.0009.0003	Horn.....	1
6	56.0010.0005	Pivoting Beacon.....	1
7	07.0703.0319	Bulb.....	2
8	07.0703.0310	Glass.....	2
9	07.0703.0302	Complete Turn Signal.....	1
10	56.0009.0009	Horn.....	1
11	56.0010.0006	Light.....	1
12	56.0010.0004	Light.....	1
13	51.0804.8700	Support.....	1
14	56.0010.0007	Light.....	1
15	56.0010.0000	Light.....	1
16	56.0010.0001	Light.....	1
17	07.0703.0535	Relay.....	1
18	07.0703.0177	Bracket.....	1
19	637513	Relay.....	1
20	07.0703.0060	Fuse from SN 16710.....	1
20	56.0005.0002	Fuse to SN 16711.....	1
21	07.0703.0061	Fuse from SN 16710.....	1
21	56.0005.0002	Fuse to SN 16711.....	1
22	07.0703.0058	Connector.....	2
23	07.0703.0176	Pull Box.....	1
24	07.0703.0066	Stuffing Box.....	1
25	07.4501.0059	Relay.....	1
26	07.0703.0304	Bulb.....	2
27	07.0703.0305	Bulb.....	2
28	07.0703.0306	Bulb.....	2
29	07.0703.0309	Complete Turn Signal.....	1
30	56.0006.0002	Relay.....	1
31	56.0021.0078	Relay.....	1
32	07.0703.0290	Connector.....	1

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
01.0001.0007	29	01.0031.0062	27	04.0605.0194	97	04.4227.0006	29
01.0001.0071	11-12	01.0031.0099	89	04.0605.0195	41	04.4227.0007	93
01.0001.0072	12	01.0031.0295	29	04.0605.0204	41	04.4229.0046	41
01.0001.0086	29	01.0031.0298	91	04.0605.0206	97	04.4229.0047	41
01.0001.0094	11-12	01.0031.0299	27, 29, 41, 77,	04.0605.0209	41	04.4235.0023	41
01.0001.0104	87		83, 93, 95, 97	04.0605.0215	91	04.4236.0049	81
01.0001.0154	29, 91, 97	01.0031.0301	27, 83, 89, 91,	04.0605.0216	91	04.4238.0030	89
01.0001.0156	21, 27, 83, 97		93, 95	04.0605.0222	41	04.4238.0033	89
01.0001.0158	91, 93	01.0032.0054	29, 39, 85	04.0605.0254	39	04.4239.0000	75
01.0001.0204	29	01.0032.0055	39, 83, 85, 89	04.0605.0255	39	04.4239.0001	77
01.0001.0207	85	01.0032.0057	89	04.0605.0260	81	04.4239.0002	83
01.0001.0209	91	01.4001.0000	27	04.0605.0261	81	04.4239.0003	81
01.0001.0254	29, 77, 83, 91,	01.4001.0001	27	04.0605.0269	97	04.4239.0004	81
	93, 97	01.4001.0006	29	04.0605.0272	37	04.4239.0005	85
01.0001.0256	27, 39, 41, 93	01.4001.0008	81	04.0605.0276	95	04.4239.0007	25
01.0001.0257	37	01.4001.0011	35	04.0605.0279	95	04.4239.0013	41, 95
01.0001.0304	73, 85	01.4001.0012	27, 89	04.0605.0308	83	04.4239.0082	97
01.0001.0306	27, 75	01.4001.0015	93	04.0605.0309	97	04.4240.0044	39
01.0001.0308	25	01.4001.0018	29	04.0605.0310	39	04.4240.0053	37
01.0001.0310	77	01.4001.0034	81	04.0605.0311	39	05.0400.0000	43
01.0001.0314	75	01.4003.0002	77	04.0605.0312	43	05.0401.0000	43
01.0001.0353	73	01.4006.0004	27	04.0605.0314	97	05.0401.0001	43
01.0001.0355	39, 83, 97	01.4006.0005	73	04.0605.0315	41	05.0401.0003	43
01.0001.0356	27, 89	01.4006.0016	27	04.0605.0316	95	05.0401.0005	43
01.0001.0357	27, 73, 89, 93	01.4023.0000	27	04.0605.0319	25	05.4309.0004	43
01.0001.0358	89	01.4031.0001	27	04.0605.0321	85	05.4315.0004	45
01.0001.0401	41	01.4031.0003	97	04.0605.0323	39	05.4329.0000	43
01.0001.0402	89	01.4031.0004	41, 91	04.0605.0326	77	05.4329.0001	43
01.0001.0409	71	01.4032.0002	21, 83, 91, 97	04.0605.0354	75	05.4329.0002	43
01.0001.0413	85	01.4032.0003	27, 39, 41, 73,	04.0605.0369	97	06.0401.0214	41
01.0001.0503	29		77, 81, 83, 91,	04.0605.0370	43	06.0401.0219	41
01.0001.0505	12, 85		93, 97	04.0605.0413	79	06.0401.0842	97
01.0001.0506	93	01.4032.0004	27, 41, 73, 89, 93	04.0605.0414	79	06.0442.0054	43
01.0001.0556	29	01.4032.0005	41, 85, 93	04.0605.0620	41	06.0442.0055	41, 43
01.0001.0606	89	01.4032.0006	27, 29, 89	04.0605.0621	41	06.0442.0057	43
01.0001.0651	29, 41	01.4032.0007	27, 41, 89	04.0605.0623	81	06.0442.0101	97
01.0001.0657	27	01.4032.0009	45	04.0605.0624	97	06.0442.0103	29, 75, 85, 95, 97
01.0001.0902	45	01.4041.0005	71	04.0607.0103	41	06.0442.0105	37, 95
01.0001.0905	29	01.4236.0050	85	04.0607.0104	41	06.0442.0109	41
01.0001.1119	29	02.0117.0053	45	04.0607.0105	41	06.0442.0111	41, 97
01.0001.1438	93	02.0117.0101	73, 85, 87	04.0607.0107	41, 95, 97	07.0700.0000	41
01.0001.1465	43	02.0117.0119	81	04.0607.0110	39, 83	07.0700.0001	41
01.0001.1482	97	02.4102.0001	87	04.0607.0111	77, 81, 85, 97	07.0701.0007	41
01.0001.1493	27	02.4102.0004	89	04.0607.0112	83, 97	07.0701.0196	41
01.0003.0110	29	03.0000.0005	81	04.0607.0114	37, 41, 43, 83	07.0703.0007	23
01.0003.0153	73	04.0214.0035	75	04.0607.0117	37, 39	07.0703.0010	23
01.0003.0155	43	04.0220.0051	97	04.0607.0119	41, 95	07.0703.0011	23
01.0003.0157	41, 75, 77, 79	04.0220.0055	29, 85, 97	04.0607.0120	41, 95	07.0703.0017	17
01.0003.0164	79	04.0227.0051	29, 93	04.0607.0122	81, 97	07.0703.0029	23
01.0003.0203	29, 73	04.0227.0067	93	04.0607.0127	41	07.0703.0032	23
01.0003.0208	89	04.0227.0144	97	04.0607.0129	41	07.0703.0058	103
01.0003.0210	39	04.0600.0013	37, 95	04.0607.0130	91, 95	07.0703.0060	103
01.0003.0257	41	04.0600.0016	85	04.0607.0131	83	07.0703.0061	103
01.0003.0262	89	04.0600.0019	83	04.0607.0132	83	07.0703.0066	103
01.0003.0405	89	04.0600.0021	41	04.0607.0137	39, 43	07.0703.0096	103
01.0006.0033	27	04.0600.0038	41	04.0607.0141	75, 83	07.0703.0125	15, 23
01.0006.0049	93	04.0600.0042	41	04.0607.0142	97	07.0703.0176	103
01.0023.0052	93	04.0600.0044	41	04.0607.0143	41	07.0703.0177	103
01.0023.0053	27, 29, 87, 93, 97	04.0600.0045	41	04.0607.0147	97	07.0703.0193	99
01.0023.0054	27, 29, 43, 77,	04.0600.0046	95	04.0607.0148	97	07.0703.0290	103
	91, 93, 95	04.0600.0050	41	04.0607.0153	37	07.0703.0302	103
01.0023.0055	25, 27, 29, 75,	04.0600.0053	41	04.0607.0156	43	07.0703.0304	103
	77, 81, 89, 91,	04.0600.0055	97	04.0607.0163	25, 79, 83	07.0703.0305	103
	93, 95	04.0600.0057	41	04.0607.0235	97	07.0703.0306	103
01.0023.0056	35, 45, 71, 85,	04.0600.0068	41	04.0607.0245	43	07.0703.0309	103
	89, 97	04.0600.0081	83	04.4210.0003	41	07.0703.0310	103
01.0023.0057	27, 89	04.0600.0087	83	04.4210.0004	41	07.0703.0319	103
01.0023.0060	27	04.0600.0159	41	04.4210.0006	95	07.0703.0321	103
01.0031.0054	29, 83, 87, 97	04.0600.0166	43	04.4210.0007	83	07.0703.0417	17
01.0031.0055	27, 37, 81, 85, 91	04.0601.0003	43	04.4210.0008	83	07.0703.0418	17
01.0031.0056	12, 85, 93, 97	04.0602.0490	41	04.4223.0000	97	07.0703.0420	17
01.0031.0057	12, 35, 93	04.0605.0112	83	04.4223.0003	41	07.0703.0423	17, 23
01.0031.0058	27, 29, 89	04.0605.0113	43, 83	04.4223.0004	41	07.0703.0424	23
01.0031.0059	29, 41	04.0605.0114	83	04.4224.0000	41, 97	07.0703.0425	23
01.0031.0061	27	04.0605.0177	37	04.4227.0000	93	07.0703.0427	23

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
07.0703.0428	23	07.0709.0374	49	07.0740.0068	11-12	07.0740.0177	45
07.0703.0429	23	07.0709.0377	51, 63	07.0740.0069	11-12	07.0740.0178	11-12
07.0703.0430	23	07.0709.0386	69	07.0740.0070	11-12	07.0740.0202	11-12
07.0703.0431	23	07.0709.0387	69	07.0740.0071	11-12, 19	07.0740.0209	11-12
07.0703.0432	23	07.0709.0422	55	07.0740.0072	11-12	07.0740.0210	11-12
07.0703.0433	23	07.0709.0424	53	07.0740.0073	11-12	07.0740.0211	11-12
07.0703.0434	23	07.0709.0426	61	07.0740.0074	11-12	07.0740.0212	11-12
07.0703.0435	23	07.0709.0439	47	07.0740.0076	11-12	07.0740.0213	11-12
07.0703.0441	17	07.0709.0440	55	07.0740.0078	11-12	07.0740.0214	11-12
07.0703.0485	99	07.0709.0441	47, 49	07.0740.0079	11-12	07.0740.0215	11-12
07.0703.0487	99	07.0709.0442	55	07.0740.0080	11-12	07.0740.0217	11-12
07.0703.0489	17	07.0709.0443	55	07.0740.0081	11-12	07.0740.0218	19
07.0703.0490	17	07.0712.0006	91	07.0740.0082	11-12	07.0740.0219	19
07.0703.0492	45	07.0712.0046	91	07.0740.0083	11-12	07.0740.0220	17
07.0703.0494	17	07.0712.0047	91	07.0740.0084	11-12	07.0740.0223	15
07.0703.0531	17	07.0712.0048	91	07.0740.0085	11-12	07.0740.0227	15
07.0703.0532	17	07.0722.0053	89	07.0740.0086	11-12	07.0740.0228	15
07.0703.0535	103	07.0723.0194	93	07.0740.0087	11-12	07.0740.0231	15
07.0703.0572	23	07.0726.0044	95	07.0740.0088	11-12	07.0740.0235	15
07.0703.0613	23	07.0726.0051	71	07.0740.0089	11-12	07.0740.0236	15
07.0704.0042	85	07.0726.0065	27	07.0740.0090	11-12	07.0740.0246	11-12
07.0704.0055	85	07.0726.0083	27	07.0740.0091	11-12	07.0740.0247	11-12
07.0704.0075	81	07.0728.0006	37, 39	07.0740.0092	11-12	07.0740.0248	11-12
07.0704.0106	85	07.0728.0007	37, 39	07.0740.0093	11-12	07.0740.0249	15
07.0704.0110	85	07.0730.0039	97	07.0740.0094	11-12	07.0740.0250	15
07.0704.0111	85	07.0730.0040	97	07.0740.0095	11-12, 45	07.0740.0251	17
07.0704.0112	85	07.0738.0000	35	07.0740.0096	11-12	07.0740.0272	15
07.0704.0154	81	07.0740.0000	15	07.0740.0097	11-12	07.0740.0273	15
07.0704.0155	81	07.0740.0001	15	07.0740.0098	11-12	07.0740.0274	15
07.0704.0156	85	07.0740.0002	15	07.0740.0099	11-12	07.0740.0275	15
07.0704.0157	85	07.0740.0003	15	07.0740.0100	11-12	07.0740.0276	15
07.0704.0158	85	07.0740.0004	15	07.0740.0101	11-12	07.0740.0279	15
07.0704.0162	85	07.0740.0005	11-12, 15, 19	07.0740.0102	11-12	07.0740.0373	15
07.0704.0164	85	07.0740.0006	11-12, 15, 19	07.0740.0103	11-12	07.0803.0357	73
07.0709.0001	57, 67	07.0740.0007	15	07.0740.0104	11-12	07.4501.0041	93
07.0709.0055	59	07.0740.0009	11-12, 15	07.0740.0105	11-12	07.4501.0042	93
07.0709.0057	49, 61	07.0740.0010	15	07.0740.0106	11-12	07.4501.0059	103
07.0709.0059	49	07.0740.0011	15, 45	07.0740.0107	11-12	07.4501.0060	93
07.0709.0060	51, 63	07.0740.0012	11-12, 15, 19	07.0740.0114	11-12	07.4501.0061	93
07.0709.0061	51, 63	07.0740.0013	15, 45	07.0740.0115	11-12	07.4501.0067	89
07.0709.0064	51, 63	07.0740.0014	11-12, 15	07.0740.0116	11-12, 17	07.4501.0068	89
07.0709.0065	51, 63	07.0740.0015	15	07.0740.0117	11-12, 17	07.4529.0071	75, 77
07.0709.0070	51, 63	07.0740.0016	11-12, 15, 19	07.0740.0118	19	07.4529.0072	81, 85
07.0709.0071	51, 63	07.0740.0017	15	07.0740.0119	19	07.4529.0073	75, 77
07.0709.0072	51, 63	07.0740.0018	15	07.0740.0120	19	07.4529.0110	85
07.0709.0073	51	07.0740.0020	15	07.0740.0121	19	07.4529.0112	89
07.0709.0074	53	07.0740.0021	15	07.0740.0122	19	07.4529.0114	77
07.0709.0075	57, 67	07.0740.0022	15	07.0740.0123	19	09.0704.0159	85
07.0709.0079	55	07.0740.0024	15	07.0740.0124	19	09.0801.0000	25
07.0709.0081	65	07.0740.0025	15	07.0740.0125	19	09.0801.0016	85
07.0709.0082	65	07.0740.0026	11-12, 15, 45	07.0740.0126	19	09.0801.0021	25
07.0709.0084	47	07.0740.0027	15	07.0740.0127	19	09.0802.0018	21
07.0709.0101	51, 63	07.0740.0028	11-12, 15, 19	07.0740.0128	15, 19	09.0803.0000	27
07.0709.0102	51, 63	07.0740.0029	15	07.0740.0129	19	09.0803.0002	29
07.0709.0103	51, 63	07.0740.0030	15	07.0740.0132	19	09.0803.0005	27
07.0709.0104	51, 63	07.0740.0032	11-12	07.0740.0133	19	09.0803.0007	93
07.0709.0105	63	07.0740.0035	11-12, 15	07.0740.0135	39	09.0803.0008	93
07.0709.0106	53, 65	07.0740.0037	17	07.0740.0136	39	09.0803.0011	27
07.0709.0113	47, 51, 59, 63	07.0740.0046	11-12	07.0740.0139	17	09.0803.0012	27
07.0709.0117	51, 63	07.0740.0047	15	07.0740.0141	17	09.0803.0013	29
07.0709.0118	51, 63	07.0740.0048	15	07.0740.0142	17	09.0803.0016	43
07.0709.0119	51, 63	07.0740.0049	15	07.0740.0143	17	09.0803.0023	27
07.0709.0121	51, 63	07.0740.0050	15	07.0740.0144	17	09.0803.0024	27
07.0709.0122	65	07.0740.0051	15	07.0740.0145	17	09.0803.0026	29, 71
07.0709.0123	65	07.0740.0052	11-12, 15	07.0740.0152	17	09.0803.0027	93
07.0709.0124	51, 63	07.0740.0054	15	07.0740.0154	17	09.0803.0043	41, 75, 77, 79
07.0709.0205	51, 63	07.0740.0055	15	07.0740.0156	11-12	09.0803.0055	71
07.0709.0215	51, 63	07.0740.0058	15	07.0740.0157	11-12	09.0803.0109	93
07.0709.0216	49	07.0740.0059	15	07.0740.0158	11-12	09.0803.0177	27
07.0709.0218	69	07.0740.0060	15	07.0740.0163	11-12	09.0803.0178	27
07.0709.0219	51, 63	07.0740.0061	15	07.0740.0170	45	09.0803.0225	21
07.0709.0327	55	07.0740.0062	15, 17	07.0740.0171	45	09.0803.0226	21
07.0709.0365	51, 63	07.0740.0063	15, 45	07.0740.0172	45	09.0803.0232	95
07.0709.0371	47, 51, 59, 63	07.0740.0064	11-12	07.0740.0173	45	09.0803.0238	85
07.0709.0372	61	07.0740.0066	11-12	07.0740.0174	45	09.0803.0245	27, 91
07.0709.0373	49	07.0740.0067	11-12	07.0740.0175	45	09.0803.0251	93

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
09.0803.0259	93	51.0200.7000	73	54.0000.0013	85	633099	61
09.0803.0275	85	51.0200.7100	73	54.0000.0027	29	633109	55
09.0803.0276	85	51.0400.2600	87	54.0000.0077	87	633161	55
09.0803.0278	29	51.0500.0100	25	54.0000.0083	71	633174	51, 63
09.0803.0358	12	51.0500.0900	25	54.0000.0123	81	633176	51, 63, 69
09.0803.0359	11-12	51.0600.4000	95	54.0000.0126	85	633202	49, 51, 55, 63
09.0804.0100	89	51.0600.4300	29	54.0000.0132	81	633203	51, 63
09.0804.0900	89	51.0800.0400	27	54.0000.0142	77	633204	63
09.0804.1000	89	51.0800.1000	27	54.0000.0143	75	633208	55
09.0804.1100	89	51.0800.1100	27	54.0000.0145	25	634499	49, 61
09.0804.1200	89	51.0800.2500	29	54.0000.0146	25	634501	49, 61
09.0804.1700	85	51.0800.3800	29	54.0001.0000	45	634546	51, 63
09.0805.0000	29	51.0801.9000	73	54.0001.0001	83	634972	99
09.0805.0007	97	51.0804.8700	103	54.0001.0022	87	634973	99
09.0805.0053	93	51.0804.9000	73	54.0002.0030	87	634974	99
09.0805.0054	93	51.0806.2700	93	54.0002.0031	87	634981	89
09.0805.0057	93	51.0806.2800	93	54.0003.0101	77	635574	81
09.0805.0058	93	51.0806.3000	41	54.0100.0020	27	635594	55
09.4601.0029	89	51.0806.3800	73	54.0100.0056	71	635596	55
09.4604.0001	41	51.0806.7200	27	54.0100.0066	89	636440	65
09.4604.0004	97	51.0806.7300	27	54.0200.0000	73	636455	81
09.4604.0039	93	51.0806.7500	89	54.0200.0001	73	637511	65
09.4610.0001	17	51.0806.8200	29	54.0201.0003	73	637513	103
09.4610.0002	27	51.0806.8900	91	54.0201.0004	73	637536	55
09.4610.0011	27	51.0807.4200	27	54.0201.0017	75, 87	637567	51, 63
09.4612.0212	31	51.0807.5700	93	54.0702.0000	73	637574	55, 65
09.4616.0040	31	51.0807.5900	93	54.0702.0001	73	637577	55
09.4616.0230	33	51.0807.9800	89	54.0702.0004	73	637582	55
09.4618.0010	31	51.0808.7600	45	54.0702.0005	73	637584	55
09.4618.0022	31	51.0809.3900	73	54.0702.0028	77	637621	65
09.4618.0026	33	51.0809.4000	73	54.0800.0000	45	637650	99
09.4618.0030	33	51.0809.8400	85	55.0208.0030	93	637850	69
09.4618.0034	31	51.0810.2800	27	55.0403.0047	35	638226	23
09.4618.0053	33	51.0811.4092	15	55.0601.0046	101	638548	51, 53, 63, 65, 69
09.4618.0068	33	51.0900.1500	93	55.0602.0129	21	639289	51, 63
09.4618.0227	31	51.0901.5500	27	55.0602.0205	101	639297	49, 61
09.4618.0230	31	51.0901.6900	11-12	55.0602.0231	101	639298	49, 61
09.4618.0241	31	51.0901.8100	27	55.0602.0233	101	639300	49, 61
09.4618.0242	31	51.0901.8200	83	55.0602.0234	101	639301	49, 61
09.4618.0243	31	51.0901.8700	27	55.0602.0235	101	639302	49, 61
09.4618.0261	31	51.0901.9500	93	55.0602.0237	101	639303	49, 61
09.4618.0271	31	51.0901.9600	29	55.0602.0238	101	639327	55
09.4618.0288	31	51.0909.5800	27	55.0602.0239	101	639328	55
09.4618.0289	31	51.1000.3000	29	56.0005.0002	103	639329	55
09.4618.0361	31	51.1000.3700	29	56.0006.0002	103	639352	61
09.4618.0540	31	51.1000.3800	29	56.0008.0002	103	639395	83
09.4618.0563	31	51.1000.4100	29	56.0009.0003	103	639624	51, 63
09.4618.0652	33	51.1300.5300	71	56.0009.0009	103	639630	51, 63
09.4618.0657	31	51.1301.2500	71	56.0010.0000	103	639631	51, 63
09.4618.0784	31	52.0900.0200	73	56.0010.0001	103	639633	49
09.4627.0017	35	52.1100.6200	27	56.0010.0004	103	639637	51, 63
09.4629.0019	35	53.0000.2700	85	56.0010.0005	103	639639	51, 63
09.4632.0016	35	53.0100.2100	77	56.0010.0006	103	639640	51, 63
09.4632.0058	35	53.0300.1500	81	56.0010.0007	103	639641	51, 63
09.4633.0026	35	53.0400.1000	75	56.0012.0000	29	639642	51, 63
09.4635.0014	35	53.0500.0400	83	56.0012.0009	25	639643	51, 63
09.4635.0024	35	53.0800.0400	25	56.0013.0000	95	639645	51, 63
09.4635.0039	35	53.0800.0500	25	56.0013.0001	29	639646	51, 63
09.4636.0014	39	53.3000.1300	97	56.0013.0015	35	639647	51, 63
09.4645.0000	93	53.3001.0500	83	56.0013.0028	97	639650	49, 61
09.4645.0003	93	53.3001.0700	97	56.0016.0022	21	639651	49, 61
09.4645.0022	45	53.3001.1100	93	56.0021.0040	99	639653	61
09.4655.0000	93	53.3001.1800	93	56.0021.0062	99	639657	49, 61
09.4656.0000	93	53.3100.0033	93	56.0021.0078	103	639659	61
09.4661.0002	97	53.3200.0022	91	626544	49, 61	639660	49, 61
09.4661.0014	97	53.3301.0002	95	626804	97	639661	49, 61
09.4661.0016	97	53.3302.0017	91	628275	55	639662	49, 61
09.4661.0020	29	53.3400.0600	43	629733	55	639664	49, 61
09.4661.0021	29	53.3400.7800	75	629735	55	639668	47, 59
09.4661.0022	29	53.3401.7700	43	630280	65	639670	47, 59
09.4670.0000	29	53.3401.7900	75	630328	53, 65	639671	57, 67
09.4670.0001	91	53.3401.8000	79	630693	49, 61	639674	53, 65
09.4670.0002	91	53.3401.8100	79	630846	51, 63	639675	53
09.4670.0004	27, 89	53.3401.8500	77	632383	47, 51, 59, 63	639676	53, 65
09.4670.0006	27	53.3401.8600	77	633069	53, 65	639679	53, 65
51.0108.0000	27	54.0000.0008	25	633098	61	639681	53, 65

Part Number	Page	Part Number	Page
639682	53, 65	901777	65
639683	53, 65	992989	39
639684	61	999058	89
639685	61		
639686	61		
639689	65		
639691	65		
639692	65		
639693	65		
639695	53, 65		
639696	65		
639778	55		
639779	55		
639780	55		
639781	55		
639782	55		
639784	55		
639785	55		
639787	55		
639789	55		
639790	55		
639791	55		
639792	55		
639793	55		
639794	55		
639796	55		
639797	55		
639798	55		
639799	55		
639800	55		
639802	55, 61		
639803	55		
639804	55		
639807	55		
639808	55		
639809	55		
639810	55		
639811	55		
639812	55		
639813	55		
639814	55		
639815	55		
639816	55		
639818	55		
639819	55		
639820	55		
639821	55		
639828	49		
640125	89		
640196	55		
640198	55		
640199	55		
640206	49		
640207	49		
640214	51		
640216	51, 63		
640270	57, 67		
640536	75		
640537	25		
640715	59		
640717	61		
640718	51, 63		
640719	63		
640720	51, 63		
640728	51, 63		
640729	51, 63		
640730	51, 63		
640731	65		
640732	65		
640885	93		
640908	51, 63		
640909	51, 63		
641089	49		
641090	49		
641124	89		
900130	45		

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

1 1st Telescopic Element.....73	Control Panel.....23 Control Valve.....85 Conveyor.....91 Cotter Pin.....45, 87 Counterweight.....29 COVER.....47, 55, 59 Cover.....17, 51, 55, 59, 63, 95 Cylinder.....25, 27, 55, 57, 67, 77, 81, 83, 85 Cylinder Packing Kit.....77	H Half Flange.....41 Half-Joint.....89 Handle.....11–12, 15, 27, 29 Handwheel Arrangement.....89 Hatch.....27 Heater.....19 Hex Cap.....11–12, 15, 19 Hinge.....11–12, 15, 27, 29 Hook.....27 Horn.....103 Hour Meter.....23 Housing.....47, 51, 55, 59, 63, 99 HUB.....89 Hub.....51, 63 Hydraulic Motor.....41
2 2nd Telescopic Element.....73	D Dashboard.....17 Diesel Engine.....89 Diesel Oil Filter.....89 Diesel Oil Tank.....29 Differential.....49, 61 Differential Case.....49 Differential Pinion.....49 Differential Side Gear.....49 Disc.....49 Display.....21 Door Stop.....11–12 DOWEL.....53, 65 Dowel.....55 Drilled Screw.....43, 75 Driving Mirror.....11–12, 27	I Indicator.....23, 41, 73 Insulation.....91 Insulator.....27, 89, 91, 95
6 604872 pos. 59.....37 604878 pos. 13.....97 604878 pos. 23.....97 604878 pos. 25.....97 604895 pos. 5.....83 604896 pos. 14.....75	E Elastic Joint.....89 Emergency Button.....17 End Piece.....81 Exhaust Muffler.....93	J Joint.....51, 63 Joint Kit.....25, 37, 39, 57, 67, 75, 81, 83, 85, 89 JOINT,ARTICULATED.....51, 63
A Accumulator.....43 Adhesive Profile.....15 Air Inlet.....19 Airinlet.....29 Arm.....11–12, 51, 63 Articulated Tie Rod.....57, 67 Articulation.....93	F Fan.....91 Female Coupling.....83 Filter.....11–12, 97 Flange.....41, 55, 61, 89 Flexible Hose.....25, 37, 39, 41, 43, 75, 77, 79, 81, 83, 85, 91, 95, 97 Fork.....71 Fork Coupling Attachment.....87 Forks Articulation Cylinder.....75 Frame.....11–12, 15, 27 Front Axle.....35 Fuel Gauge.....29 Fuse.....99 Fuse from SN 16710.....103 Fuse to SN 16711.....103 FUSE,10A.....99 FUSE,15A.....99 FUSE,3A.....99 FUSE,7.5A.....99	K Key.....15, 23 Kit.....11–12
B Back-Up Ring.....53, 65, 75, 77 Ball-Grip.....11–12, 17, 19 Battery.....103 BEARING.....49, 51, 55, 61, 63 Bearing.....51, 55, 61, 63 Bellow.....85 Bevel Gear Set.....49, 61 BLEEDER VALVE, LONG.....53, 65 Block.....85 Board With Led'S.....23 Bracket.....11–12, 29, 85, 91, 93, 103 Brake Disc.....53, 65 BRAKE DISC, INTERMEDIATE.....53, 65 Bubble Level.....17 Bulb.....103 Bushin.....51, 63, 65, 69 Bushing.....11–12, 15, 25, 51, 63, 69, 73, 75, 85, 87	G Gas Cable.....93 Gear.....55 GEAR, DIFFERENTIAL SIDE.....61 GEAR, SATELLITE.....61 Glass.....11–12, 15, 17, 23, 103 Grate.....11–12 GREASE NIPPLE.....51, 63, 69 Grease Nipple.....15, 45, 51, 63, 73, 81, 85, 87 GRUBSCREW.....65 Guard.....11–12, 27, 29, 83, 91, 93	L Label.....15, 31, 33 Left Counterweight.....29 Level Indicator.....97 Lever.....45, 65, 85, 93 Lever-Fitted Lock.....15 Light.....103 Load Cell.....21 Loadspeaker Frame.....11–12 Lock.....11–12, 17, 27 Lower Door.....15
C Cable.....45, 93 CAP.....51, 53, 63, 65, 69 Cap.....85 Cardan Joint Assembly Kit.....35 Cardan Shaft.....35 Cartridge.....41, 93 CASE, DIFFERENTIAL.....61 Chain.....29, 71 Clamp.....19, 29, 43, 77, 93, 97 Clip.....29 Coating.....15 Collar.....93 Complete Air Filter.....93 Complete Filter.....41 Complete Radiator.....91 Complete Turn Signal.....103 Connector.....103 Contact.....17 Control Lever.....85	M Magnet.....11–12 Male Coupling.....83 Manifold.....83, 93, 97 Mud-Guard.....27	N Name Plate.....19, 33 Non-Skid Coating.....15 Nut.....11–12, 15, 25, 29, 43, 49, 51, 55, 61, 63, 65, 71, 75, 77, 89, 91, 93, 95, 97 Nut, M6.....27, 29, 87, 93, 97 NUT, DIN439 JAM M16-2.0 P.....51, 63
		O O-RING.....53, 55, 61, 65 Oil Filter.....89 Oil Tank.....95

P

Panel.....15, 17, 85
 Paper Piping.....19
 Pedal.....93
 Pin.....15, 25, 29, 45, 49, 51, 61, 63, 71, 75, 77, 81, 83, 85, 87
 PINION,DIFFERENTIAL.....51, 63
 Pipe.....43, 75, 77, 79
 Pipe Fitting.....19, 25, 37, 39, 41, 43, 51, 63, 75, 77, 79, 81, 83, 85, 91, 95, 97
 Piston.....53, 55, 65
 Pivoting Beacon.....103
 Plain Washer.....27, 29, 35, 41, 45, 81, 83, 85, 87, 89, 91, 93, 95, 97
 Plate.....27, 45, 71
 PLATE,COVER.....55
 PLATE,LOCKING.....51, 63
 Plug.....15, 17, 23, 29, 47, 51, 55, 59, 63, 85, 97
 PLUG,BREATHING.....47, 55, 59
 PLUG,MAGNETIC.....55
 Power Steering.....39
 Precleaner.....93
 Pressure Switch.....43
 Pressure Tube.....41, 95
 Protection.....27, 89
 Proximity Switch.....25, 29, 35, 45, 85, 93
 Pull Box.....103
 Pulley.....45, 89
 Pump.....43, 89
 Push Button.....85

R

Radiator Core.....91
 Rain Protector.....93
 Rear Axle.....35
 Reduction.....19
 Reduction Gear.....35
 Reinforcement.....15
 Relay.....99, 103
 Removing Battery.....103
 Retainer.....29
 Retainer Pipe.....41, 75, 79, 93
 Right Counterweight.....29
 Rim.....35
 RING GEAR.....51, 63
 Ring Nut.....49, 61
 RING/SEAL.....55
 Rivet.....17
 Road Pad.....25
 ROD.....55
 Rod.....29
 Roof Lamp.....11-12
 Rope.....12
 Rubber.....11-12, 15, 19, 91
 Rubber Hose.....19, 29, 93, 97
 Rubber Platform.....15
 Rubber Protection.....55

S

SCREW.....55
 Screw.....11-12, 15, 17, 19, 21, 25, 27, 29, 35, 37, 39, 41, 43, 45, 49, 51, 53, 55, 57, 61, 63, 65, 67, 71, 73, 75, 77, 79, 81, 83, 85, 87, 89, 91, 93, 97
 SEAL.....49, 51, 53, 55, 63, 65
 Seal.....11-12, 15, 27, 41, 47, 51, 55, 59, 63, 65, 75, 77, 81, 85, 91, 95, 97
 SEAL KIT.....39

SEAL RING.....55
 SEAL,DIFFERENTIAL.....61
 SEAL,PLANETARY.....51, 63
 Seat.....15
 Security Dowel.....71
 Security Switch.....17, 55
 Selector.....23
 Selector Fork.....55
 Selector Shaft.....55
 SHAFT.....55
 Shaft.....55
 Sheath.....93
 Sheet.....11-12, 55
 SHIM.....55
 SHIM,THICKNESS.....55
 SLEEVE.....55
 Sleeve.....41
 SLIDING GUIDE.....55
 Sliding Guide.....73, 77
 Snap Ring.....45, 47, 49, 51, 61, 63, 89
 SNAP RING (CIRCLIP).....63
 Solenoid.....37, 39, 41, 81, 85
 Solenoid Valve.....37, 39, 41
 SPACER.....49, 61
 Spacer.....11-12, 49, 55, 61, 65, 73
 Speed Lever.....17
 Sphere.....55
 SPLIT PIN.....55
 Split Pin.....11-12, 15, 89
 Spring.....17, 45, 53, 55, 65, 93
 Spring Split Pin.....29, 71
 Spring Washer.....11-12, 21, 27, 29, 37, 39, 41, 45, 55, 73, 77, 81, 83, 85, 89, 91, 93, 97
 Stabilizer.....25
 Star Wheel.....35
 Starting Switch.....23
 Steering Column.....39
 Steering Wheel.....39
 Stop.....11-12
 Stop Belt.....15
 Stop Nut.....11-12, 15, 19, 27, 29, 35, 45, 81, 85, 93
 Storage Pocket.....11-12
 Stud.....49, 51, 63
 Stuffing Box.....103
 Sun Visor.....15
 Support.....11-12, 15, 19, 27, 41, 45, 51, 63, 69, 73, 89, 93, 103
 SUPPORT,RING GEAR.....51, 63
 Switch.....17, 23
 SWITCH,SELECTOR,3 POSITION.....23

T

Tank.....11-12
 Tap.....19, 41, 97
 Thickness.....51, 63, 73
 THREADED ELEMENT.....65
 Through Coupling.....11-12
 Tie Rod.....29
 Transmitter.....95
 Tube.....93
 Turn Signals Lever.....17
 Tyre.....35

U

Upper Door Complete.....15

V

Valve.....25, 41, 75, 77, 81, 83, 85, 95, 97

W

WASHER.....61, 89
 Washer.....11-12, 15, 17, 19, 21, 27, 29, 37, 39, 41, 43, 45, 51, 55, 63, 71, 75, 77, 83, 85, 89, 93, 95, 97
 WASHER,FRICTION.....49, 61
 WASHER,SEALING.....55
 Wheel.....35
 Wiper Arm.....11-12
 Wiper Blade.....11-12
 Wiper Motor.....11-12
 Wiring Harness.....21, 101

This Page Intentionally Left Blank

California Proposition 65

Warning

The exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Genie North America

Phone 425.881.1800
Toll Free USA and Canada
800.536.1800
Fax 425.883.3475

Genie Australia Pty Ltd.

Phone +61 7 3375 1660
Fax +61 7 3375 1002

Genie China

Phone +86 21 53852570
Fax +86 21 53852569

Genie Malaysia

Phone +65 98 480 775
Fax +65 67 533 544

Genie Japan

Phone +81 3 3453 6082
Fax +81 3 3453 6083

Genie Korea

Phone +82 25 587 267
Fax +82 25 583 910

Genie Brasil

Phone +55 11 41 665 755
Fax +55 11 41 665 754

Genie Holland

Phone +31 183 581 102
Fax +31 183 581 566

Genie Scandinavia

Phone +46 31 575100
Fax +46 31 579020

Genie France

Phone +33 (0)2 37 26 09 99
Fax +33 (0)2 37 26 09 98

Genie Iberica

Phone +34 93 579 5042
Fax +34 93 579 5059

Genie Germany

Phone +49 (0)4202 88520
Fax +49 (0)4202 8852-20

Genie U.K.

Phone +44 (0)1476 584333
Fax +44 (0)1476 584334

Genie Mexico City

Phone +52 55 5666 5242
Fax +52 55 5666 3241

Distributed By:

Parts Manual

GTH-4010 AU.2

from SN 16125 to 19119

Part No.
645010

Rev D

