



Parts Manual

Serial Number Range

GTH-4013

from SN 14518 to 17991

from SN 18615 to 18627

Part No. 645018

Rev D1

July 2014

Technical Publications

Genie has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy.

Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement. All communications will be carefully considered for future printings of this and all other manuals.

Contact Us:



www.genieindustries.com


e-mail: awp.techpub@terex.com

The technical data contained in this document is indicative and not binding, insofar as TEREXLIFT S.r.l reserves the right to make modifications and improvements to its products at any time in order to enhance the quality thereof.

57.0411.0005 Rev A January 2008
First Edition, First Printing

Chassis serial number

(The chassis serial number is punched on the front right part of the chassis side member)

**Machine data plate**

(On machines destined for the Italian market, the machine data plate is installed in the driving cab, on the right, and is well-visible when the door is opened. On the machines destined for foreign markets, the data plate is applied on the front right side of the chassis)

TEREXLIFT s.r.l.	
ZONA INDUSTRIALE - 06019 UMBERTIDE (PG) - ITALY Tel. +39 075 941.811 Fax +39 075 941.53.82	
MODELLO - MODEL - MODELE - TYP - MODELO	
ANNO DI COSTRUZIONE - YEAR OF CONSTRUCTION - ANNEE DE CONSTRUCTION BAUJAHR - AÑO DE FABRICACIÓN	
MATRICOLA - SERIAL N. - N. DE SERIE - FZ-IDENT NR. - NO. DE SERIE	
PESO MAX ASSALE ANT. - MAX FRONT AXLE WEIGHT - POIDS MAX ESSIEU AVANT ZUL. ACHSLAST VO. N. ST VZO - PESO MAX EJE ANTERIOR	kg
PESO MAX ASSALE POST. - MAX REAR AXLE WEIGHT - POIDS MAX ESSIEU ARRIERE ZUL. ACHSLAST HI. N. ST VZO - PESO MAX EJE POSTERIOR	kg
PESO TOTALE - TOTAL WEIGHT - POIDS TOTAL - ZUL. GESAMTGEWICHT N. ST VZO PESO TOTAL	kg
MATRICOLA MOTORE TERMICO - ENGINE SERIAL N. - N. MOTEUR THERMIQUE FABRIK NR. DIESEL MOTOR - NO. DE SERIE MOTOR TERMICO	
POTENZA MOTORE TERMICO - ENGINE POWER - PUISSANCE MOTEUR MOTORLEISTUNG - POTENCIA MOTOR	kW
CARICO STATICO VERT. GANCIO DI TRAINO-MAX.VERTICAL LOAD ON THE COUPLING HOOK-EFFORT VERTICAL MAXIMAL SUR LE CROCHET D'ATTACHE MAXIMALE STUTZLASTBEANSPRUCHUNG DES ZUGHAKENS IN VERTIKALER RICHTUNG- ESFUERZO VERTICAL SOBRE EL GANCHO DE TRACCION	kg
MASSA MAX. RIMORCHIABILE - MAX.DRAWBAR PULL AT THE COUPLING HOOK EFFORT THE TRACTION - MAXI AU CROCHET D'ATTACHE-MAXIMALE ZUGBEANSPRUCHUNG AM ZUGHAKEN-MAXIMO ESFUERZO DE TRACCION EN EL GANCHO DE TRACCION	kg
OMOLOGAZIONE	
FABBRICATO IN ITALIA - MADE IN ITALY	CE

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number.....	3
Parts Stocking List.....	7
How to Order Parts.....	8
Service Parts Fax Order Form.....	9

Electronic Version

Click on any page number to view the figure.

100 Cab and Control Place Unit

101.1 604994 Cab.....	10
102.1 604995 Cab.....	12
103.1 604996 Dashboard.....	14
104.1 604997 Cab Heater.....	16
105.1 605009 Overload Warning System.....	18
106.1 605010 Instruments and Lights Panel.....	20

200 Frame Unit

201.1 604980 Rear Frame Unit.....	22
202.1 604981 Hydraulic System - Axle Levelling.....	24
203.1 604982 Hydraulic System - Axle Locking.....	26
204.1 604983 Hydraulic System - Stabilizer.....	28
205.1 605012 Frame - Left Side.....	30
206.1 605013 Frame - Right Side (to serial number 16401).....	32
207.1 605013 Frame - Right Side (from serial number 16402).....	34

300 Transmission Unit

301.1 605003 Hydraulic System - Gearbox.....	36
302.1 605004 Power Steering System.....	38
303.1 605006 Hydraulic System - Control Valve.....	40
304.1 605008 Hydraulic System - Transmission.....	42
305.1 605011 Hydraulic System - Service Brake.....	44
306.1 605015 Transmission And Wheels.....	46
307.1 605016 Parking Brake.....	48
308.1 605017 Front Axle - Differential Case.....	50
309.1 605018 Front Axle - Differential Gear.....	52
310.1 605019 Front Axle - Steering Axle.....	54
311.1 605020 Front Axle - Brake.....	56

312.1 605021 Front Axle - Steering Cylinder.....	58
313.1 605022 Front Axle - Support.....	60
314.1 605023 Rear Axle - Differential Case.....	62
315.1 605024 Rear Axle - Differential Gear.....	64
316.1 605025 Rear Axle - Steering Axle.....	66
317.1 605026 Rear Axle - Brake.....	68
318.1 605027 Rear Axle - Steering Cylinder.....	70
319.1 605028 Rear Axle - Support.....	72
320.1 605029 Reduction Gear.....	74

400 Telescopic Boom Unit

401.1 604984 Hydraulic System - Lifting.....	76
402.1 604985 Arm.....	78
403.1 604986 Arm.....	80
404.1 604988 Forks.....	82
405.1 604989 Hydraulic System - Tilting.....	84
406.1 604990 Hydraulic System - Boom Extension.....	86
407.1 604991 Coupling Unit.....	88
408.1 604992 Hydraulic System - Auxiliary Circuit.....	90
409.1 604992 Hydraulic System - Implement Locking.....	92
410.1 605014 Hydraulic System - Fork Balancing.....	94

500 Diesel Engine Unit

501.1 604998 Diesel Engine - Supports and Accessories.....	96
502.1 604999 Diesel Engine - Engine Cooling System.....	98
503.1 605000 Diesel Engine - Exhaust System.....	100
504.1 605001 Diesel Engine - Accelerator.....	102
505.1 605002 Diesel Engine - Injection System.....	104
506.1 605005 Hydraulic System - Oil Cooler.....	106
507.1 605007 Suction System Hydraulic Pumps.....	108
508.1 605034 Decals And Plates.....	110
509.1 605035 Decals And Plates.....	112

600 Electric Installation Unit

601.1 605032 Fuse Box.....	114
602.1 605036 Electric Installation - Engine Line.....	116
603.1 605037 Electric Installation - Rear Line.....	118
604.1 605038 Electric Installation - Rear Line.....	120
605.1 605039 Electric Installation - Dashboard Line.....	122
606.1 605040 Electric Installation - Side Cab Line.....	124
607.1 605041 Electric Installation - Side Cab Line.....	126
608.1 605042 Electric Installation - Rear Line.....	128

Indices

Part Number Index.....	130
Part Description Index.....	134

Cross References

Fittings Cross Reference.....	138
-------------------------------	-----

This Page Intentionally Left Blank

Notes

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Required Parts

The following parts are required to perform maintenance procedures as outlined in the GTH-4013EX Operator's and Service Manuals.

Description	Part No.
Fuel Filter.....	07.4501.0057
Engine Oil Filter	638243
Hydraulic Oil Filter Element.....	07.0700.0023
Primary Air Filter Element.....	07.4501.0084
Safety Air Filter Element.....	07.4501.0085
Oil filter (Inside the tank).....	09.4604.0000

Used Varnishes

Description	Type
Terex Grey	RAL 7012
Terex White	RAL 1013
Terex Matte Black for Cylinders	RAL 9005
Ausa Orange.....	RAL 2004
Mz Imer Orange.....	RAL 2010
Genie Blue.....	
Genie Grey.....	
Genie Matte Black for Cylinders.....	RAL 9005

Manuals

Genie offers the following support documents for these models:

Title	Part No.
Genie GTH-4013EX - GTH 4017EX - GTH-4514EX Operator's Manual, 1 st edition (English).....	57.0009.0454
Service Manual, 1 st edition (English).....	57.0009.0427

Part list abbreviations

ZN	Zinc-plated
RNFT	Reinforced
FLNG	Flanged
PSNT	Heavy type
OC	Eye
PSRT	Through-coupling
CNTF	Hole centre

How To Order Parts

Please be prepared with the following information when ordering replacement parts for your Terex or Genie product:

- ☒ Machine model number
- ☒ Machine serial number
- ☒ Part number
- ☒ Part description and quantity
- ☒ Purchase order number
- ☒ "Ship to" address
- ☒ Desired method of shipment
- ☒ Name and telephone number of the authorized distributor in your area

Use the Service Parts Fax Order Form on the next page and fax your order to our Parts Department.

If you don't know the name of your authorized distributor, or if your area is not currently serviced by an authorized distributor, please call Terex or Genie Industries.

North America

Telephone (425) 556-6551
Toll Free (877) 367-5606 in U.S.A. and Canada
Fax (425) 556-8659
Toll Free Fax (888) 274-6192

Europe

Parts Telephone (31) (165) 519 313
Parts Fax (31) (165) 511 148

Australia

Parts Telephone (61) (7) 3456 4444
Parts Fax (61) (7) 3456 4466

South America

Parts Telephone (55) (11) 4082 5600
Parts Fax (55) (11) 4082 5630

Machine Information


Model

Serial Number

Date of Purchase

Authorized Genie Distributor

Phone Number



Date _____	Account Number _____
Your Name _____	Your Fax Number _____
_____	Your Phone Number _____
Bill To _____	Ship To _____
_____	_____
_____	_____
_____	_____
Purchase Order Number _____	Ship Via _____

Optional Equipment _____


[illegible]

☐ Ship complete order only - No back orders

☐ Ship all available parts and contact customer on disposition of back-ordered parts


☐ Other (please specify)

101.1 604994 Cab




Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0066	ELEMENT,AIR FILTER.....	1	41	07.0740.0098	Tank.....	1
2	07.0740.0067	FILTER,COVER.....	1	42	07.0740.0099	Glass.....	1
3	07.0740.0068	Ball-Grip.....	2	43	07.0740.0100	Stop.....	1
4	07.0740.0069	Seal.....	1	44	07.0740.0101	Guard.....	1
5	07.0740.0070	HOSE GUIDE.....	1	45	07.0740.0102	Washer.....	1
6	07.0740.0026	WASHER.....	12	46	07.0740.0103	Nut.....	1
7	07.0740.0071	SCREW.....	18	47	07.0740.0104	Door Stop.....	1
8	07.0740.0072	MOTOR,WIPER.....	1	48	07.0740.0105	SCREW,TE M6X30.....	3
9	07.0740.0073	Glass.....	1	49	07.0740.0106	GASKET,RUBBER.....	1
10	07.0740.0074	Glass.....	1	50	07.0740.0028	HEX HEAD CAP.....	6
11	07.0740.0246	Glass.....	1	51	07.0740.0006	WASHER 6.4X12.....	10
12	07.0740.0052	SEAL,ADHESIVE.....	1,5	52	07.0740.0005	STOP NUT.....	3
13	07.0740.0076	HANDLE.....	2	53	07.0740.0107	Frame.....	1
14	07.0740.0217	PLUG.....	2	54	07.0740.0178	Support.....	1
15	07.0740.0078	Hinge.....	2	55	07.0740.0114	Lock.....	1
16	07.0740.0079	Screw.....	7	56	07.0740.0115	Bracket.....	1
17	07.0740.0046	Stop Nut.....	7	57	07.0740.0116	SCREW,FE TGS T M6X25 UNI ZN.....	4
18	07.0740.0014	NUT,PROTECTION.....	7	58	07.0740.0117	Washer.....	4
19	07.0740.0080	Rubber.....	2	59	07.0740.0247	Kit.....	1
20	07.0740.0081	Washer.....	3	60	07.0740.0202	MIRROR,COMPLETE.....	1
21	07.0740.0082	COVER,SPEAKER.....	2	61	07.0740.0157	Wiper Blade.....	1
22	07.0740.0083	Screw.....	8	62	07.0740.0158	Wiper Motor.....	1
23	07.0740.0084	DOME LIGHT.....	1	63	07.0740.0210	Rubber.....	1
24	07.0740.0064	Screw.....	2	64	07.0740.0211	Spacer.....	1
25	07.0740.0085	GLASS, TOP.....	1	65	07.0740.0212	Screw.....	2
26	07.0740.0009	Rubber.....	3	66	07.0740.0213	Bushing.....	2
27	07.0740.0086	Rubber.....	1	67	07.0740.0214	Rubber.....	2
28	07.0740.0032	Washer.....	1	68	07.0740.0035	Rubber.....	2
29	07.0740.0087	FRONT GLASS.....	1	69	07.0740.0215	Spacer.....	2
30	07.0740.0088	WIPER ARM.....	1	70	07.0740.0156	WIPER ARM.....	1
31	07.0740.0089	WIPER BLADE.....	1	71	07.0740.0209	Kit.....	1
32	07.0740.0090	Through Coupling.....	1	72	07.0740.0156	WIPER ARM.....	1
33	07.0740.0091	GASKET.....	1,5	73	07.0740.0163	Screw.....	2
34	07.0740.0092	Lock.....	1	74	07.0740.0117	Bushing.....	2
35	07.0740.0012	WASHER.....	16	75	07.0740.0248	WIPER BLADE.....	1
36	07.0740.0093	Storage Pocket.....	1	76	07.0740.0016	WASHER 6.5X18.....	2
37	07.0740.0094	Screw.....	4				
38	07.0740.0095	Screw.....	4				
39	07.0740.0096	Stop Nut.....	2				
40	07.0740.0097	MIRROR,COMPLETE.....	2				

102.1 604995 Cab



Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0000	Pin.....	3	41	07.0740.0063	Washer.....	2
2	07.0740.0001	Split Pin.....	3	42	07.0740.0128	SCREW,KN TC 4.2X9.5 ZN.....	4
3	07.0740.0002	Grease Nipple.....	3	43	07.0740.0009	Rubber.....	1
4	07.0740.0003	Seat.....	1	44	07.0740.0060	Screw.....	1
5	07.0740.0004	Screw.....	2	45	07.0740.0231	Plug.....	1
6	07.0740.0005	STOP NUT.....	2	46	07.0740.0062	Washer.....	1
7	07.0740.0006	WASHER 6.4X12.....	2	47	07.0740.0027	CAP.....	4
8	07.0740.0007	Screw.....	4	48	07.0740.0028	HEX HEAD CAP.....	2
9	07.0740.0275	Screw.....	4	49	07.0740.0250	Lower Door.....	1
10	07.0740.0274	Coating.....	1	50	07.0740.0277	Upper Door Complete.....	1
11	07.0740.0010	Support.....	1	51	07.0740.0029	HANDLE.....	1
12	07.0740.0011	Screw.....	2	52	07.0740.0030	LOCK,DOOR.....	1
13	07.0740.0012	WASHER.....	4	53	07.0740.0228	Rubber.....	6
14	07.0740.0013	Stop Nut.....	2	54	07.0740.0227	Screw.....	2
15	07.0740.0014	NUT,PROTECTION.....	8	55	07.0740.0047	Label.....	1
16	07.0740.0015	BUMP STOP,RUBBER.....	1	56	07.0740.0041	GLASS.....	1
17	07.0740.0016	WASHER 6.5X18.....	2	56	07.0740.0279	GLASS.....	1
18	07.0740.0017	Nut.....	1	57	07.0703.0125	KEY ONLY, SWITCH/IGNITION.....	1
19	07.0740.0018	NON-SKID TREAD.....	0,7	58	07.0740.0230	Seal.....	1
20	07.0740.0235	Rubber Platform.....	1	59	07.0740.0229	Reinforcement.....	1
21	07.0740.0020	ROOF COVERING.....	1	61	07.0740.0223	Washer.....	6
22	07.0740.0021	COVERING.....	1	62	07.0740.0272	HANDLE.....	1
23	07.0740.0022	Adhesive Profile.....	1	63	07.0740.0276	Hinge.....	2
24	07.0740.0054	Stop Belt.....	1				
25	07.0740.0024	Support.....	1				
26	07.0740.0025	Screw.....	2				
27	07.0740.0026	WASHER.....	6				
28	07.0740.0048	GASKET,HANDLE.....	1				
29	07.0740.0049	GASKET,HANDLE.....	1				
30	07.0740.0050	HANDLE.....	1				
31	07.0740.0051	DOOR LOCK.....	1				
32	07.0740.0052	SEAL,ADHESIVE.....	3,5				
33	07.0740.0273	Panel.....	1				
34	07.0740.0035	Bushing.....	1				
35	07.0740.0055	Bushing.....	1				
36	07.0740.0249	Frame.....	1				
37	07.0740.0236	KIT,SUNSHIELD CURTAIN.....	1				
38	07.0740.0058	SEAL,DOOR.....	1				
39	07.0740.0059	Screw.....	2				
40	07.0740.0061	Nut.....	2				


103.1 604996 Dashboard



103.1 604996 Dashboard



Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0139	Dashboard.....	1	40	07.0740.0042	Screw.....	2
2	07.0740.0140	Dashboard.....	1	41	07.0740.0012	WASHER.....	2
3	07.0740.0141	Lock.....	1	42	56.0016.0032	Control Lever.....	1
4	07.0740.0142	Cover.....	1	43	07.0741.0017	Cap.....	1
5	07.0740.0116	SCREW,FE TGS T M6X25 UNI ZN.....	28	44	07.0741.0019	Cap.....	1
6	07.0740.0117	Washer.....	28	45	07.0703.0019	PILOT LIGHT/LAMP.....	1
7	07.0740.0037	Washer.....	3	46	07.0703.0532	CONTACT.....	1
8	07.0740.0143	COVER,RADIO HOUSING.....	1	47	07.0741.0009	Selector.....	1
9	07.0740.0144	Screw.....	3	48	07.0703.0532	CONTACT.....	2
10	07.0740.0145	Washer.....	3	49	07.0703.0534	Contact.....	5
11	09.4610.0001	WATER LEVEL,CIRCULAR BUBBLE.....	1	50	07.0703.0533	Contact.....	1
12	07.0740.0154	Spring.....	3				
13	07.0703.0035	GLASS/PILOT LIGHT.....	1				
14	07.0703.0419	Switch.....	2				
15	07.0703.0417	SPEED LEVER.....	1				
16	07.0703.0418	LIGHT SWITCH LEVER.....	1				
17	07.0703.0420	KEY.....	1				
18	07.0703.0017	PILOT LIGHT/GLASS.....	1				
19	07.0703.0441	Emergency Button.....	1				
20	07.0703.0489	Plug.....	1				
21	07.0741.0018	Handle.....	1				
22	07.0703.0423	COVER,DASH.....	5				
23	07.0740.0062	Rivet.....	3				
24	07.0740.0152	KNOB.....	1				
25	07.0740.0206	Screw.....	4				
26	07.0703.0421	2 KEYS & SWITCH.....	1				
27	07.0703.0419	Switch.....	1				
28	07.0703.0581	Panel.....	1				
29	07.0741.0010	CAP.....	1				
30	07.0741.0011	PUSH BUTTON.....	3				
31	07.0741.0012	Push Button.....	1				
32	07.0741.0014	Protection.....	1				
33	07.0703.0034	Switch Cover.....	1				
34	07.0740.0234	Lock.....	1				
35	07.0740.0208	Support.....	1				
36	07.0703.0531	Contact.....	1				
38	07.0740.0151	Bushing.....	1				
39	07.0740.0169	Rivet.....	4				

104.1 604997 Cab Heater



Item	Part No.	Description	Qty.
1	07.0740.0119	HEATER,COMPLETE.....	1
2	07.0740.0120	HOSE,AIR.....	0,75
3	07.0740.0120	HOSE,AIR.....	0,65
4	07.0740.0120	HOSE,AIR.....	1,55
5	07.0740.0120	HOSE,AIR.....	0,33
6	07.0740.0120	HOSE,AIR.....	0,32
7	07.0740.0120	HOSE,AIR.....	0,4
8	07.0740.0121	3-WAY FITTING.....	1
9	07.0740.0122	PIPE,HEATER 0.6X0.9.....	6.0
10	07.0740.0122	PIPE,HEATER 0.6X0.9.....	0,8
11	07.0740.0122	PIPE,HEATER 0.6X0.9.....	5.0
12	07.0740.0123	MEB HOSE CLAMP,19X28.....	4
13	07.0740.0124	SCREW,KN TC 3.5X16 ZN.....	4
14	07.0740.0125	AIR INLET,D76.....	5
15	07.0740.0126	REDUCER,D48.5.....	5
16	07.0740.0127	CLAMP,HOSE,MEB,40-60 H12.....	8
17	07.0740.0128	SCREW,KN TC 4.2X9.5 ZN.....	2
18	07.0740.0129	AIR INLET.....	1
19	07.0740.0006	WASHER 6.4X12.....	1
20	07.0740.0005	STOP NUT.....	1
21	07.0740.0028	HEX HEAD CAP.....	1
22	07.0740.0130	KNOB.....	1
23	07.0740.0219	NAME PLATE.....	1
24	07.0740.0118	SCREW.....	2
25	07.0740.0016	WASHER 6.5X18.....	2
26	07.0740.0132	BRACKET,SUPPORT.....	1
27	07.0740.0012	WASHER.....	2
28	07.0740.0071	SCREW.....	2
29	07.0740.0133	GROMMET,RUBBER D31.....	2
30	07.0740.0218	WATER TAP,D16 C/POMELLO.....	1
31	04.0600.0196	ADAPTER,REDUCTION,HOSE.....	1
32	04.0600.0197	Pipe Fitting.....	2
33	04.0227.0068	CLAMP,22/32.....	2
34	04.0600.0195	Pipe Fitting.....	2


105.1 605009 Overload Warning System



105.1 605009 Overload Warning System

Item	Part No.	Description	Qty.
1	56.0016.0021	Display.....	1
2	09.0802.0017	LOAD CELL.....	1
3	01.0001.0357	SCREW,TE,M10X35 UNI 8.8 ZN.....	2
4	01.0031.0056	WASHER,D10 UNI 6592 ZN.....	2
5	55.0602.0144	Wiring Harness.....	1
6	51.0902.3400	Guard.....	1
7	01.0001.0604	SCREW.....	2
8	01.4032.0006	WASHER,SPRING,D14 ZN.....	2
9	01.0001.0156	SCREW,TE,M6X20 UNI 8.8 ZN.....	2
10	01.4032.0002	WASHER,SPRING,D6 ZN.....	2


106.1 605010 Instruments and Lights Panel



106.1 605010 Instruments and Lights Panel

Item	Part No.	Description	Qty.
1	56.0017.0003	Switch.....	1
2	07.0703.0434	Glass.....	1
3	07.0703.0431	SWITCH.....	1
4	07.0703.0432	Glass.....	1
5	07.0703.0435	SWITCH.....	1
6	07.0703.0010	PILOT LIGHT/GLASS.....	1
7	07.0703.0423	COVER,DASH.....	1
8	07.0703.0032	PILOT LIGHT.....	1
9	07.0703.0572	SWITCH.....	1
10	07.0703.0029	IGNITION SWITCH W/TWO KEYS.....	1
11	07.0703.0125	KEY ONLY, SWITCH/IGNITION.....	1
12	07.0703.0614	Control Panel.....	1
13	07.0703.0494	SWITCH.....	1
14	07.0703.0425	GAUGE / OIL PRESSURE.....	1
15	07.0703.0440	Glass.....	1
16	07.0703.0430	SWITCH.....	1
17	07.0703.0007	Glass.....	1
18	07.0703.0429	SWITCH,STEERING MODE.....	1
19	638226	SWITCH,SELECTOR,3 POSITION.....	1
20	07.0703.0576	Dash Board.....	1


201.1 604980 Rear Frame Unit



201.1 604980 Rear Frame Unit

Item	Part No.	Description	Qty.
1	51.1000.3400	Last.....	1
2	01.4006.0011	SCREW.....	2
3	01.0001.0037	Stop Nut.....	2
4	01.4001.0058	Screw.....	4
5	01.0023.0055	NUT,STOP,M10 UNI 7473 6S ZN....	2
6	01.4032.0009	SPRING WASHER.....	4
7	01.0031.0061	WASHER,D20 UNI 6592 ZN.....	4
8	51.0800.2700	Hook.....	1
9	54.0004.0000	Pin.....	1
10	01.0001.0703	SCREW,TE,M16X35.....	2
11	01.4032.0007	WASHER,SPRING,D16 ZN.....	2
12	51.0809.5700	Limit Switch.....	1
13	09.0803.0026	SPRING SPLIT PIN,WIRE,D4.....	1
14	51.0902.5400	Lock.....	1
15	09.0803.0360	LATCH..... <i>Latch</i>	1
16	51.0808.9500	Support.....	1
17	09.4670.0001	ISOLATOR,VIBRATION.....	2
18	51.0804.8700	Support.....	1
19	51.0808.9400	Support.....	1
20	09.0803.0087	Fork.....	2
21	01.0031.0059	WASHER,D16 UNI 6592 ZN.....	2
22	01.0001.0306	SCREW,TE M10X60 UNI 8.8 ZN....	2
23	01.0031.0301	WASHER,D10 UNI 6593 ZN.....	4
24	09.0803.0395	Hinge.....	2
25	09.0803.0419	Key.....	1


202.1 604981 Hydraulic System - Axle Levelling



202.1 604981 Hydraulic System - Axle Levelling

Item	Part No.	Description	Qty.
1	04.4236.0055	Control Valve.....	1
2	07.0741.0001	Valve.....	1
3	07.0741.0000	Solenoid.....	6
4	01.4032.0003	WASHER,SPRING,D8 ZN.....	6
5	01.0031.0055	WASHER,D8 UNI 6592 ZN.....	2
6	07.0741.0015	Joint Kit.....	1
7	01.0001.0254	Screw TE M8 X 20 UNI 5739 8.8 ZN.....	2
8	04.0607.0145	Pipe Fitting.....	2
9	04.0605.0309	Flexible Hose.....	1
10	04.0605.0351	HOSE,FLEXIBLE,R2X2 1/2LG.1800.....	1
11	07.0741.0033	Washer.....	1
12	07.0741.0032	Plug.....	1
13	04.4210.0006	PRESSURE TUBE.....	1
14	04.0607.0114	FITTING,3/8 BSP X 9/168 ORFS.....	2
15	04.0605.0554	Flexible Hose.....	2
16	04.0607.0167	FITTING,1/2 BSP X 9/16 ORFS.....	2
17	01.0003.0208	SCREW,TCEI,M8X40 UNI 8.8ZN.....	4
18	01.4001.0026	SCREW,TE,M6X10 UNI 8.8 ZN.....	2
19	04.4239.0007	HOLDING VALVE / SWAY CYLINDER.....	1
20	53.0600.1200	Swaying Cylinder.....	1
21	02.0117.0101	GREASE ZERK,1/8".....	2
22	07.0721.0101	Bushing.....	2
23	07.4529.0108	Joint Kit.....	1
24	51.0902.3800	Guard.....	1
25	01.4032.0002	WASHER,SPRING,D6 ZN.....	2
26	07.0741.0031	Bracket.....	2


203.1 604982 Hydraulic System - Axle Locking



203.1 604982 Hydraulic System - Axle Locking

Item	Part No.	Description	Qty.
1	53.0700.0300	Cylinder.....	1
2	07.4529.0093	GASKET KIT.....	1
3	628924	Bushing.....	2
4	02.0117.0101	GREASE ZERK,1/8".....	2
5	03.0000.0008	Ball Joint.....	1
6	04.0607.0114	FITTING,3/8 BSP X 9/168 ORFS.....	1
7	04.0605.0543	Flexible Hose.....	1
8	01.4006.0001	SCREW,TSPEI,M6X16 UNI 10.9 ZN.....	2
9	51.0901.6700	COVER,VALVE PROTECTION.....	1
10	04.4240.0024	VALVE,CB (53.0700.0303).....	2
11	04.4240.0025	COIL (53.0700.0303).....	2
12	04.0600.0092	SCREW,BLEEDER M8X1.25.....	1
13	09.0803.0012	SPRING WASHER,D6.....	2


204.1 604983 Hydraulic System - Stabilizer



204.1 604983 Hydraulic System - Stabilizer

Item	Part No.	Description	Qty.
1	51.0500.1200	Stabilizer.....	2
2	51.0500.1300	End..... Base	2
3	54.0000.0096	Pin.....	4
4	01.0001.0308	SCREW,TE,M10X70 UNI 8.8 ZN....	2
5	54.0000.0097	Pin.....	2
6	54.0000.0098	Pin.....	2
7	09.0801.0000	BUSHING/EAR-RING.....	16
8	53.0800.1400	Cylinder.....	1
9	07.4529.0106	SEAL KIT.....	2
10	04.0214.0035	DRILLED SCREW.....	4
11	04.4239.0007	HOLDING VALVE / SWAY CYLINDER.....	2
12	01.0023.0055	NUT,STOP,M10 UNI 7473 6S ZN....	2
13	04.0607.0117	FITTING,3/8 BSP X 11/16 ORFS....	4
14	06.0442.0103	WASHER,BRASS.....	8
15	04.0605.0555	Flexible Hose.....	4
16	02.0117.0101	GREASE ZERK,1/8".....	4
17	53.0800.1500	Cylinder.....	1


205.1 605012 Frame - Left Side



205.1 605012 Frame - Left Side

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	51.0110.9000	Basic Frame.....	1	41	01.0031.0059	WASHER,D16 UNI 6592 ZN.....	4
2	09.0803.0178	MUD-GUARD RH.....	1	42	54.0000.0157	Pin.....	1
3	51.0805.1600	Rear Support.....	1	43	54.0000.0155	Pin.....	1
4	51.0809.3400	Front Support.....	1	44	51.0806.7400	Right Attachment.....	1
5	09.0803.0408	Left Mud-Guard.....	1	45	51.0800.0400	Plate.....	1
6	01.0001.0304	SCREW,TE,M10X50 UNI 8.8 ZN....	2	46	01.4001.0000	SCREW,8.8HCM20-2.5X240Z PT....	4
7	09.4661.0014	TANK CAP.....	1	47	01.0031.0062	WASHER.....	8
8	51.0808.9000	Ladder.....	1	48	01.4006.0011	SCREW.....	4
9	51.0600.4500	Diesel Oil Tank.....	1				
10	51.0902.3100	Guard.....	1				
11	56.0013.0001	Fuel Gauge.....	1				
12	09.0803.0352	SPRING CLIP,M8.....	6				
13	01.0001.0564	SCREW,TE,M14X130 UNI 8.8 ZN...1					
14	01.0023.0057	NUT,STOP,M14 UNI 7473 6S ZN....	5				
15	54.0003.0033	Pin.....	1				
16	01.0023.0060	NUT,STOP,M20 UNI 7473 6S ZN....	8				
17	01.0031.0061	WASHER,D20 UNI 6592 ZN.....	8				
18	01.4001.0001	SCREW.....	8				
19	01.4001.0078	SCREW,FL,TE,M8X20 8.8 ZN.....	6				
20	01.0001.0657	SCREW.....	4				
21	01.4023.0000	NUT,STOP,M22 UNI 7473 6S ZN....	4				
22	01.0001.0017	Screw.....	2				
23	01.0031.0301	WASHER,D10 UNI 6593 ZN.....	2				
24	01.0023.0055	NUT,STOP,M10 UNI 7473 6S ZN.....	10				
25	06.0442.0103	WASHER,BRASS.....	1				
26	04.0220.0055	PLUG,1/2 BSP.....	1				
27	01.4001.0110	Screw.....	2				
28	09.0803.0012	SPRING WASHER,D6.....	6				
29	01.0031.0058	WASHER,D14 UNI 6592 ZN.....	4				
30	01.0031.0054	WASHER,D6 UNI 6592 ZN.....	6				
31	01.0023.0053	NUT,STOP,M6 UNI 7473 6S ZN....	6				
32	01.4031.0003	WASHER,D12 UNI 6593 ZN.....	2				
33	01.0031.0056	WASHER,D10 UNI 6592 ZN.....	4				
34	01.0001.1493	SCREW,TE,M14X45 UNI 8.8 ZN....	4				
36	01.0001.0356	SCREW,TE,M10X30 UNI 8.8 ZN....	8				
37	09.4670.0006	INSULATOR.....	4				
38	01.0001.0314	SCREW.....	2				
39	51.0902.3200	Casing.....	1				
40	54.0100.0020	Protection.....	1				


206.1 605013 Frame - Right Side (to serial number 16401)



206.1 605013 Frame - Right Side (to serial number 16401)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	51.0805.1600	Rear Support.....	1	38	01.0001.0039	Stop Nut.....	7
2	09.0803.0177	MUD-GUARD RH.....	1	39	01.0001.0355	SCREW,TE,M10X25 UNI 8.8 ZN....	2
3	51.0809.3100	Front Support.....	1	40	01.0001.0306	SCREW,TE M10X60 UNI 8.8 ZN....	8
4	09.0803.0407	Right Mud-Guard.....	1	41	09.0610.0972	Cylinder.....	2
5	01.4001.0110	Screw.....	2	42	01.4032.0004	WASHER,SPRING,D10 ZN.....	2
6	09.0803.0012	SPRING WASHER,D6.....	6	43	09.4610.0002	DRIVING MIRROR-REAR VIEW....	1
7	01.0023.0053	NUT,STOP,M6 UNI 7473 6S ZN....	6	44	51.0808.3000	SUPPORT.....	1
8	01.0031.0301	WASHER,D10 UNI 6593 ZN.....	18	45	01.4006.0011	SCREW.....	4
9	01.0001.0466	Screw TE M8 X 50 UNI 5739 8.8 ZN.....	6	46	01.0031.0054	WASHER,D6 UNI 6592 ZN.....	6
10	01.0001.1493	SCREW,TE,M14X45 UNI 8.8 ZN....	4				
11	01.0031.0058	WASHER,D14 UNI 6592 ZN.....	4				
12	01.0023.0057	NUT,STOP,M14 UNI 7473 6S ZN....	4				
13	51.0902.4400	Guard.....	1				
14	54.0000.0155	Pin.....	1				
15	55.1100.6800	Guard.....	1				
16	51.0808.5100	Connection.....	1				
17	54.0000.0157	Pin.....	1				
18	07.0740.0050	HANDLE.....	1				
19	07.0740.0192	LOCK,ENGINE COVER.....	1				
20	01.0001.1465	Screw TE M8 X 40 UNI 5739 8.8 ZN.....	6				
21	01.0031.0055	WASHER,D8 UNI 6592 ZN.....	4				
22	01.4023.0000	NUT,STOP,M22 UNI 7473 6S ZN....	4				
23	01.0023.0054	NUT,M8 UNI 7473 6S ZN.....	12				
24	51.0902.4500	Grate.....	1				
25	09.0803.0352	SPRING CLIP,M8.....	6				
26	01.0023.0055	NUT,STOP,M10 UNI 7473 6S ZN....	9				
27	01.0001.0257	Screw TE M8 X 30 UNI 5739 8.8 ZN.....	2				
28	01.0001.0078	Screw.....	2				
29	01.4001.0078	SCREW,FL,TE,M8X20 8.8 ZN.....	6				
30	07.0740.0100	Pin.....	1				
31	51.0808.3100	Support.....	1				
32	51.0800.0400	Plate.....	1				
33	51.0808.6900	Support Casing.....	1				
34	09.0803.0368	Hinge.....	1				
35	01.4001.0000	SCREW,8.8HCM20-2.5X240Z PT....	4				
36	51.0810.5300	Bracket.....	1				
37	01.0031.0299	WASHER,D8 UNI 6593 ZN.....	6				




207.1 605013 Frame - Right Side (from serial number 16402)



207.1 605013 Frame - Right Side (from serial number 16402)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	51.0805.1500	Rear Support.....	1	38	01.0001.0039	Stop Nut.....	7
2	09.0803.0177	MUD-GUARD RH.....	1	39	01.0001.0355	SCREW,TE,M10X25 UNI 8.8 ZN....	2
3	51.0809.3100	Front Support.....	1	40	01.0001.0306	SCREW,TE M10X60 UNI 8.8 ZN....	8
4	09.0803.0407	Right Mud-Guard.....	1	41	09.0610.0972	Cylinder.....	2
5	01.4001.0110	Screw.....	2	42	01.4032.0004	WASHER,SPRING,D10 ZN.....	2
6	09.0803.0012	SPRING WASHER,D6.....	6	43	09.4610.0002	DRIVING MIRROR-REAR VIEW....	1
7	01.0023.0053	NUT,STOP,M6 UNI 7473 6S ZN....	6	44	51.0808.3000	SUPPORT.....	1
8	01.0031.0301	WASHER,D10 UNI 6593 ZN.....	18	45	51.0810.5500	Bracket.....	1
9	01.0001.0466	Screw TE M8 X 50 UNI 5739 8.8 ZN.....	6	46	01.4006.0011	SCREW.....	4
10	01.0001.1493	SCREW,TE,M14X45 UNI 8.8 ZN....	4	47	01.0031.0054	WASHER,D6 UNI 6592 ZN.....	6
11	01.0031.0058	WASHER,D14 UNI 6592 ZN.....	4				
12	01.0023.0057	NUT,STOP,M14 UNI 7473 6S ZN....	4				
13	51.0902.4400	Guard.....	1				
14	54.0000.0155	Pin.....	1				
15	55.1100.6800	Guard.....	1				
16	51.0808.5100	Connection.....	1				
17	54.0000.0157	Pin.....	1				
18	07.0740.0050	HANDLE.....	1				
19	07.0740.0192	LOCK,ENGINE COVER.....	1				
20	01.0001.1465	Screw TE M8 X 40 UNI 5739 8.8 ZN.....	6				
21	01.0031.0055	WASHER,D8 UNI 6592 ZN.....	4				
22	01.4023.0000	NUT,STOP,M22 UNI 7473 6S ZN....	4				
23	01.0023.0054	NUT,M8 UNI 7473 6S ZN.....	12				
24	51.0902.4500	Grate.....	1				
25	09.0803.0352	SPRING CLIP,M8.....	6				
26	01.0023.0055	NUT,STOP,M10 UNI 7473 6S ZN....	9				
27	01.0001.0257	Screw TE M8 X 30 UNI 5739 8.8 ZN.....	2				
28	01.0001.0078	Screw.....	2				
29	01.4001.0078	SCREW,FL,TE,M8X20 8.8 ZN.....	6				
30	07.0740.0100	Pin.....	1				
31	51.0808.3100	Support.....	1				
32	51.0800.0400	Plate.....	1				
33	51.0808.6900	Support Casing.....	1				
34	09.0803.0368	Hinge.....	1				
35	01.4001.0000	SCREW,8.8HCM20-2.5X240Z PT....	4				
36	51.0810.5300	Bracket.....	1				
37	01.0031.0299	WASHER,D8 UNI 6593 ZN.....	6				


301.1 605003 Hydraulic System - Gearbox



301.1 605003 Hydraulic System - Gearbox

Item	Part No.	Description	Qty.
1	04.0605.0547	Flexible Hose.....	1
2	04.0605.0545	Flexible Hose.....	1
3		605008 pos.5	
4	04.4240.0053	Solenoid Valve.....	1
5	04.0607.0114	FITTING,3/8 BSP X 9/168 ORFS.....	4
6	04.0605.0546	Flexible Hose.....	2
7	04.0607.0153	FITTING,M14X1.5 X 9/16 ORFS.....	2
8	01.0003.0158	SCREW,TCEI,M6X30 UNI 8.8 ZN....	2
9	07.0728.0007	COIL,SQUARE SOLENOID.....	1
10	07.0728.0006	Joint Kit.....	1
11	04.0607.0115	FITTING,TMF L 9/16 ORFS.....	1
12	04.4240.0055	SOLENOID VALVE.....	1
13	07.4529.0111	VALVE,SOLENOID,DEUTZ TCD4.1.....	1


302.1 605004 Power Steering System



302.1 605004 Power Steering System

Item	Part No.	Description	Qty.
1	09.4636.0014	POWER STEERING DIRECTION....	1
2	07.0740.0136	Steering Column.....	1
3	09.4636.0002	Steering Wheel.....	1
4	07.0728.0007	COIL,SQUARE SOLENOID.....	2
5	04.4240.0052	SOLENOID VALVE.....	1
6	04.0607.0111	FITTING,1/2 BSP X 13/16 ORFS....	3
7	04.0607.0110	FITTING,1/2 BSP X 11/16 ORFS....	2
8	07.4529.0102	Seal.....	1
9	04.0607.0117	FITTING,3/8 BSP X 11/16 ORFS....	4
10	04.0605.0525	Flexible Hose.....	1
11	04.0605.0536	Flexible Hose.....	1
12	04.0605.0309	Flexible Hose.....	1
13	01.0003.0158	SCREW,TCEI,M6X30 UNI 8.8 ZN....	2
14	04.0605.0534	Flexible Hose.....	1
15	04.0607.0137	FITTING 18X1.5 X 11/16 ORFS....	4
16	04.0605.0548	Flexible Hose.....	1
17	04.0605.0549	Flexible Hose.....	1
18	04.0605.0533	Flexible Hose.....	1
19	04.0605.0535	Flexible Hose.....	1
20	04.0605.0540	Flexible Hose.....	1
21	04.0607.0107	FITTING,3/4 BSP X 1-3/16 ORFS....	1
22	04.4238.0053	Pump.....	1
23	04.0607.0174	FITTING,1 BSP X 1-11/16 ORFS....	1
24	627521	JOINT.....	1
25	04.4223.0000	UNION.....	1
26	04.0605.0538	Flexible Hose.....	1
27	07.0722.0053	REAR COVER.....	1
28	01.0003.0255	SCREW.....	3
29	04.0607.0113	FITTING, 1 BSP X 1-3/16-12 ORFS.....	2
30	07.4529.0115	Joint Kit.....	1


303.1 605006 Hydraulic System - Control Valve



303.1 605006 Hydraulic System - Control Valve

Item	Part No.	Description	Qty.
1	04.4236.0060	Control Valve from SN 17125.....	1
1	04.4236.0075	Control Valve to SN 17126.....	1
2	04.0607.0142	FITTING 1" GAS X 1-7/16 ORFS.....	2
3		605004 pos.20	
4		605005 pos.1	
5		605014 pos.17	
6	04.0607.0113	FITTING, 1 BSP X 1-3/16-12 ORFS.....	1
7		604981 pos.9	
8		605004 pos.12	
9		605003 pos.1	
10		605011 pos.21	
11	04.0607.0130	FITTING,1BSP X 1-3/16 ORFS.....	1
12	04.0607.0160	FITTING,TMF L 1-7/16 ORFS.....	1
13	04.0605.0550	Flexible Hose.....	1
14	07.0741.0003	Valve.....	2
15	07.0741.0016	Joint Kit.....	1
16	07.0741.0002	Valve.....	1
17	07.0741.0004	Module (Seal Kit PN:07.0741.0222).....	3
18	07.0741.0005	Module (Seal Kit PN:07.0741.0222).....	1
19	07.0741.0008	Valve.....	1
20	07.0741.0006	Solenoid.....	1
21	04.0607.0121	FITTING,3/4 BSP X 13/16 ORFS.....	3
22	04.0607.0164	Pipe Fitting.....	2
23	04.0605.0557	Flexible Hose.....	1
24	04.0607.0163	NIPPLE.....	1
25	07.0741.0001	Valve.....	1


304.1 605008 Hydraulic System - Transmission



304.1 605008 Hydraulic System - Transmission

Item	Part No.	Description	Qty.
1	04.0605.0527	Flexible Hose.....	1
2	04.0605.0537	Flexible Hose.....	1
3	04.0605.0543	Flexible Hose.....	1
4	04.4238.0043	HYDRAULIC PUMP / HPR50.....	1
5	04.0605.0262	Flexible Hose.....	1
6	07.0701.0180	Joint Kit.....	1
7	07.0701.0203	Joint Kit.....	1
8	07.0701.0204	Seal.....	1
9	04.4235.0023	HYDRAULIC MOTOR.....	1
10	04.4223.0003	FLANGE,HALF D47.....	8
11	06.0401.0219	O-RING.....	4
12	07.0721.0202	Seal.....	1
13	04.0607.0103	FITTING,M12X1.5X9/16 ORFS.....	4
14	04.0605.0182	Flexible Hose.....	1
15	04.0605.0544	Flexible Hose.....	1
16	04.0607.0207	Pipe Fitting.....	2
17	04.0605.0588	Flexible Hose.....	1
18	04.0607.0184	Pipe Fitting.....	1
19	04.4229.0044	Flexible Hose.....	1
20	04.4229.0045	Flexible Hose.....	1
21	04.0607.0188	FITTING,M42X2.0 X 1-11/16 ORFS.....	1
22	04.4210.0003	PRESSURE TUBE.....	1
23	04.0600.0077	NIPPLE.....	1
24	01.0001.0401	SCREW,TE,M12X40 UNI 8.8 ZN...16	
25	01.4032.0005	WASHER,SPRING,D12 ZN.....	16
26	06.0442.0105	WASHER,JC 27,SP2,5.....	2
27	04.4239.0013	VALVE.....	1
28	04.0607.0107	FITTING,3/4 BSP X 1-3/16 ORFS....	1
29	07.0701.0007	SOLENOID (07.0701.0290).....	2
30	04.0600.0159	PIPE FITTING.....	1
31	04.0600.0067	PIPE FITTING-NIPPLE.....	1
32	04.0607.0149	PIPE FITTING.....	1
33	07.0701.0196	Solenoid Valve.....	1
34	04.4210.0004	PRESSURE TUBE.....	1
35	04.4235.0031	Hydraulic Motor.....	1
36	07.0701.0205	SOLENOID.....	1


305.1 605011 Hydraulic System - Service Brake



305.1 605011 Hydraulic System - Service Brake

Item	Part No.	Description	Qty.
1	05.4309.0000	PUMP BRAKE.....	1
2	04.0600.0166	Wheelstud.....	2
3		604981 pos.10	
4	07.0740.0266	Pipe Fitting.....	1
5	01.0031.0054	WASHER,D6 UNI 6592 ZN.....	8
6	06.0442.0055	WASHER,D.14/20X1.5.....	12
7	05.0400.0000	CONDUCT/HOSE.....	4
8	05.0401.0001	EYE CONNECTION/PIPE FITTING.....	6
9	05.0401.0003	DRILLED SCREW.....	10
10	05.0401.0000	CONNECTION/PIPE FITTING.....	2
11	09.0803.0016	Clamp.....	1
12	53.3402.0700	Pipe.....	1
13	01.0023.0054	NUT,M8 UNI 7473 6S ZN.....	2
14	01.0001.1465	Screw TE M8 X 40 UNI 5739 8.8 ZN.....	2
15	07.0740.0264	Pipe Fitting.....	2
16	04.0605.0428	FLEXIBLE HOSE.....	2
17	04.0607.0114	FITTING,3/8 BSP X 9/168 ORFS.....	2
18	53.3402.0800	Pipe.....	1
19	05.4329.0000	ACCUMULATOR,BRAKE.....	2
20	05.0401.0005	PIPE FITTING/WHEEL STUD.....	4
21	04.0605.0542	Flexible Hose.....	1
22	07.0607.0111	Pipe Fitting.....	1
23	04.0605.0541	Flexible Hose.....	1
24	07.0740.0265	Pipe Fitting.....	1
25	07.0730.0036	Plug.....	1
26	07.0730.0037	Washer.....	1
27	01.0003.0155	SCREW.....	1

306.1 605015 Transmission And Wheels



306.1 605015 Transmission And Wheels


Item	Part No.	Description	Qty.
1	09.4632.0061	Rear Steering Axle.....	1
2	09.4632.0062	Rear Steering Axle.....	1
3	09.4635.0042	Cardan Shaft.....	1
4	09.4635.0041	Cardan Shaft.....	1
5	07.0738.0000	U JOINT.....	4
6	09.4627.0017	TIRE 405/70-24 14PR R1.....	4
7	09.4635.0014	KIT,HARWARE,UNIVERSAL JOINTS.....	4
8	09.4629.0000	RIM.....	4
9	09.4633.0014	Gear Box.....	1
10	55.0403.0043	Wheel.....	4
11	09.4627.0016	TIRE 405/70/20 OPTION.....	4
12	09.4633.0020	Gear Box.....	1
13	55.0403.0044	Wheel.....	4
14	09.4629.0003	RIM.....	4

This technical diagram illustrates the assembly of a vehicle's rear suspension and brake components. The main assembly is shown in an exploded view, with various parts labeled with numbers 1 through 29. A large dashed arrow indicates the direction of assembly from the main components towards the rear of the vehicle. An inset at the top left (callout 29) provides a detailed view of the brake master cylinder and its mounting bracket (30), showing the master cylinder (31), pushrod (32), and mounting bracket (33). Another inset at the bottom right (callout 27) shows a close-up of the brake line fitting (28) and its connection to the brake line (27). The main assembly includes the rear suspension arm (1), shock absorber (2), coil spring (3), brake master cylinder (4), brake line (5), brake caliper (6), brake disc (7), brake pads (8, 9, 10, 11, 12, 13, 14, 15, 16), brake line fitting (17), brake line (18), brake line fitting (19), brake line (20), brake line fitting (21), brake line (22), brake line fitting (23), brake line (24), brake line fitting (25), brake line (26), brake line fitting (27), and brake line (28).

307.1 605016 Parking Brake

Item	Part No.	Description	Qty.
1	05.4315.0004	Lever.....	1
2	07.0740.0063	Washer.....	4
3	01.0031.0055	WASHER,D8 UNI 6592 ZN.....	7
4	01.0003.0023	Screw.....	4
5	09.4645.0022	BRAKE/CABLE.....	2
6	07.0740.0267	SENSOR,PROXIMITY.....	1
7	01.0031.0058	WASHER,D14 UNI 6592 ZN.....	2
8	02.0112.0155	COTTER PIN.....	2
9	07.0740.0170	Pin.....	1
10	07.0740.0171	Pulley.....	1
11	01.4001.0010	SCREW, 8.8 HCS 8MM1.25X100Z.....	1
12	07.0740.0172	Support.....	1
13	01.0001.0254	Screw TE M8 X 20 UNI 5739 8.8 ZN.....	1
14	07.0740.0013	Stop Nut.....	2
15	07.0740.0173	Plate.....	1
16	07.0470.0175	Washer.....	2
17	51.0808.7600	Support.....	1
18	54.0001.0041	Pin.....	2
19	02.0117.0053	GREASE NIPPLE.....	2
20	01.0001.0043	Stop Nut.....	2
21	54.0800.0000	Spring.....	2
22	01.4032.0009	SPRING WASHER.....	1
23	01.0001.0902	SCREW.....	1
24	51.0808.0700	Bracket.....	2
25	01.4032.0005	WASHER,SPRING,D12 ZN.....	2
26	01.0001.0604	SCREW.....	2
27	07.0730.0063	Spring.....	1
28	07.0730.0064	Push Button.....	1
29	07.0730.0066	Screw.....	1
30	07.0730.0067	Nut.....	1
31	07.0730.0069	Dowel.....	1
32	07.0730.0068	Pin.....	1
33	07.0730.0065	Pin.....	1


308.1 605017 Front Axle - Differential Case



308.1 605017 Front Axle - Differential Case

Item	Part No.	Description	Qty.
1	632383	SEAL / DIFFERENTIAL.....	3
2	639668	COVER.....	1
3	07.0709.0721	Housing.....	1
4	07.0709.0084	PLUG.....	1
5	639670	PLUG,BREATHER.....	1
7	07.0709.0113	PLUG.....	1
8	07.0709.0371	PLUG,MAGNET.....	1
9	07.0709.0441	SNAP RING.....	1


309.1 605018 Front Axle - Differential Gear



309.1 605018 Front Axle - Differential Gear

Item	Part No.	Description	Qty.
1	639802	NUT.....	1
2	07.0709.0426	Flange.....	1
4	633098	SEAL,DIFFERENTIAL.....	1
5	639650	Screw.....	4
6	639651	Snap Ring.....	4
7	639652	O-RING.....	1
8	630693	Ring Nut.....	1
9	639653	Spacer.....	1
10	639300	SPACER.....	1
10	639301	SPACER.....	1
10	639302	SPACER.....	1
10	639303	SPACER.....	1
11	634499	SPACER.....	1
11	634501	SPACER.....	1
11	639297	SPACER.....	1
11	639298	SPACER.....	1
12	626544	BEARING.....	2
13	07.0709.0216	Bevel Gear Set.....	1
14	639657	Screw.....	2
15	633099	Bearing.....	2
17	641090	SATELITE.....	2
18	07.0709.0724	Satellite.....	4
19	07.0709.0722	Pin.....	4
20	639661	Snap Ring.....	4
21	639662	WASHER,FRICTION.....	4
23	07.0709.0057	SCREW,RING GEAR.....	12
24	639664	Ring Nut.....	2
27	641089	DIFFERENTIAL CASE.....	1
28	07.0709.0374	Compl. Front Differential Gear.....	1
29	07.0709.0059	CLUTCH DISC.....	2


310.1 605019 Front Axle - Steering Axle



310.1 605019 Front Axle - Steering Axle

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	633174	NUT.....	2	44	639646	Snap Ring.....	2
2	640718	Screw.....	2	45	07.0709.0104	SCREW.....	4
3	640214	AXLE CASE.....	2	46	634546	NUT.....	4
4	07.0709.0377	Screw.....	32	49	639647	PLATE,LOCKING.....	2
6	640720	BUSHING.....	2	50	07.0709.0441	SNAP RING.....	2
7	630846	SEAL.....	2	52	07.0709.0068	Spacer.....	4
8	633202	BEARING.....	2	53	07.0709.0119	STUD,DRIVE AXLE.....	8
9	633203	SNAP RING.....	2	54	07.0709.0070	NUT.....	8
10	640216	O-RING.....	2	56	07.0709.0071	WASHER.....	8
11	639624	Joint.....	2	57	640728	THICKNESS.....	2
12	639289	BUSHING.....	2	57	640729	THICKNESS.....	1
13	639625	BUSHING.....	2	57	640730	THICKNESS.....	1
14	640909	Screw.....	12	58	07.0709.0072	GREASE NIPPLE.....	2
15	07.0709.0060	Cover.....	2	60	07.0709.0726	Support.....	2
16	638548	PLUG.....	4	65	07.0709.0219	JOINT BOX.....	1
17	633176	GREASE ZERK.....	2	66	07.0709.0121	Housing.....	1
18	07.0709.0061	PIN.....	2	72	07.0709.0365	SCREW,STEERING ADJUST.....	4
19	640908	PIN.....	2	76	07.0709.0727	Support.....	2
20	639630	SEAL.....	2				
21	639631	JOINT,ARTICULATED.....	2				
22	07.0709.0101	HOUSING.....	1				
23	07.0709.0215	SEAL.....	2				
25	07.0709.0371	PLUG,MAGNET.....	2				
26	07.0709.0113	PLUG.....	4				
27	07.0709.0102	HOUSING.....	1				
28	07.0709.0205	SEAL.....	2				
29	639637	Bearing.....	4				
30	07.0709.0117	WHEEL STUD.....	16				
31	07.0709.0064	HUB.....	2				
32	632383	SEAL / DIFFERENTIAL.....	2				
33	639639	RING GEAR.....	2				
34	639640	SUPPORT,RING GEAR.....	2				
35	639641	SNAP RING.....	8				
36	639642	PINION,DIFFERENTIAL.....	8				
37	639643	Bearing.....	8				
38	07.0709.0118	NUT.....	16				
40	07.0709.0065	SCREW.....	4				
41	07.0709.0724	Support.....	2				
42	639645	Stud.....	16				
43	637567	Nut.....	16				





311.1 605020 Front Axle - Brake



311.1 605020 Front Axle - Brake

Item	Part No.	Description	Qty.
1	639674	Brake Disc.....	6
2	639675	Screw.....	6
3	07.0709.0106	SPRING.....	6
4	07.0709.0424	Piston.....	2
5	639676	Spring.....	6
6	639679	SEAL/BACK-UP RING.....	2
7	639695	O-RING.....	2
8	639681	SEAL/BACK-UP RING.....	2
9	639682	SEAL.....	2
10	639683	BRAKE DISC,INTERMEDIATE.....	8
11	630328	BLEEDER VALVE, LONG.....	2
12	638548	PLUG.....	2
13	633069	DOWEL.....	2
14	07.0709.0074	Piston.....	2


312.1 605021 Front Axle - Steering Cylinder



312.1 605021 Front Axle - Steering Cylinder

Item	Part No.	Description	Qty.
1	639671	Screw.....	4
2	640270	GASKET KIT.....	2
3	641109	SHAFT,TIE ROD.....	1
4	07.0709.0001	Cylinder.....	1
5	641108	SHAFT,TIE ROD.....	1


313.1 605022 Front Axle - Support



313.1 605022 Front Axle - Support

Item	Part No.	Description	Qty.
1	07.0709.0218	BUSHING.....	4
2	637850	Bushing.....	2
3	07.0709.0386	Support.....	2
4	633176	GREASE ZERK.....	2
5	638548	PLUG.....	2
6	09.4632.0002	Support.....	2


314.1 605023 Rear Axle - Differential Case



314.1 605023 Rear Axle - Differential Case

Item	Part No.	Description	Qty.
1	632383	SEAL / DIFFERENTIAL.....	3
2	639668	COVER.....	1
3	07.0709.0721	Housing.....	1
4	07.0709.0084	PLUG.....	1
5	639670	PLUG,BREATHER.....	1
7	07.0709.0113	PLUG.....	1
8	07.0709.0371	PLUG,MAGNET.....	1
9	07.0709.0441	SNAP RING.....	1


315.1 605024 Rear Axle - Differential Gear



315.1 605024 Rear Axle - Differential Gear

Item	Part No.	Description	Qty.
1	639652	O-RING.....	1
2	639300	SPACER.....	1
2	639301	SPACER.....	1
2	639302	SPACER.....	1
2	639303	SPACER.....	1
3	07.0709.0372	Bevel Gear Set.....	1
4	633099	Bearing.....	2
5	639664	Ring Nut.....	2
6	639650	Screw.....	4
7	639657	Screw.....	2
8	07.0709.0057	SCREW,RING GEAR.....	12
9	639684	WASHER.....	2
10	639685	GEAR,DIFFERENTIAL SIDE.....	2
11	07.0709.0722	Pin.....	4
12	639661	Snap Ring.....	4
13	639662	WASHER,FRICTION.....	4
14	07.0709.0723	Satellite.....	4
15	639686	CASE,DIFFERENTIAL.....	1
16	626544	BEARING.....	2
17	634499	SPACER.....	1
17	634501	SPACER.....	1
17	639297	SPACER.....	1
17	639298	SPACER.....	1
18	639653	Spacer.....	1
19	630693	Ring Nut.....	1
20	633098	SEAL,DIFFERENTIAL.....	1
22	07.0709.0426	Flange.....	1
23	639802	NUT.....	1
24	639651	Snap Ring.....	4
25	640717	COMPL. REAR DIFFERENTIAL GEAR.....	1

316.1 605025 Rear Axle - Steering Axle




*65: Position Kit = 22+12

*66: Position Kit = 27+12

316.1 605025 Rear Axle - Steering Axle

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	633174	NUT.....	2	44	639646	Snap Ring.....	2
2	640718	Screw.....	2	45	07.0709.0104	SCREW.....	4
3	640719	Arm.....	2	46	634546	NUT.....	4
4	07.0709.0377	Screw.....	32	49	639647	PLATE,LOCKING.....	2
6	640720	BUSHING.....	2	50	07.0709.0441	SNAP RING.....	2
7	630846	SEAL.....	2	53	07.0709.0119	STUD,DRIVE AXLE.....	8
8	633202	BEARING.....	2	54	07.0709.0070	NUT.....	8
9	633203	SNAP RING.....	2	56	07.0709.0071	WASHER.....	8
10	640216	O-RING.....	2	57	640728	THICKNESS.....	1
11	639624	Joint.....	2	57	640729	THICKNESS.....	1
12	639289	BUSHING.....	2	57	640730	THICKNESS.....	1
13	07.0709.0124	BUSHING.....	2	58	07.0709.0072	GREASE NIPPLE.....	2
14	640909	Screw.....	16	60	07.0709.0726	Support.....	2
15	07.0709.0060	Cover.....	2	65	07.0709.0219	JOINT BOX.....	1
16	638548	PLUG.....	4	66	07.0709.0220	JOINT BOX.....	1
17	633176	GREASE ZERK.....	2	72	07.0709.0365	SCREW,STEERING ADJUST.....	4
18	07.0709.0061	PIN.....	2	76	07.0709.0727	Support.....	2
19	640908	PIN.....	2				
20	639630	SEAL.....	2				
21	639631	JOINT,ARTICULATED.....	2				
22	07.0709.0101	HOUSING.....	1				
23	07.0709.0215	SEAL.....	2				
25	07.0709.0371	PLUG,MAGNET.....	2				
26	07.0709.0113	PLUG.....	4				
27	07.0709.0102	HOUSING.....	1				
28	07.0709.0205	SEAL.....	2				
29	639637	Bearing.....	4				
30	07.0709.0117	WHEEL STUD.....	16				
31	07.0709.0064	HUB.....	2				
32	632383	SEAL / DIFFERENTIAL.....	2				
33	639639	RING GEAR.....	2				
34	639640	SUPPORT,RING GEAR.....	2				
35	639641	SNAP RING.....	8				
36	639642	PINION,DIFFERENTIAL.....	8				
37	639643	Bearing.....	8				
38	07.0709.0118	NUT.....	16				
40	07.0709.0065	SCREW.....	4				
41	07.0709.0724	Support.....	2				
42	639645	Stud.....	16				
43	637567	Nut.....	16				


317.1 605026 Rear Axle - Brake



317.1 605026 Rear Axle - Brake

Item	Part No.	Description	Qty.
1	639689	LEVER.....	1
2	630328	BLEEDER VALVE, LONG.....	2
3	638548	PLUG.....	2
4	901777	Screw.....	6
5	637574	SEAL.....	2
6	07.0709.0122	BUSHIN 4 HURTH.....	2
7	639691	GRUBSCREW.....	2
8	636440	Nut.....	2
10	639692	Lever.....	2
11	633517	Spacer.....	2
12	07.0709.0430	Screw.....	2
13	639683	BRAKE DISC, INTERMEDIATE.....	10
14	639693	Screw.....	6
15	07.0709.0106	SPRING.....	3
16	640731	Piston.....	1
17	639679	SEAL/BACK-UP RING.....	1
18	639695	O-RING.....	1
19	633069	DOWEL.....	2
20	639696	Lever.....	1
21	639676	Spring.....	6
22	637621	THREADED ELEMENT.....	2
23	639681	SEAL/BACK-UP RING.....	1
24	639682	SEAL.....	1
25	639674	Brake Disc.....	8
26	640732	Piston.....	1
36	07.0709.0081	Piston.....	1
37	07.0709.0082	Piston.....	1
38	07.0709.0123	SEAL HURTH.....	2


318.1 605027 Rear Axle - Steering Cylinder



318.1 605027 Rear Axle - Steering Cylinder

Item	Part No.	Description	Qty.
1	639671	Screw.....	4
2	640270	GASKET KIT.....	1
3	641109	SHAFT,TIE ROD.....	1
4	07.0709.0001	Cylinder.....	1
5	641108	SHAFT,TIE ROD.....	1


319.1 605028 Rear Axle - Support



319.1 605028 Rear Axle - Support

Item	Part No.	Description	Qty.
1	07.0709.0218	BUSHING.....	4
2	637850	Bushing.....	2
3	07.0709.0386	Support.....	2
4	633176	GREASE ZERK.....	2
5	638548	PLUG.....	2
6	09.4632.0002	Support.....	2


320.1 605029 Reduction Gear



320.1 605029 Reduction Gear

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	639778	SCREW.....	2	39	07.0709.0079	Flange.....	2
2	07.0709.0076	PLUG/STOPPER.....	1	40	633161	O-RING.....	2
3	639780	Cylinder.....	1	41	639802	NUT.....	2
4	639781	O-RING.....	1	42	639803	SCREW.....	1
5	633202	BEARING.....	1	43	639804	SEAL.....	1
6	633208	PLUG.....	1	44	639807	Seal.....	1
7	07.0709.0077	Cover.....	1	45	639808	PLUG.....	2
8	639783	COVER.....	1	46	639809	ROD.....	1
9	639784	Bearing.....	1	47	639810	SEAL.....	1
10	637574	SEAL.....	1	48	639811	SLIDING GUIDE.....	2
11	639785	DOWEL.....	2	49	639812	Selector Fork.....	1
12	07.0709.0078	Housing.....	1	50	639813	Selector Shaft.....	1
13	639787	Screw.....	12	51	639814	PLATE,COVER.....	1
15	639689	LEVER.....	1	52	639815	Piston.....	1
16	639790	SEAL.....	1	53	639816	O-RING.....	1
17	639791	Spacer.....	2	55	56.0012.0020	Proximity Switch.....	1
18	639792	SCREW.....	2	57	07.0709.0357	SPHERE.....	1
19	07.0709.0719	Washer.....	2	58	633109	Spring Washer.....	12
20	639793	Sheet.....	1	59	639819	SHAFT.....	1
21	639794	Bearing.....	4	60	639820	Gear.....	1
22	639795	Shaft.....	1	61	639821	Gear.....	1
23	639796	SLEEVE.....	1				
24	639797	SPLIT PIN.....	2				
25	07.0709.0720	GUARD.....	1				
26	628275	PLUG,MAGNET.....	1				
27	637577	O-RING.....	1				
28	637584	WASHER.....	1				
29	637582	BOOT.....	1				
31	635594	SCREW.....	1				
32	635596	SPRING.....	1				
33	07.0709.0327	BALL.....	1				
34	639799	O-RING.....	1				
35	629733	SHIM 0.10MM.....	1				
35	629735	SHIM 0.30MM.....	1				
35	639327	SHIM 0.40MM.....	1				
35	639328	SHIM 0.15MM.....	1				
35	639329	SHIM 0.20MM.....	1				
36	07.0709.0443	BEARING.....	2				
37	637536	SEAL RING.....	2				
38	639800	Cover.....	1				


401.1 604984 Hydraulic System - Lifting



401.1 604984 Hydraulic System - Lifting


Item	Part No.	Description	Qty.
1	01.0001.0505	SCREW,TE,M12X25 UNI 8.8 ZN.....1	
2	04.0607.0121	FITTING,3/4 BSP X 13/16 ORFS.....2	
3	54.0000.0099	Pin.....1	
4	01.0117.0101	Grease Nipple.....2	
5	04.0605.0559	Flexible Hose.....2	
6	04.0607.0111	FITTING,1/2 BSP X 13/16 ORFS.....2	
7	01.0003.0210	SCREW,TCEI,M8X50 UNI 8.8ZN.....4	
8	04.4239.0005	LOAD HOLDING VALVE / LIFT.....1	
9	53.0000.3816	Cylinder.....1	
10	07.0721.0119	Seal Kit, Please See the Note.....1 <i>Use For "Rod Side Labelled Cylinder Model"</i>	
10	07.4529.0110	Seal Kit, Please See the Note.....1 <i>Use For "No Labelled Cylinder Model"</i>	
11	09.0801.0001	Bushing.....2	
12	54.0000.0126	Pin.....1	
13	07.4529.0072	SEAL.....2	
14	01.4032.0005	WASHER,SPRING,D12 ZN.....1	
15	04.0607.0173	Pipe Fitting.....1	
16	05.4329.0021	Accumulator.....1	
17	01.0023.0054	NUT,M8 UNI 7473 6S ZN.....1	
18	01.0001.1465	Screw TE M8 X 40 UNI 5739 8.8 ZN.....1	
19	04.0605.0261	Flexible Hose.....1	
20	01.0001.0413	SCREW,TE,M12X120 UNI 8.8 ZN...1	
21	01.0023.0056	NUT,STOP,M12 UNI 7473 6S ZN.....1	
22	04.0607.0122	FITTING,TMF 13/16 ORFS.....1	
23	09.0801.0025	Bushing.....2	

402.1 604985 Arm




Item	Part No.	Description	Qty.
1	51.0200.8400	1st Telescopic Element.....	1
2	54.0702.0000	Sliding Guide.....	4
3	54.0200.0001	Bushing.....	8
4	54.0702.0001	Sliding Guide.....	4
5	51.0801.9000	Support.....	2
6	01.4032.0004	WASHER,SPRING,D10 ZN.....	16
7	01.0001.0357	SCREW,TE,M10X35 UNI 8.8 ZN...	12
8	01.0001.0304	SCREW,TE,M10X50 UNI 8.8 ZN....	4
9	54.0201.0003	Bushing.....	2
10	52.0900.0200	Spacer.....	2
11	54.0201.0004	Bushing.....	2
12	02.0117.0101	GREASE ZERK,1/8".....	1
13	54.0200.0000	BUSHING.....	8
14	51.0804.9000	Thickness.....	4
15	51.0809.4000	Thickness.....	4

403.1 604986 Arm




Item	Part No.	Description	Qty.
1	51.0200.8500	2nd Telescopic Element.....	1
2	54.0702.0000	Sliding Guide.....	8
3	54.0200.0001	Bushing.....	20
4	54.0702.0001	Sliding Guide.....	8
5	51.0801.9100	Support.....	2
6	01.4032.0004	WASHER,SPRING,D10 ZN.....	16
7	01.0001.0356	SCREW,TE,M10X30 UNI 8.8 ZN...	12
8	01.4006.0005	SCREW/BOLT / WEAR PAD.....	4
9	51.0200.8600	3rd Telescopic Element.....	1
10	54.0702.0003	Sliding Guide.....	2
11	54.0200.0000	BUSHING.....	16
12	01.0001.0304	SCREW,TE,M10X50 UNI 8.8 ZN....	2
13	01.0001.0355	SCREW,TE,M10X25 UNI 8.8 ZN...	10
14	01.0001.0353	SCREW/BOLT / BOOM WEAR PAD.....	8
15	54.0702.0004	Sliding Guide.....	2
16	51.0804.9000	Thickness.....	8
17	51.0809.4000	Thickness.....	8
18	51.0809.4600	Thickness.....	2
19	51.0809.3900	Thickness.....	2

404.1 604988 Forks



Item	Part No.	Description	Qty.
1	51.1300.5300	Plate.....	1
2	51.1301.2500	Fork.....	2
3	54.0000.0083	Pin.....	1
4	54.0100.0056	Washer.....	1
5	01.0001.0409	SCREW,TE,M12X80 UNI 8.8 ZN.....	1
6	01.0023.0056	NUT,STOP,M12 UNI 7473 6S ZN.....	1
7	09.0803.0055	Chain.....	0,45
8	09.0803.0026	SPRING SPLIT PIN,WIRE,D4.....	2
9	07.0726.0051	Pin.....	2
10	01.4041.0005	SECURITY DOWEL 5519.....	2
11	02.4115.0000	RIVETTO A STRAPPO.....	2
12	09.4616.0109	Name Plate.....	1


405.1 604989 Hydraulic System - Tilting



405.1 604989 Hydraulic System - Tilting


Item	Part No.	Description	Qty.
1	04.0607.0141	FITTING,90,1/2GAS X 13/16 M ORFS.....	1
2	09.0803.0043	CLAMP,D16.....	8
3	04.0605.0505	FLEXIBLE HOSE.....	1
4	53.3402.0600	Pipe.....	1
5	01.0003.0157	SCREW, M6X25 SHCS Z.....	8
6	06.0442.0103	WASHER,BRASS.....	2
7	54.0201.0017	Bushing.....	2
8	04.4239.0000	VALVE BLOCK.....	1
9	53.0400.1200	Forks Articulation Cylinder.....	1
10	640536	JOINT/GASKET KIT.....	1
11	54.0000.0001	Pin.....	1
12	04.0214.0035	DRILLED SCREW.....	1
13	07.4529.0073	Back-Up Ring.....	2
14	07.4529.0071	O-RING.....	2
15	01.4001.0003	SCREW,8.8HCS 12MM1.75X100Z.....	1
16	01.0023.0056	NUT,STOP,M12 UNI 7473 6S ZN.....	1
17		605014 pos.14	
18	01.0001.0306	SCREW,TE M10X60 UNI 8.8 ZN....	4
19	53.3402.0500	Pipe.....	1
20	01.0003.0164	SCREW.....	8
21	04.0604.0124	Through Coupling.....	2
22	04.0605.0558	Flexible Hose.....	2
23	04.0607.0801	90° Elbow.....	4
24	04.0607.0223	Pipe Fitting.....	4

406.1 604990 Hydraulic System - Boom Extension




406.1 604990 Hydraulic System - Boom Extension

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	53.0100.2400	Cylinder.....	1	38	06.0401.0123	GASKET/SEAL.....	2
2	640101	GASKET KIT / UPPER BOOM CYL.....	1	39	01.4001.0008	SCREW,TE,M0X90 UNI 5737 8.8,ZN.....	1
3	54.0000.0128	Pin.....	1	40	01.0001.0014	Screw.....	4
4	54.0000.0004	Pin.....	1	41	01.0032.0055	SPRING WASHER.....	4
5	01.0001.0310	SCREW, 8.8 HCS 10MM-1.5X80Z...	2	42	01.4003.0002	SCREW.....	4
6	01.0023.0055	NUT,STOP,M10 UNI 7473 6S ZN....	3	43	06.0442.0101	WASHER.....	2
7	51.0800.0600	Collar.....	1	44	04.0607.0111	FITTING,1/2 BSP X 13/16 ORFS....	1
8	01.4001.0005	SCREW,TE,M14X25 UNI 8.8 ZN....	2				
9	01.4032.0006	WASHER,SPRING,D14 ZN.....	2				
10	04.4239.0079	Valve.....	1				
11	04.0607.0141	FITTING,90,1/2GAS X 13/16 M ORFS.....	2				
12	04.0605.0304	Flexible Hose.....	2				
13	04.0605.0560	Flexible Hose.....	2				
14	06.0442.0103	WASHER,BRASS.....	3				
15	53.3400.9200	Pipe.....	1				
16	53.0200.0700	Cylinder.....	1				
17	640102	GASKET KIT / INNER BOOM CYL.....	1				
18	54.0000.0129	Pin.....	1				
19	04.4239.0001	VALVE.....	1				
20	07.4529.0073	Seal.....	4				
21	07.4529.0071	O-RING.....	4				
22	01.4032.0003	WASHER,SPRING,D8 ZN.....	1				
23	09.0803.0043	CLAMP,D16.....	6				
24	01.0003.0157	SCREW, M6X25 SHCS Z.....	12				
25	51.0803.0300	Guide.....	1				
26	53.3400.9100	Pipe.....	1				
27	01.0001.0254	Screw TE M8 X 20 UNI 5739 8.8 ZN.....	1				
28	640594	BYPASS VALVE.....	2				
29	01.0031.0299	WASHER,D8 UNI 6593 ZN.....	1				
30	04.0607.0121	FITTING,3/4 BSP X 13/16 ORFS....	2				
31	54.0600.0001	Block.....	1				
32	04.0607.0155	Pipe Fitting.....	1				
33	04.0214.0035	DRILLED SCREW.....	1				
34	54.0004.0099	Pin.....	1				
35	04.0605.0504	Flexible Hose.....	1				
36	01.0001.0073	Spring Washer.....	4				
37	01.0001.1492	Screw.....	4				



Item	Part No.	Description	Qty.
1	51.0400.2700	Fork Coupling Attachment.....	1
2	54.0001.0022	Pin.....	2
3	01.0023.0053	NUT,STOP,M6 UNI 7473 6S ZN.....	4
4	01.0001.0104	SCREW,TE,M6X40 UNI 8.8 ZN.....	4
5	54.0201.0017	Bushing.....	2
6	54.0000.0122	Pin.....	1
7	54.0002.0031	Pin.....	1
8	02.0117.0101	GREASE ZERK,1/8".....	1


408.1 604992 Hydraulic System - Auxiliary Circuit



408.1 604992 Hydraulic System - Auxiliary Circuit

Item	Part No.	Description	Qty.
1	01.0003.0164	SCREW.....	8
2	04.0607.0160	FITTING,TMF L 1-7/16 ORFS.....	2
3	09.0803.0043	CLAMP,D16.....	8
4	01.0003.0157	SCREW, M6X25 SHCS Z.....	8
5	04.0605.0506	FLEXIBLE HOSE.....	1
6	04.0605.0558	Flexible Hose.....	2
7	53.3402.0400	Pipe.....	1
8	53.3402.0300	Pipe.....	1
9	04.0605.0331	Flexible Hose.....	2
10	04.0607.0121	FITTING,3/4 BSP X 13/16 ORFS.....	2


409.1 604992 Hydraulic System - Implement Locking



409.1 604992 Hydraulic System - Implement Locking

Item	Part No.	Description	Qty.
1	53.3001.0500	Manifold.....	1
2	04.0600.0019	PIPE FITTING,MFK 90 1/2 BSP.....	1
3	04.0600.0087	PIPE FITTING,90 A207140-2121.....	2
4	04.4210.0008	FEMALE QUICK COUPLER.....	2
5	04.4210.0007	MALE QUICK COUPLER.....	2
6	04.0607.0141	FITTING,90,1/2GAS X 13/16 M ORFS.....	2
7	04.0607.0110	FITTING,1/2 BSP X 11/16 ORFS.....	2
8	04.0605.0308	Flexible Hose.....	2
9	04.0607.0114	FITTING,3/8 BSP X 9/168 ORFS.....	3
10	01.0001.0156	SCREW,TE,M6X20 UNI 8.8 ZN.....	2
11	04.0607.0112	FTNG,90,1/4 BSP X 9/16 ORFS.....	1
12	04.0605.0114	FLEXIBLE HOSE.....	1
13	04.0605.0113	FLEXIBLE HOSE.....	1
14	04.0605.0112	FLEXIBLE HOSE.....	1
15	04.0607.0131	FITTING,TMF C 9/16 OFRS.....	1
16	01.4032.0002	WASHER,SPRING,D6 ZN.....	2
17		604993 pos.5	
18	53.0500.0400	Cylinder.....	1
19	01.0031.0054	WASHER,D6 UNI 6592 ZN.....	4
20	01.0001.0355	SCREW,TE,M10X25 UNI 8.8 ZN.....	4
21	01.4032.0004	WASHER,SPRING,D10 ZN.....	4
22	01.0031.0301	WASHER,D10 UNI 6593 ZN.....	4
23	54.0001.0001	Pin.....	2
24	04.0600.0081	PIPE FITTING,FMF+L 1/2 BSP.....	1
25	04.4239.0002	VALVE.....	1
26	04.0607.0132	PIPE FITTING.....	1
27	01.0031.0299	WASHER,D8 UNI 6593 ZN.....	3
28	07.4529.0107	Joint Kit.....	1
29	51.0901.7700	Guard.....	1
30	01.0001.0254	Screw TE M8 X 20 UNI 5739 8.8 ZN.....	3
31	01.4032.0003	WASHER,SPRING,D8 ZN.....	3
32	04.0607.0163	NIPPLE.....	2
33	54.0100.0077	Bushing.....	2
34	01.4001.0016	SCREW.....	2
35	01.0023.0053	NUT,STOP,M6 UNI 7473 6S ZN.....	2


410.1. 605014 Hydraulic System - Fork Balancing



410.1. 605014 Hydraulic System - Fork Balancing

Item	Part No.	Description	Qty.
1	04.0607.0114	FITTING,3/8 BSP X 9/168 ORFS.....	1
2	04.0607.0121	FITTING,3/4 BSP X 13/16 ORFS.....	2
3	04.0607.0558	Flexible Hose.....	2
4	04.0607.0122	FITTING,TMF 13/16 ORFS.....	2
5	04.0607.0111	FITTING,1/2 BSP X 13/16 ORFS.....	2
6	04.4239.0003	VALVE / FORK BALANCING.....	1
7	07.4529.0072	SEAL.....	2
8	53.0300.1600	Compensation Cylinder.....	1
9	07.4529.0109	SEAL KIT.....	1
10	02.0117.0101	GREASE ZERK,1/8".....	2
11		605003 pos.2	
12	54.0000.0123	Pin.....	1
13	04.4239.0004	VALVE,5 BAR.....	2
14	04.0605.0331	Flexible Hose.....	2
15	902935	Ball Joint.....	1
16	01.0003.0210	SCREW,TCEI,M8X50 UNI 8.8ZN.....	6
17	04.0605.0556	FLEXIBLE HOSE.....	1
18	04.0607.0115	FITTING,TMF L 9/16 ORFS.....	1
19	54.0000.0156	Pin.....	1
20	01.0001.0410	SCREW,TE,M12X90 UNI 8.8 ZN.....	1
21	01.0023.0056	NUT,STOP,M12 UNI 7473 6S ZN.....	1


501.1 604998 Diesel Engine - Supports and Accessories



501.1 604998 Diesel Engine - Supports and Accessories

Item	Part No.	Description	Qty.
1	09.4601.0031	Diesel Engine.....	1
2	51.0808.1200	Support.....	1
3	51.0808.1400	Support.....	1
4	51.0808.1300	Support.....	1
5	09.4670.0004	ENGINE ISOLATOR,PERKINS.....	4
6	01.4001.0012	SCREW,TE,M14X100 UNI 8.8 ZN...	4
7	01.0031.0058	WASHER,D14 UNI 6592 ZN.....	8
8	01.0001.0357	SCREW,TE,M10X35 UNI 8.8 ZN...	16
9	01.0023.0057	NUT,STOP,M14 UNI 7473 6S ZN....	4
10	01.0023.0055	NUT,STOP,M10 UNI 7473 6S ZN.....	16
11	01.0031.0057	WASHER,D12 UNI 6592 ZN.....	14
12	01.4032.0005	WASHER,SPRING,D12 ZN.....	14
13	01.0001.0401	SCREW,TE,M12X40 UNI 8.8 ZN...	14
14	09.0804.1600	Handwheel Arrangement.....	1
15	01.0001.0507	SCREW,TE,M12X35 UNI 8.8 ZN....	1
16	07.0713.0005	Plain Washer.....	1
17	638744	HUB.....	1
18	638748	ELASTIC JOINT.....	1
19	07.0713.0008	Spring Washer.....	8
20	07.0713.0057	Screw.....	8
21	638747	PROTECTION.....	1
22	07.0713.0023	Spring Washer.....	12
23	01.0001.0356	SCREW,TE,M10X30 UNI 8.8 ZN...	12
24	07.4501.0103	Fan.....	1
25	07.4501.0100	Oil Filter.....	1
26	07.4501.0096	Diesel Oil Filter.....	1
27	07.4501.0098	Clamp.....	6
28	09.0805.0000	RUBBER HOSE.....	2
29	07.4501.0099	Rubber Hose.....	1
30	07.4501.0097	Diesel Oil Filter.....	1
31	04.0607.0198	Pipe Fitting.....	2
32	04.0605.0589	Flexible Hose.....	1
33	04.0605.0561	Flexible Hose.....	1
34	04.0607.0197	Pipe Fitting.....	2
35	01.4005.0006	Screw.....	2
36	01.0031.0054	WASHER,D6 UNI 6592 ZN.....	2
37	01.0001.0069	Plain Washer.....	2


502.1 604999 Diesel Engine - Engine Cooling System



502.1 604999 Diesel Engine - Engine Cooling System

Item	Part No.	Description	Qty.
1	07.0712.0093	Radiator Core.....	1
2	07.0712.0094	RADIATOR CAP, GTH5519.....	1
3	07.0712.0095	Conveyor.....	1
4	07.0712.0096	Grate.....	1
5	53.3200.0029	Complete Radiator.....	1
6	09.0803.0351	Seal.....	0,7
7	09.0803.0245	GASKET,STRIP.....	0,8
8	09.0803.0351	Seal.....	0,9
9	09.4670.0002	PUFFER/INSULATOR.....	2
10	01.0031.0301	WASHER,D10 UNI 6593 ZN.....	2
11	01.0023.0055	NUT,STOP,M10 UNI 7473 6S ZN.....	3
12	01.0031.0056	WASHER,D10 UNI 6592 ZN.....	2
13	04.0227.0064	CLAMP,90/110.....	2
14	01.0031.0299	WASHER,D8 UNI 6593 ZN.....	1
15	01.4032.0003	WASHER,SPRING,D8 ZN.....	1
16	01.0001.0254	Screw TE M8 X 20 UNI 5739 8.8 ZN.....	1
17	01.0001.0304	SCREW,TE,M10X50 UNI 8.8 ZN.....	1
18	04.0227.0067	SLIGHT CLAMP,DN50/70 LG12.....	1
19	51.0808.8100	Support.....	1
20	04.0227.0058	CLAMP,40/60.....	3
21	09.0805.0078	Rubber Hose.....	1
22	53.3001.4300	Rubber Hose.....	1
23	09.0805.0000	RUBBER HOSE.....	1
24	07.4501.0101	Pipe Fitting.....	1
25	09.0803.0351	Seal.....	0,7


503.1 605000 Diesel Engine - Exhaust System



503.1 605000 Diesel Engine - Exhaust System

Item	Part No.	Description	Qty.
1	53.3100.0030	Exhaust Muffler.....	1
2	01.0023.0055	NUT,STOP,M10 UNI 7473 6S ZN.....	1
3	53.3001.3600	Manifold.....	1
4	01.0001.0304	SCREW,TE,M10X50 UNI 8.8 ZN.....	1
5	09.0803.0348	CLAMP.....	1
6	01.0031.0056	WASHER,D10 UNI 6592 ZN.....	4
7	01.4032.0004	WASHER,SPRING,D10 ZN.....	2
8	01.0001.0356	SCREW,TE,M10X30 UNI 8.8 ZN.....	2
9	07.0726.0100	Exhaust Pipe.....	1
10	07.4501.0102	Clamp.....	2
11	07.0726.0103	Exhaust Muffler.....	1


504.1 605001 Diesel Engine - Accelerator



504.1 605001 Diesel Engine - Accelerator

Item	Part No.	Description	Qty.
1	09.4655.0000	ACCELERATOR LEVER/MANIPULATOR.....	1
2	09.4645.0003	ACCELERATOR CABLE.....	1
3	09.4656.0000	PEDAL.....	1
4	09.4645.0000	CABLE.....	1
5	09.0803.0007	KIT IMPLANTATION CABLES/CLAMP.....	2
6	51.0807.5700	Bracket.....	1
7	01.0001.1438	SCREW,TE,M5X20 UNI 8.8 ZN.....	1
8	01.0031.0053	WASHER,D5 UNI 6592 ZN.....	2
9	01.0023.0052	NUT,STOP,M5 UNI 7473 6S ZN.....	1
10	01.0023.0053	NUT,STOP,M6 UNI 7473 6S ZN.....	1
11	09.0803.0008	KNEE-CAP/ARTICULATION JOINT.....	1


505.1 605002 Diesel Engine - Injection System



505.1 605002 Diesel Engine - Injection System

Item	Part No.	Description	Qty.
1	09.4604.0044	Complete Air Filter.....	1
2	07.4501.0084	CARTRIDGE.....	1
3	53.3001.2100	Sleeve.....	1
4	04.0227.0058	CLAMP,40/60.....	2
5	01.0023.0055	NUT,STOP,M10 UNI 7473 6S ZN....	4
6	01.0031.0299	WASHER,D8 UNI 6593 ZN.....	4
7	01.0001.0254	Screw TE M8 X 20 UNI 5739 8.8 ZN.....	2
8	07.4501.0085	CARTRIDGE.....	1
9	09.4604.0045	SENSOR.....	1
10	09.0805.0018	RUBBER PIPE.....	1,6
11	53.3001.3000	Manifold.....	1
12	04.4227.0001	CLAMP.....	1
13	04.4227.0000	CLAMP,60/80.....	1
14	51.0809.7100	Support.....	1
15	01.4032.0004	WASHER,SPRING,D10 ZN.....	2
16	01.0031.0056	WASHER,D10 UNI 6592 ZN.....	2
17	01.0001.0353	SCREW/BOLT / BOOM WEAR PAD.....	2


506.1 605005 Hydraulic System - Oil Cooler



506.1 605005 Hydraulic System - Oil Cooler

Item	Part No.	Description	Qty.
1	04.0605.0551	Flexible Hose.....	1
2	04.0607.0160	FITTING,TMF L 1-7/16 ORFS.....	1
3	04.0607.0142	FITTING 1" GAS X 1-7/16 ORFS.....	1
4	04.4239.0077	VALVE,1" PA 8.....	1
5	04.0600.0037	PIPE FITTING.....	1
6	04.0605.0553	Flexible Hose.....	1
7	04.0607.0172	Pipe Fitting.....	2
8	04.0607.0199	Pipe Fitting.....	1
9	04.0605.0552	Flexible Hose.....	1


507.1 605007 Suction System Hydraulic Pumps



507.1 605007 Suction System Hydraulic Pumps

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1		605008 pos.2		42	04.0600.0085	UNION.....	1
2		605008 pos.1		43	04.0607.0111	FITTING,1/2 BSP X 13/16 ORFS.....	1
3		605008 pos.3		44	06.0442.0107	WASHER/UNION.....	1
4	04.0605.0539	Flexible Hose.....	1	47		604982 pos.7	
5		605011 pos.23		48	09.4604.0000	FILTER, HYD. OIL TANK.....	1
6	04.0607.0107	FITTING,3/4 BSP X 1-3/16 ORFS....	2				
7	09.4661.0014	TANK CAP.....	1				
8	51.0600.4600	Oil Tank.....	1				
9	01.0023.0054	NUT,M8 UNI 7473 6S ZN.....	10				
10	01.0031.0299	WASHER,D8 UNI 6593 ZN.....	10				
11	07.0726.0044	COVER.....	1				
12	53.3301.0002	Seal.....	1				
13	01.0001.0039	Nut.....	4				
14	01.0031.0301	WASHER,D10 UNI 6593 ZN.....	4				
15	09.4670.0002	PUFFER/INSULATOR.....	4				
17	06.0442.0105	WASHER,JC 27,SP.2,5.....	1				
18	04.0220.0063	STOPPER HEAD.....	2				
19	09.4661.0002	OIL LEVEL INDICATOR.....	1				
20	06.0442.0111	WASHER.....	1				
21	01.0001.0353	SCREW/BOLT / BOOM WEAR PAD.....	4				
22	01.0032.0055	SPRING WASHER.....	4				
23	07.0700.0006	CAP,HYDRAULIC FILTER.....	1				
24	09.4604.0047	HYD OIL FILTER 5519.....	1				
25	07.0700.0023	OIL FILTER,CARTRIDGE.....	1				
26	07.0700.0028	INDICATOR (OIL CLOGGING).....	1				
27	01.0001.0113	Washer.....	1				
28	04.4220.0003	Plug.....	1				
29	04.0600.0200	Pipe Fitting.....	1				
30	56.0013.0000	SENSOR,TEMP,HYD OIL.....	1				
32		605004 pos.26					
33	04.4224.0001	VALVE,MANUAL,BEARING 2".....	1				
34	53.3000.0400	Manifold.....	1				
35	04.4238.0049	PUMP.....	1				
36	04.0607.0130	FITTING,1BSP X 1-3/16 ORFS.....	1				
37	04.0607.0114	FITTING,3/8 BSP X 9/168 ORFS.....	1				
38	04.4223.0002	KIT,FITTING G1 12.....	1				
39	04.0607.0170	Pipe Fitting.....	1				
40	04.0607.0119	PIPE FITTING.....	1				
41	04.4223.0001	KIT,FITTING G2 34.....	1				


508.1 605034 Decals And Plates



508.1 605034 Decals And Plates

Item	Part No.	Description	Qty.
1	09.4618.0243	Label.....	1
2	09.4618.0230	Label.....	-
3	09.4618.0361	Label.....	2
4	09.4612.0212	Label.....	2
5	09.4618.0242	Label.....	1
6	09.4618.0010	DECAL, (DO NOT OPEN WHEN RUN).....	1
7	09.4618.0547	Label.....	4
8	09.4618.0661	Label.....	2
9	09.4618.0271	LABEL.....	1
10	09.4618.0662	Label.....	1
11	09.4618.0034	Label.....	1
12	09.4618.0663	Label.....	1
13	09.4616.0040	Label.....	1
14	09.4618.0022	ADHESIVE NON SOSTARE.....	1
15	09.4618.0516	Label.....	1
16	09.4618.0784	DECAL.....	1


509.1 605035 Decals And Plates



509.1 605035 Decals And Plates

Item	Part No.	Description	Qty.
1	09.4618.0230	Label.....	-
2	09.4618.0068	DECAL,.....	1
3	09.4618.0026	ADHESIVE ELEC CABLES.....	1
4	09.4618.0030	Label.....	1
5	09.4618.0227	Label.....	1
6	09.4618.0241	LABEL,GENIE DECAL.....	1
7	09.4618.0563	Label.....	1
8	09.4618.0673	Label.....	1
8	09.4618.0674	Label.....	1
8	09.4618.0675	Label.....	1
8	09.4618.0676	Label.....	1

601.1 605032 Fuse Box




Item	Part No.	Description	Qty.
1	637650	FUSE,3A.....	2
2	07.0703.0193	FUSE,5A.....	1
3	634972	FUSE,7.5A.....	4
4	634974	FUSE,10A.....	15
5	634973	FUSE,15A.....	5
6	07.0703.0485	RELAY.....	15
7	07.0703.0487	RELAY.....	1
8	56.0021.0057	Card.....	1
9	56.0021.0073	Control Unit.....	1
10	07.0703.0486	RELAY.....	1

The diagram illustrates the electrical system for the 1000 cc engine. Key components and their connections are as follows:

- Alternator (7):** Connected to the battery (12) via a main power line (3) and a ground line (4). It also provides power to the engine's ignition system (5) and the alternator's own control circuit (6).
- Battery (12):** Provides power to the alternator (7) and the engine's ignition system (5). It is connected to the main power line (3) and ground (4).
- Engine (15):** Receives power from the alternator (7) and the battery (12) via the ignition system (5). It is also connected to various sensors (X1-X19) and the main power line (3).
- Sensors (X1-X19):** Various sensors are connected to the engine (15) and the main power line (3). These include X1, X2, X3, X4, X5, X6, X7, X8, X9, X10, X11, X12, X13, X14, X15, X16, X17, X18, and X19.
- Grounding (A):** A specific ground connection point is indicated by the letter 'A' in a box, connected to the main power line (3) and ground (4).

602.1 605036 Electric Installation - Engine Line


Item	Part No.	Description	Qty.
1	07.0703.0650	Wiring Harness.....	1
2	07.0703.0643	Cable.....	1
3	07.0703.0644	Wiring Harness.....	1
4	07.0703.0645	Cable.....	1
5	07.0703.0192	RELAY.....	1
6		604981 pos.1.....	-
7		605002 pos.1.....	-
8	56.0008.0012	Battery.....	1
9	07.0703.0192	RELAY.....	1
10	56.0005.0001	Fuse.....	1
11	07.0703.0061	FUSE.....	1
12	07.0703.0615	Electric Box.....	1
13		605008 pos.4.....	-
14	07.0703.0597	Fuse Holder.....	2
15	56.0013.0036	Proximity Switch.....	1



603.1 605037 Electric Installation - Rear Line

Item	Part No.	Description	Qty.
1		605038 pos.1.....-	
2	05.4329.0001	PRESSURE SWITCH.....1	
3	05.4329.0002	PRESSURE SWITCH.....1	
4		605011 pos.1.....-	
5		605015 pos.9.....-	
6	07.0709.0442	Proximity Switch.....1	
7	56.0012.0021	Proximity Switch.....1	
8	56.0009.0003	Horn.....1	
9	01.0019.0104	NUT,M8,UNI 5588 6S ZN.....1	
11	55.0602.0297	Wiring Harness.....2	
12		605004 pos.5.....-	
13		605003 pos.4.....-	
14	56.0012.0017	Proximity Switch.....2	
15	01.4003.0011	Screw.....4	
16	01.0001.0100	Spring Washer.....4	
17	07.0703.0310	GLASS.....2	
18	07.0703.0302	GLASS, AMBER.....1	
19	07.0703.0306	BULB, HEADLAMP.....4	
20	07.0703.0309	GLASS, AMBER.....1	
21	07.0703.0304	BULB, HEADLAMP.....2	
22	07.0703.0305	Bulb.....2	
23	56.0010.0034	Light.....1	
24	56.0010.0035	Light.....1	


604.1 605038 Electric Installation - Rear Line



604.1 605038 Electric Installation - Rear Line

Item	Part No.	Description	Qty.
1		605037 pos.1.....	-
2	01.4003.0011	Screw.....	4
3	01.0001.0100	Plain Washer.....	4
4	56.0012.0017	Proximity Switch.....	2
5	07.0703.0648	Wiring Harness.....	1
6		605006 pos.1.....	-
7	56.0009.0002	Horn.....	1
8	56.0012.0024	Proximity Switch.....	1
9		604982 pos.1	
10	56.0010.0036	Light.....	1
11	56.0010.0037	Light.....	1
12	56.0010.0004	Licence Plate Light.....	1
13	07.0703.0175	Bulb.....	4
14	07.0703.0663	Glass.....	1
15	07.0703.0320	Glass.....	1
16	07.0703.0321	BULB, TAIL LIGHT.....	1
17	07.0703.0319	BULB, TAIL LIGHT.....	2
18	56.0013.0028	Level Indicator.....	1
19	56.0013.0006	SENSOR,PRESSURE,HYD OIL.....	1
20	56.0013.0008	Proximity Switch.....	1
21		605007 pos.8.....	-
22	07.0703.0649	Wiring Harness.....	1
23	01.0031.0054	WASHER,D6 UNI 6592 ZN.....	2
24	56.0021.0023	Housing.....	1
25	07.0703.0359	PUSHBUTTON HEAD.....	1
26	07.0703.0363	Contact.....	1
27	01.0003.0153	SCREW.....	2
28	01.4032.0002	WASHER,SPRING,D6 ZN.....	2


605.1 605039 Electric Installation - Dashboard Line



605.1 605039 Electric Installation - Dashboard Line

Item	Part No.	Description	Qty.
1	07.0703.0639	Wiring Harness.....	1
2	07.0703.0535	RELAY	1
3	56.0021.0059	Control Unit.....	1
4	56.0021.0071	Control Unit.....	1
5	07.0703.0640	Diode Valve.....	1
6	07.0703.0641	Wiring Harness.....	1
7	56.0021.0078	Relay.....	1

606.1 605040 Electric Installation - Side Cab Line




606.1 605040 Electric Installation - Side Cab Line

Item	Part No.	Description	Qty.
1		605039 pos.1.....-	
2	07.0703.0642	Wiring Harness.....1	1
3	56.0010.0005	Pivoting Beacon.....1	1
4	07.0703.0384	BULB.....1	1
5	56.0002.0000	Support.....1	1

607.1 605041 Electric Installation - Side Cab Line


ONLY FOR SHIFT ON FLY KIT



607.1 605041 Electric Installation - Side Cab Line

Item	Part No.	Description	Qty.
1	07.0703.0647	Wiring Harness.....	1
2	07.0703.0484	Micro-Switch.....	1
3	56.0021.0068	Control Unit.....	1
4	56.0006.0002	Relay.....	1
5	07.0703.0656	FUSE,1A.....	1
6	07.0703.0486	RELAY.....	1
7	634972	FUSE,7.5A.....	1
8	07.0703.0657	Housing.....	2
9	07.0703.0617	Glass.....	2
10	640009	Pilot Light.....	1
11	07.0703.0618	Pilot Light.....	1

608.1 605042 Electric Installation - Rear Line



608.1 605042 Electric Installation - Rear Line

Item	Part No.	Description	Qty.
1		605041 pos.1.....-	
2		605003 pos.12.....-	
3		605008 pos.35.....-	
4		605015 pos.12.....-	
5	07.0709.0356	SWITCH,SECURITY.....2	
6	56.0012.0047	PROX SWITCH.....1	

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
01.0001.0014	87	01.0031.0301	23, 31, 33, 35, 93, 99, 109	04.0605.0506	91	04.4210.0003	43
01.0001.0017	31			04.0605.0525	39	04.4210.0004	43
01.0001.0037	23	01.0032.0055	87, 109	04.0605.0527	43	04.4210.0006	25
01.0001.0039	33, 35, 109	01.0117.0101	77	04.0605.0533	39	04.4210.0007	93
01.0001.0043	49	01.4001.0000	31, 33, 35	04.0605.0534	39	04.4210.0008	93
01.0001.0069	97	01.4001.0001	31	04.0605.0535	39	04.4220.0003	109
01.0001.0073	87	01.4001.0003	85	04.0605.0536	39	04.4223.0000	39
01.0001.0078	33, 35	01.4001.0005	87	04.0605.0537	43	04.4223.0001	109
01.0001.0100	119, 121	01.4001.0008	87	04.0605.0538	39	04.4223.0002	109
01.0001.0104	89	01.4001.0010	49	04.0605.0539	109	04.4223.0003	43
01.0001.0113	109	01.4001.0012	97	04.0605.0540	39	04.4224.0001	109
01.0001.0156	19, 93	01.4001.0016	93	04.0605.0541	45	04.4227.0000	105
01.0001.0254	25, 49, 87, 93, 99, 105	01.4001.0026	25	04.0605.0542	45	04.4227.0001	105
01.0001.0257	33, 35	01.4001.0058	23	04.0605.0543	27, 43	04.4229.0044	43
01.0001.0304	31, 79, 81, 99, 101	01.4001.0078	31, 33, 35	04.0605.0544	43	04.4229.0045	43
		01.4001.0110	31, 33, 35	04.0605.0545	37	04.4235.0023	43
01.0001.0306	23, 33, 35, 85	01.4003.0002	87	04.0605.0546	37	04.4235.0031	43
01.0001.0308	29	01.4003.0011	119, 121	04.0605.0547	37	04.4236.0055	25
01.0001.0310	87	01.4005.0006	97	04.0605.0548	39	04.4236.0060	41
01.0001.0314	31	01.4006.0001	27	04.0605.0549	39	04.4236.0075	41
01.0001.0353	81, 105, 109	01.4006.0005	81	04.0605.0550	41	04.4238.0043	43
01.0001.0355	33, 35, 81, 93	01.4006.0011	23, 31, 33, 35	04.0605.0551	107	04.4238.0049	109
01.0001.0356	31, 81, 97, 101	01.4023.0000	31, 33, 35	04.0605.0552	107	04.4238.0053	39
01.0001.0357	19, 79, 97	01.4031.0003	31	04.0605.0553	107	04.4239.0000	85
01.0001.0401	43, 97	01.4032.0002	19, 25, 93, 121	04.0605.0554	25	04.4239.0001	87
01.0001.0409	83	01.4032.0003	25, 87, 93, 99	04.0605.0555	29	04.4239.0002	93
01.0001.0410	95	01.4032.0004	33, 35, 79, 81, 93, 101, 105	04.0605.0556	95	04.4239.0003	95
01.0001.0413	77			04.0605.0557	41	04.4239.0004	95
01.0001.0466	33, 35	01.4032.0005	43, 49, 77, 97	04.0605.0558	85, 91	04.4239.0005	77
01.0001.0505	77	01.4032.0006	19, 87	04.0605.0559	77	04.4239.0007	25, 29
01.0001.0507	97	01.4032.0007	23	04.0605.0560	87	04.4239.0013	43
01.0001.0564	31	01.4032.0009	23, 49	04.0605.0561	97	04.4239.0077	107
01.0001.0604	19, 49	01.4041.0005	83	04.0605.0588	43	04.4239.0079	87
01.0001.0657	31	02.0112.0155	49	04.0605.0589	97	04.4240.0024	27
01.0001.0703	23	02.0117.0053	49	04.0607.0103	43	04.4240.0025	27
01.0001.0902	49	02.0117.0101	25, 27, 29, 79, 89, 95	04.0607.0107	39, 43, 109	04.4240.0052	39
01.0001.1438	103			04.0607.0110	39, 93	04.4240.0053	37
01.0001.1465	33, 35, 45, 77	02.4115.0000	83	04.0607.0111	39, 77, 87, 95, 109	04.4240.0055	37
01.0001.1492	87	03.0000.0008	27			05.0400.0000	45
01.0001.1493	31, 33, 35	04.0214.0035	29, 85, 87	04.0607.0112	93	05.0401.0000	45
01.0003.0023	49	04.0220.0055	31	04.0607.0113	39, 41	05.0401.0001	45
01.0003.0153	121	04.0220.0063	109	04.0607.0114	25, 27, 37, 45, 93, 95, 109	05.0401.0003	45
01.0003.0155	45	04.0227.0058	99, 105			05.0401.0005	45
01.0003.0157	85, 87, 91	04.0227.0064	99	04.0607.0115	37, 95	05.4309.0000	45
01.0003.0158	37, 39	04.0227.0067	99	04.0607.0117	29, 39	05.4315.0004	49
01.0003.0164	85, 91	04.0227.0068	17	04.0607.0119	109	05.4329.0000	45
01.0003.0208	25	04.0600.0019	93	04.0607.0121	41, 77, 87, 91, 95	05.4329.0001	119
01.0003.0210	77, 95	04.0600.0037	107	04.0607.0122	77, 95	05.4329.0002	119
01.0003.0255	39	04.0600.0067	43	04.0607.0130	41, 109	05.4329.0021	77
01.0019.0104	119	04.0600.0077	43	04.0607.0131	93	06.0401.0123	87
01.0023.0052	103	04.0600.0081	93	04.0607.0132	93	06.0401.0219	43
01.0023.0053	31, 33, 35, 89, 93, 103	04.0600.0085	109	04.0607.0137	39	06.0442.0055	45
		04.0600.0087	93	04.0607.0141	85, 87, 93	06.0442.0101	87
01.0023.0054	33, 35, 45, 77, 109	04.0600.0092	27	04.0607.0142	41, 107	06.0442.0103	29, 31, 85, 87
		04.0600.0159	43	04.0607.0145	25	06.0442.0105	43, 109
01.0023.0055	23, 29, 31, 33, 35, 87, 97, 99, 101, 105	04.0600.0166	45	04.0607.0149	43	06.0442.0107	109
		04.0600.0195	17	04.0607.0153	37	06.0442.0111	109
		04.0600.0196	17	04.0607.0155	87	07.0470.0175	49
		04.0600.0197	17	04.0607.0160	41, 91, 107	07.0607.0111	45
01.0023.0056	77, 83, 85, 95	04.0600.0200	109	04.0607.0163	41, 93	07.0700.0006	109
01.0023.0057	31, 33, 35, 97	04.0604.0124	85	04.0607.0164	41	07.0700.0023	109
01.0023.0060	31	04.0605.0112	93	04.0607.0167	25	07.0700.0028	109
01.0031.0053	103	04.0605.0113	93	04.0607.0170	109	07.0701.0007	43
01.0031.0054	31, 33, 35, 45, 93, 97, 121	04.0605.0114	93	04.0607.0172	107	07.0701.0180	43
		04.0605.0182	43	04.0607.0173	77	07.0701.0196	43
01.0031.0055	25, 33, 35, 49	04.0605.0261	77	04.0607.0174	39	07.0701.0203	43
01.0031.0056	19, 31, 99, 101, 105	04.0605.0262	43	04.0607.0184	43	07.0701.0204	43
		04.0605.0304	87	04.0607.0188	43	07.0701.0205	43
01.0031.0057	97	04.0605.0308	93	04.0607.0197	97	07.0703.0007	21
01.0031.0058	31, 33, 35, 49, 97	04.0605.0309	25, 39	04.0607.0198	97	07.0703.0010	21
01.0031.0059	23, 31	04.0605.0331	91, 95	04.0607.0199	107	07.0703.0017	15
01.0031.0061	23, 31	04.0605.0351	25	04.0607.0207	43	07.0703.0019	15
01.0031.0062	31	04.0605.0428	45	04.0607.0223	85	07.0703.0029	21
01.0031.0299	33, 35, 87, 93, 99, 105, 109	04.0605.0504	87	04.0607.0558	95	07.0703.0032	21
		04.0605.0505	85	04.0607.0801	85	07.0703.0034	15

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
07.0703.0035	15	07.0709.0072	55, 67	07.0730.0069	49	07.0740.0093	11
07.0703.0061	117	07.0709.0074	57	07.0738.0000	47	07.0740.0094	11
07.0703.0125	13, 21	07.0709.0076	75	07.0740.0000	13	07.0740.0095	11
07.0703.0175	121	07.0709.0077	75	07.0740.0001	13	07.0740.0096	11
07.0703.0192	117	07.0709.0078	75	07.0740.0002	13	07.0740.0097	11
07.0703.0193	115	07.0709.0079	75	07.0740.0003	13	07.0740.0098	11
07.0703.0302	119	07.0709.0081	69	07.0740.0004	13	07.0740.0099	11
07.0703.0304	119	07.0709.0082	69	07.0740.0005	11, 13, 17	07.0740.0100	11, 33, 35
07.0703.0305	119	07.0709.0084	51, 63	07.0740.0006	11, 13, 17	07.0740.0101	11
07.0703.0306	119	07.0709.0101	55, 67	07.0740.0007	13	07.0740.0102	11
07.0703.0309	119	07.0709.0102	55, 67	07.0740.0009	11, 13	07.0740.0103	11
07.0703.0310	119	07.0709.0104	55, 67	07.0740.0010	13	07.0740.0104	11
07.0703.0319	121	07.0709.0106	57, 69	07.0740.0011	13	07.0740.0105	11
07.0703.0320	121	07.0709.0113	51, 55, 63, 67	07.0740.0012	11, 13, 15, 17	07.0740.0106	11
07.0703.0321	121	07.0709.0117	55, 67	07.0740.0013	13, 49	07.0740.0107	11
07.0703.0359	121	07.0709.0118	55, 67	07.0740.0014	11, 13	07.0740.0114	11
07.0703.0363	121	07.0709.0119	55, 67	07.0740.0015	13	07.0740.0115	11
07.0703.0384	125	07.0709.0121	55	07.0740.0016	11, 13, 17	07.0740.0116	11, 15
07.0703.0417	15	07.0709.0122	69	07.0740.0017	13	07.0740.0117	11, 15
07.0703.0418	15	07.0709.0123	69	07.0740.0018	13	07.0740.0118	17
07.0703.0419	15	07.0709.0124	67	07.0740.0020	13	07.0740.0119	17
07.0703.0420	15	07.0709.0205	55, 67	07.0740.0021	13	07.0740.0120	17
07.0703.0421	15	07.0709.0215	55, 67	07.0740.0022	13	07.0740.0121	17
07.0703.0423	15, 21	07.0709.0216	53	07.0740.0024	13	07.0740.0122	17
07.0703.0425	21	07.0709.0218	61, 73	07.0740.0025	13	07.0740.0123	17
07.0703.0429	21	07.0709.0219	55, 67	07.0740.0026	11, 13	07.0740.0124	17
07.0703.0430	21	07.0709.0220	67	07.0740.0027	13	07.0740.0125	17
07.0703.0431	21	07.0709.0327	75	07.0740.0028	11, 13, 17	07.0740.0126	17
07.0703.0432	21	07.0709.0356	129	07.0740.0029	13	07.0740.0127	17
07.0703.0434	21	07.0709.0357	75	07.0740.0030	13	07.0740.0128	13, 17
07.0703.0435	21	07.0709.0365	55, 67	07.0740.0032	11	07.0740.0129	17
07.0703.0440	21	07.0709.0371	51, 55, 63, 67	07.0740.0035	11, 13	07.0740.0130	17
07.0703.0441	15	07.0709.0372	65	07.0740.0037	15	07.0740.0132	17
07.0703.0484	127	07.0709.0374	53	07.0740.0041	13	07.0740.0133	17
07.0703.0485	115	07.0709.0377	55, 67	07.0740.0042	15	07.0740.0136	39
07.0703.0486	115, 127	07.0709.0386	61, 73	07.0740.0046	11	07.0740.0139	15
07.0703.0487	115	07.0709.0424	57	07.0740.0047	13	07.0740.0140	15
07.0703.0489	15	07.0709.0426	53, 65	07.0740.0048	13	07.0740.0141	15
07.0703.0494	21	07.0709.0430	69	07.0740.0049	13	07.0740.0142	15
07.0703.0531	15	07.0709.0441	51, 55, 63, 67	07.0740.0050	13, 33, 35	07.0740.0143	15
07.0703.0532	15	07.0709.0442	119	07.0740.0051	13	07.0740.0144	15
07.0703.0533	15	07.0709.0443	75	07.0740.0052	11, 13	07.0740.0145	15
07.0703.0534	15	07.0709.0719	75	07.0740.0054	13	07.0740.0151	15
07.0703.0535	123	07.0709.0720	75	07.0740.0055	13	07.0740.0152	15
07.0703.0572	21	07.0709.0721	51, 63	07.0740.0058	13	07.0740.0154	15
07.0703.0576	21	07.0709.0722	53, 65	07.0740.0059	13	07.0740.0156	11
07.0703.0581	15	07.0709.0723	65	07.0740.0060	13	07.0740.0157	11
07.0703.0597	117	07.0709.0724	53, 55, 67	07.0740.0061	13	07.0740.0158	11
07.0703.0614	21	07.0709.0726	55, 67	07.0740.0062	13, 15	07.0740.0163	11
07.0703.0615	117	07.0709.0727	55, 67	07.0740.0063	13, 49	07.0740.0169	15
07.0703.0617	127	07.0712.0093	99	07.0740.0064	11	07.0740.0170	49
07.0703.0618	127	07.0712.0094	99	07.0740.0066	11	07.0740.0171	49
07.0703.0639	123	07.0712.0095	99	07.0740.0067	11	07.0740.0172	49
07.0703.0640	123	07.0712.0096	99	07.0740.0068	11	07.0740.0173	49
07.0703.0641	123	07.0713.0005	97	07.0740.0069	11	07.0740.0178	11
07.0703.0642	125	07.0713.0008	97	07.0740.0070	11	07.0740.0192	33, 35
07.0703.0643	117	07.0713.0023	97	07.0740.0071	11, 17	07.0740.0202	11
07.0703.0644	117	07.0713.0057	97	07.0740.0072	11	07.0740.0206	15
07.0703.0645	117	07.0721.0101	25	07.0740.0073	11	07.0740.0208	15
07.0703.0647	127	07.0721.0119	77	07.0740.0074	11	07.0740.0209	11
07.0703.0648	121	07.0721.0202	43	07.0740.0076	11	07.0740.0210	11
07.0703.0649	121	07.0722.0053	39	07.0740.0078	11	07.0740.0211	11
07.0703.0650	117	07.0726.0044	109	07.0740.0079	11	07.0740.0212	11
07.0703.0656	127	07.0726.0051	83	07.0740.0080	11	07.0740.0213	11
07.0703.0657	127	07.0726.0100	101	07.0740.0081	11	07.0740.0214	11
07.0703.0663	121	07.0726.0103	101	07.0740.0082	11	07.0740.0215	11
07.0709.0001	59, 71	07.0728.0006	37	07.0740.0083	11	07.0740.0217	11
07.0709.0057	53, 65	07.0728.0007	37, 39	07.0740.0084	11	07.0740.0218	17
07.0709.0059	53	07.0730.0036	45	07.0740.0085	11	07.0740.0219	17
07.0709.0060	55, 67	07.0730.0037	45	07.0740.0086	11	07.0740.0223	13
07.0709.0061	55, 67	07.0730.0063	49	07.0740.0087	11	07.0740.0227	13
07.0709.0064	55, 67	07.0730.0064	49	07.0740.0088	11	07.0740.0228	13
07.0709.0065	55, 67	07.0730.0065	49	07.0740.0089	11	07.0740.0229	13
07.0709.0068	55	07.0730.0066	49	07.0740.0090	11	07.0740.0230	13
07.0709.0070	55, 67	07.0730.0067	49	07.0740.0091	11	07.0740.0231	13
07.0709.0071	55, 67	07.0730.0068	49	07.0740.0092	11	07.0740.0234	15

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
07.0740.0235	13	09.0803.0245	99	51.0200.8600	81	53.3402.0500	85
07.0740.0236	13	09.0803.0348	101	51.0400.2700	89	53.3402.0600	85
07.0740.0246	11	09.0803.0351	99	51.0500.1200	29	53.3402.0700	45
07.0740.0247	11	09.0803.0352	31, 33, 35	51.0500.1300	29	53.3402.0800	45
07.0740.0248	11	09.0803.0360	23	51.0600.4500	31	54.0000.0001	85
07.0740.0249	13	09.0803.0368	33, 35	51.0600.4600	109	54.0000.0004	87
07.0740.0250	13	09.0803.0395	23	51.0800.0400	31, 33, 35	54.0000.0083	83
07.0740.0264	45	09.0803.0407	33, 35	51.0800.0600	87	54.0000.0096	29
07.0740.0265	45	09.0803.0408	31	51.0800.2700	23	54.0000.0097	29
07.0740.0266	45	09.0803.0419	23	51.0801.9000	79	54.0000.0098	29
07.0740.0267	49	09.0804.1600	97	51.0801.9100	81	54.0000.0099	77
07.0740.0272	13	09.0805.0000	97, 99	51.0803.0300	87	54.0000.0122	89
07.0740.0273	13	09.0805.0018	105	51.0804.8700	23	54.0000.0123	95
07.0740.0274	13	09.0805.0078	99	51.0804.9000	79, 81	54.0000.0126	77
07.0740.0275	13	09.4601.0031	97	51.0805.1500	35	54.0000.0128	87
07.0740.0276	13	09.4604.0000	109	51.0805.1600	31, 33	54.0000.0129	87
07.0740.0277	13	09.4604.0044	105	51.0806.7400	31	54.0000.0155	31, 33, 35
07.0740.0279	13	09.4604.0045	105	51.0807.5700	103	54.0000.0156	95
07.0741.0000	25	09.4604.0047	109	51.0808.0700	49	54.0000.0157	31, 33, 35
07.0741.0001	25, 41	09.4610.0001	15	51.0808.1200	97	54.0001.0001	93
07.0741.0002	41	09.4610.0002	33, 35	51.0808.1300	97	54.0001.0022	89
07.0741.0003	41	09.4612.0212	111	51.0808.1400	97	54.0001.0041	49
07.0741.0004	41	09.4616.0040	111	51.0808.3000	33, 35	54.0002.0031	89
07.0741.0005	41	09.4616.0109	83	51.0808.3100	33, 35	54.0003.0033	31
07.0741.0006	41	09.4618.0010	111	51.0808.5100	33, 35	54.0004.0000	23
07.0741.0008	41	09.4618.0022	111	51.0808.6900	33, 35	54.0004.0099	87
07.0741.0009	15	09.4618.0026	113	51.0808.7600	49	54.0100.0020	31
07.0741.0010	15	09.4618.0030	113	51.0808.8100	99	54.0100.0056	83
07.0741.0011	15	09.4618.0034	111	51.0808.9000	31	54.0100.0077	93
07.0741.0012	15	09.4618.0068	113	51.0808.9400	23	54.0200.0000	79, 81
07.0741.0014	15	09.4618.0227	113	51.0808.9500	23	54.0200.0001	79, 81
07.0741.0015	25	09.4618.0230	111, 113	51.0809.3100	33, 35	54.0201.0003	79
07.0741.0016	41	09.4618.0241	113	51.0809.3400	31	54.0201.0004	79
07.0741.0017	15	09.4618.0242	111	51.0809.3900	81	54.0201.0017	85, 89
07.0741.0018	15	09.4618.0243	111	51.0809.4000	79, 81	54.0600.0001	87
07.0741.0019	15	09.4618.0271	111	51.0809.4600	81	54.0702.0000	79, 81
07.0741.0031	25	09.4618.0361	111	51.0809.5700	23	54.0702.0001	79, 81
07.0741.0032	25	09.4618.0516	111	51.0809.7100	105	54.0702.0003	81
07.0741.0033	25	09.4618.0547	111	51.0810.5300	33, 35	54.0702.0004	81
07.4501.0084	105	09.4618.0563	113	51.0810.5500	35	54.0800.0000	49
07.4501.0085	105	09.4618.0661	111	51.0901.6700	27	55.0403.0043	47
07.4501.0096	97	09.4618.0662	111	51.0901.7700	93	55.0403.0044	47
07.4501.0097	97	09.4618.0663	111	51.0902.3100	31	55.0602.0144	19
07.4501.0098	97	09.4618.0673	113	51.0902.3200	31	55.0602.0297	119
07.4501.0099	97	09.4618.0674	113	51.0902.3400	19	55.1100.6800	33, 35
07.4501.0100	97	09.4618.0675	113	51.0902.3800	25	56.0002.0000	125
07.4501.0101	99	09.4618.0676	113	51.0902.4400	33, 35	56.0005.0001	117
07.4501.0102	101	09.4618.0784	111	51.0902.4500	33, 35	56.0006.0002	127
07.4501.0103	97	09.4627.0016	47	51.0902.5400	23	56.0008.0012	117
07.4529.0071	85, 87	09.4627.0017	47	51.1000.3400	23	56.0009.0002	121
07.4529.0072	77, 95	09.4629.0000	47	51.1300.5300	83	56.0009.0003	119
07.4529.0073	85, 87	09.4629.0003	47	51.1301.2500	83	56.0010.0004	121
07.4529.0093	27	09.4632.0002	61, 73	52.0900.0200	79	56.0010.0005	125
07.4529.0102	39	09.4632.0061	47	53.0000.3816	77	56.0010.0034	119
07.4529.0106	29	09.4632.0062	47	53.0100.2400	87	56.0010.0035	119
07.4529.0107	93	09.4633.0014	47	53.0200.0700	87	56.0010.0036	121
07.4529.0108	25	09.4633.0020	47	53.0300.1600	95	56.0010.0037	121
07.4529.0109	95	09.4635.0014	47	53.0400.1200	85	56.0012.0017	119, 121
07.4529.0110	77	09.4635.0041	47	53.0500.0400	93	56.0012.0020	75
07.4529.0111	37	09.4635.0042	47	53.0600.1200	25	56.0012.0021	119
07.4529.0115	39	09.4636.0002	39	53.0700.0300	27	56.0012.0024	121
09.0610.0972	33, 35	09.4636.0014	39	53.0800.1400	29	56.0012.0047	129
09.0801.0000	29	09.4645.0000	103	53.0800.1500	29	56.0013.0000	109
09.0801.0001	77	09.4645.0003	103	53.3000.0400	109	56.0013.0001	31
09.0801.0025	77	09.4645.0022	49	53.3001.0500	93	56.0013.0006	121
09.0802.0017	19	09.4655.0000	103	53.3001.2100	105	56.0013.0008	121
09.0803.0007	103	09.4656.0000	103	53.3001.3000	105	56.0013.0028	121
09.0803.0008	103	09.4661.0002	109	53.3001.3600	101	56.0013.0036	117
09.0803.0012	27, 31, 33, 35	09.4661.0014	31, 109	53.3001.4300	99	56.0016.0021	19
09.0803.0016	45	09.4670.0001	23	53.3100.0030	101	56.0016.0032	15
09.0803.0026	23, 83	09.4670.0002	99, 109	53.3200.0029	99	56.0017.0003	21
09.0803.0043	85, 87, 91	09.4670.0004	97	53.3301.0002	109	56.0021.0023	121
09.0803.0055	83	09.4670.0006	31	53.3400.9100	87	56.0021.0057	115
09.0803.0087	23	51.0110.9000	31	53.3400.9200	87	56.0021.0059	123
09.0803.0177	33, 35	51.0200.8400	79	53.3402.0300	91	56.0021.0068	127
09.0803.0178	31	51.0200.8500	81	53.3402.0400	91	56.0021.0071	123

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page
56.0021.0073	115	639662	53, 65	641109	59, 71
56.0021.0078	123	639664	53, 65	901777	69
626544	53, 65	639668	51, 63	902935	95
627521	39	639670	51, 63		
628275	75	639671	59, 71		
628924	27	639674	57, 69		
629733	75	639675	57		
629735	75	639676	57, 69		
630328	57, 69	639679	57, 69		
630693	53, 65	639681	57, 69		
630846	55, 67	639682	57, 69		
632383	51, 55, 63, 67	639683	57, 69		
633069	57, 69	639684	65		
633098	53, 65	639685	65		
633099	53, 65	639686	65		
633109	75	639689	69, 75		
633161	75	639691	69		
633174	55, 67	639692	69		
633176	55, 61, 67, 73	639693	69		
633202	55, 67, 75	639695	57, 69		
633203	55, 67	639696	69		
633208	75	639778	75		
633517	69	639780	75		
634499	53, 65	639781	75		
634501	53, 65	639783	75		
634546	55, 67	639784	75		
634972	115, 127	639785	75		
634973	115	639787	75		
634974	115	639790	75		
635594	75	639791	75		
635596	75	639792	75		
636440	69	639793	75		
637536	75	639794	75		
637567	55, 67	639795	75		
637574	69, 75	639796	75		
637577	75	639797	75		
637582	75	639799	75		
637584	75	639800	75		
637621	69	639802	53, 65, 75		
637650	115	639803	75		
637850	61, 73	639804	75		
638226	21	639807	75		
638548	55, 57, 61, 67, 69, 73	639808	75		
		639809	75		
638744	97	639810	75		
638747	97	639811	75		
638748	97	639812	75		
639289	55, 67	639813	75		
639297	53, 65	639814	75		
639298	53, 65	639815	75		
639300	53, 65	639816	75		
639301	53, 65	639819	75		
639302	53, 65	639820	75		
639303	53, 65	639821	75		
639327	75	640009	127		
639328	75	640101	87		
639329	75	640102	87		
639624	55, 67	640214	55		
639625	55	640216	55, 67		
639630	55, 67	640270	59, 71		
639631	55, 67	640536	85		
639637	55, 67	640594	87		
639639	55, 67	640717	65		
639640	55, 67	640718	55, 67		
639641	55, 67	640719	67		
639642	55, 67	640720	55, 67		
639643	55, 67	640728	55, 67		
639645	55, 67	640729	55, 67		
639646	55, 67	640730	55, 67		
639647	55, 67	640731	69		
639650	53, 65	640732	69		
639651	53, 65	640908	55, 67		
639652	53, 65	640909	55, 67		
639653	53, 65	641089	53		
639657	53, 65	641090	53		
639661	53, 65	641108	59, 71		

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

FILTER, HYD. OIL TANK.....109

1

1st Telescopic Element.....79

2

2 KEYS & SWITCH.....15
2nd Telescopic Element.....81

3

3-WAY FITTING.....17
3rd Telescopic Element.....81

6

604981 pos.1.....117
604981 pos.10.....45
604981 pos.9.....41
604982 pos.1.....121
604982 pos.7.....109
604993 pos.5.....93
605002 pos.1.....117
605003 pos.1.....41
605003 pos.12.....129
605003 pos.2.....95
605003 pos.4.....119
605004 pos.12.....41
605004 pos.20.....41
605004 pos.26.....109
605004 pos.5.....119
605005 pos.1.....41
605006 pos.1.....121
605007 pos.8.....121
605008 pos.1.....109
605008 pos.2.....109
605008 pos.3.....109
605008 pos.35.....129
605008 pos.4.....117
605008 pos.5.....37
605011 pos.1.....119
605011 pos.21.....41
605011 pos.23.....109
605014 pos.14.....85
605014 pos.17.....41
605015 pos.12.....129
605015 pos.9.....119
605037 pos.1.....121
605038 pos.1.....119
605039 pos.1.....125
605041 pos.1.....129

9

90° Elbow.....85

A

ACCELERATOR CABLE.....103
ACCELERATOR LEVER/MANIPULATOR....103
Accumulator.....77
ACCUMULATOR,BRAKE.....45
ADAPTER,REDUCTION,HOSE.....17
ADHESIVE ELEC CABLES.....113
ADHESIVE NON SOSTARE.....111
Adhesive Profile.....13
AIR INLET.....17

AIR INLET,D76.....17
Arm.....67
AXLE CASE.....55

B

Back-Up Ring.....85
BALL.....75
Ball Joint.....27, 95
Ball-Grip.....11
Basic Frame.....31
Battery.....117
BEARING.....53, 55, 65, 67, 75
Bearing.....53, 55, 65, 67, 75
Bevel Gear Set.....53, 65
BLEEDER VALVE, LONG.....57, 69
Block.....87
BOOT.....75
Bracket.....11, 25, 33, 35, 49, 103
BRACKET,SUPPORT.....17
Brake Disc.....57, 69
BRAKE DISC,INTERMEDIATE.....57, 69
BRAKE/CABLE.....49
BULB.....125
Bulb.....119, 121
BULB, HEADLAMP.....119
BULB, TAIL LIGHT.....121
BUMP STOP,RUBBER.....13
BUSHIN 4 HURTH.....69
BUSHING.....55, 61, 67, 73, 79, 81
Bushing.....11, 13, 15, 25, 27, 61, 73, 77, 79, 81, 85, 89, 93
BUSHING/EAR-RING.....29
BYPASS VALVE.....87

C

CABLE.....103
Cable.....117
CAP.....13, 15
Cap.....15
CAP,HYDRAULIC FILTER.....109
Card.....115
Cardan Shaft.....47
CARTRIDGE.....105
CASE,DIFFERENTIAL.....65
Casing.....31
Chain.....83
CLAMP.....101, 105
Clamp.....45, 97, 101
CLAMP,22/32.....17
CLAMP,40/60.....99, 105
CLAMP,60/80.....105
CLAMP,90/110.....99
CLAMP,D16.....85, 87, 91
CLAMP,HOSE,MEB,40-60 H12.....17
CLUTCH DISC.....53
Coating.....13
COIL (53.0700.0303).....27
COIL,SQUARE SOLENOID.....37, 39
Collar.....87
Compensation Cylinder.....95
Compl. Front Differential Gear.....53
COMPL. REAR DIFFERENTIAL GEAR.....65
Complete Air Filter.....105
Complete Radiator.....99
CONDUCT/HOSE.....45
Connection.....33, 35

CONNECTION/PIPE FITTING.....45
CONTACT.....15
Contact.....15, 121
Control Lever.....15
Control Panel.....21
Control Unit.....115, 123, 127
Control Valve.....25
Control Valve from SN 17125.....41
Control Valve to SN 17126.....41
Conveyor.....99
COTTER PIN.....49
COVER.....51, 63, 75, 109
Cover.....15, 55, 67, 75
COVER,DASH.....15, 21
COVER,RADIO HOUSING.....15
COVER,SPEAKER.....11
COVER,VALVE PROTECTION.....27
COVERING.....13
Cylinder.....27, 29, 33, 35, 59, 71, 75, 77, 87, 93

D

Dash Board.....21
Dashboard.....15
DECAL.....111
DECAL,.....113
DECAL, (DO NOT OPEN WHEN RUN).....111
Diesel Engine.....97
Diesel Oil Filter.....97
Diesel Oil Tank.....31
DIFFERENTIAL CASE.....53
Diode Valve.....123
Display.....19
DOME LIGHT.....11
DOOR LOCK.....13
Door Stop.....11
DOWEL.....57, 69, 75
Dowel.....49
DRILLED SCREW.....29, 45, 85, 87
DRIVING MIRROR-REAR VIEW.....33, 35

E

ELASTIC JOINT.....97
Electric Box.....117
ELEMENT,AIR FILTER.....11
Emergency Button.....15
End.....29
ENGINE ISOLATOR,PERKINS.....97
Exhaust Muffler.....101
Exhaust Pipe.....101
EYE CONNECTION/PIPE FITTING.....45

F

Fan.....97
FEMALE QUICK COUPLER.....93
FILTER,COVER.....11
FITTING 1" GAS X 1-7/16 ORFS.....41, 107
FITTING 18X1.5 X 11/16 ORFS.....39
FITTING, 1 BSP X 1-3/16-12 ORFS.....39, 41
FITTING,1 BSP X 1-11/16 ORFS.....39
FITTING,1/2 BSP X 11/16 ORFS.....39, 93
FITTING,1/2 BSP X 13/16 ORFS.....39, 77, 87, 95, 109
FITTING,1/2 BSP X 9/16 ORFS.....25
FITTING,1BSP X 1-3/16 ORFS.....41, 109
FITTING,3/4 BSP X 1-3/16 ORFS.....39, 43, 109

FITTING,3/4 BSP X 13/16 ORFS.....41, 77, 87, 91, 95
 FITTING,3/8 BSP X 11/16 ORFS.....29, 39
 FITTING,3/8 BSP X 9/168 ORFS.....25, 27, 37, 45, 93, 95, 109
 FITTING,90,1/2GAS X 13/16 M ORFS.....85, 87, 93
 FITTING,M12X1.5X9/16 ORFS.....43
 FITTING,M14X1.5 X 9/16 ORFS.....37
 FITTING,M42X2.0 X 1-11/16 ORFS.....43
 FITTING,TMF 13/16 ORFS.....77, 95
 FITTING,TMF C 9/16 OFRS.....93
 FITTING,TMF L 1-7/16 ORFS.....41, 91, 107
 FITTING,TMF L 9/16 ORFS.....37, 95
 Flange.....53, 65, 75
 FLANGE,HALF D47.....43
 FLEXIBLE HOSE.....85, 91
 FLEXIBLE HOSE.....45, 93, 95
 Flexible Hose.....25, 27, 29, 37, 39, 41, 43, 45, 77, 85, 87, 91, 93, 95, 97, 107, 109
 Fork.....23, 83
 Fork Coupling Attachment.....89
 Forks Articulation Cylinder.....85
 Frame.....11, 13
 FRONT GLASS.....11
 Front Support.....31, 33, 35
 FTNG,90,1/4 BSP X 9/16 ORFS.....93
 Fuel Gauge.....31
 FUSE.....117
 Fuse.....117
 Fuse Holder.....117
 FUSE,10A.....115
 FUSE,15A.....115
 FUSE,1A.....127
 FUSE,3A.....115
 FUSE,5A.....115
 FUSE,7.5A.....115, 127

G

GASKET.....11
 GASKET KIT.....27, 59, 71
 GASKET KIT / INNER BOOM CYL.....87
 GASKET KIT / UPPER BOOM CYL.....87
 GASKET,HANDLE.....13
 GASKET,RUBBER.....11
 GASKET,STRIP.....99
 GASKET/SEAL.....87
 GAUGE / OIL PRESSURE.....21
 Gear.....75
 Gear Box.....47
 GEAR,DIFFERENTIAL SIDE.....65
 GLASS.....13, 119
 Glass.....11, 21, 121, 127
 GLASS, AMBER.....119
 GLASS, TOP.....11
 GLASS/PILOT LIGHT.....15
 Grate.....33, 35, 99
 GREASE NIPPLE.....49, 55, 67
 Grease Nipple.....13, 77
 GREASE ZERK.....55, 61, 67, 73
 GREASE ZERK,1/8".....25, 27, 29, 79, 89, 95
 GROMMET,RUBBER D31.....17
 GRUBSCREW.....69
 GUARD.....75
 Guard.....11, 19, 25, 31, 33, 35, 93
 Guide.....87

H

HANDLE.....11, 13, 33, 35
 Handle.....15
 Handwheel Arrangement.....97
 HEATER,COMPLETE.....17
 HEX HEAD CAP.....11, 13, 17
 Hinge.....11, 13, 23, 33, 35
 HOLDING VALVE / SWAY CYLINDER.....25, 29
 Hook.....23
 Horn.....119, 121
 HOSE GUIDE.....11
 HOSE,AIR.....17
 HOSE,FLEXIBLE,R2X2 1/2LG.1800.....25
 HOUSING.....55, 67
 Housing.....51, 55, 63, 75, 121, 127
 HUB.....55, 67, 97
 HYD OIL FILTER 5519.....109
 HYDRAULIC MOTOR.....43
 Hydraulic Motor.....43
 HYDRAULIC PUMP / HPR50.....43

I

IGNITION SWITCH W/TWO KEYS.....21
 INDICATOR (OIL CLOGGING).....109
 INSULATOR.....31
 ISOLATOR,VIBRATION.....23

J

JOINT.....39
 Joint.....55, 67
 JOINT BOX.....55, 67
 Joint Kit.....25, 37, 39, 41, 43, 93
 JOINT,ARTICULATED.....55, 67
 JOINT/GASKET KIT.....85

K

KEY.....15
 Key.....23
 KEY ONLY, SWITCH/IGNITION.....13, 21
 Kit.....11
 KIT IMPLANTATION CABLES/CLAMP.....103
 KIT,FITTING G1 12.....109
 KIT,FITTING G2 34.....109
 KIT,HARWARE,UNIVERSAL JOINTS.....47
 KIT,SUNSHIELD CURTAIN.....13
 KNEE-CAP/ARTICULATION JOINT.....103
 KNOB.....15, 17

L

LABEL.....111
 Label.....13, 111, 113
 LABEL,GENIE DECAL.....113
 Ladder.....31
 Last.....23
 LATCH.....23
 Left Mud-Guard.....31
 Level Indicator.....121
 LEVER.....69, 75
 Lever.....49, 69
 Licence Plate Light.....121
 Light.....119, 121
 LIGHT SWITCH LEVER.....15
 Limit Switch.....23
 LOAD CELL.....19
 LOAD HOLDING VALVE / LIFT.....77
 Lock.....11, 15, 23

LOCK,DOOR.....13
 LOCK,ENGINE COVER.....33, 35
 Lower Door.....13

M

MALE QUICK COUPLER.....93
 Manifold.....93, 101, 105, 109
 MEB HOSE CLAMP,19X28.....17
 Micro-Switch.....127
 MIRROR,COMPLETE.....11
 Module (Seal Kit PN:07.0741.0222).....41
 MOTOR,WIPER.....11
 MUD-GUARD RH.....31, 33, 35

N

NAME PLATE.....17
 Name Plate.....83
 NIPPLE.....41, 43, 93
 NON-SKID TREAD.....13
 NUT.....53, 55, 65, 67, 75
 Nut.....11, 13, 49, 55, 67, 69, 109
 NUT,M8 UNI 7473 6S ZN.....33, 35, 45, 77, 109
 NUT,M8,UNI 5588 6S ZN.....119
 NUT,PROTECTION.....11, 13
 NUT,STOP,M10 UNI 7473 6S ZN.....23, 29, 31, 33, 35, 87, 97, 99, 101, 105
 NUT,STOP,M12 UNI 7473 6S ZN.....77, 83, 85, 95
 NUT,STOP,M14 UNI 7473 6S ZN.....31, 33, 35, 97
 NUT,STOP,M20 UNI 7473 6S ZN.....31
 NUT,STOP,M22 UNI 7473 6S ZN.....31, 33, 35
 NUT,STOP,M5 UNI 7473 6S ZN.....103
 NUT,STOP,M6 UNI 7473 6S ZN.....31, 33, 35, 89, 93, 103

O

O-RING.....43, 53, 55, 57, 65, 67, 69, 75, 85, 87
 Oil Filter.....97
 OIL FILTER,CARTRIDGE.....109
 OIL LEVEL INDICATOR.....109
 Oil Tank.....109

P

Panel.....13, 15
 PEDAL.....103
 PILOT LIGHT.....21
 Pilot Light.....127
 PILOT LIGHT/GLASS.....15, 21
 PILOT LIGHT/LAMP.....15
 PIN.....55, 67
 Pin.....13, 23, 29, 31, 33, 35, 49, 53, 65, 77, 83, 85, 87, 89, 93, 95
 PINION,DIFFERENTIAL.....55, 67
 Pipe.....45, 85, 87, 91
 PIPE FITTING.....43, 93, 107, 109
 Pipe Fitting.....17, 25, 41, 43, 45, 77, 85, 87, 97, 99, 107, 109
 PIPE FITTING,90 A207140-2121.....93
 PIPE FITTING,FMF+L 1/2 BSP.....93
 PIPE FITTING,MFK 90 1/2 BSP.....93
 PIPE FITTING-NIPPLE.....43
 PIPE FITTING/WHEEL STUD.....45
 PIPE,HEATER 0.6X0.9.....17
 Piston.....57, 69, 75
 Pivoting Beacon.....125
 Plain Washer.....97, 121

Part Description Index (continued)

Plate.....31, 33, 35, 49, 83
 PLATE,COVER.....75
 PLATE,LOCKING.....55, 67
 PLUG.....11, 51, 55, 57, 61, 63, 67, 69, 73, 75
 Plug.....13, 15, 25, 45, 109
 PLUG,1/2 BSP.....31
 PLUG,BREATHER.....51, 63
 PLUG,MAGNET.....51, 55, 63, 67, 75
 PLUG/STOPPER.....75
 POWER STEERING DIRECTION.....39
 PRESSURE SWITCH.....119
 PRESSURE TUBE.....25, 43
 PROTECTION.....97
 Protection.....15, 31
 PROX SWITCH.....129
 Proximity Switch.....75, 117, 119, 121
 PUFFER/INSULATOR.....99, 109
 Pulley.....49
 PUMP.....109
 Pump.....39
 PUMP BRAKE.....45
 PUSH BUTTON.....15
 Push Button.....15, 49
 PUSHBUTTON HEAD.....121

R

RADIATOR CAP, GTH5519.....99
 Radiator Core.....99
 REAR COVER.....39
 Rear Steering Axle.....47
 Rear Support.....31, 33, 35
 REDUCER,D48.5.....17
 Reinforcement.....13
 RELAY.....115, 117, 123, 127
 Relay.....123, 127
 Right Attachment.....31
 Right Mud-Guard.....33, 35
 RIM.....47
 RING GEAR.....55, 67
 Ring Nut.....53, 65
 Rivet.....15
 RIVETTO A STRAPPO.....83
 ROD.....75
 ROOF COVERING.....13
 Rubber.....11, 13
 RUBBER HOSE.....97, 99
 Rubber Hose.....97, 99
 RUBBER PIPE.....105
 Rubber Platform.....13

S

SATELITE.....53
 Satellite.....53, 65
 SCREW.....11, 17, 19, 23, 31, 33, 35, 39, 45,
 49, 55, 67, 75, 85, 87, 91, 93, 121
 Screw.....11, 13, 15, 23, 31, 33, 35, 49, 53, 55,
 57, 59, 65, 67, 69, 71, 75, 87, 97, 119, 121
 Screw TE M8 X 20 UNI 5739 8.8 ZN.....25, 49,
 87, 93, 99, 105
 Screw TE M8 X 30 UNI 5739 8.8 ZN.....33, 35
 Screw TE M8 X 40 UNI 5739 8.8 ZN.....33, 35,
 45, 77
 Screw TE M8 X 50 UNI 5739 8.8 ZN.....33, 35
 SCREW, 8.8 HCS 10MM-1.5X80Z.....87
 SCREW, 8.8 HCS 8MM1.25X100Z.....49
 SCREW, M6X25 SHCS Z.....85, 87, 91
 SCREW,8.8HCM20-2.5X240Z PT.....31, 33, 35
 SCREW,8.8HCS 12MM1.75X100Z.....85

SCREW,BLEEDER M8X1.25.....27
 SCREW,FE TGS T M6X25 UNI ZN.....11, 15
 SCREW,FL,TE,M8X20 8.8 ZN.....31, 33, 35
 SCREW,KN TC 3.5X16 ZN.....17
 SCREW,KN TC 4.2X9.5 ZN.....13, 17
 SCREW,RING GEAR.....53, 65
 SCREW,STEERING ADJUST.....55, 67
 SCREW,TCEI,M6X30 UNI 8.8 ZN.....37, 39
 SCREW,TCEI,M8X40 UNI 8.8ZN.....25
 SCREW,TCEI,M8X50 UNI 8.8ZN.....77, 95
 SCREW,TE M10X60 UNI 8.8 ZN.....23, 33, 35,
 85
 SCREW,TE M6X30.....11
 SCREW,TE,M0X90 UNI 5737 8.8,ZN.....87
 SCREW,TE,M10X25 UNI 8.8 ZN.....33, 35, 81,
 93
 SCREW,TE,M10X30 UNI 8.8 ZN.....31, 81, 97,
 101
 SCREW,TE,M10X35 UNI 8.8 ZN.....19, 79, 97
 SCREW,TE,M10X50 UNI 8.8 ZN.....31, 79, 81,
 99, 101
 SCREW,TE,M10X70 UNI 8.8 ZN.....29
 SCREW,TE,M12X120 UNI 8.8 ZN.....77
 SCREW,TE,M12X25 UNI 8.8 ZN.....77
 SCREW,TE,M12X35 UNI 8.8 ZN.....97
 SCREW,TE,M12X40 UNI 8.8 ZN.....43, 97
 SCREW,TE,M12X80 UNI 8.8 ZN.....83
 SCREW,TE,M12X90 UNI 8.8 ZN.....95
 SCREW,TE,M14X100 UNI 8.8 ZN.....97
 SCREW,TE,M14X130 UNI 8.8 ZN.....31
 SCREW,TE,M14X25 UNI 8.8 ZN.....87
 SCREW,TE,M14X45 UNI 8.8 ZN.....31, 33, 35
 SCREW,TE,M16X35.....23
 SCREW,TE,M5X20 UNI 8.8 ZN.....103
 SCREW,TE,M6X10 UNI 8.8 ZN.....25
 SCREW,TE,M6X20 UNI 8.8 ZN.....19, 93
 SCREW,TE,M6X40 UNI 8.8 ZN.....89
 SCREW,TSPEI,M6X16 UNI 10.9 ZN.....27
 SCREW/BOLT / BOOM WEAR PAD.....81, 105,
 109
 SCREW/BOLT / WEAR PAD.....81
 SEAL.....55, 57, 67, 69, 75, 77, 95
 Seal.....11, 13, 39, 43, 75, 87, 99, 109
 SEAL / DIFFERENTIAL.....51, 55, 63, 67
 SEAL HURTH.....69
 SEAL KIT.....29, 95
 Seal Kit, Please See the Note.....77
 SEAL RING.....75
 SEAL,ADHESIVE.....11, 13
 SEAL,DIFFERENTIAL.....53, 65
 SEAL,DOOR.....13
 SEAL/BACK-UP RING.....57, 69
 Seat.....13
 SECURITY DOWEL 5519.....83
 Selector.....15
 Selector Fork.....75
 Selector Shaft.....75
 SENSOR.....105
 SENSOR,PRESSURE,HYD OIL.....121
 SENSOR,PROXIMITY.....49
 SENSOR,TEMP,HYD OIL.....109
 SHAFT.....75
 Shaft.....75
 SHAFT,TIE ROD.....59, 71
 Sheet.....75
 SHIM 0.10MM.....75
 SHIM 0.15MM.....75
 SHIM 0.20MM.....75
 SHIM 0.30MM.....75

SHIM 0.40MM.....75
 SLEEVE.....75
 Sleeve.....105
 SLIDING GUIDE.....75
 Sliding Guide.....79, 81
 SLIGHT CLAMP,DN50/70 LG12.....99
 SNAP RING.....51, 55, 63, 67
 Snap Ring.....53, 55, 65, 67
 SOLENOID.....43
 Solenoid.....25, 41
 SOLENOID (07.0701.0290).....43
 SOLENOID VALVE.....37, 39
 Solenoid Valve.....37, 43
 SPACER.....53, 65
 Spacer.....11, 53, 55, 65, 69, 75, 79
 SPEED LEVER.....15
 SPHERE.....75
 SPLIT PIN.....75
 Split Pin.....13
 SPRING.....57, 69, 75
 Spring.....15, 49, 57, 69
 SPRING CLIP,M8.....31, 33, 35
 SPRING SPLIT PIN,WIRE,D4.....23, 83
 SPRING WASHER.....23, 49, 87, 109
 Spring Washer.....75, 87, 97, 119
 SPRING WASHER,D6.....27, 31, 33, 35
 Stabilizer.....29
 Steering Column.....39
 Steering Wheel.....39
 Stop.....11
 Stop Belt.....13
 STOP NUT.....11, 13, 17
 Stop Nut.....11, 13, 23, 33, 35, 49
 STOPPER HEAD.....109
 Storage Pocket.....11
 Stud.....55, 67
 STUD,DRIVE AXLE.....55, 67
 SUPPORT.....33, 35
 Support.....11, 13, 15, 23, 33, 35, 49, 55, 61,
 67, 73, 79, 81, 97, 99, 105, 125
 Support Casing.....33, 35
 SUPPORT,RING GEAR.....55, 67
 Swaying Cylinder.....25
 SWITCH.....21
 Switch.....15, 21
 Switch Cover.....15
 SWITCH,SECURITY.....129
 SWITCH,SELECTOR,3 POSITION.....21
 SWITCH,STEERING MODE.....21

T

Tank.....11
 TANK CAP.....31, 109
 THICKNESS.....55, 67
 Thickness.....79, 81
 THREADED ELEMENT.....69
 Through Coupling.....11, 85
 TIRE 405/70-24 14PR R1.....47
 TIRE 405/70/20 OPTION.....47

U

U JOINT.....47
 UNION.....39, 109
 Upper Door Complete.....13

V

VALVE.....43, 87, 93
 Valve.....25, 41, 87

VALVE / FORK BALANCING.....95
 VALVE BLOCK.....85
 VALVE,1" PA 8.....107
 VALVE,5 BAR.....95
 VALVE,CB (53.0700.0303).....27
 VALVE,MANUAL,BEARING 2".....109
 VALVE,SOLENOID,DEUTZ TCD4.1.....37

W

WASHER.....11, 13, 15, 17, 31, 55, 65, 67, 75,
 87, 109
 Washer.....11, 13, 15, 25, 45, 49, 75, 83, 109
 WASHER 6.4X12.....11, 13, 17
 WASHER 6.5X18.....11, 13, 17
 WASHER,BRASS.....29, 31, 85, 87
 WASHER,D.14/20X1.5.....45
 WASHER,D10 UNI 6592 ZN.....19, 31, 99, 101,
 105
 WASHER,D10 UNI 6593 ZN.....23, 31, 33, 35,
 93, 99, 109
 WASHER,D12 UNI 6592 ZN.....97
 WASHER,D12 UNI 6593 ZN.....31
 WASHER,D14 UNI 6592 ZN.....31, 33, 35, 49,
 97
 WASHER,D16 UNI 6592 ZN.....23, 31
 WASHER,D20 UNI 6592 ZN.....23, 31
 WASHER,D5 UNI 6592 ZN.....103
 WASHER,D6 UNI 6592 ZN.....31, 33, 35, 45,
 93, 97, 121
 WASHER,D8 UNI 6592 ZN.....25, 33, 35, 49
 WASHER,D8 UNI 6593 ZN.....33, 35, 87, 93,
 99, 105, 109
 WASHER,FRICTION.....53, 65
 WASHER,JC 27,SP2,5.....43, 109
 WASHER,SPRING,D10 ZN.....33, 35, 79, 81,
 93, 101, 105
 WASHER,SPRING,D12 ZN.....43, 49, 77, 97
 WASHER,SPRING,D14 ZN.....19, 87
 WASHER,SPRING,D16 ZN.....23
 WASHER,SPRING,D6 ZN.....19, 25, 93, 121
 WASHER,SPRING,D8 ZN.....25, 87, 93, 99
 WASHER/UNION.....109
 WATER LEVEL,CIRCULAR BUBBLE.....15
 WATER TAP,D16 C/POMELLO.....17
 Wheel.....47
 WHEEL STUD.....55, 67
 Wheelstud.....45
 WIPER ARM.....11
 WIPER BLADE.....11
 Wiper Blade.....11
 Wiper Motor.....11
 Wiring Harness.....19, 117, 119, 121, 123, 125,
 127

Fitting Cross References

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
12342	6-4 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	42794	1 CR-S	ELBOW,90°,MALE PIPE
13757	4 R6X-S	RUN TEE,SWIVEL NUT,ORFS	42795	BV-0839	BALL VALVE
19685	12-10 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42796	BV-0838	BALL VALVE
22664	12-10 C5OX	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42874	6-8 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
27431	8-12 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	42912	13943-6-4	HOSE END,90° FEMALE SWIVEL,JIC
28678	AS-B-33	SLEEVE,NYLON,1.81" ID	42920	BV-0840	BALL VALVE,90°
39871	6 WETX-WLN-S	UNION,90° BULKHEAD W/NUT,FLARE TUBE	42932	AS-B-17	SLEEVE,NYLON,1.22" ID
39872	4 R5OX-S	RUN TEE,STRAIGHT THREAD	42936	10243-2-4	HOSE END,FEMALE PIPE
39873	6 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42953	1/2 DD-S	ELBOW,90°,FEMALE PIPE
39874	8-6 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42956	6 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS
39875	4-6 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	45349	8 V5OX-S	ELBOW,45°,STRAIGHT THREAD TO FLARE TUBE
39876	6-8 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	45351	4 V5OX-S	ELBOW,45°,STRAIGHT THREAD TO FLARE TUBE
39877	4 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	47223	10343-6-6	HOSE END,MALE,JIC
39878	6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	47419	PS690503-6-6	SWIVEL,90°,STRAIGHT THREAD TO 37° FLARE
39879	4-8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	48750	421-4	HOSE,1/4 INCH ID
39880	6-10 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	48751	481TC-4	HOSE,1/4 INCH ID
39881	4-6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	48752	482TC-4	HOSE,1/4 INCH ID
39882	4-HP5ON-S	PLUG,STRAIGHT THREAD	48753	451TC-6	HOSE,3/8 INCH ID
39883	8-8 FTX-S	CONNECTOR,MALE PIPE TO FLARE TUBE	48754	482TC-6	HOSE,3/8 INCH ID
39885	269HB 12-12	ELBOW,90°,BEADED HOSE BARB TO MALE PIPE	48755	381-6	HOSE,3/8 INCH ID
39886	431-6	HOSE,3/8 INCH ID	48756	451TC-8	HOSE,1/2 INCH ID
39887	540N-2	HOSE,1/8 INCH ID	48757	482TC-8	HOSE,1/2 INCH ID
39888	801-8	HOSE,1/2 INCH ID	48758	381-8	HOSE,1/2 INCH ID
39889	801-12	HOSE,3/4 INCH ID	48759	381-10	HOSE,5/8 INCH ID
39890	10643-6-6	HOSE END,FEMALE SWIVEL,JIC	48760	451TC-10	HOSE,5/8 INCH ID
39891	13943-6-6	HOSE END,90° FEMALE SWIVEL,JIC	48761	482TC-12	HOSE,3/4 INCH ID
39892	13743-6-6	HOSE END,45° FEMALE SWIVEL,JIC	48762	451TC-12	HOSE,3/4 INCH ID
39894	30682-8-8	HOSE END,FEMALE SWIVEL,JIC	48763	772-12	HOSE,3/4 INCH ID
39895	30682-10-12	HOSE END,FEMALE SWIVEL,JIC	48764	881-16	HOSE,1 INCH ID
42286	8-8 CTX-S	ELBOW,90°,MALE PIPE TO FLARE TUBE	48765	772-16	HOSE,1 INCH ID
42756	8-12 CLO-S	ELBOW,90,MALE PIPE TO ORFS	48766	AS-B-15	SLEEVE,NYLON,1.06" ID
42757	8-12 FLO-S	CONNECTOR,MALE PIPE TO ORFS	48767	AS-B-22	SLEEVE,NYLON,1.42" ID
42758	4 JLO-S	UNION TEE,ORFS	48770	881-8	HOSE,1/2 INCH ID
42759	4-4 FLO-S	CONNECTOR,MALE PIPE TO ORFS			
42760	6-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS			
42761	1J143-6-4	HOSE END,90° FEMALE SWIVEL,SEAL LOK			
42762	1J743-6-4	HOSE END,45° FEMALE SWIVEL,SEAL LOK			
42768	1JO43-4-4	HOSE END,MALE,SEAL LOK			
42776	601-8	HOSE,1/2 INCH ID			
42777	1J743-16-16	HOSE END,45° FEMALE SWIVEL,SEAL LOK			
42786	16 CLO-S	ELBOW,90°,MALE PIPE TO ORFS			
42787	16 R6LO-S	RUN TEE,SWIVEL NUT,ORFS			
42788	16-8 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS			
42789	6-6 CLO-S	ELBOW,90°,MALE PIPE TO ORFS			
42790	8-10 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			
42791	3/4 CD-S	ELBOW,90°,MALE TO FEMALE PIPE			
42792	3/4 X 1/2 PTR-S	REDUCER,MALE TO FEMALE PIPE			
42793	1/2 CR-S	ELBOW,90°,MALE PIPE			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description
48771	881-10	HOSE, 5/8 INCH ID
48772	381-4	HOSE, 1/4 INCH ID
48773	AS-B-13	SLEEVE, NYLON, .86" ID
48800	1JC43-4-4	HOSE END, FEMALE SWIVEL, SEAL LOK
48801	1J743-4-4	HOSE END, 45° FEMALE SWIVEL, SEAL LOK
48802	1J943-4-4	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48804	1JM43-4-4	HOSE END, MALE, SEAL LOK, NO O-RING
48805	10643-4-4	HOSE END, FEMALE SWIVEL, JIC
48806	13943-4-4	HOSE END, 90° FEMALE SWIVEL, JIC
48807	1JS43-4-4	HOSE END, FEMALE SWIVEL, SEAL LOK
48808	3JC82-8-8	HOSE END, FEMALE SWIVEL, SEAL LOK
48809	3JC82-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
48810	1JC43-6-4	HOSE END, FEMALE SWIVEL, SEAL LOK
48811	1J943-6-4	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48812	1JC43-6-6	HOSE END, FEMALE SWIVEL, SEAL LOK
48813	1J143-6-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48814	1J543-6-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48815	1J743-6-6	HOSE END, 45° FEMALE SWIVEL, SEAL LOK
48816	1J943-6-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48817	1JS43-6-8	HOSE END, FEMALE SWIVEL, SEAL LOK
48818	1J943-8-4	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48819	1JC43-8-6	HOSE END, FEMALE SWIVEL, SEAL LOK
48820	1J743-8-6	HOSE END, 45° FEMALE SWIVEL, SEAL LOK
48821	1J943-8-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48822	1JC43-8-8	HOSE END, FEMALE SWIVEL, SEAL LOK
48823	1JS43-8-8	HOSE END, FEMALE SWIVEL, SEAL LOK
48824	1J143-8-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48825	1J543-8-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48826	1J743-8-8	HOSE END, 45° FEMALE SWIVEL, SEAL LOK
48827	1J943-8-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48828	1JC43-10-8	HOSE END, FEMALE SWIVEL, SEAL LOK
48829	1JS43-10-8	HOSE END, FEMALE SWIVEL, SEAL LOK
48830	1J743-10-8	HOSE END, 45° FEMALE SWIVEL, SEAL LOK
48831	1J943-10-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48833	1JC43-10-10	HOSE END, FEMALE SWIVEL, SEAL LOK
48834	1J943-10-10	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48835	1JS43-10-12	HOSE END, FEMALE SWIVEL, SEAL LOK
48836	1JC43-12-8	HOSE END, FEMALE SWIVEL, SEAL LOK
48837	1JS43-12-8	HOSE END, FEMALE SWIVEL, SEAL LOK
48838	1J743-12-8	HOSE END, 45° FEMALE SWIVEL, SEAL LOK
48839	1J943-12-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48840	1J943-12-10	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48841	1JC43-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
48842	1JO43-12-12	HOSE END, MALE, SEAL LOK
48843	1J143-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48844	1J543-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48845	1J743-12-12	HOSE END, 45° FEMALE SWIVEL, SEAL LOK
48846	1J943-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK

Genie PN	Parker PN	Description
48847	13943-12-12	HOSE END, 90° FEMALE SWIVEL, JIC
48848	10543-12-12	HOSE END, MALE, STRAIGHT THREAD
48849	1JC71-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
48850	1JS71-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
48851	1J171-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48852	1J771-12-12	HOSE END, 45° FEMALE SWIVEL, SEAL LOK
48853	1J971-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48854	1JC43-16-16	HOSE END, FEMALE SWIVEL, SEAL LOK
48855	1J943-16-16	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48856	1J171-16-16	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48857	1J971-16-16	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48859	1JS43-8-4	HOSE END, FEMALE SWIVEL, SEAL LOK
48867	PD36BTL	DIAGNOSTIC NIPPLE, SEAL-LOK SWIVEL
48873	6 PNLO-S	PLUG, TUBE END, ORFS
48874	6 PNTX-S	PLUG, FLARE TUBE
48875	6 R6LO-S	RUN TEE, SWIVEL NUT, ORFS
48877	4 F5OLO-SW.025	CONNECTOR, STRAIGHT THREAD TO ORFS, W/.025 ORI
48878	16-12 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS
48879	8 C6LO-S	ELBOW, 90°, SWIVEL NUT ORFS
48880	PD6-285	CAP, DIAGNOSTIC NIPPLE
48881	6 HLO-S	UNION, ORFS
48883	8 P5ON-S	PLUG, STRAIGHT THREAD
48884	8M18F87OMLO-S	CONNECTOR, METRIC, STRAIGHT THREAD TO ORFS
48885	4 WGTX-WLN-S	CONNECTOR, BULKHEAD, FEMALE PIPE TO FLARE TUBE
48886	4 F5OLO-SW/2MM	CONNECTOR, MACHINED STRAIGHT THREAD TO ORFS
48887	4 CTX-S	ELBOW, 90°, MALE PIPE TO FLARE TUBE
48888	10-12 V5OLO-S	ELBOW, 45°, STRAIGHT THREAD TO ORFS
48890	4 S5OLO-S	BRANCH TEE, STRAIGHT THREAD TO ORFS
48891	4 S6LO-S	BRANCH TEE, SWIVEL NUT TO ORFS

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
48892	6 C6LO-S	ELBOW,90°,SWIVEL NUT ORFS	48938	8 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48893	6 F5OHAQ-S	UNION,STRAIGHT THREAD	48939	8 S6LO-S	BRANCH TEE,SWIVEL NUT TO ORFS
48894	8 WLO-WLNL-S	UNION,BULKHEAD,ORFS	48940	8 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48895	DT-370-MSMO-5	VALVE,CHECK	48941	8-4 TRLO-S	REDUCER,TUBE END TO SWIVEL,ORFS
48896	6 JLO-S	UNION,TEE,ORFS	48942	8-6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48897	DT-750-MSMS-5	VALVE,CHECK	48943	8-6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48898	DT-750-MOMS-5	VALVE,CHECK	48944	8-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48899	DT-620-MOMS-5	VALVE,CHECK	48945	8 FTX-S	CONNECTOR,MALE PIPE TO FLARE TUBE
48900	4-6 F5OLO-SW/.035	CONNECTOR,STRAIGHT THREAD TO ORFS, W/.035 ORI	48946	8-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48902	16-1 AOE4G-S	ELBOW,90° LONG,FEMALE PIPE TO STRAIGHT THREAD	48947	8-12 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48903	1 FF-S	NIPPLE,PIPE	48948	8-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48904	4 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48949	8-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48905	4 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48950	10 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48906	4 R5OLO-S	RUN TEE,STRAIGHT THREAD	48951	10 CC5OLO-S	ELBOW,90° LONG,STRAIGHT THREAD TO ORFS
48907	4 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	48952	10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48908	4 R6LO-S	RUN TEE,SWIVEL NUT,ORFS	48953	10 R5OLO-S	RUN TEE,STRAIGHT THREAD
48909	4 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS	48954	10 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48910	4 GTX-S W/.030	CONNECTOR,FEMALE PIPE TO FLARE TUBE	48955	10 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48911	4-6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48956	10-4 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48912	4-6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48957	10-6 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48913	4-6 F5OLO-SW/.030	CONNECTOR,STRAIGHT THREAD TO ORFS, W/.030 ORI	48958	10-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48914	4-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48959	12 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48915	6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48960	12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48916	6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48961	12 R5OLO-S	RUN TEE,STRAIGHT THREAD
48917	6 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS	48962	12 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48918	6 R5OLO-S	RUN TEE,STRAIGHT THREAD	48963	12 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48919	6 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS	48964	12 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48920	6 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	48965	12 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
48921	6 FLO-S	CONNECTOR,MALE PIPE TO ORFS	48966	12 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48922	6-6 FLO-S	CONNECTOR,MALE PIPE TO ORFS	48967	12 JLO-S	UNION TEE,ORFS
48923	6 P5ON-S	PLUG,STRAIGHT THREAD	48968	12 WLO-WLNL-S	UNION,BULKHEAD,ORFS
48925	6 WELO-S	UNION,90° BULKHEAD,ORFS	48969	12 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48926	6-4 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48970	12 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS
48927	6-4 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48928	6-4 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			
48929	6-8 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS			
48930	6-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48931	6-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48932	8 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS			
48933	8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48934	8 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS			
48935	8 R5OLO-S	RUN TEE,STRAIGHT THREAD			
48936	8 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS			
48937	8 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
48971	12 G5G5JG5-S	TEE,FEMALE STRAIGHT THREAD	49612	PKT02586	O-RING KIT (ORFS FITTINGS)
48972	12 XHL6-S	ADAPTER, 37° MALE TO SWIVEL ORFS	49613	PKT06276	PLUG AND CAP KIT-SERVICE,ORFS
48973	12-1/2 F5OG-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD	49728	10143-12-12	HOSE END, MALE PIPE
48974	12-10 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	49729	16-1 F5OG-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD
48975	12-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	49814	12-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48976	12-16 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	49829	DT-500-MOMF-5	VALVE,CHECK
48977	12-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	49831	881-12	HOSE,3/4 INCH ID
48978	12-16 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	49834	16 JLO-S	UNION TEE,ORFS
48980	12-16 FLO-S	CONNECTOR,MALE PIPE TO ORFS	49838	12-8 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48983	16 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	49840	8 JLO-S	UNION TEE,ORFS
48984	16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	49844	10-8 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48985	16 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	49854	8 P5ON-S	PLUG,STRAIGHT THREAD
48986	16 FLO-S	CONNECTOR,MALE PIPE TO ORFS	49855	1JC43-16-12	HOSE END,FEMALE SWIVEL,SEAL LOK
48988	16 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	49859	4 P5ON-S	PLUG,STRAIGHT THREAD
48989	12 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	49861	4 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS
48990	8 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	49867	12-3/4 F5OG-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD
48991	16-12 FLO-S	CONNECTOR,MALE PIPE TO ORFS	51152	6 R6X-S	RUN TEE,SWIVEL NUT,ORFS
48992	16-12 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	51153	6-4 TRTX-S	REDUCER,TUBE END TO SWIVEL,ORFS
48993	XV501-12	BALL VALVE	51154	4-4 GTX	CONNECTOR,FEMALE PIPE TO FLARE TUBE
48994	XV501-16	BALL VALVE	51264	881-12	HOSE,3/4 INCH ID
48995	XV510P-12	BALL VALVE	51265	8 JLO-S	UNION TEE,ORFS
48996	XV510P-16	BALL VALVE	51508	6 BTX-S	NUT,FLARE TUBE
48997	PD341	DIAGNOSTIC NIPPLE, STRAIGHT THREAD	51580	12-8 TRLO-BL-S	TUBE END REDUCER,ORFS
48998	PD 361	DIAGNOSTIC NIPPLE, STRAIGHT THREAD	51628	6 R6X-S	RUN TEE,SWIVEL NUT,ORFS
48999	DT-500-MOMS-5	VALVE,CHECK	51735	3/8 HHP	PLUG,PIPE THREAD
49201	10 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	51803	1J943-6-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK
49202	1JC43-12-10	HOSE END,FEMALE SWIVEL,SEAL LOK	53023	125HBL-5-4	FITTING,HOSE BARB TO MALE PIPE
49203	10-8 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	53497	PKT02585	O-RING KIT
49205	6 F5OHAO-S	UNION,STRAIGHT THREAD	53499	1JC71-16-16	HOSE END,FEMALE SWIVEL,SEAL LOK
49207	PD34BTL	DIAGNOSTIC NIPPLE,SEAL-LOK SWIVEL	53500	3-904	O-RING,STRAIGHT THREAD,-4
49209	8M18F870MX-S	CONNECTOR,METRIC,STRAIGHT THREAD TO FLARE TUBE	53501	3-906	O-RING,STRAIGHT THREAD,-6
49212	8 WGTX-WLN-S	CONNECTOR,BULKHEAD,FEMALE PIPE TO FLARE TUBE	53502	3-908	O-RING,STRAIGHT THREAD,-8
49213	30682-8-8	HOSE END,FEMALE SWIVEL,JIC	53503	3-910	O-RING,STRAIGHT THREAD,-10
49216	831-8	HOSE,1/2 INCH ID			
49217	33982-8-8	HOSE END,90° FEMALE SWIVEL,JIC			
49219	PS-B-35	SLEEVE,NYLON,2.19" ID			
49418	4-6 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			
49511	DT370-MOMS-5	VALVE,CHECK			
49512	1 DD-S	ELBOW,90°,FEMALE PIPE			
49513	1 FF-S	NIPPLE,PIPE			
49514	10 HP5ON-S	PLUG,STRAIGHT THREAD			
49515	12-16 CLO-S	ELBOW,90°,MALE PIPE TO ORFS			
49517	6 HP5ON-S	PLUG,STRAIGHT THREAD			
49519	16-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
49520	4 VTX-S	ELBOW,45°,MALE PIPE TO FLARE TUBE			
49530	16 C6LO-S	ELBOW,90°,SWIVEL NUT ORFS			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
53535	3-912	O-RING, STRAIGHT THREAD, -12	61083	24 F5OLO-S	CONNECTOR, STRAIGHT THREAD TO ORFS
53536	4-PNLO-S	PLUG, TUBE END, ORFS	61086	20 R5OLO-S	RUN TEE, STRAIGHT THREAD
53537	6 PNLO-S	PLUG, TUBE END, ORFS	61090	24-20 F5OLO-S	CONNECTOR, STRAIGHT THREAD TO ORFS
53538	8 PNLO-S	PLUG, TUBE END, ORFS	61091	1J943 24-24	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
53539	10 PNLO-S	PLUG, TUBE END, ORFS	61093	1J978-12-12	HOSE END, 90° FEMALE SWIVEL, JIC
53540	12 PNLO-S	PLUG, TUBE END, ORFS	61095	1JS43-20-16	HOSE END, FEMALE SWIVEL, SEAL LOK
53946	129HB-5-4	FITTING, 90° HOSE BARB TO MALE PIPE	61100	811-24	HOSE, 1 1/2 INCH ID
53951	8-1/4F5OG-S	ADAPTER, FEMALE PIPE TO STRAIGHT THREAD	61130	1JS43-24-24	HOSE END, FEMALE SWIVEL, SEAL LOK
53980	6 S6LO-S	BRANCH TEE, SWIVEL NUT TO ORFS	61131	1JS78 12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
54132	4 C6LO-S	ELBOW, 90°, SWIVEL NUT ORFS	61132	1J778-12-12	HOSE END, 45° FEMALE SWIVEL, JIC
54135	11343-16-16	HOSE END, MALE SWIVEL, PIPE	61152	139HB-6-4	ELBOW, 45°, BARB TO MALE PIPE
54283	8-10 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS	61251	BV-0750	BALL VALVE
54428	8M18C87OMLO-S	ELBOW, 90° METRIC, STRAIGHT THREAD TO ORFS	61259	4 CC5OLO-S	ELBOW, 90° LONG, STRAIGHT THREAD TO ORFS
54803	FS-F-16-10	SLEEVE, FIRE, .96" ID	61260	20-12 TRLO-BL	REDUCER, TUBE END TO SWIVEL, ORFS
54954	10143-2-4	HOSE END, MALE PIPE	61262	12 C6LO-S	ELBOW, 90°, SWIVEL NUT ORFS
55190	3/8 HP-S	PLUG, PIPE THREAD	61263	20 F5OHAO-S	UNION, STRAIGHT THREAD
55448	8 HLO-S	UNION, ORFS	61264	6-10 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS
55839	6 F65OX-S	CONNECTOR, STRAIGHT THREAD TO 37° SWIVEL	61265	6 WNLO-WLNL-S	UNION, BULKHEAD 45°, ORFS
55968	10 C5OX-S	ELBOW, 90°, STRAIGHT THREAD TO FLARE TUBE	61268	4 WNLO-WLNL-S	UNION, BULKHEAD 45°, ORFS
56003	6 CC5OLO-S	ELBOW, 90° LONG, STRAIGHT THREAD TO ORFS	61269	4 WLO-WLNL-S	UNION, BULKHEAD, ORFS
56166	BV-0837	BALL VALVE, 90°	61272	12 AOEL6	ELBOW, 90°, STRAIGHT THREAD TO ORFS SWIVEL
56188	10143-8-6	HOSE END, MALE PIPE	61316	482TC-16	HOSE, 1 INCH ID
56233	2-011	O-RING, ORFS, -4	61321	6 JLO-S	UNION TEE, ORFS
56234	2-012	O-RING, ORFS, -6	61327	782-12	HOSE, 3/4 INCH ID
56235	2-014	O-RING, ORFS, -8	61328	881-24	HOSE, 1 1/2 INCH ID
56236	2-016	O-RING, ORFS, -10	61336	11943-20-24	HOSE END, 90° FLANGE HEAD
56237	2-018	O-RING, ORFS, -12	61345	12 WJJLO-WLNL-S	RUN TEE, BULKHEAD, ORFS
56238	2-021	O-RING, ORFS, -16	61346	8 WNLO-WLNL-S 4	UNION, BULKHEAD 45°, ORFS
56352	6 WLNL-S	LOCKNUT, BULKHEAD	61569	33782-8-8	HOSE END, 45° FEMALE SWIVEL, JIC
56353	3J782-12-12	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	61610	12 FF5OLO-S	CONNECTOR, LONG, STRAIGHT THREAD TO ORFS
56354	3J982-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	61742	1/8 X 1.5 FFF	NIPPLE, PIPE
56604	10-8 F5OLO-S	CONNECTOR, STRAIGHT THREAD TO ORFS	63426	8 PNTX-S	PLUG, FLARE TUBE
56639	3JC82-10-10	HOSE END, FEMALE SWIVEL, SEAL LOK			
56640	3J982-10-10	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
56655	3JC82-8-10	HOSE END, FEMALE SWIVEL, SEAL LOK			
56676	10-8 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS			
56776	471TC-6	HOSE, 3/8 INCH ID			
56777	471TC-8	HOSE, 1/2 INCH ID			
56789	811-16	HOSE, 1 INCH ID			
57884	3/8 FF	NIPPLE, PIPE			
59335	6 FNL-S	CAP, TUBE END			
59342	4 FNL-S	CAP, TUBE END			
59371	8 HP5ON-S	PLUG, STRAIGHT THREAD			
60653	BV-0751	BALL VALVE			
60806	125HB-3-4	FITTING, HOSE BARB TO MALE PIPE			
61064	5-1/4 F5OG-S	ADAPTER, FEMALE PIPE TO STRAIGHT THREAD			
61079	4 WELO-WLNL-S	UNION, 90° BULKHEAD W/NUT, ORFS			
61080	6 WLO-WLNL-S	UNION, BULKHEAD, ORFS			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
64271	4 WLO-WLNL-S	UNION,BULKHEAD,ORFS	75631	801-6	HOSE,3/8 INCH ID
64272	6 WLO-WLNL-S	UNION,BULKHEAD,ORFS	75654	20 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
65776	8 F65OL-S	CONNECTOR,STRAIGHT THREAD TO ORFS SWIVEL	75655	1J943-20-20	HOSE END,90° FEMALE SWIVEL,SEAL LOK
65880	6001012	O-RING KIT	75656	881-20	HOSE,1-1/4 INCH ID
66154	6 WTX-WLNS	UNION,BULKHEAD,FLARE TUBE	75971	8 F5OHAO-S	UNION,STRAIGHT THREAD
66155	6 WETX-S	UNION,BULKHEAD 90°,FLARE TUBE	77307	1JB43-8-8	HOSE END,BULKHEAD,SEAL LOK
66156	6 WLNL-S	BULKHEAD LOCKNUT	77309	8 WLNL-S	BULKHEAD LOCKNUT
66389	6-8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	77379	8M18C87OMX-S	ELBOW,90° METRIC,STRAIGHT THREAD TO FLARE TUBE
66392	6 R5OX-S	RUN TEE,STRAIGHT THREAD	77703	3J982-8-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK
66396	811-12	HOSE,3/4 INCH ID	77711	801-10	HOSE,5/8 INCH ID
66829	H3174PP	CLAMP,TUBE	77758	12 WNLO-WLNL-S	UNION,BULKHEAD 45°,ORFS
67217	4 KLO-S	UNION,CROSS,ORFS	78091	6 C6X-S	ELBOW,90°,SWIVEL NUT TO FLARE TUBE
67339	10-6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	78684	30582-8-8B	HOSE END,PUSH LOK,MALE
67357	13943-8-6	HOSE END,90° FEMALE SWIVEL,JIC	78852	549-2	HOSE,1/8 INCH ID
67358	10 HP5ON-S	PLUG,STRAIGHT THREAD	78855	10657-4-2	HOSE END,FEMALE SWIVEL,JIC
67371	12 S6LO-S	BRANCH TEE,SWIVEL NUT TO ORFS	79138	PS-B-37	SLEEVE,NYLON,2.38" ID
67498	4 FNL-S	CAP, TUBE END	79476	1JS43-6-8	HOSE END,FEMALE SWIVEL,SEAL LOK
67906	DC-370-F0F0-5	VALVE,CHECK	79847	12-3/4 A0EG-S	ELBOW,90°,STRAIGHT THREAD TO FEMALE PIPE
69316	8 FLO-S	CONNECTOR,MALE PIPE TO ORFS	80044	8 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
69333	H3174PP	CLAMP,HYDRAULIC HOSE	80502	8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
69503	4 F65OX-S	CONNECTOR,STRAIGHT THREAD TO 37° SWIVEL	80503	8 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE
69775	8 FNL-S	CAP, TUBE END	81010	AS-B-27	SLEEVE,NYLON,1.63" ID
71038	1/4X1/4F3HG-S	ADAPTER,CONVERSION	83052	821-6	HOSE,3/8 INCH ID
71196	12-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	83053	821-8	HOSE,1/2 INCH ID
71383	1/4 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	83054	821-12	HOSE,3/4 INCH ID
72270	12FNL-S	CAP, TUBE END	83055	30682-6-6	HOSE END,FEMALE SWIVEL,JIC
73436	60C-4	SLEEVE,COMPRESSION	83056	30682-12-12	HOSE END,FEMALE SWIVEL,JIC
73437	61C-4	NUT,COMPRESSION	83057	33782-6-6	HOSE END,45° FEMALE SWIVEL,JIC
73438	33482-4-4B	HOSE END,PUSH LOK,MALE	83058	33982-6-6	HOSE END,90° FEMALE SWIVEL,JIC
73767	1CD-S	ELBOW,90°,MALE TO FEMALE PIPE	83060	33982-12-12	HOSE END,90° FEMALE SWIVEL,JIC
73768	20-16-F5OG5-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD	83063	13743-4-4	HOSE END,45° FEMALE SWIVEL,JIC
73769	16-20 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
74660	6-8 F42EDMLO-S	CONNECTOR,MALE BSPP TO ORFS			
74661	8-8 F42EDMLO-S	CONNECTOR,MALE BSPP TO ORFS			
75007	4 FLO-S	CONNECTOR,MALE PIPE TO ORFS			
75008	1/8 HP-S	PLUG,PIPE THREAD			
75014	1/2 HP-S	PLUG,PIPE THREAD			
75042	8 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS			
75043	3/4 FF-S	NIPPLE,PIPE			
75254	24 F5OHAO-S	UNION,STRAIGHT THREAD			
75255	12 F5OHAO-S	UNION,STRAIGHT THREAD			
75256	XV506P-24	BALL VALVE			
75574	4 WLNL-S	BULKHEAD LOCKNUT			
75612	8 WJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS			
75613	12-8 F5OG5-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD			
75614	8 CC5OLO-S	ELBOW,90° LONG,STRAIGHT THREAD TO ORFS			
75628	1JB43-4-4	HOSE END,BULKHEAD,SEAL LOK			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description
83064	13743-8-8	HOSE END,45° FEMALE SWIVEL,JIC
83065	13743-12-12	HOSE END,45° FEMALE SWIVEL,JIC
83066	13943-8-8	HOSE END,90° FEMALE SWIVEL,JIC
83067	14143-6-6	HOSE END,90° FEMALE SWIVEL,JIC
83068	14143-8-8	HOSE END,90° FEMALE SWIVEL,JIC
83069	14143-12-12	HOSE END,90° FEMALE SWIVEL,JIC
83070	772-8	HOSE,1/2 INCH ID
83071	10671-8-8	HOSE END,FEMALE SWIVEL,JIC
83072	10671-12-12	HOSE END,FEMALE SWIVEL,JIC
83073	13771-8-8	HOSE END,45° FEMALE SWIVEL,JIC
83074	13771-12-12	HOSE END,45° FEMALE SWIVEL,JIC
83075	13971-8-8	HOSE END,90° FEMALE SWIVEL,JIC
83076	13971-12-12	HOSE END,90° FEMALE SWIVEL,JIC
83077	14171-8-8	HOSE END,90° FEMALE SWIVEL,JIC
83078	14171-12-12	HOSE END,90° FEMALE SWIVEL,JIC
83080	13943-16-16	HOSE END,90° FEMALE SWIVEL,JIC
83103	10671-16-12	HOSE END,FEMALE SWIVEL,JIC
83104	10671-10-12	HOSE END,FEMALE SWIVEL,JIC
83112	1JC71-8-8	HOSE END,FEMALE SWIVEL,SEAL LOK
83113	1JS71-16-12	HOSE END,FEMALE SWIVEL,SEAL LOK
83114	1JS71-10-12	HOSE END,FEMALE SWIVEL,SEAL LOK
83115	1J971-8-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK
83116	1J171-8-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK
83117	1J771-8-8	HOSE END,45° FEMALE SWIVEL,SEAL LOK
83127	1J543-6-8	HOSE END,90° FEMALE SWIVEL,JIC
83128	1JC43-6-8	HOSE END,FEMALE SWIVEL,SEAL LOK
87033	12-6 TRLO-S	REDUCER,TUBE END TO SWIVEL,ORFS
87034	3J782-8-8	HOSE END,45° FEMALE SWIVEL,SEAL LOK
87172	12 HP50N-S	PLUG,STRAIGHT THREAD
87185	8 WNLO-WLNL-S	UNION,BULKHEAD 45°,ORFS
87246	4 C6X-S	ELBOW,90°,SWIVEL NUT TO FLARE TUBE
87679	6 LHP-S	FLANGE SEAL FITTING, MALE
87681	6PLS N0702	BONDED SEAL
88100	SR88100	ADAPTER,OIL DRAIN,GM 3.0L
88311	1JS43-20-20	HOSE END,FEMALE SWIVEL,SEAL LOK
88353	20 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
88474	10081-20	Crimp Shell, 1.25"
88475	1988-20-24	HOSE END,90° FLANGE HEAD
88476	JS88-24-24	HOSE END,FEMALE SWIVEL,SEAL LOK
88477	1JC88-20-20	HOSE END,FEMALE SWIVEL,SEAL LOK
88478	811-20	HOSE,11/4 INCH ID
88936	20-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
88937	20-16 FLO-S	CONNECTOR,MALE PIPE TO ORFS
88938	1JC88-16-16	HOSE END,FEMALE SWIVEL,SEAL LOK
88939	1J988-16-16	HOSE END,90° FEMALE SWIVEL,ORFS
88940	811-16	HOSE,1 INCH ID
88944	1J988-20-20	HOSE END,90° FEMALE SWIVEL,ORFS
89403	16 VLO-S	ELBOW,45°,MALE PIPE TO ORFS

Genie PN	Parker PN	Description
89449	6 WJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
89489	4 WJMLO-S	BRANCH TEE,BULKHEAD,ORFS
89551	1JB43-6-6	HOSE END,BULKHEAD,SEAL LOK
89552	1JB43-8-8	HOSE END,BULKHEAD,SEAL LOK
89593	20 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
94161	8-8 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
94358	351TC-12	HOSE,3/4 INCH ID
94418	20 FLO-S	CONNECTOR,MALE PIPE TO ORFS
96358	12 TX-S	SLEEVE,FLARE TUBE
96359	12 BTX-S	NUT,FLARE TUBE
96397	8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
96398	12-8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
96402	10343-6-6	HOSE END,MALE,JIC
96407	30382-6-6B	HOSE END,MALE,JIC

California Proposition 65

Warning

The exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Genie North America

Phone 425.881.1800
Toll Free USA and Canada
800.536.1800
Fax 425.883.3475

Genie Australia Pty Ltd.

Phone +61 7 3375 1660
Fax +61 7 3375 1002

Genie China

Phone +86 21 53852570
Fax +86 21 53852569

Genie Malaysia

Phone +65 98 480 775
Fax +65 67 533 544

Genie Japan

Phone +81 3 3453 6082
Fax +81 3 3453 6083

Genie Korea

Phone +82 25 587 267
Fax +82 25 583 910

Genie Brasil

Phone +55 11 41 665 755
Fax +55 11 41 665 754

Genie Holland

Phone +31 183 581 102
Fax +31 183 581 566

Genie Scandinavia

Phone +46 31 575100
Fax +46 31 579020

Genie France

Phone +33 (0)2 37 26 09 99
Fax +33 (0)2 37 26 09 98

Genie Iberica

Phone +34 93 579 5042
Fax +34 93 579 5059

Genie Germany

Phone +49 (0)4202 88520
Fax +49 (0)4202 8852-20

Genie U.K.

Phone +44 (0)1476 584333
Fax +44 (0)1476 584334

Genie Mexico City

Phone +52 55 5666 5242
Fax +52 55 5666 3241

Distributed By:

Parts Manual

GTH-4013

*from SN 14518 to 17991
from SN 18615 to 18627*

Part No.
645018

Rev D1

