



Parts Manual

Serial Number Range

***Work Platform:
3P/700-REM
4400***

from SN 60980

Part No. 645031

Rev D

March 2012

Technical Publications

Genie has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy.

Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement. All communications will be carefully considered for future printings of this and all other manuals.

Contact Us:




www.genieindustries.com

e-mail: awp.techpub@terex.com

The technical data contained in this document is indicative and not binding, insofar as TEREXLIFT S.r.l reserves the right to make modifications and improvements to its products at any time in order to enhance the quality thereof.

57.0701.9003 Rev A November 2009
First Edition, First Printing



■ WORK PLATFORM IDENTIFICATION PLATE

The work platform identification plate is applied in the rear side of the work platform (see the image here below).

The following data are printed on the identification plate:

- A** type
- B** serial number
- C** year of manufacture
- D** payload
- E** weight

TEREXLIFT s.r.l.	
NAVICELLA PORTAPERSONE AERIAL WORK PLATFORM	
MODELLO TYPE	A
N° SERIE SERIAL N°	B
ANNO DI FABBRICAZIONE YEAR OF MANUFACTURE	C
PORTATA NOMINALE PAY LOAD	D
MASSA MASS	E
CE	

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

Part Number Index.....	48
Part Description Index.....	49

Cross References

How to Read Your Serial Number.....	3
Parts Stocking List.....	7
How to Order Parts.....	8
Service Parts Fax Order Form.....	9

Electronic Version

Click on any page number to view the figure.

100 Decals

101.1 606291 Decals.....	10
--------------------------	----

200 Structure And Frame

201.1 606292 Rail, View 1.....	12
202.1 606293 Rail, View 2.....	14
203.1 606294 Rail, View 3.....	16
204.1 606295 Basement, View 1.....	18
205.1 606296 Basement, View 2.....	20
206.1 606297 Basement Support, EX and Australia Version.....	22
207.1 606298 Basement Support, SR Version.....	24
208.1 606299 Coupling Frame.....	26

300 Hydraulic Part

301.1 606300 Hydraulic Part.....	28
----------------------------------	----

400 Electrical Part

401.1 606301 Coded Proximity Switch.....	30
402.1 606302 Dashboard Support, EX and SR Version.....	32
403.1 606303 Dashboard Support, Australia Version.....	34
404.1 606304 Dashboard, EX, ER and SR Version.....	36
405.1 606305 Dashboard, Australia Version.....	38
406.1 606306 Cable Reel.....	40
407.1 606307 Wirings and Components.....	42

500 Optionals

501.1 606308 Air Compressor And Electrical Line, Part 1...44	
502.1 606309 Air Compressor And Electrical Line, Part 2...46	

Indices

This Page Intentionally Left Blank

Notes

[illegible]

Used Varnishes

Description	Type
Terex Grey	RAL 7012
Terex White	RAL 1013
Terex Matte Black for Cylinders	RAL 9005
Ausa Orange.....	RAL 2004
Mz Imer Orange.....	RAL 2010
Genie Blue	
Genie Grey.....	
Genie Matte Black for Cylinders.....	RAL 9005

Manuals

Genie offers the following support documents for these models:

Title	Part No.
Genie Work platform 3P/700-REM 4400	
Operator's Manual, 1 st edition (English).....	57.0303.5102
Operator's Manual, 1 st edition (Italian)	57.0303.5103
Operator's Manual, 1 st edition (French)	57.0303.5104
Operator's Manual, 1 st edition (German).....	57.0303.5105
Operator's Manual, 1 st edition (Deutsch).....	57.0009.0513

Part list abbreviations

ZN	Zinc-plated
RNFT	Reinforced
FLNG	Flanged
PSNT	Heavy type
OC	Eye
PSRT	Through-coupling
CNTF	Hole centre

How To Order Parts

How To Order Parts

Please be prepared with the following information when ordering replacement parts for your Terex or Genie product:

- ☒ Machine model number
- ☒ Machine serial number
- ☒ Part number
- ☒ Part description and quantity
- ☒ Purchase order number
- ☒ "Ship to" address
- ☒ Desired method of shipment
- ☒ Name and telephone number of the authorized distributor in your area

Use the Service Parts Fax Order Form on the next page and fax your order to our Parts Department.

If you don't know the name of your authorized distributor, or if your area is not currently serviced by an authorized distributor, please call Terex or Genie Industries.

North America

Telephone (425) 556-6551
Toll Free (877) 367-5606 in U.S.A. and Canada
Fax (425) 556-8659
Toll Free Fax (888) 274-6192

Europe

Parts Telephone (31) (165) 519 313
Parts Fax (31) (165) 511 148

Australia

Parts Telephone (61) (7) 3456 4444
Parts Fax (61) (7) 3456 4466

South America

Parts Telephone (55) (11) 4082 5600
Parts Fax (55) (11) 4082 5630

Machine Information


Model

Serial Number

Date of Purchase

Authorized Genie Distributor

Phone Number



Date _____	Account Number _____
Your Name _____	Your Fax Number _____
_____	Your Phone Number _____
Bill To _____	Ship To _____
_____	_____
_____	_____
_____	_____
Purchase Order Number _____	Ship Via _____

Optional Equipment _____


[illegible]

☐ Ship complete order only - No back orders

☐ Ship all available parts and contact customer on disposition of back-ordered parts


☐ Other (please specify)

101.1 606291 Decals







Item	Part No.	Description	Qty.
1	09.4618.0790	Decal - Keep away from path of moving work platform.....2	2
2	09.4618.0788	Decal - Maximum wind allowed on the work platform 12,5 m/sec.....2	2
3	09.4618.1344	Decal - Fall hazard.....2	2
4	09.4618.1268	Decal - Lanyard attachment point...12	12
5	09.4618.1183	Decal - Maximum payload 700 kg including people on board; maximum occupants 3.....2	2
6	09.4618.0789	Decal - Overturning danger alarm....1	1
7	09.4618.0922	Decal - Crush hazard, keep away from moving parts.....2	2
8	09.4618.1269	Decal - Read the operator's manual.....1	1
9	09.4618.0919	Decal - Crush Hazard, keep away from moving parts.....4	4
10	09.4618.0921	Decal - Use limits close to electric power lines.....1	1
11	09.4618.1185	Decal - Crush Hazard, keep away from moving parts.....3	3
12	09.4618.1330	Decal - Maximum Slope Allowed....1	1
13	09.4618.1342	Decal - Maximum payload of the extensible parts.....4	4
14	09.4618.1343	Decal - Lock the extensible parts.....4	4
15	09.4618.1345	Decal - Reflecting decal.....3x0,6-m	3
16	09.4618.1345	Decal - Reflecting decal.....2x0,9-m	2
17	09.4618.1345	Decal - Reflecting decal (only on work platforms coupled to SR machine).....2x0,25-m	2
18	09.4618.1185	Decal - Crush Hazard, keep away from moving parts (only on work platforms coupled to EX & ER machine).....3	3

201.1 606292 Rail, View 1




Item	Part No.	Description	Qty.
1	55.0904.0044	Complete Manplatform Chassis.....	1
2	01.4001.0141	Screw TCEI M6x20 ISO4762.....	8
3	01.4041.0013	Grub Screw M10x10.....	24
4	01.4001.0157	Screw TE M10x25 ISO4017 8.8 ZN.....	24
5	01.4030.0004	Washer D10.....	24
6	01.0031.0308	Plain Washer D6x18 ISO7093.....	24
7	01.0023.0206	Stop Nut M6 ISO10511 8.8 ZN.....	27
8	01.4001.0130	Screw M6x16 ISO7380 10.9ZN.....	3
9	09.0803.0579	Manuals Box.....	1
10	01.0031.0054	CHAMFERED WASHER,D6,UNI 6592ZN.....	3
11	01.0023.0056	NUT,M12,UNI,7473 6SZN.....	4
12	01.0031.0057	WASHER,MM FL WASH 12 Z.....	4
13	01.0031.0305	Washer D12.....	4
14	01.0031.0306	Washer D12.....	4
15	54.0100.0110	Load Cell Spacer.....	12
16	01.4001.0138	Screw M16x60 ISO4014 10.9 ZN.....	4

202.1 606293 Rail, View 2




Item	Part No.	Description	Qty.
1	51.1301.9035	Rail.....	2
2	51.1301.9032	Rail.....	2
3	51.1301.9028	Rail.....	2
4	51.1301.9030	Rail.....	1
5	51.1301.9033	Rail.....	2
6	51.1301.9042	Rail.....	2
7	51.1301.9040	Rail.....	2
8	55.0904.0036	Rail.....	1
9	51.1301.9034	Manplatform Frame.....	2
10	51.1301.9036	Rail.....	2
11	51.1301.9041	Rail.....	2
12	51.1301.9029	Rail.....	1
13	51.1301.9039	Rail.....	2
14	01.4001.0133	Rail.....	4
15	54.0302.0001	Screw M10x30 ISO4017 8.8ZN.....	4
16	01.4019.0013	Nylon Locking Pin.....	28
17	01.0031.0308	Stop Nut M6x1 ISO10511 8.8ZN....	24
18	01.4019.0017	Plain Washer D6x18 ISO7093.....	4
19	01.4001.0140	Stop Nut M10 ISO10511 8.8ZN.....	16
20	01.4001.0157	Screw M6x16 ISO4762.....	24
21	01.4032.0004	SPRING WASHER,D10 ZN.....	24
22	01.0031.0055	WASHER,D 8,UNI 6592 ZN.....	16
23	01.4001.0156	Washer D8.....	4
24	51.1301.9044	Screw M8x16 ISO 7380 8:8ZN.....	4
25	51.0811.4192	Handle Support Plate.....	4
26	51.0811.4193	handle Safety Cursor.....	4
27	51.1301.9043	Rod.....	4
28	01.4001.0158	Handle Support.....	8
29	01.4019.0012	Screw M6x30 ISO4762 8.8ZN.....	8
30	01.4019.0013	Nut M8 8.8ZN.....	28
31	51.0400.5004	Handle Balance.....	4
32	51.0400.5005	Handle Balance.....	4
33	01.4001.0139	Screw M6x25 ISO 4762.....	4
34	51.0811.4127	Handle.....	4
35	01.0031.0054	CHAMFERED WASHER,D6,UNI 6592ZN.....	8
36	01.4001.0153	Screw M8 - 10x40 ISO 7379 ZN.....	4
37	01.4001.0152	Screw m6 - 8x40 ISO 7379 ZN.....	4

203.1 606294 Rail, View 3





Item	Part No.	Description	Qty.
1	51.1100.0026	Lateral Handle Guard.....	2
2	51.1301.9060	Protection Gate.....	2
3	51.1100.0029	Frontal Extensible Handle Guard.....	2
4	51.1100.0028	Front Right Handle Guard.....	1
5	51.1100.0027	Front Left Handle Guard.....	1
6	09.0803.0611	Cap.....	12
7	01.0001.0207	SCREW,8MM-1.25X60 8.8HCS Z.....	24
8	01.0031.0055	WASHER,D 8,UNI 6592 ZN.....	48
9	01.0023.0054	NUT,M8,UNI 7473.....	24

204.1 606295 Basement, View 1



Item	Part No.	Description	Qty.
1	51.1301.9049	Fixed Base Chassis 1.....	2
2	51.1301.9048	Fixed Base Chassis 2.....	2
3	51.1301.9023	Base Frame.....	1
4	54.0100.0104	Spacer.....	16
5	51.0811.4143	Roller Support.....	4
6	01.0031.0055	WASHER,D 8,UNI 6592 ZN.....	16
7	01.4001.0148	Screw TCEI M8x25 ISO4762 12.9 ZN.....	16
8	54.0500.0036	Roller D90.....	4
9	51.1301.9027	Roller Support Bracket.....	8


205.1 606296 Basement, View 2



Item	Part No.	Description	Qty.
1	55.0904.0037	Complete Extensible Chassis.....	2
2	51.1301.9025	Base Chassis.....	2
3	51.1301.9024	Extensible Chassis.....	2
4	54.0500.0037	Roller D75.....	4
5	01.4001.0140	Screw M10x25 ISO10642 10.9 ZN...	8
6	01.4001.0150	Screw M10x40 ISO10642 10.9 ZN...	4
7	03.0158.0002	Bearing.....	4
8	01.0031.0056	WASHER,MM FL WASH 10 Z.....	8
9	01.0023.0055	NUT,SELFLOCK,M10,UNI7473,ZN...	4
10	01.0031.0058	PLAIN WASHER.....	8
11	54.0500.0035	Roller Chassis.....	4
12	54.0002.0039	Roller Chassis Pin.....	4
13	03.0158.0001	Bearing.....	8

206.1 606297 Basement Support, EX and Australia Version

ONLY 'EX AND AUSTRALIA' MACHINE VERSION




206.1 606297 Basement Support, EX and Australia Version

Item	Part No.	Description	Qty.
1	01.4001.0130	Screw M6x16.....	10
2	01.0031.0298	PLAIN WASHER,FEND 6MM X 18MM Z.....	4
3	51.0903.4944	Protection Bracket.....	1
4	51.0811.4109	Unit Control Support.....	1
5	56.0021.0119	Unit Control.....	1
6	01.0023.0052	NUT,M5-0.8 NYLOCKHXNUT Z.....	4
7	01.4001.0135	Screw M5x12 8.8 ZN.....	4
8	01.0023.0053	NUT,NYLOCK M6-1.0 Z.....	6
9	01.0031.0059	WASHER,D16,UNI 6592,ZN.....	18
10	01.4001.0137	Screw M16x40 ISO4014.....	4
11	01.4001.0136	Screw M16x60 ISO4014 10.9 ZN....	6
12	01.4001.0138	Screw M12x80 ISO4014 10.9 ZN...12	
13	01.0031.0057	WASHER,MM FL WASH 12 Z.....	12
14	51.0903.4943	Left Load Cell Protection.....	2
15	51.1301.9022	Support Frame.....	1
16	51.0811.4107	Load Cell Support.....	4
17	01.0019.0106	NUT.....	8
18	01.4019.0004	NUT.....	8
19	51.0903.4973	Right Load Cell Protection.....	2
20	09.0802.0030	Front Right Wired Load Cell.....	1
21	09.0802.0031	Rear Right Wired Load Cell.....	1
22	09.0802.0032	Rear Left Wired Load Cell.....	1
23	09.0802.0033	Front Left Wired Load Cell.....	1




207.1 606298 Basement Support, SR Version

ONLY 'SR' MACHINE VERSION



Item	Part No.	Description	Qty.
1	01.4001.0130	Screw M6x16.....	10
2	01.0031.0298	PLAIN WASHER,FEND 6MM X 18MM Z.....	4
3	51.0903.4944	Protection Bracket.....	1
4	51.0811.4109	Unit Control Support.....	1
5	56.0021.0119	Unit Control.....	1
6	01.0023.0052	NUT,M5-0.8 NYLOCKHXNUT Z.....	4
7	01.4001.0135	Screw M5x12 8.8 ZN.....	4
8	01.0023.0053	NUT,NYLOCK M6-1.0 Z.....	6
9	01.0031.0059	WASHER,D16,UNI 6592,ZN.....	18
10	01.4001.0137	Screw M16x40 ISO4014.....	4
11	01.4001.0136	Screw M16x60 ISO4014 10.9 ZN....	6
12	01.4001.0138	Screw M12x80 ISO4014 10.9 ZN...12	
13	01.0031.0057	WASHER,MM FL WASH 12 Z.....	12
14	51.0903.4943	Left Load Cell Protection.....	2
15	51.1301.9022	Support Frame.....	1
16	51.0811.4107	Load Cell Support.....	4
17	01.0019.0106	NUT.....	8
18	01.4019.0004	NUT.....	8
19	51.0903.4973	Right Load Cell Protection.....	2
20	09.0802.0030	Front Right Wired Load Cell.....	1
21	09.0802.0031	Rear Right Wired Load Cell.....	1
22	09.0802.0032	Rear Left Wired Load Cell.....	1
23	09.0802.0033	Front left Wired Load Cell.....	1
24	01.0001.0303	Screw TE M10x45 ISO4017 8.8 ZN.....	4
25	51.0811.4181	Rear Base Support.....	1
26	51.0811.4186	Step Support.....	2
27	51.0811.4187	Step.....	2
28	51.0811.4183	Complete Step.....	2
29	01.0031.0056	WASHER,MM FL WASH 10 Z.....	8
30	01.4001.0133	Screw M10x30 ISO4762.....	8
31	51.0811.4182	Front Base Support.....	2
32	01.0031.0055	WASHER,D 8,UNI 6592 ZN.....	16
33	01.0001.0256	SCREW, 8.8 HCS 8MM-1.25X25Z.....	16
34	01.0031.0056	WASHER,MM FL WASH 10 Z.....	8
35	01.0023.0055	NUT,SELFLOCK,M10,UNI7473,ZN..4	


208.1 606299 Coupling Frame



208.1 606299 Coupling Frame

Item	Part No.	Description	Qty.
1	02.4102.0014	Spring Pin D6x16 ISO13337.....	1
2	51.1301.9020	Lock Frame.....	1
2	51.1301.9055	Lock Frame - Only ER Machine Version.....	1
3	01.4019.0015	Stop Nut M22X1,5 ISO 10512.....	2
4	54.0003.0037	Actuator Pin.....	1
5	01.4001.0144	Screw TE M12x35-N ISO 4017 ZIN 8.8.....	8
6	01.4001.0142	Screw TE M5x16-N ISO 10642 ZIN 8.8.....	2
7	51.0811.4176	Wire Locking Bracket.....	1
8	01.0031.0063	WASHER M24.....	3
9	01.0023.0062	STOP NUT M24.....	1
10	51.0811.4110	Frame.....	1
11	01.4001.0143	Screw TCEI M14x60 ISO 4762.....	8
12	01.0031.0058	PLAIN WASHER.....	16
13	01.0031.0057	WASHER,MM FL WASH 12 Z.....	8
14	54.0100.0109	Shim.....	2
15	01.0023.0057	STOP NUT.....	8
16	51.1301.9021	Frame.....	1
17	01.4001.0141	Screw M4 x 40 ISO 7380 ZN 8.8....	4
18	56.0012.0077	Microswitch..... ECN 00910	2
19	51.0811.4108	Microswitch Braket.....	2
20	06.0403.0002	Oil Seal.....	1
21	03.0158.0000	Bearing.....	2
22	02.0117.0121	Greaser.....	1
23	06.0401.1504	O-ring.....	1


301.1 606300 Hydraulic Part



Item	Part No.	Description	Qty.
1	04.4210.0032	Quick Coupling Female.....	1
2	06.0442.0114	Copper Washer 21,5x27x1,5.....	2
3	04.0600.0034	NIPPLE/PIPE FITTING.....	2
4	04.0602.0591	Pipe 1/4" R2 Hole 3/8" FD 1/4" LG2000.....	1
5	04.0602.0590	Pipe 1/4" R2 Hole 3/8" FD 1/4" LG2100.....	1
6	04.4210.0031	Quick Coupling Male.....	1
7	09.0803.0598	Pipe Lock Bracket 2xD16.....	1
8	01.4001.0129	Screw M8x40.....	1
9	06.0442.0113	Copper Washer 3/8".....	12
10	04.0600.0188	SCREW, 5519.....	4
11	04.0602.0589	Pipe 1/4 R2 Hole 3/8" FD1/4" LG280.....	2
12	04.0600.0231	Pipe Fitting 7/16"-1/4" JIC.....	2
13	06.0442.0101	WASHER.....	6
14	04.4235.0043	Rotation Actuator.....	1
15	01.4001.0126	Screw TCEI M24x140 12.9 ISO4762.....	4
16	01.0031.0063	WASHER M24.....	4
17	01.0023.0062	STOP NUT M24.....	4
18	04.0607.0808	Pipe Fitting 1/4".....	2
19	04.0607.0809	Pipe Fitting Adapter.....	2
20	04.4240.0063	Regulation Valve.....	2
21	04.0600.0028	PIPE FITTING.....	2
22	04.0602.0588	Pipe 1/4" R2 F901/4"-FD1/4" LG360.....	2
23	04.4240.0062	Solenoid Valve.....	1
24	01.4001.0128	Screw M5x35 ISO4762.....	4
25	01.4001.0127	Screw M5x50 ISO4762.....	4
26	04.4240.0061	Valve.....	1
27	01.0031.0304	Plain Washer D5x15 ISO7093.....	16

401.1 606301 Coded Proximity Switch

ONLY 'AUSTRALIA' MACHINE VERSION




401.1 606301 Coded Proximity Switch

Item	Part No.	Description	Qty.
1	51.0811.4189	Codified Proximity Switch Protection.....	1
2	01.0001.0076	Plain Washer D6x18 ISO7093.....	4
3	01.4001.0140	Screw TCEI M6x16 ISO4762.....	4
4	56.0017.0086	Proximity Switch.....	1
5	01.4032.0011	WASHER,D 4,ZN.....	4
6	01.4006.0002	SCREW.....	4
7	56.0017.0087	Codified Magnet.....	1
8	51.0811.4190	Codified Magnet Protection.....	1
9	51.0811.4188	Codified Magnet Support.....	1
10	01.4001.0139	Screw TCEI M6x16 ZN.....	2

402.1 606302 Dashboard Support, EX and SR Version

ONLY 'EX AND SR' MACHINE VERSION




402.1 606302 Dashboard Support, EX and SR Version

Item	Part No.	Description	Qty.
1	01.4001.0148	Screw M8x25 ISO4762 12.9 ZN.....2	
2	09.0803.0596	Handle.....1	
3	51.0903.4954	Protection Cover.....1	
4	01.0031.0055	WASHER,D 8,UNI 6592 ZN.....2	
5	01.0023.0054	NUT,M8,UNI 7473.....2	
6	01.4001.0147	Screw M5x16 ISO7380.....8	
7	09.0803.0597	Hinge.....2	
8	01.0031.0053	WASHER,D5,UNI 6592,ZN.....8	
9	01.0023.0052	NUT,M5-0.8 NYLOCKHXNUT Z.....8	
10	51.0811.4119	Dashboard Fixing Bracket.....1	
11	01.0031.0054	CHAMFERED WASHER,D6,UNI 6592ZN.....2	
12	01.0023.0053	NUT,NYLOCK M6-1.0 Z.....2	
13	51.0903.4955	Dashboard Support.....1	
14	01.4001.0132	Screw M8x55 ISO7380 10.9 ZN.....2	
15	01.4019.0012	Stop Nut M8 ISO10511 8.8 ZN.....2	
16	01.4001.0131	Screw M6x50 ISO7380 10.9 ZN.....2	
17	01.0031.0298	PLAIN WASHER,FEND 6MM X 18MM Z.....2	
18	01.4019.0013	Stop Nut M6 ISO10511 8.8 ZN.....2	

403.1 606303 Dashboard Support, Australia Version

ONLY 'AUSTRALIA' MACHINE VERSION




403.1 606303 Dashboard Support, Australia Version

Item	Part No.	Description	Qty.
1	01.4001.0148	Screw M8x25 ISO4762 12.9 ZN.....2	
2	09.0803.0596	Handle.....1	
3	51.0903.4954	Protection Cover.....1	
4	01.0031.0055	WASHER,D 8,UNI 6592 ZN.....2	
5	01.0023.0054	NUT,M8,UNI 7473.....2	
6	01.4001.0147	Screw M5x16 ISO7380.....8	
7	09.0803.0597	Hinge.....2	
8	01.0031.0053	WASHER,D5,UNI 6592,ZN.....8	
9	01.0023.0052	NUT,M5-0.8 NYLOCKHXNUT Z.....8	
10	51.0811.4119	Dashboard Fixing Bracket.....1	
11	01.0031.0054	CHAMFERED WASHER,D6,UNI 6592ZN.....2	
12	01.0023.0053	NUT,NYLOCK M6-1.0 Z.....2	
13	51.0811.4191	Dashboard Support.....1	
14	01.4001.0132	Screw M8x55 ISO7380 10.9 ZN.....2	
15	01.4019.0012	Stop Nut M8 ISO10511 8.8 ZN.....2	
16	01.4001.0131	Screw M6x50 ISO7380 10.9 ZN.....2	
17	01.0031.0298	PLAIN WASHER,FEND 6MM X 18MM Z.....4	
18	01.4019.0013	Stop Nut M6 ISO10511 8.8 ZN.....4	

404.1 606304 Dashboard, EX, ER and SR Version

ONLY 'EX, ER AND SR' MACHINE VERSION




404.1 606304 Dashboard, EX, ER and SR Version

Item	Part No.	Description	Qty.
1	56.0016.0100	Joystick.....	3
2	56.0017.0077	Key Selector.....	1
3	56.0017.0079	Yellow Light Switch.....	3
4	09.4618.1323	Dashboard Decal.....	1
5	56.0024.0029	Dashboard Body.....	1
6	56.0017.0080	Red Light Switch.....	1
7	56.0017.0078	Blue Light Switch.....	1
8	56.0017.0084	Red Led Indicator Light.....	1
9	01.4019.0016	Stop Nut M3 ISO7040 8.8 ZN.....	4
10	01.0031.0307	Plain Washer D3 ISO7091 8.8 ZN....	4
11	56.0017.0083	Switch Adapter.....	6
12	56.0002.0304	Switch Contact N/A.....	6
13	09.4618.1324	Genie Decal.....	1
14	56.0002.0301	7 Way Connector.....	3
15	56.0010.0061	Alarm Buzzer.....	1
16	56.0008.5203	Bypass Battery 12V 1,2Ah.....	1
17	56.0017.0081	White Led Indicator Light.....	2
18	56.0002.0303	Switch Contact N/C.....	1
19	56.0017.0085	Emergency Stop Decal.....	1
20	56.0017.0082	Emergency Switch.....	1
21	56.0002.0302	Switch Contact N/A.....	1
22	56.0002.0305	23 Way Connector.....	1
23	01.4001.0151	Screw TCEI M3x16 ISO4762.....	4

405.1 606305 Dashboard, Australia Version


ONLY 'AUSTRALIA' MACHINE VERSION



405.1 606305 Dashboard, Australia Version

Item	Part No.	Description	Qty.
1	56.0016.0100	Joystick.....	3
2	56.0017.0077	Key Selector.....	1
3	56.0017.0088	Bright Selector.....	1
4	56.0017.0084	Red Led Indicator Light.....	1
5	09.4618.1325	Dashboard Decal.....	1
6	56.0017.0080	Red Light Switch.....	1
7	56.0017.0078	Blue Light Switch.....	1
8	56.0024.0031	Dashboard Body.....	1
9	01.4019.0016	Stop Nut M3 ISO7040 8.8 ZN.....	4
10	01.0031.0307	Plain Washer D3 ISO7091 8.8 ZN....	4
11	56.0017.0079	Yellow Light Switch.....	1
12	09.4618.1326	Genie Decal.....	1
13	56.0017.0083	Switch Adapter.....	6
14	56.0002.0304	Switch Contact N/A.....	7
15	56.0002.0301	7 Way Connector.....	3
16	56.0010.0061	Alarm Buzzer.....	1
17	56.0002.0306	Switch Cover.....	1
18	56.0017.0089	Switch.....	1
19	56.0008.5203	Bypass Battery 12V 1,2Ah.....	1
20	56.0017.0081	White Led Indicator Light.....	2
21	56.0002.0302	Switch Contact N/A.....	1
22	56.0017.0085	Emergency Stop Decal.....	1
23	56.0017.0082	Emergency Switch.....	1
24	56.0002.0303	Switch Contact N/C.....	1
25	56.0002.0305	23 Way Connector.....	1
26	01.4001.0151	Screw TCEI M3x16 ISO4762.....	4


406.1 606306 Cable Reel



406.1 606306 Cable Reel

Item	Part No.	Description	Qty.
1	56.0002.0299	Electric Box.....	1
1	56.0002.0300	Electric Box - AUSTRALIA Machine Version.....	1
2	56.0023.0033	Cable Reel - AUSTRALIA Machine Version.....	1
2	56.0023.0041	Cable Reel - SR Machine Version.... <i>ECN 04310</i>	1
2	56.0023.0042	Cable Reel - EX Machine Version.... <i>ECN 04310</i>	1
3	01.4019.0014	Stop Nut M12 ISO10511 8.8 ZN.....	4
4	01.0031.0151	Plain Washer D12 ISO7089 8.8 ZN.....	8
5	51.0811.4178	Cable Reel Support.....	1
6	01.0001.0507	Screw TCEI M12x35 ISO4017 8.8 ZN.....	4
7	51.0811.4179	Cable Protection Carter.....	1
8	01.0031.0056	Plain Washer D10 ISO7089 8.8 ZN.....	4
9	01.0001.0358	Screw TE M10x40 ISO4017 8.8 ZN.....	4
10	51.0811.4180	Cable Reel Support.....	1
11	01.0031.0298	Plain Washer D6x18 ISO7093.....	2
12	01.0001.0156	Screw TE M6x20 ISO4017 8.8 ZN...2	
13	01.0031.0054	Plain Washer D6 ISO7089.....	3
14	01.4019.0013	Stop Nut M6 ISO10511 8.8 ZN.....	3


407.1 606307 Wirings and Components



407.1 606307 Wirings and Components

Item	Part No.	Description	Qty.
1	56.0002.0048	Deutch Connector.....	1
2	56.0024.0028	Dashboard - EX And SR Machine Version.....	1
2	56.0024.0030	Dashboard - AUSTRALIA Machine Version.....	1
3	637650	Fuse 3A.....	3
4	07.0703.0067	Relay.....	1
5	56.0006.0002	Relay.....	1
6	56.0021.0119	Control Unit.....	1
7	55.0602.0554	Wiring - ER Machine Version.....	1
8	55.0602.0551	Cable Reel Wiring.....	1
9	55.0602.0550	Microswitch And Load Cell Wiring....	1
10	09.0802.0031	Rear Right Wired Load Cell.....	1
11	09.0802.0030	Front Right Wired Load Cell.....	1
12	09.0802.0032	Rear Left Wired Load Cell.....	1
13	09.0802.0033	Front Left Wired Load Cell.....	1
14	56.0012.0073	Microswitch.....	2
15	04.4240.0062	Solenoid Valve.....	1
16	55.0602.0509	Old Attachment Plug - New Machine Plug Interface.....	1
17	55.0602.0510	New Attachment Plug - Old Machine Plug Interface.....	1
18	56.0002.0307	Wire Clamp (to be used together with p/n 56.0001.0021).....	1
		<i>ECN 1809</i>	
18	56.0007.0018	Wire Clamp (to be used together with p/n 56.0002.0309).....	1
		<i>ECN 1809</i>	
19	56.0001.0021	Deutch Cap Connector (to be used together with p/n 56.0002.0307).....	1
19	56.0002.0309	Deutch Cap Connector (to be used together with p/n 56.0007.0018).....	1





501.1 606308 Air Compressor And Electrical Line, Part 1



501.1 606308 Air Compressor And Electrical Line, Part 1

Item	Part No.	Description	Qty.
1	04.4227.0003	Clamp.....	1
2	01.0031.0298	PLAIN WASHER,FEND 6MM X 18MM Z.....	2
3	01.0001.0069	Spring Washer D6.....	3
4	01.0001.0154	SCREW, 8.8 HCS 6MM-1.0X16 Z....	1
5	09.0803.0069	SPRING ATTACH.....	1
6	09.0803.0108	CHAIN.....	0,3-m
7	01.4001.0046	Screw TE M6X45 UNI 5739 8.8 ZN.....	1
8	01.0031.0054	CHAMFERED WASHER,D6,UNI 6592ZN.....	7
9	01.0001.0104	SCREW, 8.8HCSM6-1.0X40Z FT.....	1
10	56.0002.0297	Male Electric Connector.....	1
11	09.0803.0593	Male Quick Coupling.....	1
12	09.0803.0046	SINGLE STIRRUP FIRM TUBE.....	1
13	09.0803.0380	Cable Support.....	2
14	01.0001.0156	SCREW,TE,M6X20.....	4
15	01.0031.0055	WASHER,D 8,UNI 6592 ZN.....	4
16	01.4032.0003	SPRING WASHER,D 8,ZN.....	4
17	01.0001.0254	SCREW, 8.8 HCS 8MM-1.25X20Z...2	
18	51.0809.8000	Cable Support Bracket.....	2
19	01.0023.0053	NUT,NYLOCK M6-1.0 Z.....	4
20	01.0001.0258	SCREW.....	2
21	54.0101.0000	Spacer.....	2

502.1 606309 Air Compressor And Electrical Line, Part 2



502.1 606309 Air Compressor And Electrical Line, Part 2

Item	Part No.	Description	Qty.
1	51.0811.4174	Bracket.....	1
2	04.0602.0593	Pipe 13X23 3/8 LG.3300 FD 3/8 F90 3/8.....	1
3	09.0803.0592	Female Quick Coupling.....	1
4	01.0023.0052	NUT,M5-0.8 NYLOCKHXNUT Z.....	4
5	01.0031.0053	WASHER,D5,UNI 6592,ZN.....	8
6	01.4001.0102	SCREW.....	4
7	56.0002.0296	Female Electric Connector.....	1
8	51.0811.4175	Bracket.....	1
9	01.0003.0159	SCREW,M6X35,UNI 5931.....	2
10	09.0803.0046	SINGLE STIRRUP FIRM TUBE.....	1
11	56.0023.0031	Cable Reel.....	1
12	01.0023.0055	NUT,SELFLOCK,M10,UNI7473,ZN..	4
13	01.0031.0056	WASHER,MM FL WASH 10 Z.....	12
14	51.1301.9050	Bracket.....	1
15	01.0001.0357	SCREW, 8.8 HCS 10MM-1.5X35Z..	4
16	51.1301.9052	Calbe Protection.....	1
17	01.0001.0401	SCREW.....	4
18	01.4032.0005	WASHER.....	4
19	51.1301.9051	Bracket.....	1
20	01.0031.0054	CHAMFERED WASHER,D6,UNI 6592ZN.....	5
21	01.0001.0156	SCREW,TE,M6X20.....	2
22	01.0023.0053	NUT,NYLOCK M6-1.0 Z.....	3

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
01.0001.0069	45	01.4019.0013	15, 33, 35, 41	51.0400.5005	15	55.0602.0550	43
01.0001.0076	31	01.4019.0014	41	51.0809.8000	45	55.0602.0551	43
01.0001.0104	45	01.4019.0015	27	51.0811.4107	23, 25	55.0602.0554	43
01.0001.0154	45	01.4019.0016	37, 39	51.0811.4108	27	55.0904.0036	15
01.0001.0156	41, 45, 47	01.4019.0017	15	51.0811.4109	23, 25	55.0904.0037	21
01.0001.0207	17	01.4030.0004	13	51.0811.4110	27	55.0904.0044	13
01.0001.0254	45	01.4032.0003	45	51.0811.4119	33, 35	56.0001.0021	43
01.0001.0256	25	01.4032.0004	15	51.0811.4127	15	56.0002.0048	43
01.0001.0258	45	01.4032.0005	47	51.0811.4143	19	56.0002.0296	47
01.0001.0303	25	01.4032.0011	31	51.0811.4174	47	56.0002.0297	45
01.0001.0357	47	01.4041.0013	13	51.0811.4175	47	56.0002.0299	41
01.0001.0358	41	02.0117.0121	27	51.0811.4176	27	56.0002.0300	41
01.0001.0401	47	02.4102.0014	27	51.0811.4178	41	56.0002.0301	37, 39
01.0001.0507	41	03.0158.0000	27	51.0811.4179	41	56.0002.0302	37, 39
01.0003.0159	47	03.0158.0001	21	51.0811.4180	41	56.0002.0303	37, 39
01.0019.0106	23, 25	03.0158.0002	21	51.0811.4181	25	56.0002.0304	37, 39
01.0023.0052	23, 25, 33, 35, 47	04.0600.0028	29	51.0811.4182	25	56.0002.0305	37, 39
01.0023.0053	23, 25, 33, 35, 45, 47	04.0600.0034	29	51.0811.4183	25	56.0002.0306	39
01.0023.0054	17, 33, 35	04.0600.0188	29	51.0811.4186	25	56.0002.0307	43
01.0023.0055	21, 25, 47	04.0600.0231	29	51.0811.4187	25	56.0002.0309	43
01.0023.0056	13	04.0602.0588	29	51.0811.4188	31	56.0006.0002	43
01.0023.0057	27	04.0602.0589	29	51.0811.4189	31	56.0007.0018	43
01.0023.0062	27, 29	04.0602.0590	29	51.0811.4190	31	56.0008.5203	37, 39
01.0023.0206	13	04.0602.0591	29	51.0811.4191	35	56.0010.0061	37, 39
01.0031.0053	33, 35, 47	04.0602.0593	47	51.0811.4192	15	56.0012.0073	43
01.0031.0054	13, 15, 33, 35, 41, 45, 47	04.0607.0808	29	51.0811.4193	15	56.0012.0077	27
01.0031.0055	15, 17, 19, 25, 33, 35, 45	04.0607.0809	29	51.0903.4943	23, 25	56.0016.0100	37, 39
01.0031.0056	21, 25, 41, 47	04.4210.0031	29	51.0903.4944	23, 25	56.0017.0077	37, 39
01.0031.0057	13, 23, 25, 27	04.4210.0032	29	51.0903.4954	33, 35	56.0017.0078	37, 39
01.0031.0058	21, 27	04.4227.0003	45	51.0903.4955	33	56.0017.0079	37, 39
01.0031.0059	23, 25	04.4235.0043	29	51.0903.4973	23, 25	56.0017.0080	37, 39
01.0031.0063	27, 29	04.4240.0061	29	51.1100.0026	17	56.0017.0081	37, 39
01.0031.0151	41	04.4240.0062	29, 43	51.1100.0027	17	56.0017.0082	37, 39
01.0031.0298	23, 25, 33, 35, 41, 45	04.4240.0063	29	51.1100.0028	17	56.0017.0083	37, 39
01.0031.0304	29	06.0401.1504	27	51.1100.0029	17	56.0017.0084	37, 39
01.0031.0305	13	06.0403.0002	27	51.1301.9020	27	56.0017.0085	37, 39
01.0031.0306	13	06.0442.0101	29	51.1301.9021	27	56.0017.0086	31
01.0031.0307	37, 39	06.0442.0113	29	51.1301.9022	23, 25	56.0017.0087	31
01.0031.0308	13, 15	06.0442.0114	29	51.1301.9023	19	56.0017.0088	39
01.4001.0046	45	07.0703.0067	43	51.1301.9024	21	56.0017.0089	39
01.4001.0102	47	09.0802.0030	23, 25, 43	51.1301.9025	21	56.0021.0119	23, 25, 43
01.4001.0126	29	09.0802.0031	23, 25, 43	51.1301.9027	19	56.0023.0031	47
01.4001.0127	29	09.0802.0032	23, 25, 43	51.1301.9028	15	56.0023.0033	41
01.4001.0128	29	09.0802.0033	23, 25, 43	51.1301.9029	15	56.0023.0041	41
01.4001.0129	29	09.0803.0046	45, 47	51.1301.9030	15	56.0023.0042	41
01.4001.0130	13, 23, 25	09.0803.0069	45	51.1301.9032	15	56.0024.0028	43
01.4001.0131	33, 35	09.0803.0108	45	51.1301.9033	15	56.0024.0029	37
01.4001.0132	33, 35	09.0803.0380	45	51.1301.9034	15	56.0024.0030	43
01.4001.0133	15, 25	09.0803.0579	13	51.1301.9035	15	56.0024.0031	39
01.4001.0135	23, 25	09.0803.0592	47	51.1301.9036	15	637650	43
01.4001.0136	23, 25	09.0803.0593	45	51.1301.9039	15		
01.4001.0137	23, 25	09.0803.0596	33, 35	51.1301.9040	15		
01.4001.0138	13, 23, 25	09.0803.0597	33, 35	51.1301.9041	15		
01.4001.0139	15, 31	09.0803.0598	29	51.1301.9042	15		
01.4001.0140	15, 21, 31	09.0803.0611	17	51.1301.9043	15		
01.4001.0141	13, 27	09.4618.0788	11	51.1301.9044	15		
01.4001.0142	27	09.4618.0789	11	51.1301.9048	19		
01.4001.0143	27	09.4618.0790	11	51.1301.9049	19		
01.4001.0144	27	09.4618.0919	11	51.1301.9050	47		
01.4001.0147	33, 35	09.4618.0921	11	51.1301.9051	47		
01.4001.0148	19, 33, 35	09.4618.0922	11	51.1301.9052	47		
01.4001.0150	21	09.4618.1183	11	51.1301.9055	27		
01.4001.0151	37, 39	09.4618.1185	11	51.1301.9060	17		
01.4001.0152	15	09.4618.1268	11	54.0002.0039	21		
01.4001.0153	15	09.4618.1269	11	54.0003.0037	27		
01.4001.0156	15	09.4618.1323	37	54.0100.0104	19		
01.4001.0157	13, 15	09.4618.1324	37	54.0100.0109	27		
01.4001.0158	15	09.4618.1325	39	54.0100.0110	13		
01.4006.0002	31	09.4618.1326	39	54.0101.0000	45		
01.4019.0004	23, 25	09.4618.1330	11	54.0302.0001	15		
01.4019.0012	15, 33, 35	09.4618.1342	11	54.0500.0035	21		
		09.4618.1343	11	54.0500.0036	19		
		09.4618.1344	11	54.0500.0037	21		
		09.4618.1345	11	55.0602.0509	43		
		51.0400.5004	15	55.0602.0510	43		

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

2 23 Way Connector.....37, 39 7 7 Way Connector.....37, 39	Decal - Lanyard attachment point.....11 Decal - Lock the extensible parts.....11 Decal - Maximum payload 700 kg including people on board; maximum occupants 3.....11 Decal - Maximum payload of the extensible parts.....11 Decal - Maximum Slope Allowed.....11 Decal - Maximum wind allowed on the work platform 12,5 m/sec.....11 Decal - Overturning danger alarm.....11 Decal - Read the operator's manual.....11 Decal - Reflecting decal.....11 Decal - Reflecting decal (only on work platforms coupled to SR machine).....11 Decal - Use limits close to electric power lines.....11 Deutsch Cap Connector (to be used together with p/n 56.0002.0307).....43 Deutsch Cap Connector (to be used together with p/n 56.0007.0018).....43 Deutsch Connector.....43	K Key Selector.....37, 39 L Lateral Handle Guard.....17 Left Load Cell Protection.....23, 25 Load Cell Spacer.....13 Load Cell Support.....23, 25 Lock Frame.....27 Lock Frame - Only ER Machine Version.....27
A Actuator Pin.....27 Alarm Buzzer.....37, 39 B Base Chassis.....21 Base Frame.....19 Bearing.....21, 27 Blue Light Switch.....37, 39 Bracket.....47 Bright Selector.....39 Bypass Battery 12V 1,2Ah.....37, 39	C Cable Protection Carter.....41 Cable Reel.....47 Cable Reel - AUSTRALIA Machine Version...41 Cable Reel - EX Machine Version.....41 Cable Reel - SR Machine Version.....41 Cable Reel Support.....41 Cable Reel Wiring.....43 Cable Support.....45 Cable Support Bracket.....45 Calbe Protection.....47 Cap.....17 CHAIN.....45 CHAMFERED WASHER,D6,UNI 6592ZN.....13, 15, 33, 35, 45, 47 Clamp.....45 Codified Magnet.....31 Codified Magnet Protection.....31 Codified Magnet Support.....31 Codified Proximity Switch Protection.....31 Complete Extensible Chassis.....21 Complete Manplatform Chassis.....13 Complete Step.....25 Control Unit.....43 Copper Washer 21,5x27x1,5.....29 Copper Washer 3/8".....29	M Male Electric Connector.....45 Male Quick Coupling.....45 Manplatform Frame.....15 Manuals Box.....13 Microswitch.....27, 43 Microswitch And Load Cell Wiring.....43 Microswitch Braket.....27
D Dashboard - AUSTRALIA Machine Version...43 Dashboard - EX And SR Machine Version.....43 Dashboard Body.....37, 39 Dashboard Decal.....37, 39 Dashboard Fixing Bracket.....33, 35 Dashboard Support.....33, 35 Decal - Crush Hazard, keep away from moving parts.....11 Decal - Crush hazard, keep away from moving parts.....11 Decal - Crush Hazard, keep away from moving parts (only on work platforms coupled to EX & ER machine).....11 Decal - Fall hazard.....11 Decal - Keep away from path of moving work platform.....11	E Electric Box.....41 Electric Box - AUSTRALIA Machine Version.....41 Emergency Stop Decal.....37, 39 Emergency Switch.....37, 39 Extensible Chassis.....21 F Female Electric Connector.....47 Female Quick Coupling.....47 Fixed Base Chassis 1.....19 Fixed Base Chassis 2.....19 Frame.....27 Front Base Support.....25 Front Left Handle Guard.....17 Front Left Wired Load Cell.....23, 43 Front left Wired Load Cell.....25 Front Right Handle Guard.....17 Front Right Wired Load Cell.....23, 25, 43 Frontal Extensible Handle Guard.....17 Fuse 3A.....43 G Genie Decal.....37, 39 Greaser.....27 Grub Screw M10x10.....13	N New Attachment Plug - Old Machine Plug Interface.....43 NIPPLE/PIPE FITTING.....29 NUT.....23, 25 Nut M8 8.8ZN.....15 NUT,M12,UNI,7473 6SZN.....13 NUT,M5-0.8 NYLOCKHXNUT Z.....23, 25, 33, 35, 47 NUT,M8,UNI 7473.....17, 33, 35 NUT,NYLOCK M6-1.0 Z.....23, 25, 33, 35, 45, 47 NUT,SELFLOCK,M10,UNI7473,ZN.....21, 25, 47 Nylon Locking Pin.....15 O O-ring.....27 Oil Seal.....27 Old Attachment Plug - New Machine Plug Interface.....43
P Pipe 1/4" R2 Hole 3/8" FD1/4" LG280.....29 Pipe 1/4" R2 F901/4"-FD1/4" LG360.....29 Pipe 1/4" R2 Hole 3/8" FD 1/4" LG2000.....29 Pipe 1/4" R2 Hole 3/8" FD 1/4" LG2100.....29 Pipe 13X23 3/8 LG.3300 FD 3/8 F90 3/8.....47 PIPE FITTING.....29 Pipe Fitting 1/4".....29 Pipe Fitting 7/16"-1/4" JIC.....29 Pipe Fitting Adapter.....29 Pipe Lock Bracket 2xD16.....29 PLAIN WASHER.....21, 27 Plain Washer D10 ISO7089 8.8 ZN.....41 Plain Washer D12 ISO7089 8.8 ZN.....41 Plain Washer D3 ISO7091 8.8 ZN.....37, 39 Plain Washer D5x15 ISO7093.....29 Plain Washer D6 ISO7089.....41 Plain Washer D6x18 ISO7093.....13, 15, 31, 41 PLAIN WASHER,FEND 6MM X 18MM Z.....23, 25, 33, 35, 45 Protection Bracket.....23, 25	h handle Safety Cursor.....15 H Handle.....15, 33, 35 Handle Balance.....15 Handle Support.....15 Handle Support Plate.....15 Hinge.....33, 35 J Joystick.....37, 39	P Pipe 1/4" R2 Hole 3/8" FD1/4" LG280.....29 Pipe 1/4" R2 F901/4"-FD1/4" LG360.....29 Pipe 1/4" R2 Hole 3/8" FD 1/4" LG2000.....29 Pipe 1/4" R2 Hole 3/8" FD 1/4" LG2100.....29 Pipe 13X23 3/8 LG.3300 FD 3/8 F90 3/8.....47 PIPE FITTING.....29 Pipe Fitting 1/4".....29 Pipe Fitting 7/16"-1/4" JIC.....29 Pipe Fitting Adapter.....29 Pipe Lock Bracket 2xD16.....29 PLAIN WASHER.....21, 27 Plain Washer D10 ISO7089 8.8 ZN.....41 Plain Washer D12 ISO7089 8.8 ZN.....41 Plain Washer D3 ISO7091 8.8 ZN.....37, 39 Plain Washer D5x15 ISO7093.....29 Plain Washer D6 ISO7089.....41 Plain Washer D6x18 ISO7093.....13, 15, 31, 41 PLAIN WASHER,FEND 6MM X 18MM Z.....23, 25, 33, 35, 45 Protection Bracket.....23, 25

Part Description Index (continued)

Protection Cover.....33, 35
 Protection Gate.....17
 Proximity Switch.....31

Q

Quick Coupling Female.....29
 Quick Coupling Male.....29

R

Rail.....15
 Rear Base Support.....25
 Rear Left Wired Load Cell.....23, 25, 43
 Rear Right Wired Load Cell.....23, 25, 43
 Red Led Indicator Light.....37, 39
 Red Light Switch.....37, 39
 Regulation Valve.....29
 Relay.....43
 Right Load Cell Protection.....23, 25
 Rod.....15
 Roller Chassis.....21
 Roller Chassis Pin.....21
 Roller D75.....21
 Roller D90.....19
 Roller Support.....19
 Roller Support Bracket.....19
 Rotation Actuator.....29

S

SCREW.....31, 45, 47
 Screw M10x25 ISO10642 10.9 ZN.....21
 Screw M10x30 ISO4017 8.8ZN.....15
 Screw M10x30 ISO4762.....25
 Screw M10x40 ISO10642 10.9 ZN.....21
 Screw M12x80 ISO4014 10.9 ZN.....23, 25
 Screw M16x40 ISO4014.....23, 25
 Screw M16x60 ISO4014 10.9 ZN.....13, 23, 25
 Screw M4 x 40 ISO 7380 ZN 8.8.....27
 Screw M5x12 8.8 ZN.....23, 25
 Screw M5x16 ISO7380.....33, 35
 Screw M5x35 ISO4762.....29
 Screw M5x50 ISO4762.....29
 Screw m6 - 8x40 ISO 7379 ZN.....15
 Screw M6x16.....23, 25
 Screw M6x16 ISO4762.....15
 Screw M6x16 ISO7380 10.9ZN.....13
 Screw M6x25 ISO 4762.....15
 Screw M6x30 ISO4762 8.8ZN.....15
 Screw M6x50 ISO7380 10.9 ZN.....33, 35
 Screw M8 - 10x40 ISO 7379 ZN.....15
 Screw M8x16 ISO 7380 8.8ZN.....15
 Screw M8x25 ISO4762 12.9 ZN.....33, 35
 Screw M8x40.....29
 Screw M8x55 ISO7380 10.9 ZN.....33, 35
 Screw TCEI M12x35 ISO4017 8.8 ZN.....41
 Screw TCEI M14x60 ISO 4762.....27
 Screw TCEI M24x140 12.9 ISO4762.....29
 Screw TCEI M3x16 ISO4762.....37, 39
 Screw TCEI M6x16 ISO4762.....31
 Screw TCEI M6x16 ZN.....31
 Screw TCEI M6x20 ISO4762.....13
 Screw TCEI M8x25 ISO4762 12.9 ZN.....19
 Screw TE M10x25 ISO4017 8.8 ZN.....13
 Screw TE M10x40 ISO4017 8.8 ZN.....41
 Screw TE M10x45 ISO4017 8.8 ZN.....25
 Screw TE M12x35-N ISO 4017 ZIN 8.8.....27
 Screw TE M5x16-N ISO 10642 ZIN 8.8.....27
 Screw TE M6x20 ISO4017 8.8 ZN.....41
 Screw TE M6X45 UNI 5739 8.8 ZN.....45

SCREW, 5519.....29
 SCREW, 8.8 HCS 10MM-1.5X35Z.....47
 SCREW, 8.8 HCS 6MM-1.0X16 Z.....45
 SCREW, 8.8 HCS 8MM-1.25X20Z.....45
 SCREW, 8.8 HCS 8MM-1.25X25Z.....25
 SCREW, 8.8HCSM6-1.0X40Z FT.....45
 SCREW,8MM-1.25X60 8.8HCS Z.....17
 SCREW,M6X35,UNI 5931.....47
 SCREW,TE,M6X20.....45, 47
 Shim.....27
 SINGLE STIRRUP FIRM TUBE.....45, 47
 Solenoid Valve.....29, 43
 Spacer.....19, 45
 SPRING ATTACH.....45
 Spring Pin D6x16 ISO13337.....27
 Spring Washer D6.....45
 SPRING WASHER,D 8,ZN.....45
 SPRING WASHER,D10 ZN.....15
 Step.....25
 Step Support.....25
 STOP NUT.....27
 Stop Nut M10 ISO10511 8.8ZN.....15
 Stop Nut M12 ISO10511 8.8 ZN.....41
 Stop Nut M22X1,5 ISO 10512.....27
 STOP NUT M24.....27, 29
 Stop Nut M3 ISO7040 8.8 ZN.....37, 39
 Stop Nut M6 ISO10511 8.8 ZN.....13, 33, 35, 41
 Stop Nut M6x1 ISO10511 8.8ZN.....15
 Stop Nut M8 ISO10511 8.8 ZN.....33, 35
 Support Frame.....23, 25
 Switch.....39
 Switch Adapter.....37, 39
 Switch Contact N/A.....37, 39
 Switch Contact N/C.....37, 39
 Switch Cover.....39

U

Unit Control.....23, 25
 Unit Control Support.....23, 25

V

Valve.....29

W

WASHER.....29, 47
 Washer D10.....13
 Washer D12.....13
 Washer D8.....15
 WASHER M24.....27, 29
 WASHER,D 4,ZN.....31
 WASHER,D 8,UNI 6592 ZN.....15, 17, 19, 25, 33, 35, 45
 WASHER,D16,UNI 6592,ZN.....23, 25
 WASHER,D5,UNI 6592,ZN.....33, 35, 47
 WASHER,MM FL WASH 10 Z.....21, 25, 47
 WASHER,MM FL WASH 12 Z.....13, 23, 25, 27
 White Led Indicator Light.....37, 39
 Wire Clamp (to be used together with p/n 56.0001.0021).....43
 Wire Clamp (to be used together with p/n 56.0002.0309).....43
 Wire Locking Bracket.....27
 Wiring - ER Machine Version.....43

Y

Yellow Light Switch.....37, 39

California Proposition 65

Warning

The exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Genie North America

Phone 425.881.1800
Toll Free USA and Canada
800.536.1800
Fax 425.883.3475

Genie Australia Pty Ltd.

Phone +61 7 3375 1660
Fax +61 7 3375 1002

Genie China

Phone +86 21 53852570
Fax +86 21 53852569

Genie Malaysia

Phone +65 98 480 775
Fax +65 67 533 544

Genie Japan

Phone +81 3 3453 6082
Fax +81 3 3453 6083

Genie Korea

Phone +82 25 587 267
Fax +82 25 583 910

Genie Brasil

Phone +55 11 41 665 755
Fax +55 11 41 665 754

Genie Holland

Phone +31 183 581 102
Fax +31 183 581 566

Genie Scandinavia

Phone +46 31 575100
Fax +46 31 579020

Genie France

Phone +33 (0)2 37 26 09 99
Fax +33 (0)2 37 26 09 98

Genie Iberica

Phone +34 93 579 5042
Fax +34 93 579 5059

Genie Germany

Phone +49 (0)4202 88520
Fax +49 (0)4202 8852-20

Genie U.K.

Phone +44 (0)1476 584333
Fax +44 (0)1476 584334

Genie Mexico City

Phone +52 55 5666 5242
Fax +52 55 5666 3241

Distributed By:

Parts Manual

Work Platform: 3P/700-REM 4400 *from SN 60980*

Part No.
645031

Rev D

