



Parts Manual

Serial Number Range

GTH-4013 AU.2

from SN 19281

Part No. 645032

Rev A

February 2010

Technical Publications

Genie has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy.

Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement. All communications will be carefully considered for future printings of this and all other manuals.

Contact Us:



www.genieindustries.com


e-mail: awp.techpub@terex.com

The technical data contained in this document is indicative and not binding, insofar as TEREXLIFT S.r.l reserves the right to make modifications and improvements to its products at any time in order to enhance the quality thereof.

57.0411.0023 Rev A February 2010
First Edition, First Printing

Chassis serial number

(The chassis serial number is punched on the front right part of the chassis side member)

**Machine data plate**

(On machines destined for the Italian market, the machine data plate is installed in the driving cab, on the right, and is well-visible when the door is opened. On the machines destined for foreign markets, the data plate is applied on the front right side of the chassis)

TEREXLIFT s.r.l.	
ZONA INDUSTRIALE - 06019 UMBERTIDE (PG) - ITALY Tel. +39 075 941.811 Fax +39 075 941.53.82	
MODELLO - MODEL - MODELE - TYP - MODELO	
ANNO DI COSTRUZIONE - YEAR OF CONSTRUCTION - ANNEE DE CONSTRUCTION BAUJAHR - AÑO DE FABRICACIÓN	
MATRICOLA - SERIAL N. - N. DE SERIE - FZ.-IDENT NR. - NO. DE SERIE	
PESO MAX ASSALE ANT. - MAX FRONT AXLE WEIGHT - POIDS MAX ESSIEU AVANT ZUL. ACHSLAST VO. N. ST VZO - PESO MAX EJE ANTERIOR	kg
PESO MAX ASSALE POST. - MAX REAR AXLE WEIGHT - POIDS MAX ESSIEU ARRIERE ZUL. ACHSLAST HI. N. ST VZO - PESO MAX EJE POSTERIOR	kg
PESO TOTALE - TOTAL WEIGHT - POIDS TOTAL - ZUL. GESAMTGEWICHT N. ST VZO PESO TOTAL	kg
MATRICOLA MOTORE TERMICO - ENGINE SERIAL N. - N. MOTEUR THERMIQUE FABRIK NR. DIESEL MOTOR - NO. DE SERIE MOTOR TERMICO	
POTENZA MOTORE TERMICO - ENGINE POWER - PUISSANCE MOTEUR MOTORLEISTUNG - POTENCIA MOTOR	kW
CARICO STATICO VERT. GANCIO DI TRAINO-MAX.VERTICAL LOAD ON THE COUPLING HOOK-EFFORT VERTICAL MAXIMAL SUR LE CROCHET D'ATTelage MAXIMALE STUTZLASTBEANSPRUCHUNG DES ZUGHAKENS IN VERTIKALER RICHTUNG- ESFUERZO VERTICAL SOBRE EL GANCHO DE TRACCION	kg
MASSA MAX. RIMORCHIABILE - MAX.DRAWBAR PULL AT THE COUPLING HOOK EFFORT THE TRACTION - MAXI AU CROCHET D'ATTelage-MAXIMALE ZUGBEANSPRUCHUNG AM ZUGHAKEN-MAXIMO ESFUERZO DE TRACCION EN EL GANCHO DE TRACCION	kg
OMOLOGAZIONE	
FABBRICATO IN ITALIA - MADE IN ITALY	

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genieindustries.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genieindustries.com.

How to Read Your Serial Number.....	3
Parts Stocking List.....	7
How to Order Parts.....	8
Service Parts Fax Order Form.....	9

Electronic Version

Click on any page number to view the figure.

100 Cab and Control Place Unit

101.1 606361 Complete Seat.....	10
102.1 606362 Complete Air Heater.....	12
103.1 606363 Cab.....	14
104.1 606364 Cab.....	16
105.1 606365 Dashboard.....	18
106.1 606366 Cab Heater.....	20
107.1 606367 Instruments And Lights Panel.....	22
108.1 606368 Overload Warning System.....	24

200 Frame Unit

201.1 606369 Rear Frame Unit.....	26
202.1 606370 Hydraulic System - Axle Levelling.....	28
203.1 606371 Hydraulic System - Axle Locking.....	30
204.1 606372 Hydraulic System - Stabilizer.....	32
205.1 606373 Frame.....	34
206.1 606374 Frame.....	36

300 Transmission Unit

301.1 606375 Hydraulic System - Gearbox.....	38
302.1 606376 Power Steering System.....	40
303.1 606377 Hydraulic System - Control Valve.....	42
304.1 606378 Parking Brake.....	44
305.1 606379 Hydraulic System - Transmission.....	46
306.1 606380 Hydraulic System - Service Brake.....	48
307.1 606381 Transmission And Wheels.....	50
308.1 606382 Reduction Gear.....	52
309.1 606383 Front Axle - Differential Case.....	54
310.1 606384 Front Axle - Differential Gear.....	56
311.1 606385 Front Axle - Steering Axle.....	58
312.1 606386 Front Axle - Brake.....	60
313.1 606387 Front Axle - Steering Cylinder.....	62
314.1 606388 Front And Rear Axle - Support.....	64
315.1 606389 Rear Axle - Differential Case.....	66
316.1 606390 Rear Axle - Differential Gear.....	68
317.1 606391 Rear Axle - Steering Axle.....	70
318.1 606392 Rear Axle - Brake.....	72
319.1 606393 Rear Axle - Steering Cylinder.....	74

400 Telescopic Boom Unit

401.1 606400 Arm.....	76
402.1 606401 Arm.....	78
403.1 606402 Forks.....	80
404.1 606403 Hydraulic System - Tilting.....	82
405.1 606404 Hydraulic System - Boom Extension.....	84
406.1 606405 Coupling Unit.....	86
407.1 606406 Hydraulic System - Implement Locking.....	88
408.1 606407 Hydraulic System - Auxiliary Circuit.....	90
409.1 606408 Hydraulic System - Fork Balancing.....	92
410.1 606409 Hydraulic System - Lifting.....	94

500 Diesel Engine Unit

501.1 606412 Decals And Plates.....	96
502.1 606413 Diesel Engine - Supports And Accessories.....	98
503.1 606414 Diesel Engine - Engine Cooling System.....	100
504.1 606415 Diesel Engine - Exhaust System.....	102
505.1 606416 Diesel Engine - Accelerator.....	104
506.1 606417 Diesel Engine - Injection System.....	106
507.1 606418 Hydraulic System - Oil Cooler.....	108
508.1 606419 Suction System Hydraulic Pumps.....	110

600 Electric Installation Unit

601.1 606420 Fuse Box.....	112
602.1 606421 Electric Installation - Engine Line.....	114
603.1 606422 Electric Installation - Rear Line.....	116
604.1 606423 Electric Installation - Rear Line.....	118
605.1 606424 Electric Installation - Dashboard Line.....	120
606.1 606425 Electric Installation - Side Cab Line.....	122
607.1 606427 Electric Installation - Rear Line.....	124
608.1 606428 Electric Installation - Rear Lights.....	126
609.1 606429 Connector Initials.....	128
610.1 606430 Connector Initials.....	130
611.1 606431 Connector Initials.....	132
612.1 606432 Connector Initials.....	134
613.1 606433 Connector Initials.....	136

700 Optionals

701.1 606394 Hydraulic Jack.....	138
702.1 606395 Rear View Mirror.....	140
703.1 606396 Windscreen Grate.....	142
704.1 606397 Boom Work Light (Part 1).....	144
705.1 606398 Boom Work Light (Part 2).....	146
706.1 606399 Cabin Work Light.....	148
707.1 606410 Windscreen Wiper.....	150
708.1 606411 Lock Forks.....	152

Indices

Part Number Index.....	154
Part Description Index.....	158

Cross References

Fittings Cross Reference.....	162
-------------------------------	-----

This Page Intentionally Left Blank

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal grey lines across the entire width of the page, typical of notebook or primary writing paper. There are no margins, text, or other markings present.

Required Parts

The following parts are required to perform maintenance procedures as outlined in the GTH-4013EX Operator's and Service Manuals.

Description	Part No.
Fuel Filter.....	07.4501.0057
Engine Oil Filter	638243
Hydraulic Oil Filter Element	07.0700.0023
Primary Air Filter Element	07.4501.0084
Safety Air Filter Element	07.4501.0085
Oil filter (Inside the tank).....	09.4604.0000

Used Varnishes

Description	Type
Terex Grey	RAL 7012
Terex White	RAL 1013
Terex Matte Black for Cylinders	RAL 9005
Ausa Orange.....	RAL 2004
Mz Imer Orange.....	RAL 2010
Genie Blue	
Genie Grey.....	
Genie Matte Black for Cylinders.....	RAL 9005

Manuals

Genie offers the following support documents for these models:

Title	Part No.
Genie GTH-4013AU.2 - GTH 4017AU.2 - GTH-4514AU.2 Operator's Manual, 1 st edition (English).....	57.0009.0508
Service Manual, 1 st edition (English).....	57.0009.0427

Part list abbreviations

ZN	Zinc-plated
RNFT	Reinforced
FLNG	Flanged
PSNT	Heavy type
OC	Eye
PSRT	Through-coupling
CNTF	Hole centre

How To Order Parts

Please be prepared with the following information when ordering replacement parts for your Genie product:

- ☒ Machine model number
- ☒ Machine serial number
- ☒ Genie part number
- ☒ Part description and quantity
- ☒ Purchase order number
- ☒ "Ship to" address
- ☒ Desired method of shipment
- ☒ Name and telephone number of the authorized
Genie Distributor in your area

Use the Service Parts Fax Order Form on the next page and fax your order to our Parts Department.

If you don't know the name of your authorized distributor, or if your area is not currently serviced by an authorized distributor, please call Genie Industries.

Machine Information

Model

Serial Number

Date of Purchase

Authorized Genie Distributor

Phone Number

Genie North America

Telephone (425) 556-6551

Toll Free (877) 367-5606 in U.S.A. and Canada

Fax (425) 556-8659

Genie UK

Parts Telephone (44) (0) 1476 584352

Parts Fax (44) (0) 1476 584340

Genie Australia

Parts Telephone (617) 03375 1660

Parts Fax (617) 03375 1002

Genie France

Parts Telephone (33) (0) 237 26 09 99

Parts Fax (33) (0) 237 31 50 10

Genie Germany

Parts Telephone (49) (0) 4202 885223

Parts Fax (49) (0) 4202 885225

Genie Scandinavia

Parts Telephone (46) (31) 3409612

Parts Fax (46) (31) 3409613

Genie Iberica

Parts Telephone (34) (93) 5795042

Genie Brazil

Parts Telephone (55) (114) 1665755

Parts Fax (55) (114) 1665754

Genie Japan


Parts Telephone (81) (33) 4536082

Parts Fax (81) (33) 4536083


Genie China

Parts Telephone (86) (215) 3852570

Parts Fax (86) (215) 3852569




101.1 606361 Complete Seat




Item	Part No.	Description	Qty.
1	07.0740.0363	Back Cover Assembly.....	1
2	07.0740.0364	Seat Cover Assembly.....	1
3	07.0740.0365	Back Foam Kit.....	1
4	07.0740.0366	Seat Foam Kit.....	1
5	07.0740.0367	Seat Frame Assembly.....	1
6	07.0740.0368	Suspension Cover Kit.....	1
7	07.0740.0369	Handle Kit.....	1
8	07.0740.0370	Weight Adjuster Kit.....	1
9	07.0740.0371	Damper Kit.....	1
10	07.0740.0372	Height Adjustment Kit.....	1

102.1 606362 Complete Air Heater




Item	Part No.	Description	Qty.
1	07.0740.0360	Electrical Fan.....	1
2	07.0740.0361	Diffuser.....	1
3	07.0740.0359	Heater.....	1

103.1 606363 Cab




Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0066	Filter.....	1	41	07.0740.0098	Tank.....	1
2	07.0740.0067	Grate.....	1	42	07.0740.0099	Glass.....	1
3	07.0740.0130	Ball-Grip.....	2	43	07.0740.0100	Stop.....	1
4	07.0740.0069	Seal.....	1	44	07.0740.0374	Trough Coupling.....	1
5	07.0740.0070	Sheet.....	1	45	07.0740.0102	Washer.....	1
6	01.0031.0055	Washer.....	12	46	07.0740.0103	Nut.....	1
7	01.0001.0254	Screw.....	18	47	07.0740.0104	Door Stop.....	1
8	07.0740.0072	Wiper Motor.....	1	48	07.0740.0105	Screw.....	3
9	07.0740.0073	Glass.....	1	49	07.0740.0106	Seal.....	1
10	07.0740.0074	Glass.....	1	50	07.0740.0028	Hex Cap.....	6
11	07.0740.0246	Glass.....	1	51	07.0740.0006	Washer.....	10
12	07.0740.0052	Seal.....	2,5-m	52	07.0740.0005	Stop Nut.....	3
13	07.0740.0076	Handle.....	2	53	07.0740.0107	Frame.....	1
14	07.0740.0217	Split Pin.....	2	59	07.0740.0247	Kit.....	1
15	07.0740.0078	Hinge.....	2	60	07.0740.0202	Driving Mirror.....	1
16	07.0740.0079	Screw.....	7	61	07.0740.0157	Wiper Blade.....	1
17	07.0740.0046	Stop Nut.....	7	62	07.0740.0158	Wiper Motor.....	1
18	07.0740.0014	Hex Cap.....	7	63	07.0740.0210	Rubber.....	1
19	07.0740.0080	Rubber.....	2	64	07.0740.0211	Spacer.....	1
20	07.0740.0081	Washer.....	3	65	07.0740.0212	Screw.....	2
21	07.0740.0082	Loadspeaker Frame.....	2	66	07.0740.0213	Bushing.....	2
22	01.4001.0116	Screw.....	10	67	07.0740.0214	Rubber.....	2
23	07.0740.0084	Roof Lamp.....	1	68	07.0740.0035	Rubber.....	2
24	07.0740.0203	Mirror Arm.....	1	69	07.0740.0215	Spacer.....	2
25	07.0740.0085	Glass.....	1	70	07.0740.0156	Wiper Arm.....	1
26	07.0740.0009	Rubber.....	3	71	07.0740.0209	Kit.....	1
27	07.0740.0086	Rubber.....	1	72	07.0740.0156	Wiper Arm.....	1
28	07.0740.0032	Washer.....	1	73	07.0740.0163	Screw.....	2
29	07.0740.0087	Glass.....	1	74	07.0740.0117	Bushing.....	2
30	07.0740.0088	Wiper Arm.....	1	75	07.0740.0248	Wiper Blade.....	1
31	07.0740.0089	Wiper Blade.....	1	76	07.0740.0374	Trough Coupling.....	1
32	07.0740.0090	Through Coupling.....	1				
33	07.0740.0091	Seal.....	1,5-m				
34	07.0740.0092	Lock.....	1				
35	01.0031.0299	Washer.....	8				
36	07.0740.0093	Storage Pocket.....	1				
37	01.4001.0116	Screw.....	4				
38	01.0003.0203	Screw.....	4				
39	01.0023.0054	Stop Nut.....	2				
40	07.0740.0097	Mirror Kit.....	1				

104.1 606364 Cab




Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0000	Pin.....	3	41	07.0740.0063	Washer.....	2
2	07.0740.0001	Split Pin.....	3	42	07.0740.0128	Screw.....	4
3	07.0740.0002	Grease Nipple.....	3	43	07.0740.0009	Rubber.....	1
4	07.0740.0003	Seat.....	1	44	07.0740.0060	Screw.....	1
5	07.0740.0004	Screw.....	2	45	07.0740.0231	Plug.....	1
6	07.0740.0005	Stop Nut.....	2	46	07.0740.0062	Washer.....	1
7	07.0740.0006	Washer.....	2	47	07.0740.0027	Plug.....	4
8	07.0740.0007	Screw.....	4	48	07.0740.0028	Hex Cap.....	2
9	07.0740.0275	Screw.....	4	49	07.0740.0250	Lower Door.....	1
10	07.0740.0274	Coating.....	1	50	07.0740.0277	Upper Door Complete.....	1
11	07.0740.0010	Support.....	1	51	07.0740.0029	Handle.....	1
12	07.0740.0011	Screw.....	2	52	07.0740.0030	Pin.....	1
13	07.0740.0012	Washer.....	4	53	07.0740.0228	Rubber.....	6
14	07.0740.0013	Stop Nut.....	2	54	07.0740.0227	Screw.....	2
15	07.0740.0014	Hex Cap.....	8	55	07.0740.0047	Label.....	1
16	07.0740.0015	Rubber.....	1	56	07.0740.0279	Glass.....	1
17	07.0740.0016	Washer.....	2	57	07.0703.0125	Key.....	1
18	07.0740.0017	Nut.....	1	58	07.0740.0230	Seal.....	1
19	07.0740.0018	Non-Skid Coating.....	0,7-m	59	07.0740.0229	Reinforcement.....	1
20	07.0740.0235	Rubber Platform.....	1	61	07.0740.0223	Washer.....	6
21	07.0740.0020	Coating.....	1	62	07.0740.0272	Handle.....	1
22	07.0740.0021	Coating.....	1	63	07.0740.0276	Hinge.....	2
23	07.0740.0022	Adhesive Profile.....	1				
24	07.0740.0054	Stop Belt.....	1				
25	07.0740.0024	Support.....	1				
26	07.0740.0025	Screw.....	2				
27	07.0740.0026	Washer.....	6				
28	07.0740.0048	Seal.....	1				
29	07.0740.0049	Seal.....	1				
30	07.0740.0050	Handle.....	1				
31	07.0740.0051	Lever-Fitted Lock.....	1				
32	07.0740.0052	Seal.....	3,5-m				
33	07.0740.0273	Panel.....	1				
34	07.0740.0035	Bushing.....	1				
35	07.0740.0055	Bushing.....	1				
36	07.0740.0249	Frame.....	1				
37	07.0740.0236	Sun Visor.....	1				
38	07.0740.0058	Seal.....	1				
39	07.0740.0059	Screw.....	2				
40	07.0740.0061	Nut.....	2				

105.1 606365 Dashboard




Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0139	Dashboard.....	1	42	56.0016.0032	Control Lever.....	1
2	07.0740.0140	Dashboard.....	1	43	07.0741.0017	Cap.....	1
3	07.0740.0141	Lock.....	1	44	07.0741.0019	Cap.....	1
4	07.0740.0142	Cover.....	1	45	07.0703.0019	Pilot Light.....	1
5	07.0740.0116	Screw.....	28	46	07.0703.0532	Contact.....	1
6	07.0740.0117	Washer.....	28	47	07.0741.0009	Selector.....	1
7	07.0740.0037	Washer.....	3	48	633606	Relay.....	1
8	07.0740.0143	Cover.....	1				
9	07.0740.0144	Screw.....	3				
10	07.0740.0145	Washer.....	3				
11	09.4610.0001	Bubble Level.....	1				
12	07.0740.0154	Spring.....	3				
13	07.0703.0035	Switch Cover.....	1				
14	07.0703.0419	Switch.....	2				
15	07.0703.0417	Speed Lever.....	1				
16	07.0703.0418	Turn Signals Lever.....	1				
17	07.0703.0420	Security Switch.....	1				
18	07.0703.0017	Switch Cover.....	1				
19	07.0703.0441	Emergency Button.....	1				
20	07.0703.0489	Plug.....	1				
21	07.0741.0018	Handle.....	1				
22	07.0703.0423	Plug.....	5				
23	07.0740.0062	Rivet.....	3				
24	07.0740.0152	Ball-Grip.....	1				
25	07.0740.0206	Screw.....	4				
26	96008	Selector.....	1				
27	07.0703.0419	Switch.....	1				
28	07.0703.0581	Panel.....	1				
29	07.0741.0010	Cap.....	1				
30	07.0741.0011	Push Button.....	3				
31	07.0741.0012	Push Button.....	1				
32	07.0741.0014	Protection.....	1				
33	07.0703.0034	Switch Cover.....	1				
34	07.0740.0234	Lock.....	1				
35	07.0740.0208	Support.....	1				
36	07.0703.0531	Contact.....	1				
38	07.0740.0151	Bushing.....	1				
39	07.0740.0169	Rivet.....	4				
40	07.0740.0042	Screw.....	2				
41	07.0740.0012	Washer.....	2				

106.1 606366 Cab Heater



Item	Part No.	Description	Qty.
1	07.0740.0119	Heater.....	1
2	07.0740.0120	Paper Piping.....	0,75-m
3	07.0740.0120	Paper Piping.....	0,65-m
4	07.0740.0120	Paper Piping.....	1,55-m
5	07.0740.0120	Paper Piping.....	0,33-m
6	07.0740.0120	Paper Piping.....	0,32-m
7	07.0740.0120	Paper Piping.....	0,4-m
8	07.0740.0121	Pipe Fitting.....	1
9	07.0740.0122	Rubber Hose.....	6.0-m
10	07.0740.0122	Rubber Hose.....	0,8-m
11	07.0740.0122	Rubber Hose.....	5.0-m
12	07.0740.0123	Clamp.....	4
13	07.0740.0124	Screw.....	4
14	07.0740.0125	Air Inlet.....	5
15	07.0740.0126	Reduction.....	5
16	07.0740.0127	Clamp.....	8
17	07.0740.0128	Screw.....	2
18	07.0740.0129	Air Inlet.....	1
19	07.0740.0006	Washer.....	1
20	07.0740.0005	Stop Nut.....	1
21	07.0740.0028	Hex Cap.....	1
22	07.0740.0130	Ball-Grip.....	1
23	07.0740.0219	Name Plate.....	1
24	07.0740.0118	Screw.....	2
25	07.0740.0016	Washer.....	2
26	07.0740.0132	Support.....	1
27	07.0740.0012	Washer.....	2
28	07.0740.0071	Screw.....	2
29	07.0740.0133	Rubber.....	2
30	07.0740.0218	Tap.....	1
31	04.0227.0068	Light Hose-clamp 22\32.....	2
32	04.0600.0196	Reduction adapter.....	2




107.1 606367 Instruments And Lights Panel



107.1 606367 Instruments And Lights Panel

Item	Part No.	Description	Qty.
1	07.0703.0433	Switch.....	1
2	07.0703.0434	Glass.....	1
3	07.0703.0433	Switch.....	1
4	56.0017.0032	Glass.....	1
5	07.0703.0435	Switch.....	1
6	07.0703.0010	Glass.....	1
7	07.0703.0673	Glass.....	1
8	07.0703.0572	Glass.....	1
9	07.0703.0032	Switch.....	1
10	07.0703.0029	Starting Switch.....	1
11	07.0703.0125	Key.....	1
12	07.0703.0614	Control Panel.....	1
13	07.0703.0618	Pilot Light.....	1
14	07.0703.0425	Hydraulic oil Temperature Indicator.....	1
15	07.0703.0431	Switch.....	1
16	56.0017.0059	Glass.....	1
17	07.0703.0430	Switch.....	1
18	07.0703.0429	Selector.....	1
19	638226	Switch, Selector, 3 Position.....	1
20	07.0703.0423	Plug.....	1
21	07.0703.0440	Glass.....	1


108.1 606368 Overload Warning System



108.1 606368 Overload Warning System

Item	Part No.	Description	Qty.
1	01.0031.0054	Washer.....	6
2	01.4032.0002	Spring Washer.....	6
3	01.0001.0158	Screw.....	2
4	51.0811.2400	Bracket.....	1
5	56.0000.0051	Lock Cable Kit.....	1
6	01.0003.0157	Screw.....	4
7	56.0012.0042	Length Angle Trasducer.....	1
8	09.0803.0357	Angle Indicator.....	1
9	01.4003.0000	Screw.....	2
10	56.0016.0077	Overload Display.....	1
11	56.0021.0093	Overload Sistem Control Box.....	1
12	56.0012.0062	Pressure Transducer.....	4


201.1 606369 Rear Frame Unit



201.1 606369 Rear Frame Unit

Item	Part No.	Description	Qty.
1	51.1000.4900	Counterweight.....	1
2	01.0001.0156	Screw.....	2
3	01.4032.0002	Spring washer D6 ZN.....	10
4	01.4001.0058	Screw.....	4
5	01.0023.0055	Nut.....	2
6	01.4032.0009	Spring Washer.....	4
7	01.0031.0061	Plain Washer.....	4
8	51.0800.2700	Hook.....	1
9	09.0803.0039	Pin.....	1
10	01.0001.0604	Screw.....	4
11	01.4032.0006	Spring Washer.....	4
12	51.0809.5700	Bracket.....	1
13	09.0803.0026	Spring Split Pin.....	1
14	51.0902.5400	Lock.....	1
15	09.0803.0360	Hook..... Latch	1
16	51.0811.4042	Support.....	2
17	09.4670.0001	Dumper.....	2
18	51.0811.4019	Plate Support.....	2
19	51.0811.4043	Support.....	2
20	09.0803.0087	Fork.....	2
21	01.0031.0058	Plain Washer.....	4
22	01.0001.0306	Screw.....	2
23	01.0031.0301	Plain Washer.....	6
24	09.0803.0395	Hinge.....	2
25	09.0803.0419	Key.....	1
26	01.0031.0062	Spring Washer.....	4
27	01.4001.0001	Screw.....	4
28	51.1000.4700	Counterweight.....	2
29	01.4023.0000	Stop Nut.....	4
30	01.0031.0054	Washer D6 ZN.....	10
31	01.0001.0154	Screw TE M 6X16 UNI 5739 8.8 ZN.....	8
32	01.0031.0055	Washer D8 UNI 6592 ZN.....	6
33	01.4032.0003	Spring washer D8 UNI 1752.....	4
34	01.0001.0256	Screw TE M 8X25 UNI 5739 8.8 ZN.....	4


202.1 606370 Hydraulic System - Axle Levelling



202.1 606370 Hydraulic System - Axle Levelling

Item	Part No.	Description	Qty.
1	04.4236.0058	Control Valve.....	1
2	07.0741.0001	Valve.....	1
3	07.0741.0000	Solenoid.....	6
4	07.0741.0031	Bracket.....	2
5	01.4032.0003	Plain Washer.....	2
6	07.0741.0015	Joint Kit.....	1
7	01.0001.0254	Screw.....	2
8	04.0607.0145	Pipe Fitting.....	2
9	04.0605.0309	Flexible Hose.....	1
10	04.0605.0351	Flexible Hose.....	1
11	07.0741.0033	Washer.....	1
12	07.0741.0032	Plug.....	1
13	04.4210.0006	Pressure Tube.....	1
14	04.0607.0114	Pipe Fitting.....	2
15	04.0605.0554	Flexible Hose.....	2
16	04.0607.0167	Pipe Fitting.....	2
17	01.4003.0002	Screw.....	4
18	01.0001.0154	Screw.....	2
19	04.4239.0007	Valve.....	1
20	53.0600.1200	Swaying Cylinder.....	1
21	02.0117.0101	Grease Nipple.....	2
22	07.0721.0101	Bushing.....	2
23	07.4529.0108	Joint Kit.....	1
24	51.0902.3800	Guard.....	1
25	01.4032.0002	Spring Washer.....	2


203.1 606371 Hydraulic System - Axle Locking



203.1 606371 Hydraulic System - Axle Locking

Item	Part No.	Description	Qty.
1	53.0700.0300	Cylinder.....	1
2	07.4529.0093	Joint Kit.....	1
3	628924	Bushing.....	2
4	02.0117.0101	Grease Nipple.....	2
5	03.0000.0008	Ball Joint.....	1
6	04.0607.0145	Pipe Fitting.....	1
7	04.0605.0543	Flexible Hose.....	1
8	01.4006.0001	Screw.....	2
9	51.0901.6700	Guard.....	1
10	04.4240.0024	Solenoid Valve.....	2
11	04.4240.0025	Solenoid.....	2
12	04.0600.0092	Screw.....	1
13	09.0803.0012	Washer.....	2


204.1 606372 Hydraulic System - Stabilizer



204.1 606372 Hydraulic System - Stabilizer


Item	Part No.	Description	Qty.
1	51.0500.1200	Stabilizer.....	2
2	51.0500.1300	End..... Base	2
3	54.0000.0096	Pin.....	4
4	01.0001.0310	Screw.....	2
5	54.0000.0097	Pin.....	2
6	54.0000.0098	Pin.....	2
7	09.0801.0000	Bushing.....	12
8	53.0800.1400	Right Stabilizer Cylinder.....	1
9	07.4529.0106	Joint Kit.....	2
10	04.0214.0035	Drilled Screw.....	4
11	04.4239.0007	Valve.....	2
12	01.0023.0055	Nut.....	2
13	04.0607.0117	Pipe Fitting.....	4
14	06.0442.0103	Washer.....	8
15	04.0605.0555	Flexible Hose.....	4
16	02.0117.0101	Grease Nipple.....	4
17	53.0800.1500	Left Stabilizer Cylinder.....	1
18	09.0801.0001	Bushing.....	4

205.1 606373 Frame




Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	51.0113.9000	Basic Frame.....	1	42	54.0002.0022	Pin.....	1
2	09.0803.0414	Left Mud-Guard.....	1	43	54.0002.0023	Pin.....	1
3	51.0805.1600	Rear Support.....	1	44	51.0806.7400	Right Attachment.....	1
4	51.0809.3400	Front Support.....	1	45	51.0800.0400	Plate.....	1
5	09.0803.0414	Left Mud-Guard.....	1	46	01.4001.0000	Screw.....	4
6	01.0001.0304	Screw.....	2	47	01.0031.0062	Plain Washer.....	8
7	09.4661.0014	Plug.....	1	48	09.4661.0016	Filter.....	1
8	51.0808.9000	Ladder.....	1				
9	51.0600.9200	Diesel Oil Tank.....	1				
10	51.0902.3100	Guard.....	1				
11	56.0013.0001	Fuel Gauge.....	1				
12	09.0803.0352	Threaded Plate.....	7				
13	01.0001.0564	Screw.....	1				
14	01.0023.0057	Stop Nut.....	5				
15	54.0003.0033	Pin.....	1				
16	01.0023.0060	Stop Nut.....	8				
17	01.0031.0061	Plain Washer.....	8				
18	01.4001.0001	Screw.....	8				
19	01.4001.0078	Screw.....	7				
20	01.0001.0657	Screw.....	4				
21	01.4023.0000	Stop Nut.....	4				
22	01.0001.0017	Screw.....	2				
23	01.0031.0301	Spring Washer.....	2				
24	01.0023.0055	Stop Nut.....	10				
25	06.0442.0103	Washer.....	1				
26	04.0220.0055	Plug.....	1				
27	01.4006.0011	Screw.....	6				
28	09.0803.0012	Conic Washer.....	6				
29	01.0031.0058	Plain Washer.....	10				
30	01.0031.0054	Plain Washer.....	6				
31	01.0023.0053	Nut, M6.....	6				
32	01.4031.0003	Plain Washer.....	2				
33	01.0031.0056	Washer.....	4				
34	01.0001.1493	Screw.....	4				
36	01.0001.0356	Screw.....	8				
37	09.4670.0006	Insulator.....	4				
38	01.0001.0314	Screw.....	2				
39	51.0902.3200	Casing.....	1				
40	54.0100.0020	Protection.....	1				
41	01.0031.0059	Plain Washer.....	4				

206.1 606374 Frame



Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	51.0805.1500	Rear Support.....	1	41	09.0803.0501	Gas Spring.....	2
2	09.0803.0414	Right Mud-Guard.....	1	42	01.4032.0004	Spring Washer.....	2
3	51.0809.3100	Front Support.....	1	43	09.4610.0002	Driving Mirror.....	1
4	09.0803.0414	Right Mud-Guard.....	1	44	51.0808.3000	Support.....	1
5	01.4006.0011	Screw.....	6	45	51.0810.5500	Stop.....	1
6	09.0803.0012	Conic Washer.....	6	46	09.0804.2500	Sound-Proof Panel.....	1
7	01.0023.0053	Nut, M6.....	6	47	09.0804.2600	Sound-Proof Panel.....	1
8	01.0031.0301	Plain Washer.....	18	48	09.0804.2700	Sound-Proof Panel.....	1
9	01.0001.0466	Screw.....	6	49	09.0804.2800	Sound-Proof Panel.....	1
10	01.0001.1493	Screw.....	4	50	09.0804.2900	Sound-Proof Panel.....	1
11	01.0031.0058	Plain Washer.....	4	51	09.0804.3000	Sound-Proof Panel.....	1
12	01.0023.0057	Stop Nut.....	4				
13	51.0902.3100	Guard.....	1				
14	54.0000.0157	Pin.....	1				
15	52.1100.7700	Guard.....	1				
16	51.0808.5100	Connection.....	1				
17	54.0000.0155	Pin.....	1				
18	07.0740.0050	Handle.....	1				
19	07.0740.0192	Lock.....	1				
20	01.0001.1465	Screw.....	6				
21	01.0031.0055	Washer.....	4				
22	01.4023.0000	Stop Nut.....	4				
23	01.0023.0054	Stop Nut.....	12				
24	51.0902.4500	Grate.....	1				
25	09.0804.2400	Sound-Proof Panel.....	1				
26	01.0023.0055	Nut.....	9				
27	01.0001.0257	Screw.....	2				
28	01.0001.0078	Screw.....	2				
29	01.4001.0078	Screw.....	5				
30	07.0740.0100	Pin.....	1				
31	51.0808.3100	Support.....	1				
32	51.0800.0400	Plate.....	1				
33	51.0808.6900	Support Casing.....	1				
34	09.0803.0368	Hinge.....	1				
35	01.4001.0000	Screw.....	4				
36	51.0810.5300	Bracket.....	1				
37	01.0031.0299	Plain Washer.....	6				
38	01.0001.0039	Stop Nut.....	7				
39	01.0001.0355	Screw.....	2				
40	01.0001.0306	Screw.....	8				


301.1 606375 Hydraulic System - Gearbox



301.1 606375 Hydraulic System - Gearbox

Item	Part No.	Description	Qty.
1	04.0605.0547	Flexible Hose.....	1
2	04.0605.0545	Flexible Hose.....	1
3		606379 pos.5	
4	04.4240.0055	Solenoid Valve.....	1
5	04.0607.0114	Pipe Fitting.....	4
6	04.0605.0546	Flexible Hose.....	2
7	04.0607.0153	Pipe Fitting.....	2
8	01.0003.0158	Screw.....	2
9	07.4529.0111	Solenoid.....	1
10	07.0728.0006	Joint Kit.....	1
11	04.0607.0115	Pipe Fitting.....	1


302.1 606376 Power Steering System



302.1 606376 Power Steering System

Item	Part No.	Description	Qty.
1	09.4636.0014	Power Steering.....	1
2	07.0740.0136	Steering Column.....	1
3	07.0740.0135	Steering Wheel.....	1
4	07.4529.0111	Solenoid.....	2
5	04.4240.0052	Solenoid Valve.....	1
6	04.0607.0111	Pipe Fitting.....	3
7	04.0607.0110	Pipe Fitting.....	2
8	07.4529.0102	Seal.....	1
9	04.0607.0117	Pipe Fitting.....	4
10	04.0605.0525	Flexible Hose.....	1
11	04.0605.0536	Flexible Hose.....	1
12	04.0605.0309	Flexible Hose.....	1
13	01.0003.0158	Screw.....	2
14	04.0605.0534	Flexible Hose.....	1
15	04.0607.0137	Pipe Fitting.....	4
16	04.0605.0548	Flexible Hose.....	1
17	04.0605.0549	Flexible Hose.....	1
18	04.0605.0533	Flexible Hose.....	1
19	04.0605.0535	Flexible Hose.....	1
20	04.0605.0540	Flexible Hose.....	1
21	04.0607.0107	Pipe Fitting.....	1
22	04.4238.0053	Pump.....	1
23	04.0607.0174	Pipe Fitting.....	1
24	627521	Seal.....	1
25	04.4223.0000	Flange.....	1
26	04.0605.0538	Flexible Hose.....	1
27	07.0722.0053	Flange.....	1
28	01.0003.0255	Screw.....	3
29	04.0607.0113	Pipe Fitting.....	2
30	07.4529.0115	Joint Kit.....	1
31	07.0737.0012	Steering Set Screw.....	1
32	07.0723.0195	Lever.....	1


303.1 606377 Hydraulic System - Control Valve



303.1 606377 Hydraulic System - Control Valve

Item	Part No.	Description	Qty.
1	04.4236.0082	Control Valve.....	1
2	04.0607.0142	Pipe Fitting.....	2
3		606376 pos.20	
4		606418 pos.1	
5		606408 pos.17	
6	04.0607.0113	Pipe Fitting.....	1
7		606370 pos.9	
8		606376 pos.12	
9		606375 pos.1	
10		606380 pos.21	
11	04.0607.0130	Pipe Fitting.....	1
12	04.0607.0160	Pipe Fitting.....	1
13	04.0605.0550	Flexible Hose.....	1
14	07.0741.0003	Valve.....	2
15	07.0741.0016	Joint Kit.....	1
16	07.0741.0002	Valve.....	1
17	07.0741.0004	Modulus.....	3
18	07.0741.0005	Modulus.....	1
19	07.0741.0008	Valve.....	1
20	07.0741.0058	Solenoid.....	1
21	04.0607.0121	Pipe Fitting.....	3
22	04.0607.0164	Pipe Fitting.....	2
23	04.0605.0557	Flexible Hose.....	1
24	04.0607.0163	Pipe Fitting.....	1
25	07.0741.0001	Valve.....	1


304.1 606378 Parking Brake



304.1 606378 Parking Brake

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	05.4315.0004	Lever.....	1	37	01.0023.0053	Nut..... ECN 028/09	2
2	07.0740.0063	Washer.....	4				
3	01.0031.0055	Plain Washer.....	7				
4	01.0003.0023	Screw.....	4				
5	09.4645.0022	Cable.....	2				
6	07.0703.0492	Microswitch.....	1				
7	01.0031.0058	Plain Washer.....	2				
8	02.0112.0155	Cotter Pin.....	2				
9	07.0740.0170	Pin.....	1				
10	07.0740.0171	Pulley.....	1				
11	01.4001.0010	Screw.....	1				
12	51.0811.4146	Support..... ECN 028/09	1				
13	01.0001.0254	Screw.....	1				
14	07.0740.0013	Stop Nut.....	2				
15	51.0811.4147	Plate..... ECN 028/09	1				
16	07.0470.0175	Washer.....	2				
17	51.0808.7600	Support.....	1				
18	54.0001.0041	Pin.....	2				
19	02.0117.0053	Grease Nipple.....	2				
20	01.0001.0043	Stop Nut.....	2				
21	54.0800.0000	Spring.....	2				
22	01.4032.0009	Spring Washer.....	1				
23	01.0001.0902	Screw.....	1				
24	51.0808.0700	Bracket.....	2				
25	01.4032.0005	Spring Washer.....	2				
26	01.0001.0604	Screw.....	2				
27	07.0730.0063	Spring.....	1				
28	07.0730.0064	Push Button.....	1				
29	07.0730.0066	Screw.....	1				
30	07.0730.0067	Nut.....	1				
31	07.0730.0069	Dowel.....	1				
32	07.0730.0068	Pin.....	1				
33	07.0730.0065	Pin.....	1				
34	01.0001.0156	Screw..... ECN 028/09	2				
35	01.0031.0054	Washer..... ECN 028/09	2				
36	51.0811.4148	Microswitch Bracket..... ECN 028/09	1				


305.1 606379 Hydraulic System - Transmission



305.1 606379 Hydraulic System - Transmission

Item	Part No.	Description	Qty.
1	04.0605.0527	Flexible Hose.....	1
2	04.0605.0537	Flexible Hose.....	1
3	04.0605.0543	Flexible Hose.....	1
4	04.4238.0071	Pump.....	1
5	04.0605.0599	Flexible Hose.....	1
6	07.0701.0180	Joint Kit.....	1
7	07.0701.0203	Joint Kit.....	1
8	07.0701.0204	Seal.....	1
9	04.4235.0041	Hydraulic Motor.....	1
10	04.4223.0003	Half Flange.....	8
11	06.0401.0219	Seal.....	4
12	07.0721.0202	Seal.....	1
13	07.0701.0205	Solenoid.....	1
14	04.4210.0004	Pressure Tube.....	1
15	07.0701.0196	Solenoid Valve.....	1
16	04.0607.0207	Pipe Fitting.....	2
17	04.0605.0420	Flexible Hose.....	1
18	04.0607.0184	Pipe Fitting.....	1
19	04.4229.0044	Flexible Hose.....	1
20	04.4229.0045	Flexible Hose.....	1
21	04.0607.0188	Pipe Fitting.....	1
22	04.4210.0003	Pressure Tube.....	1
23	04.0600.0077	Pipe Fitting.....	1
24	01.0001.0401	Screw.....	16
25	01.4032.0005	Spring Washer.....	16
26	06.0442.0105	Washer.....	2
27	04.4239.0013	Valve.....	1
28	04.0607.0107	Pipe Fitting.....	1
29	07.0701.0007	Solenoid.....	2
30	04.0600.0159	Pipe Fitting.....	1
31	04.0600.0067	Pipe Fitting.....	1
32	04.0607.0149	Pipe Fitting.....	1
33	07.0701.0205	Solenoid Valve.....	1


306.1 606380 Hydraulic System - Service Brake



306.1 606380 Hydraulic System - Service Brake

Item	Part No.	Description	Qty.
1	05.4309.0000	Pump.....	1
2	04.0600.0166	Wheelstud.....	2
3		606370 pos.10	
4	01.0031.0055	Plain Washer.....	4
5	01.0031.0054	Washer.....	8
6	06.0442.0055	Washer.....	12
7	05.0400.0000	Flexible Hose.....	4
8	05.0401.0001	Pipe Fitting.....	6
9	05.0401.0003	Drilled Screw.....	10
10	05.0401.0000	Pipe Fitting.....	2
11	09.0803.0016	Clamp.....	1
12	53.3402.0700	Pipe.....	1
13	01.0023.0054	Nut.....	2
14	01.0001.1466	Screw.....	2
15	07.0740.0264	Pipe Fitting.....	2
16	04.0605.0245	Flexible Hose.....	2
17	04.0607.0114	Pipe Fitting.....	2
18	53.3402.0800	Pipe.....	1
19	05.4329.0029	Accumulator.....	2
20	05.0401.0005	Wheelstud.....	4
21	04.0605.0542	Flexible Hose.....	1
22	07.0607.0111	Pipe Fitting.....	1
23	04.0605.0541	Flexible Hose.....	1
24	07.0740.0264	Pipe Fitting.....	1
25	07.0730.0036	Plug.....	1
26	07.0730.0037	Washer.....	1
27	01.0003.0155	Screw.....	1
28	01.0001.0256	Screw.....	4
29	01.4032.0003	Spring Washer.....	4


307.1 606381 Transmission And Wheels



307.1 606381 Transmission And Wheels

Item	Part No.	Description	Qty.
1	09.4632.0061	Front Steering Axle.....	1
2	09.4632.0062	Rear Steering Axle.....	1
3	09.4635.0042	Cardan Shaft.....	1
4	09.4635.0041	Cardan Shaft.....	1
5	07.0738.0000	Star Wheel.....	4
6	09.4627.0017	Tyre 24".....	4
7	09.4635.0014	Cardan Joint Assembly Kit.....	4
8	09.4629.0000	Rim 20".....	4
9	09.4633.0020	Gear Box.....	1
10	55.0403.0043	Wheel 20".....	4
11	09.4627.0016	Tyre 20".....	4
12	09.4629.0003	Rim 12".....	4
13	55.0403.0044	Wheel 24".....	4


308.1 606382 Reduction Gear



308.1 606382 Reduction Gear

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0709.0847	Housing.....	1	37	07.0709.0864	O-Ring.....	1
2	639785	Dowel.....	2	38	07.0709.0865	O-Ring.....	1
3	629733	Shim.....	1	39	07.0709.0866	Piston.....	1
3	629735	Shim.....	1	40	07.0709.0867	Protection Ring.....	2
3	639327	Shim.....	1	41	07.0709.0868	O-Ring.....	2
3	639328	Shim.....	1	42	639808	Cap.....	2
3	639329	Shim.....	1	43	07.0709.0327	Dented Ball.....	1
4	07.0709.0848	Ball Bearing.....	1	44	635596	Spring.....	1
5	07.0709.0849	Cover.....	1	45	07.0709.0869	Grub Bolt.....	1
6	633202	Ball Bearing.....	1	46	07.0709.0870	O-Ring.....	1
7	639790	Seal Ring.....	1	47	639783	Cover.....	1
8	639789	Cover.....	1	48	07.0709.0010	Shim.....	1
9	07.0709.0079	Flange.....	2	48	07.0709.0011	Shim.....	1
10	639779	Vent Cap.....	1	48	07.0709.0012	Shim.....	1
11	633161	O-Ring.....	2	48	07.0709.0013	Shim.....	1
12	639802	Nut.....	2	49	07.0709.0941	Washer.....	2
13	639799	O-Ring.....	1	50	07.0709.0872	Sensor.....	2
14	07.0709.0851	Cover.....	1	51	07.0709.0942	Rubber Cap.....	2
15	637536	Seal.....	2	52	07.0709.0873	Seal Ring.....	1
16	56.0012.0047	Sensor.....	1	53	07.0709.0422	Screw.....	2
17	07.0709.0853	Phonic Wheel.....	1	54	639818	Washer.....	2
18	07.0709.0443	Ball Bearing.....	2	55	07.0709.0883	Input Shaft.....	1
19	633203	Protection Ring.....	1	56	07.0709.0880	Gear.....	1
20	07.0709.0854	Ball Bearing.....	4	57	07.0709.0881	Gear.....	1
21	07.0709.0855	Output Shaft.....	1				
22	07.0709.0856	Protection Ring.....	2				
23	07.0709.0857	Protection Ring.....	2				
24	07.0709.0858	Syncronizer.....	1				
25	07.0709.0720	Cover.....	1				
26	639792	Screw.....	2				
27	07.0709.0718	Washer.....	2				
28	639787	Screw.....	16				
29	633208	Cap.....	1				
30	628275	Magnetic Cap.....	1				
31	07.0709.0859	Cylinder.....	1				
32	07.0709.0860	Selector Shaft.....	1				
33	637576	O-Ring.....	1				
34	07.0709.0861	Seal Ring.....	1				
35	07.0709.0862	Reduction Bushing.....	1				
36	07.0709.0863	Sliding Pin.....	2				


309.1 606383 Front Axle - Differential Case



309.1 606383 Front Axle - Differential Case

Item	Part No.	Description	Qty.
1	632383	Seal.....	3
2	639668	Cover.....	1
3	07.0709.0721	Housing.....	1
4	07.0709.0084	Cover.....	1
5	639670	PlugG ,Breather.....	1
7	07.0709.0113	Plug.....	1
8	07.0709.0371	Plug.....	1
9	07.0709.0441	Snap Ring.....	1


310.1 606384 Front Axle - Differential Gear



310.1 606384 Front Axle - Differential Gear

Item	Part No.	Description	Qty.
1	639802	Nut.....	1
2	07.0709.0426	Flange.....	1
4	633098	Seal, Differential.....	1
5	639650	Screw.....	4
6	639651	Snap Ring.....	4
7	639652	O-Ring.....	1
8	630693	Ring Nut.....	1
9	639653	Spacer.....	1
10	639300	Spacer.....	1
10	639301	Spacer.....	1
10	639302	Spacer.....	1
10	639303	Spacer.....	1
11	634499	Spacer.....	1
11	634501	Spacer.....	1
11	639297	Spacer.....	1
11	639298	Spacer.....	1
12	626544	Bearing.....	2
13	07.0709.0216	Bevel Gear Set.....	1
14	639657	Screw.....	2
15	633099	Bearing.....	2
17	641090	Satellite.....	2
18	07.0709.0724	Satellite.....	4
19	07.0709.0722	Pin.....	4
20	639661	Snap Ring.....	4
21	639662	Washer, Friction.....	4
23	07.0709.0057	Screw.....	12
24	639664	Ring Nut.....	2
27	641089	Differential Case.....	1
28	07.0709.0374	Compl. Front Differential Gear.....	1
29	07.0709.0059	Clutch Disc.....	2

311.1 606385 Front Axle - Steering Axle




*65: Position Kit = 22+12

*66: Position Kit = 27+12

311.1 606385 Front Axle - Steering Axle

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	633174	Nut.....	2	44	639646	Snap Ring.....	2
2	640718	Screw.....	2	45	07.0709.0104	Screw.....	4
3	640214	Axle Case.....	2	46	634546	Nut, DIN439 JAM M16-2.0 P.....	4
4	07.0709.0377	Screw.....	32	49	639647	Plate, Locking.....	2
6	640720	Bushing.....	2	50	07.0709.0441	Snap Ring.....	2
7	630846	Seal, Planetary.....	2	52	07.0709.0068	Spacer.....	4
8	633202	BEARING.....	2	53	07.0709.0119	Stud.....	8
9	633203	Snap Ring.....	2	54	07.0709.0070	Nut.....	8
10	640216	Seal.....	2	56	07.0709.0071	Washer.....	8
11	639624	Joint.....	2	57	640728	Spacer.....	2
12	639289	Bushing.....	2	57	640729	Spacer.....	1
13	639625	BUSHING.....	2	57	640730	Spacer.....	1
14	640909	Screw.....	12	58	07.0709.0072	Grease Nipple.....	2
15	07.0709.0060	Cover.....	2	60	07.0709.0726	Support.....	2
16	638548	Cap.....	4	65	07.0709.0219	Housing.....	1
17	633176	Grease Nipple.....	2	66	07.0709.0121	Housing.....	1
18	07.0709.0061	Pin.....	2	72	07.0709.0365	Screw.....	4
19	640908	Pin.....	2	76	07.0709.0727	Support.....	2
20	639630	Seal.....	2				
21	639631	Joint, Articulated.....	2				
22	07.0709.0101	Housing.....	1				
23	07.0709.0215	Seal.....	2				
25	07.0709.0371	Plug.....	2				
26	07.0709.0113	Plug.....	4				
27	07.0709.0102	Housing.....	1				
28	07.0709.0205	Seal.....	2				
29	639637	Bearing.....	4				
30	07.0709.0117	Wheel Stud.....	16				
31	07.0709.0064	Hub.....	2				
32	632383	Seal.....	2				
33	639639	Ring Gear.....	2				
34	639640	Support, Ring Gear.....	2				
35	639641	Snap Ring.....	8				
36	639642	Pinion, Differential.....	8				
37	639643	Bearing.....	8				
38	07.0709.0118	Nut.....	16				
40	07.0709.0065	Screw.....	4				
41	07.0709.0724	Support.....	2				
42	639645	Stud.....	16				
43	637567	Nut.....	16				





312.1 606386 Front Axle - Brake



312.1 606386 Front Axle - Brake

Item	Part No.	Description	Qty.
1	639674	Brake Disc.....	6
2	639675	Screw.....	6
3	07.0709.0106	Spring.....	6
4	07.0709.0424	Piston.....	2
5	639676	Spring.....	6
6	639679	Back-Up Ring.....	2
7	639695	O-RING.....	2
8	639681	Back-Up Ring.....	2
9	639682	Seal.....	2
10	639683	Brake Disc, Intermediate.....	8
11	630328	Bleeder Valve, Long.....	2
12	638548	Cap.....	2
13	633069	Dowel.....	2
14	07.0709.0074	Piston.....	2


313.1 606387 Front Axle - Steering Cylinder



313.1 606387 Front Axle - Steering Cylinder

Item	Part No.	Description	Qty.
1	639671	Screw.....	4
2	640270	Joint Kit.....	2
3	641109	Articulated Tie Rod.....	1
4	07.0709.0001	Cylinder.....	1
5	641108	Articulated Tie Rod.....	1


314.1 606388 Front And Rear Axle - Support



314.1 606388 Front And Rear Axle - Support

Item	Part No.	Description	Qty.
1	07.0709.0218	Bushin.....	8
2	637850	Bushing.....	4
3	07.0709.0386	Support.....	4
4	633176	Grease Nipple.....	4
5	638548	Cap.....	4
6	09.4632.0002	Support.....	4


315.1 606389 Rear Axle - Differential Case



315.1 606389 Rear Axle - Differential Case

Item	Part No.	Description	Qty.
1	632383	Seal.....	3
2	639668	Cover.....	1
3	07.0709.0721	Housing.....	1
4	07.0709.0084	Cover.....	1
5	639670	Plug, Breather.....	1
7	07.0709.0113	Plug.....	1
8	07.0709.0371	Plug.....	1
9	07.0709.0441	Snap Ring.....	1


316.1 606390 Rear Axle - Differential Gear



316.1 606390 Rear Axle - Differential Gear

Item	Part No.	Description	Qty.
1	639652	O-Ring.....	1
2	639300	Spacer.....	1
2	639301	Spacer.....	1
2	639302	Spacer.....	1
2	639303	Spacer.....	1
3	07.0709.0372	Bevel Gear Set.....	1
4	633099	Bearing.....	2
5	639664	Ring Nut.....	2
6	639650	Screw.....	4
7	639657	Screw.....	2
8	07.0709.0057	Screw.....	12
9	639684	Washer.....	2
10	639685	Gear, Differential Side.....	2
11	07.0709.0722	Pin.....	4
12	639661	Snap Ring.....	4
13	639662	Washer, Friction.....	4
14	07.0709.0723	Satellite.....	4
15	639686	Case, Differential.....	1
16	626544	Bearing.....	2
17	634499	Spacer.....	1
17	634501	Spacer.....	1
17	639297	Spacer.....	1
17	639298	Spacer.....	1
18	639653	Spacer.....	1
19	630693	Ring Nut.....	1
20	633098	Seal, Differential.....	1
22	07.0709.0426	Flange.....	1
23	639802	Nut.....	1
24	639651	Snap Ring.....	4
25	640717	Differential.....	1


317.1 606391 Rear Axle - Steering Axle



317.1 606391 Rear Axle - Steering Axle

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	633174	Nut.....	2	44	639646	Snap Ring.....	2
2	640718	Screw.....	2	45	07.0709.0104	Screw.....	4
3	640719	Arm.....	2	46	634546	Nut, DIN439 JAM M16-2.0 P.....	4
4	07.0709.0377	Screw.....	32	49	639647	Plate, Locking.....	2
6	640720	Bushin.....	2	50	07.0709.0441	Snap Ring.....	2
7	630846	Seal, Planetary.....	2	53	07.0709.0119	Stud.....	8
8	633202	Bearing.....	2	54	07.0709.0070	Nut.....	8
9	633203	Snap Ring.....	2	56	07.0709.0071	Washer.....	8
10	640216	Seal.....	2	57	640728	Thickness.....	1
11	639624	Joint.....	2	57	640729	Thickness.....	1
12	639289	Bushing.....	2	57	640730	Thickness.....	1
13	07.0709.0124	Bushing.....	2	58	07.0709.0072	Grease Nipple.....	2
14	640909	Screw.....	16	60	07.0709.0726	Support.....	2
15	07.0709.0060	Cover.....	2	65	07.0709.0219	Housing.....	1
16	638548	Cap.....	4	66	07.0709.0220	Housing.....	1
17	633176	Grease Nipple.....	2	72	07.0709.0365	Screw.....	4
18	07.0709.0061	Pin.....	2	76	07.0709.0727	Support.....	2
19	640908	Pin.....	2				
20	639630	Seal.....	2				
21	639631	Joint, Articulated.....	2				
22	07.0709.0101	Housing.....	1				
23	07.0709.0215	Seal.....	2				
25	07.0709.0371	Plug.....	2				
26	07.0709.0113	Plug.....	4				
27	07.0709.0102	Housing.....	1				
28	07.0709.0205	Seal.....	2				
29	639637	Bearing.....	4				
30	07.0709.0117	Pipe Fitting.....	16				
31	07.0709.0064	Hub.....	2				
32	632383	Seal.....	2				
33	639639	Ring Gear.....	2				
34	639640	Support, Ring Gear.....	2				
35	639641	Snap Ring.....	8				
36	639642	Pinion, Differential.....	8				
37	639643	Bearing.....	8				
38	07.0709.0118	Nut.....	16				
40	07.0709.0065	Screw.....	4				
41	07.0709.0724	Support.....	2				
42	639645	Stud.....	16				
43	637567	Nut.....	16				


318.1 606392 Rear Axle - Brake



318.1 606392 Rear Axle - Brake

Item	Part No.	Description	Qty.
1	639689	Lever.....	1
2	630328	Bleeder Valve, Long.....	2
3	638548	Cap.....	2
4	901777	Screw.....	6
5	637574	Seal.....	2
6	07.0709.0122	Bushin.....	2
7	639691	Grubscrew.....	2
8	636440	Nut.....	2
10	639692	Lever.....	2
11	633517	Spacer.....	2
12	07.0709.0430	Screw.....	2
13	639683	Brake Disc, Intermediate.....	10
14	639693	Screw.....	6
15	07.0709.0106	Spring.....	3
16	640731	Piston.....	1
17	639679	Back-Up Ring.....	1
18	639695	O-Ring.....	1
19	633069	Dowel.....	2
20	639696	Lever.....	1
21	639676	Spring.....	6
22	637621	Threaded Element.....	2
23	639681	Back-Up Ring.....	1
24	639682	Seal.....	1
25	639674	Brake Disc.....	8
26	640732	Piston.....	1
36	07.0709.0081	Piston.....	1
37	07.0709.0082	Piston.....	1
38	07.0709.0123	Seal.....	2


319.1 606393 Rear Axle - Steering Cylinder



319.1 606393 Rear Axle - Steering Cylinder


Item	Part No.	Description	Qty.
1	639671	Screw.....	4
2	640270	Joint Kit.....	1
3	641109	Articulated Tie Rod.....	1
4	07.0709.0001	Cylinder.....	1
5	641108	Articulated Tie Rod.....	1

401.1 606400 Arm




Item	Part No.	Description	Qty.
1	51.0200.8400	1st Telescopic Element.....	1
2	54.0702.0000	Sliding Guide.....	4
3	54.0200.0001	Bushing.....	8
4	54.0702.0001	Sliding Guide.....	4
5	51.0801.9000	Support.....	2
6	01.4032.0004	Spring Washer.....	16
7	01.0001.0357	Screw.....	12
8	01.0001.0304	Screw.....	4
9	54.0201.0003	Bushing.....	2
10	52.0900.0200	Spacer.....	2
11	54.0201.0004	Bushing.....	2
12	02.0117.0101	Grease Nipple.....	1
13	54.0200.0000	Bushing.....	8
14	51.0804.9000	Thickness.....	4
15	51.0809.4000	Thickness.....	4

402.1 606401 Arm




Item	Part No.	Description	Qty.
1	51.0200.8500	2nd Telescopic Element.....	1
2	54.0702.0000	Sliding Guide.....	8
3	54.0200.0001	Bushing.....	20
4	54.0702.0001	Sliding Guide.....	8
5	51.0801.9100	Support.....	2
6	01.4032.0004	Spring Washer.....	16
7	01.0001.0356	Screw.....	12
8	01.4006.0005	Screw.....	4
9	51.0200.8600	3rd Telescopic Element.....	1
10	54.0702.0003	Sliding Guide.....	2
11	54.0200.0000	Bushing.....	16
12	01.0001.0304	Screw.....	2
13	01.0001.0355	Screw.....	10
14	01.0001.0353	Screw.....	8
15	54.0702.0004	Sliding Guide.....	2
16	51.0804.9000	Thickness.....	8
17	51.0809.4000	Thickness.....	8
18	51.0809.4600	Thickness.....	2
19	51.0809.3900	Thickness.....	2

403.1 606402 Forks



Item	Part No.	Description	Qty.
1	51.1300.5300	Plate.....	1
2	51.1301.2500	Fork.....	2
3	54.0000.0083	Pin.....	1
4	54.0100.0056	Washer.....	1
5	01.0001.0409	Screw.....	1
6	01.0023.0056	Nut.....	1
7	09.0803.0055	Chain.....	0,45-m
8	09.0803.0026	Spring Split Pin.....	2
9	07.0726.0051	Pin.....	2
10	01.4041.0005	Security Dowel.....	2
11	02.4115.0000	Rivet.....	2
12	09.4616.0112	Name Plate.....	1
13	09.4675.0007	Key.....	1
14	09.4675.0008	Key.....	1


404.1 606403 Hydraulic System - Tilting



404.1 606403 Hydraulic System - Tilting

Item	Part No.	Description	Qty.
1	04.0607.0141	Pipe Fitting.....	1
2	09.0803.0043	Retainer Pipe.....	8
3	04.0605.0505	Flexible Hose.....	1
4	53.3402.0600	Pipe.....	1
5	01.0003.0157	Screw.....	8
6	06.0442.0103	Washer.....	2
7	54.0201.0017	Bushing.....	2
8	04.4239.0000	Valve.....	1
9	53.0400.1200	Forks Articulation Cylinder.....	1
10	640536	Joint Kit.....	1
11	54.0000.0001	Pin.....	1
12	04.0214.0035	Drilled Screw.....	1
13	07.4529.0073	Back-Up Ring.....	2
14	07.4529.0071	Seal.....	2
15	01.4001.0003	Screw.....	1
16	01.0023.0056	Nut.....	1
17		606408 pos.14	
18	01.0001.0306	Screw.....	4
19	53.3402.0500	Pipe.....	1
20	01.0003.0164	Screw.....	8
21	04.0604.0124	Through Coupling.....	2
22	04.0605.0558	Flexible Hose.....	2


405.1 606404 Hydraulic System - Boom Extension



405.1 606404 Hydraulic System - Boom Extension


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	53.0100.2400	Cylinder.....	1	41	01.0032.0055	Spring Washer.....	4
2	640101	Cylinder Packing Kit.....	1	42	01.4003.0002	Screw.....	4
3	54.0000.0128	Pin.....	1	43	06.0442.0101	Washer.....	2
4	54.0000.0004	Pin.....	1	44	04.0607.0111	Pipe Fitting.....	1
5	01.0001.0310	Screw.....	2	45	01.0001.0304	Screw.....	2
6	01.0023.0055	Nut.....	3	46	01.4032.0004	Spring Washer.....	2
7	51.0800.0600	Collar.....	1	47	01.0031.0056	Plain Washer.....	2
8	01.4001.0005	Screw.....	2				
9	01.4032.0006	Washer.....	2				
10	04.4239.0079	Valve.....	1				
11	04.0607.0141	Pipe Fitting.....	2				
12	04.0605.0304	Flexible Hose.....	2				
13	04.0605.0560	Flexible Hose.....	2				
14	06.0442.0103	Washer.....	3				
15	53.3400.9200	Pipe.....	1				
16	53.0200.0700	Cylinder.....	1				
17	640102	Cylinder Packing Kit.....	1				
18	54.0000.0129	Pin.....	1				
19	04.4239.0001	Valve.....	1				
20	07.4529.0073	Seal.....	4				
21	07.4529.0071	Back-Up Ring.....	4				
22	01.4032.0003	Spring Washer.....	1				
23	09.0803.0043	Retainer Pipe.....	6				
24	01.0003.0157	Screw.....	12				
25	51.0803.0300	Guide.....	1				
26	53.3400.9100	Pipe.....	1				
27	01.0001.0254	Screw.....	1				
28	04.4239.0047	Valve.....	2				
29	01.0031.0299	Spring Washer.....	1				
30	04.0607.0121	Pipe Fitting.....	2				
31	54.0600.0001	Block.....	1				
32	04.0607.0155	Pipe Fitting.....	1				
33	04.0214.0035	Drilled Screw.....	1				
34	54.0004.0099	Pin.....	1				
35	04.0605.0504	Flexible Hose.....	1				
36	01.0001.0073	Spring Washer.....	4				
37	01.4001.0004	Screw.....	4				
38	06.0401.0123	Seal.....	2				
39	01.4001.0008	Screw.....	1				
40	01.0001.0014	Screw.....	4				

406.1 606405 Coupling Unit



Item	Part No.	Description	Qty.
1	51.0400.4700	Fork Coupling Attachment.....	1
2	54.0001.0022	Pin.....	2
3	01.0023.0053	Nut, M6.....	4
4	01.0001.0104	Screw.....	4
5	54.0201.0017	Bushing.....	2
6	54.0000.0122	Pin.....	1
7	54.0002.0031	Pin.....	1
8	02.0117.0101	Grease Nipple.....	1


407.1 606406 Hydraulic System - Implement Locking



407.1 606406 Hydraulic System - Implement Locking

Item	Part No.	Description	Qty.
1	53.3001.0500	Manifold.....	1
2	04.0600.0019	Pipe Fitting.....	1
3	04.0600.0087	Pipe Fitting.....	2
4	04.4210.0008	Female Coupling.....	2
5	04.4210.0007	Male Coupling.....	2
6	04.0607.0141	Pipe Fitting.....	2
7	04.0607.0110	Pipe Fitting.....	2
8	04.0605.0308	Flexible Hose.....	2
9	04.0607.0114	Pipe Fitting.....	3
10	01.0001.0156	Screw.....	2
11	04.0607.0112	Pipe Fitting.....	1
12	04.0605.0114	Flexible Hose.....	1
13	04.0605.0113	Flexible Hose.....	1
14	04.0605.0112	Flexible Hose.....	1
15	04.0607.0131	Pipe Fitting.....	1
16	01.4032.0002	Spring Washer.....	2
17		606407 pos.5	
18	53.0500.0600	Cylinder.....	1
19	01.0031.0054	Plain Washer.....	4
20	01.0001.0355	Screw.....	4
21	01.4032.0004	Spring Washer.....	4
22	01.0031.0301	Plain Washer.....	4
23	54.0001.0058	Pin.....	1
24	04.0600.0081	Pipe Fitting.....	1
25	04.4239.0002	Valve.....	1
26	04.0607.0132	Pipe Fitting.....	1
27	01.0031.0299	Plain Washer.....	3
28	07.4529.0107	Joint Kit.....	1
29	51.0901.7700	Guard.....	1
30	01.0001.0254	Screw.....	3
31	01.4032.0003	Spring Washer.....	3
32	04.0607.0089	Pipe Fitting.....	2
33	54.0100.0077	Bushing.....	2
34	01.4001.0016	Screw.....	2
35	01.0023.0053	Nut, M6.....	2
36	54.0001.0059	Pin.....	1
37	07.0705.0084	Joint Kit.....	1


408.1 606407 Hydraulic System - Auxiliary Circuit



408.1 606407 Hydraulic System - Auxiliary Circuit

Item	Part No.	Description	Qty.
1	01.0003.0164	Screw.....	8
2	04.0607.0160	Pipe Fitting.....	2
3	09.0803.0043	Retainer Pipe.....	8
4	01.0003.0157	Screw.....	8
5	04.0605.0506	Flexible Hose.....	1
6	04.0605.0558	Flexible Hose.....	2
7	53.3402.0400	Pipe.....	1
8	53.3402.0300	Pipe.....	1
9	04.0605.0331	Flexible Hose.....	2
10	04.0607.0121	Pipe Fitting.....	2


409.1 606408 Hydraulic System - Fork Balancing



409.1 606408 Hydraulic System - Fork Balancing

Item	Part No.	Description	Qty.
1	04.0607.0114	Pipe Fitting.....	1
2	04.0607.0121	Pipe Fitting.....	2
3	04.0607.0558	Flexible Hose.....	2
4	04.0607.0122	Pipe Fitting.....	2
5	04.0607.0111	Pipe Fitting.....	2
6	04.4239.0003	Valve.....	1
7	07.4529.0072	Seal.....	2
8	53.0300.1600	Compensation Cylinder.....	1
9	07.4529.0109	Joint Kit.....	1
10	02.0117.0101	Grease Nipple.....	2
11		606375 pos.2	
12	54.0000.0123	Pin.....	1
13	04.4239.0004	Valve.....	2
14	04.0605.0331	Flexible Hose.....	2
15	902935	Ball Joint.....	1
16	01.0003.0210	Screw.....	6
17	04.0605.0556	Flexible Hose.....	1
18	04.0607.0115	Pipe Fitting.....	1
19	54.0000.0156	Pin.....	1
20	01.0001.0410	Screw.....	1
21	01.0023.0056	Stop Nut.....	1
22	01.4001.0088	Screw.....	1
23	01.0023.0055	Nut.....	1


410.1 606409 Hydraulic System - Lifting



410.1 606409 Hydraulic System - Lifting

Item	Part No.	Description	Qty.
1	01.0001.0505	Screw.....	1
2	04.0607.0121	Pipe Fitting.....	2
3	54.0000.0099	Pin.....	1
4	01.0117.0101	Grease Nipple.....	2
5	04.0605.0559	Flexible Hose.....	2
6	04.0607.0111	Pipe Fitting.....	2
7	01.0003.0210	Screw.....	4
8	04.4239.0001	Valve.....	1
9	53.0000.3300	Lifting Cylinder.....	1
10	07.4529.0110	Joint Kit.....	1
11	09.0801.0001	Bushing.....	2
12	54.0000.0126	Pin.....	1
13	07.4529.0072	O-Ring.....	2
14	01.4032.0005	Spring Washer.....	1
15	04.0607.0163	Pipe Fitting.....	1
16	05.4329.0027	Accumulator.....	1
17	01.4032.0003	Spring washer.....	2
18	01.0001.0254	Screw.....	2
19	04.0605.0261	Flexible Hose.....	1
20	01.0001.0413	Screw.....	1
21	01.0023.0056	Stop Nut.....	1
22	04.0607.0122	Pipe Fitting.....	1
23	09.0801.0025	Bushing.....	2
24	01.0031.0055	Plain Washer.....	2
25	04.4227.0016	Clamp.....	2


501.1 606412 Decals And Plates



501.1 606412 Decals And Plates

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	09.4618.0791	Cosmetic - Safety pin operation.....	1	34	09.4618.1251	Cosmetic - Cabin Fuses & Relays Board.....	1
2	09.4618.0784	Cosmetic - Capacity of the truck and attachment.....	1	35	09.4618.0652	Cosmetic - Rules for machine stability.....	1
3	09.4618.0061	Cosmetic - Tyre Pressure.....	4	36	09.4618.1122	Cosmetic - Tip-over Hazard.....	1
4	09.4618.0918	Cosmetic - Falling Object Hazard.....	3	37	09.4618.0653	Cosmetic - Machine data plate.....	1
5	09.4618.0919	Cosmetic - Crush Hazard.....	4	38	07.0723.0142	Cosmetic - Bubble Level.....	1
6	09.4616.0041	Cosmetic - Guaranteed max sound power level.....	1	39	09.4616.0100	Plate - ROPS-FOPS cab type-approval plate.....	1
7	09.4618.0920	Cosmetic - Compartment Access.....	1	40	09.4616.0122	Plate - Machine data plate.....	1
8	09.4616.0040	Cosmetic - Max Capacity.....	1	41	09.4616.0109	Plate - Fork data plate.....	1
9	09.4618.0991	Cosmetic - Stabilizer Max Pressure.....	2	42	09.0803.0357	Plate - Boom Tilting Degree.....	1
10	09.4618.0776	Cosmetic - Upper Door Internal Unlock System.....	1				
11	09.4618.1242	Cosmetic - Quick guide and Control Lever.....	1				
12	09.4618.0921	Cosmetic - Use limits close to electric power lines.....	1				
13	09.4618.0933	Cosmetic - Crush Hazard.....	4				
14	09.4618.0922	Cosmetic - Crush Hazard.....	6				
15	09.4618.0243	Cosmetic - GENIE Logo in White.....	1				
16	09.4618.0241	Cosmetic - GENIE Logo in White.....	1				
17	09.4618.0242	Cosmetic - GENIE Logo in White.....	1				
18	09.4618.0813	Cosmetic - Genie GTH-4013.AU.2...2	2				
19	09.4618.0814	Cosmetic - Genie GTH-4013.AU.2...1	1				
20	09.4618.0923	Cosmetic - Burn Hazard.....	2				
21	09.4618.0924	Cosmetic - Burn/Explosion Hazard...1	1				
22	09.4618.0925	Cosmetic - Crush Hazard.....	1				
23	09.4618.0926	Cosmetic - No Riders.....	1				
24	09.4618.0927	Cosmetic - Burn Hazard.....	1				
25	09.4618.0916	Cosmetic - Lift Point.....	4				
26	09.4618.0917	Cosmetic - Diesel Fuel Cap.....	1				
27	09.4618.0928	Cosmetic - Hydraulic Oil.....	2				
28	09.4618.1181	Cosmetic - Engine Fuses & Relays Board.....	1				
29	09.4618.1001	Cosmetic - Maintenance Collar.....	1				
30	09.4618.1124	Cosmetic - Emergency Manual Controls Of The Main Valve.....	1				
31	09.4618.0986	Cosmetic - Crush Hazard.....	1				
32	09.4618.1028	Cosmetic - Parking Brake.....	1				
33	09.4618.0171	Cosmetic - Re-sequencing the telescopic boom extension.....	1				


502.1 606413 Diesel Engine - Supports And Accessories



502.1 606413 Diesel Engine - Supports And Accessories

Item	Part No.	Description	Qty.
1	09.4601.0054	Diesel Engine.....	1
2	51.0810.8300	Support.....	1
3	51.0810.8500	Right Support.....	1
4	51.0810.8400	Left Support.....	1
5	09.4670.0004	Insulator.....	4
6	01.4001.0012	Screw.....	4
7	01.0031.0058	Plain Washer.....	8
8	01.0001.0356	Screw.....	16
9	01.0023.0057	Stop Nut.....	4
10	01.0023.0055	Stop Nut.....	16
11	01.0031.0057	Plain Washer.....	14
12	01.4032.0005	Spring Washer.....	14
13	01.0001.0401	Screw.....	14
14	09.0804.3100	Handwheel Arrangement.....	1
15	07.4501.0158	Alternator.....	1
16	07.4501.0090	Starting Motor.....	1
17	07.0713.0065	Hub.....	1
18	07.0713.0058	Elastic Joint.....	1
19	01.4032.0004	Spring Washer.....	20
20	01.4001.0021	Screw.....	8
21	07.0713.0060	Protection.....	1
22	07.4501.0057	Diesel Fuel Filter.....	1
23	01.0001.0355	Screw.....	12
24	638243	Filter, Oil,Engine.....	1
25	09.0805.0000	Rubber Hose..... Lg: 3,25 m	2
26	07.4501.0098	Clamp.....	6


503.1 606414 Diesel Engine - Engine Cooling System



503.1 606414 Diesel Engine - Engine Cooling System

Item	Part No.	Description	Qty.
1	07.0712.0093	Radiator Core.....	1
2	07.0712.0094	Plug.....	1
3	07.0712.0095	Conveyor.....	1
4	07.0712.0096	Grate.....	1
5	53.3200.0029	Complete Radiator.....	1
6	09.0803.0351	Seal.....	0,7-m
7	09.0803.0245	Seal.....	0,8-m
8	09.0803.0351	Seal.....	0,9-m
9	09.4670.0002	Insulator.....	2
10	01.0031.0301	Plain Washer.....	2
11	01.0023.0055	Nut.....	3
12	01.0031.0056	Washer.....	2
13	04.0227.0064	Clamp.....	2
14	01.0031.0299	Plain Washer.....	1
15	01.4032.0003	Spring Washer.....	1
16	01.0001.0254	Screw.....	1
17	01.0001.0304	Screw.....	1
18	04.0227.0067	Clamp.....	1
19	51.0808.8100	Support.....	1
20	04.0227.0058	Clamp.....	4
21	09.0805.0018	Rubber Hose.....	1
22	53.3001.6704	Sleeve.....	1
23	09.0805.0000	Rubber Hose.....	1
24	01.0001.0254	Plug.....	1
25	09.0803.0351	Seal.....	0,7-m
26	04.4227.0067	Clamp.....	2
27	09.0805.0005	Rubber Hose.....	2


504.1 606415 Diesel Engine - Exhaust System



504.1 606415 Diesel Engine - Exhaust System

Item	Part No.	Description	Qty.
1	53.3100.0036	Exhaust Muffler.....	1
2	01.0023.0055	Nut.....	1
3	53.3001.6000	Manifold.....	1
4	01.0001.0304	Screw.....	1
5	09.0803.0348	Clamp.....	1
6	01.0031.0056	Plain Washer.....	4
7	01.4032.0004	Spring Washer.....	2
8	01.0001.0356	Screw.....	2
9	07.0726.0100	Exhaust Pipe.....	1
10	04.0227.0152	Clamp.....	1
11	07.0726.0103	Silencer.....	1
12	54.0100.0096	Flange.....	1

505.1 606416 Diesel Engine - Accelerator




505.1 606416 Diesel Engine - Accelerator

Item	Part No.	Description	Qty.
1	09.4655.0000	Lever.....	1
2	09.4645.0003	Cable.....	1
3	09.4656.0000	Pedal.....	1
4	09.4645.0000	Gas Cable.....	1
5	09.0803.0007	Clamp.....	2
6	51.0810.2500	Bracket.....	1
7	01.0001.1438	Screw.....	1
8	01.0031.0053	Washer.....	2
9	01.0023.0052	Nut.....	1
11	09.0803.0008	Articulation.....	1

506.1 606417 Diesel Engine - Injection System

Item	Part No.	Description	Qty.
1	09.4604.0044	Complete Air Filter.....	1
2	07.4501.0084	Cartridge.....	1
3	53.3001.2100	Sleeve.....	1
4	04.0227.0058	Clamp.....	2
5	01.0023.0055	Nut.....	4
6	01.0031.0299	Plain Washer.....	4
7	01.0001.0254	Screw.....	2
8	07.4501.0085	Air Filter.....	1
9	09.4604.0045	Indicator.....	1
10	09.0805.0018	Rubber Hose.....	1,5-m
11	53.3001.6700	Rubber Hose.....	1
12	04.4227.0064	Clamp.....	1
13	04.0227.0067	Clamp.....	1
15	04.4227.0028	Special Clamp.....	1
16	51.0811.4047	Bracket.....	1
17	01.0001.0357	Screw.....	1
18	01.0031.0301	Washer.....	1
19	01.0023.0055	Nut.....	1


507.1 606418 Hydraulic System - Oil Cooler



507.1 606418 Hydraulic System - Oil Cooler

Item	Part No.	Description	Qty.
1	04.0605.0551	Flexible Hose.....	1
2	04.0607.0160	Pipe Fitting.....	1
3	04.0607.0142	Pipe Fitting.....	1
4	04.4239.0077	Valve.....	1
5	04.0600.0037	Pipe Fitting.....	1
6	04.0605.0553	Flexible Hose.....	1
7	04.0607.0172	Pipe Fitting.....	2
8	04.0607.0199	Pipe Fitting.....	1
9	04.0605.0552	Flexible Hose.....	1



508.1 606419 Suction System Hydraulic Pumps



508.1 606419 Suction System Hydraulic Pumps

Item	Part No.	Description	Qty.
1		606379 pos.2	
2		606379 pos.1	
3		606379 pos.3	
4	04.0605.0539	Flexible Hose.....	1
5		606380 pos.23	
6	04.0607.0107	Pipe Fitting.....	3
7	09.4661.0014	Plug.....	1
8	53.3001.4200	Manifold.....	1
9	01.0023.0054	Stop Nut.....	10
10	01.0031.0299	Plain Washer.....	10
11	07.0726.0044	Cover.....	1
12	53.3301.0002	Seal.....	1
13	01.0001.0039	Nut.....	4
14	01.0031.0301	Plain Washer.....	6
15	09.4670.0002	Insulator.....	4
16	51.0600.9000	Oil Tank.....	1
17	06.0442.0105	Washer.....	1
18	04.0220.0063	Plug.....	2
19	09.4661.0002	Level Indicator.....	1
20	06.0442.0111	Washer.....	1
21	01.0001.0353	Screw.....	6
22	01.0032.0055	Spring Washer.....	6
23	07.0700.0006	Cover.....	1
24	09.4604.0047	Oil Filter.....	1
25	07.0700.0023	Cartridge.....	1
26	07.0700.0028	Pressure Switch.....	1
27	01.0001.0113	Washer.....	1
28	04.4220.0003	Plug.....	1
29	04.0600.0200	Pipe Fitting.....	1
30	04.0227.0144	Clamp.....	2
31	09.0805.0030	Sleeve.....	1
32		606376 pos.26	
33	04.4224.0001	Tap.....	1
34	53.3000.0400	Manifold.....	1
35	04.4238.0067	Pump.....	1
36	04.0607.0130	Pipe Fitting.....	1
37	04.0607.0121	Pipe Fitting.....	1
38	09.4604.0000	Filter.....	1
39	56.0013.0000	Sensor.....	1
40	09.4661.0016	Filter.....	1

601.1 606420 Fuse Box




Item	Part No.	Description	Qty.
1	637650	Fuse, 3A.....	2
2	07.0703.0193	Fuse 5A.....	1
3	634972	Fuse ,7.5A.....	4
4	634974	Fuse, 10A.....	15
5	634973	Fuse, 15A.....	5
6	07.0703.0485	Relay.....	14
7	07.0703.0487	Relay.....	1
8	56.0021.0057	Card.....	1
9	07.0703.0486	Relay.....	1

602.1 606421 Electric Installation - Engine Line


Item	Part No.	Description	Qty.
1	55.0602.0371	Alternator Cable.....	1
2	55.0602.0389	Engine Line.....	1
3	56.0013.0036	Thermistor.....	1
4	55.0602.0365	Positive Battery Cable.....	1
5	56.0008.0012	Battery.....	1
6	55.0602.0366	Negative Battery Cable.....	1
7	07.0703.0069	Max Fuse 30A.....	1
8	56.0005.0000	Max Fuse 40A.....	1
9	56.0005.0002	Max Fuse 60A.....	2
10	07.0703.0189	Max Fuse Holder.....	1
11	56.0006.9202	Relay.....	2
12	07.0703.0192	Relay.....	2
13	07.0703.0223	Relay Holder.....	2
14	07.0703.0188	Relay Holder.....	2
15	55.0602.0460	Resistor.....	1
16	634973	Fuse 15A.....	2
17	56.0005.0009	Fuse Holder.....	2
18	56.0005.0010	Electric Box Base.....	1
19	56.0005.0005	Electric Box Cover.....	1
20	09.0803.0545	Pommel.....	2

603.1 606422 Electric Installation - Rear Line



Item	Part No.	Description	Qty.
1	55.0602.0350	Wiring Harness.....	1
2	05.4329.0001	Pressure Switch.....	1
3	05.4329.0002	Pressure Switch.....	1
4	56.0009.0003	Horn.....	1
5	55.0602.0297	Wiring Harness.....	2
6	56.0010.0034	Light.....	1
7	56.0010.0035	Light.....	1
8	01.0019.0104	Proximity Switch.....	2
9	07.0703.0306	Bulb.....	2
10	07.0703.0305	Bulb.....	2
11	07.0703.0304	Bulb.....	2
12	07.0703.0309	Complete Turn Signal.....	1
13	07.0703.0310	Glass.....	2
14	01.0001.0100	Spring Washer.....	4
15	01.4003.0011	Screw.....	4
16	07.0703.0302	Complete Turn Signal.....	1


604.1 606423 Electric Installation - Rear Line



604.1 606423 Electric Installation - Rear Line

Item	Part No.	Description	Qty.
1	55.0602.0350	Wiring Harness.....	1
2	01.4003.0011	Screw.....	4
3	01.0001.0100	Plain Washer.....	4
4	56.0012.0017	Proximity Switch.....	2
5	07.0703.0648	Right Wiring Harness Light.....	1
6	56.0013.0028	Level Indicator.....	1
7	56.0009.0002	Horn.....	1
8	56.0012.0024	Proximity Sensor.....	1
9	07.0703.0359	Push Button.....	1
10	01.0023.0055	Contact.....	1
11	01.0003.0153	Screw.....	2
12	01.4032.0002	Spring Washer.....	2
13	01.0031.0054	Washer.....	2
14	56.0021.0023	Housing.....	1
15	07.0703.0649	Left Wiring Harness Light.....	2
16	56.0013.0006	Proximity Switch.....	1
17	56.0013.0008	Proximity Switch.....	1


605.1 606424 Electric Installation - Dashboard Line



605.1 606424 Electric Installation - Dashboard Line

Item	Part No.	Description	Qty.
1	55.0602.0382	Dashboard Line.....	1
2	55.0602.0498	Driver Line.....	1
3	56.0021.0085	Boom Functions Control Unit.....	1
4	56.0021.0060	Manplatform Control Unit.....	1
5	56.0021.0093	Overload System Control Unit.....	1
6	56.0021.0071	Wheel Aligned Control Unit.....	1
7	56.0021.0106	Input/Output Outriggers Control Unit.....	1
8	639982	Relais Box.....	1
9	56.0021.0068	Transmission Control Unit.....	1
10	07.0703.0535	Relay.....	1
11	07.0703.0640	Diode.....	1
12	56.0021.0078	Overload System Timer.....	1
13	07.0703.0486	Relay.....	2
14	07.0703.0223	Relay Holder.....	3
15	07.0703.0224	Fuse Holder.....	3
16	634975	Fuse 20A.....	1
17	634972	Fuse 7,5A.....	1
18	07.0703.0656	Fuse 1A.....	1


606.1 606425 Electric Installation - Side Cab Line



606.1 606425 Electric Installation - Side Cab Line

Item	Part No.	Description	Qty.
1	55.0602.0425	Wiring Harness.....	1
2	07.0703.0384	Bulb.....	1
3	56.0010.0005	Flashing Beacon.....	1


607.1 606427 Electric Installation - Rear Line



607.1 606427 Electric Installation - Rear Line

Item	Part No.	Description	Qty.
1	55.0602.0421	Electrical Line.....	1
2	56.0012.0047	Electronic Sensor.....	1
3	07.0709.0872	Security Switch.....	2


608.1 606428 Electric Installation - Rear Lights



608.1 606428 Electric Installation - Rear Lights








Item	Part No.	Description	Qty.
1	56.0010.0056	Left Support.....	1
2	56.0017.0057	Plug.....	1
3	06.4401.0001	O-Ring.....	1
4	56.0010.0052	Rear Light.....	1
5	56.0010.0053	Light.....	1
6	56.0010.0054	Light.....	1
7	01.0003.0948	Screw.....	3
8	56.0010.0050	Reflector.....	1
9	56.0010.0051	Reflector.....	1
10	01.0003.0949	Screw.....	2
11	01.4031.0006	Washer.....	2
12	01.4032.0012	Washer.....	2
13	01.0003.0950	Screw.....	1
14	01.0003.0951	Screw.....	1
15	51.0811.4044	Support.....	1
16	56.0010.0055	Glass.....	1
17	06.4401.0002	Seal.....	1
18	07.0703.0175	Bulb.....	2
19	07.0703.0319	Bulb.....	1
20	56.0010.0057	Right Support.....	1
21	56.0010.0041	Right Light.....	1
22	56.0010.0042	Left Light.....	1

609.1 606429 Connector Initials













Item	Part No.	Description	Qty.
1	56.0002.0132	5-Way Mark li Connector	
2	56.0002.0144	11-Way Mark li Connector	
3	07.0703.0634	6-Way Mark li Connector	
4	07.0703.0627	13-Way Mark li Connector	
5	56.0002.0103	17-Way Mark li Connector	
6	56.0002.0105	21-Way Mark li Connector	
7	07.0703.0224	1-Way Connector	
8	07.0703.0223	1-Way Connector	
9	56.0002.0164	4-Way Connector	
10	56.0002.0124	18-Way Connector	
11	56.0002.0108	6-Way Connector	
12	07.0703.0635	4-Way Connector	
13	07.0703.0522	Connector	
14	56.0002.0111	36-Pole Connector	

610.1 606430 Connector Initials



Item	Part No.	Description	Qty.
1	56.0002.0100	24-Way Deutsch Connector	
2	56.0002.0075	24-Way Deutsch Connector	
3	56.0002.0146	24-Way Deutsch Connector	
4	56.0002.0149	40-Way Connector - Type A	
5	56.0002.0150	40-Way Connector - Type A	
6	56.0002.0101	24-Way Deutsch Connector - Type A	
7	56.0002.0145	24-Way Connector	


611.1 606431 Connector Initials




Item	Part No.	Description	Qty.
1	56.0002.0056	4-Way Deutsch Connector	
2	56.0002.0141	2-Way Deutsch Connector	
3	07.0703.0383	6-Way Deutsch Connector	
4	07.0703.0382	6-Way Deutsch Connector	
5	56.0002.0069	3-Way Deutsch Connector	
6	56.0002.0247	6-Pole Connector	
7	56.0002.0076	2-Way Connector	
8	56.0002.0181	2-Way Connector	
9	56.0002.0153	2-Way Connector	
10	56.0002.0019	2-Way Connector	
11	56.0002.0104	21-Way Mark Deutsch Connector	
12	56.0002.0133	4-Way Connector	
13	56.0002.0128	6-Way Delphi Connector	
14	56.0002.0113	6-Way Connector	
15	56.0002.0129	10-Way Connector	
16	07.0703.0629	2-Way Connector	

612.1 606432 Connector Initials


1

125900
XE0900033


4

125418
125419
150100
120111


8

125423
120111
150100


2

113623
120119
101115


5

124234
150119
120476
120258


9

125474
150100
120110


6

124235
120476
120258


10

124679
120110


3

125741
120171
120097

7


125494
120589
150100

11

125376
120119
120198


Item	Part No.	Description	Qty.
1	56.0002.0071	EV Connector	
2	07.0703.0189	Fuses Box	
3	56.0002.0205	Deutsch Connector	
4	07.0703.0636	8-Way Deutsch Connector	
5	56.0002.0097	Connector	
6	56.0002.0230	Connector	
7	56.0002.0250	12-Way Deutsch Connector	
8	07.0703.0315	12-Way Deutsch Connector	
9	56.0002.0095	12-Way Connector	
10	56.0002.0294	8-Way Connector	
11	56.0002.0079	2-Way Connector	

613.1 606433 Connector Initials



Item	Part No.	Description	Qty.
1	56.0002.0031	2-Way Connector	
2	56.0002.0134	2-Way Connector	
3	56.0002.0196	Connector	
4	56.0002.0169	Rigid White Faston Cover	
5	56.0002.0165	90° 2-Way Connector	
6	56.0002.0248	2-Way Deutsch Connector	
7	07.0703.0619	2-Way Connector	
8	56.0002.0249	3-Way Connector	
9	56.0002.0117	Red Fork D.43	
10	07.0703.0620	C/C D. 10	
11	56.0002.0622	C/C D. 5,3 For Wire D. 1-2,5	
12	56.0002.0631	C/C D.	
13	56.0002.0118	C/C D. 6 For Wire D. 4	
14	56.0002.0119	C/C D. 5,3	
15	56.0002.0009	C/C D. 8	
16	07.0703.0623	C/C D.	
17	56.0002.0102	9-Way Connector	


701.1 606394 Hydraulic Jack



701.1 606394 Hydraulic Jack

Item	Part No.	Description	Qty.
1	09.4675.0003	Hydraulic Jack.....	1
2	09.4675.0000	Ratchet Socket.....	1


702.1 606395 Rear View Mirror



702.1 606395 Rear View Mirror

Item	Part No.	Description	Qty.
1	09.4610.0028	Driving Mirror.....	1
2	51.0810.7200	Support.....	1
3	01.0031.0056	Washer D10.....	2
4	01.4032.0004	Spring Washer D10.....	2
5	01.0001.0355	Screw TE M10X25 UNI 5739 8.8 ZN.....	2


703.1 606396 Windscreen Grate



703.1 606396 Windscreen Grate

Item	Part No.	Description	Qty.
1	01.0001.0505	Screw TE M12X25 UNI 5739 8.8 ZN.....	2
2	01.4032.0005	Spring Washer D12.....	2
3	01.0031.0057	Washer D12.....	2
4	51.0901.6900	Grate.....	1
5	01.0001.0304	Screw TE M10X50 UNI 5739 8.8 ZN.....	2
6	01.4032.0004	Spring Washer D10.....	2
7	01.0031.0301	Washer D10.....	2
8	54.0101.0019	Spacer.....	2


704.1 606397 Boom Work Light (Part 1)



704.1 606397 Boom Work Light (Part 1)

Item	Part No.	Description	Qty.
1	04.4227.0003	Clamp.....	4
2	01.0031.0298	Washer.....	4
3	01.0003.0150	Screw TCEI M 6X10 UNI5931 8.8ZN.....	4
4	56.0010.0039	Light.....	1
5	07.0703.0047	Bulb.....	1
6	01.0031.0055	Washer.....	2
7	01.4032.0003	Washer.....	2
8	01.0001.0254	Screw TE M8 x 20 LG. 8.8 ZN UNI 5737.....	2
9	51.0806.5700	Bracket.....	1
10	56.0002.0141	Connector.....	1
11	56.0002.0032	Cable Terminal.....	2
12	56.0002.0142	Plate.....	1
13	56.0002.0153	Connector.....	1
14	56.0002.0040	Cable Terminal.....	2
15	56.0002.0154	Plate.....	1


705.1 606398 Boom Work Light (Part 2)



705.1 606398 Boom Work Light (Part 2)

Item	Part No.	Description	Qty.
1	09.0803.0011	Washer.....	2
2	01.0001.0256	Screw TE M8X25 UNI 5739 8.8 ZN.....	2
3	56.0023.0018	Cable Reel.....	1
4	56.0010.0039	Boom Work Light.....	1
5	51.0808.6000	Bracket.....	2
6	01.0031.0054	Washer.....	4
7	01.0023.0053	Nut, M6.....	4
8	56.0023.0017	Slab Buildibng.....	2
9	01.0001.0254	Screw TE M8 x 20 8.8 ZN UNI 5737.....	4
10	01.4032.0005	Washer.....	4
11	01.0031.0055	Washer.....	4
12	01.0003.0150	Screw TCEI M6X10 UNI5931 8.8ZN 8.8ZN.....	3
13	01.0031.0298	Washer.....	3
14	04.4227.0003	Clamp.....	3
15	09.0803.0069	Chain.....	0,7 Mt.
16	09.0803.0069	Spring Catch.....	1
17	04.0227.0051	Clamp.....	1
18	07.0703.0433	Switch.....	1
19	56.0017.0032	Glass.....	1



706.1 606399 Cabin Work Light



706.1 606399 Cabin Work Light

Item	Part No.	Description	Qty.
1	56.0010.0039	Work Light.....	1
2	07.0703.0047	Bulb.....	1
3	01.0001.0505	Screw.....	1
4	01.4032.0005	Washer.....	1
5	01.0031.0057	Spring Washer.....	1
6	55.0403.0047	Bracket.....	1
7	09.0803.0052	Gum.....	1
8	56.0017.0032	Switch Glass.....	1
9	07.0703.0433	Switch.....	1


707.1 606410 Windscreen Wiper



707.1 606410 Windscreen Wiper

Item	Part No.	Description	Qty.
1	07.0740.0156	Wiper Arm.....	1
2	09.0803.0125	Cap.....	4
3	07.0740.0035	Rubber.....	2
4	07.0740.0212	Screw.....	2
5	07.0740.0213	Bushing.....	2
6	07.0740.0214	Rubber.....	2
7	07.0740.0157	Wiper Blade.....	1
8	07.0740.0209	Rear Window Fixing Kit.....	1
9	07.0740.0210	Rubber.....	1
10	07.0740.0158	Wiper Motor.....	1
11	07.0740.0211	Spacer.....	1

708.1 606411 Lock Forks



Item	Part No.	Description	Qty.
1	51.1300.0500	Guard.....	2
2	09.0803.0026	Split Pin.....	4
3	51.1300.0400	Plate.....	1
4	01.0001.0256	Screw.....	2
5	01.4032.0003	Washer.....	2
6	01.0031.0055	Washer.....	2
7	51.1300.0100	Guard.....	2
8	09.0803.0391	Fork.....	2
9	09.0803.0068	Chain.....	1.2-m
10	09.0803.0069	Spring Catch.....	1
11	09.4618.0093	Label.....	3.1-m
12	51.1300.0300	Guard.....	1

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
01.0001.0014	85	01.0031.0058	27, 35, 37, 45, 99	04.0600.0200	111	04.0607.0188	47
01.0001.0017	35	01.0031.0059	35	04.0604.0124	83	04.0607.0199	109
01.0001.0039	37, 111	01.0031.0061	27, 35	04.0605.0112	89	04.0607.0207	47
01.0001.0043	45	01.0031.0062	27, 35	04.0605.0113	89	04.0607.0558	93
01.0001.0073	85	01.0031.0298	145, 147	04.0605.0114	89	04.4210.0003	47
01.0001.0078	37	01.0031.0299	15, 37, 85, 89,	04.0605.0245	49	04.4210.0004	47
01.0001.0100	117, 119		101, 107, 111	04.0605.0261	95	04.4210.0006	29
01.0001.0104	87	01.0031.0301	27, 35, 37, 89,	04.0605.0304	85	04.4210.0007	89
01.0001.0113	111		101, 107, 111,	04.0605.0308	89	04.4210.0008	89
01.0001.0154	27, 29		143	04.0605.0309	29, 41	04.4220.0003	111
01.0001.0156	27, 45, 89	01.0032.0055	85, 111	04.0605.0331	91, 93	04.4223.0000	41
01.0001.0158	25	01.0117.0101	95	04.0605.0351	29	04.4223.0003	47
01.0001.0254	15, 29, 45, 85,	01.4001.0000	35, 37	04.0605.0420	47	04.4224.0001	111
	89, 95, 101, 107,	01.4001.0001	27, 35	04.0605.0504	85	04.4227.0003	145, 147
	145, 147	01.4001.0003	83	04.0605.0505	83	04.4227.0016	95
01.0001.0256	27, 49, 147, 153	01.4001.0004	85	04.0605.0506	91	04.4227.0028	107
01.0001.0257	37	01.4001.0005	85	04.0605.0525	41	04.4227.0064	107
01.0001.0304	35, 77, 79, 85,	01.4001.0008	85	04.0605.0527	47	04.4227.0067	101
	101, 103, 143	01.4001.0010	45	04.0605.0533	41	04.4229.0044	47
01.0001.0306	27, 37, 83	01.4001.0012	99	04.0605.0534	41	04.4229.0045	47
01.0001.0310	33, 85	01.4001.0016	89	04.0605.0535	41	04.4235.0041	47
01.0001.0314	35	01.4001.0021	99	04.0605.0536	41	04.4236.0058	29
01.0001.0353	79, 111	01.4001.0058	27	04.0605.0537	47	04.4236.0082	43
01.0001.0355	37, 79, 89, 99,	01.4001.0078	35, 37	04.0605.0538	41	04.4238.0053	41
	141	01.4001.0088	93	04.0605.0539	111	04.4238.0067	111
01.0001.0356	35, 79, 99, 103	01.4001.0116	15	04.0605.0540	41	04.4238.0071	47
01.0001.0357	77, 107	01.4003.0000	25	04.0605.0541	49	04.4239.0000	83
01.0001.0401	47, 99	01.4003.0002	29, 85	04.0605.0542	49	04.4239.0001	85, 95
01.0001.0409	81	01.4003.0011	117, 119	04.0605.0543	31, 47	04.4239.0002	89
01.0001.0410	93	01.4006.0001	31	04.0605.0545	39	04.4239.0003	93
01.0001.0413	95	01.4006.0005	79	04.0605.0546	39	04.4239.0004	93
01.0001.0466	37	01.4006.0011	35, 37	04.0605.0547	39	04.4239.0007	29, 33
01.0001.0505	95, 143, 149	01.4023.0000	27, 35, 37	04.0605.0548	41	04.4239.0013	47
01.0001.0564	35	01.4031.0003	35	04.0605.0549	41	04.4239.0047	85
01.0001.0604	27, 45	01.4031.0006	127	04.0605.0550	43	04.4239.0077	109
01.0001.0657	35	01.4032.0002	25, 27, 29, 89,	04.0605.0551	109	04.4239.0079	85
01.0001.0902	45		119	04.0605.0552	109	04.4240.0024	31
01.0001.1438	105	01.4032.0003	27, 29, 49, 85,	04.0605.0553	109	04.4240.0025	31
01.0001.1465	37		89, 95, 101, 145,	04.0605.0554	29	04.4240.0052	41
01.0001.1466	49		153	04.0605.0555	33	04.4240.0055	39
01.0001.1493	35, 37	01.4032.0004	37, 77, 79, 85,	04.0605.0556	93	05.0400.0000	49
01.0003.0023	45		89, 99, 103, 141,	04.0605.0557	43	05.0401.0000	49
01.0003.0150	145, 147		143	04.0605.0558	83, 91	05.0401.0001	49
01.0003.0153	119	01.4032.0005	45, 47, 95, 99,	04.0605.0559	95	05.0401.0003	49
01.0003.0155	49		143, 147, 149	04.0605.0560	85	05.0401.0005	49
01.0003.0157	25, 83, 85, 91	01.4032.0006	27, 85	04.0605.0599	47	05.4309.0000	49
01.0003.0158	39, 41	01.4032.0009	27, 45	04.0607.0089	89	05.4315.0004	45
01.0003.0164	83, 91	01.4032.0012	127	04.0607.0107	41, 47, 111	05.4329.0001	117
01.0003.0203	15	01.4041.0005	81	04.0607.0110	41, 89	05.4329.0002	117
01.0003.0210	93, 95	02.0112.0155	45	04.0607.0111	41, 85, 93, 95	05.4329.0027	95
01.0003.0255	41	02.0117.0053	45	04.0607.0112	89	05.4329.0029	49
01.0003.0948	127	02.0117.0101	29, 31, 33, 77,	04.0607.0113	41, 43	06.0401.0123	85
01.0003.0949	127		87, 93	04.0607.0114	29, 39, 49, 89, 93	06.0401.0219	47
01.0003.0950	127	02.4115.0000	81	04.0607.0115	39, 93	06.0442.0055	49
01.0003.0951	127	03.0000.0008	31	04.0607.0117	33, 41	06.0442.0101	85
01.0019.0104	117	04.0214.0035	33, 83, 85	04.0607.0121	43, 85, 91, 93,	06.0442.0103	33, 35, 83, 85
01.0023.0052	105	04.0220.0055	35		95, 111	06.0442.0105	47, 111
01.0023.0053	35, 37, 45, 87,	04.0220.0063	111	04.0607.0122	93, 95	06.0442.0111	111
	89, 147	04.0227.0051	147	04.0607.0130	43, 111	06.4401.0001	127
01.0023.0054	15, 37, 49, 111	04.0227.0058	101, 107	04.0607.0131	89	06.4401.0002	127
01.0023.0055	27, 33, 35, 37,	04.0227.0064	101	04.0607.0132	89	07.0470.0175	45
	85, 93, 99, 101,	04.0227.0067	101, 107	04.0607.0137	41	07.0607.0111	49
	103, 107, 119	04.0227.0068	21	04.0607.0141	83, 85, 89	07.0700.0006	111
01.0023.0056	81, 83, 93, 95	04.0227.0144	111	04.0607.0142	43, 109	07.0700.0023	111
01.0023.0057	35, 37, 99	04.0227.0152	103	04.0607.0145	29, 31	07.0700.0028	111
01.0023.0060	35	04.0600.0019	89	04.0607.0149	47	07.0701.0007	47
01.0031.0053	105	04.0600.0037	109	04.0607.0153	39	07.0701.0180	47
01.0031.0054	25, 27, 35, 45,	04.0600.0067	47	04.0607.0155	85	07.0701.0196	47
	49, 89, 119, 147	04.0600.0077	47	04.0607.0160	43, 91, 109	07.0701.0203	47
01.0031.0055	15, 27, 37, 45,	04.0600.0081	89	04.0607.0163	43, 95	07.0701.0204	47
	49, 95, 145, 147,	04.0600.0087	89	04.0607.0164	43	07.0701.0205	47
	153	04.0600.0092	31	04.0607.0167	29	07.0703.0010	23
01.0031.0056	35, 85, 101, 103,	04.0600.0159	47	04.0607.0172	109	07.0703.0017	19
	141	04.0600.0166	49	04.0607.0174	41	07.0703.0019	19
01.0031.0057	99, 143, 149	04.0600.0196	21	04.0607.0184	47	07.0703.0029	23

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
07.0703.0032	23	07.0709.0065	59, 71	07.0709.0941	53	07.0740.0063	17, 45
07.0703.0034	19	07.0709.0068	59	07.0709.0942	53	07.0740.0066	15
07.0703.0035	19	07.0709.0070	59, 71	07.0712.0093	101	07.0740.0067	15
07.0703.0047	145, 149	07.0709.0071	59, 71	07.0712.0094	101	07.0740.0069	15
07.0703.0069	115	07.0709.0072	59, 71	07.0712.0095	101	07.0740.0070	15
07.0703.0125	17, 23	07.0709.0074	61	07.0712.0096	101	07.0740.0071	21
07.0703.0175	127	07.0709.0079	53	07.0713.0058	99	07.0740.0072	15
07.0703.0188	115	07.0709.0081	73	07.0713.0060	99	07.0740.0073	15
07.0703.0189	115, 135	07.0709.0082	73	07.0713.0065	99	07.0740.0074	15
07.0703.0192	115	07.0709.0084	55, 67	07.0721.0101	29	07.0740.0076	15
07.0703.0193	113	07.0709.0101	59, 71	07.0721.0202	47	07.0740.0078	15
07.0703.0223	115, 121, 129	07.0709.0102	59, 71	07.0722.0053	41	07.0740.0079	15
07.0703.0224	121, 129	07.0709.0104	59, 71	07.0723.0142	97	07.0740.0080	15
07.0703.0302	117	07.0709.0106	61, 73	07.0723.0195	41	07.0740.0081	15
07.0703.0304	117	07.0709.0113	55, 59, 67, 71	07.0726.0044	111	07.0740.0082	15
07.0703.0305	117	07.0709.0117	59, 71	07.0726.0051	81	07.0740.0084	15
07.0703.0306	117	07.0709.0118	59, 71	07.0726.0100	103	07.0740.0085	15
07.0703.0309	117	07.0709.0119	59, 71	07.0726.0103	103	07.0740.0086	15
07.0703.0310	117	07.0709.0121	59	07.0728.0006	39	07.0740.0087	15
07.0703.0315	135	07.0709.0122	73	07.0730.0036	49	07.0740.0088	15
07.0703.0319	127	07.0709.0123	73	07.0730.0037	49	07.0740.0089	15
07.0703.0359	119	07.0709.0124	71	07.0730.0063	45	07.0740.0090	15
07.0703.0382	133	07.0709.0205	59, 71	07.0730.0064	45	07.0740.0091	15
07.0703.0383	133	07.0709.0215	59, 71	07.0730.0065	45	07.0740.0092	15
07.0703.0384	123	07.0709.0216	57	07.0730.0066	45	07.0740.0093	15
07.0703.0417	19	07.0709.0218	65	07.0730.0067	45	07.0740.0097	15
07.0703.0418	19	07.0709.0219	59, 71	07.0730.0068	45	07.0740.0098	15
07.0703.0419	19	07.0709.0220	71	07.0730.0069	45	07.0740.0099	15
07.0703.0420	19	07.0709.0327	53	07.0737.0012	41	07.0740.0100	15, 37
07.0703.0423	19, 23	07.0709.0365	59, 71	07.0738.0000	51	07.0740.0102	15
07.0703.0425	23	07.0709.0371	55, 59, 67, 71	07.0740.0000	17	07.0740.0103	15
07.0703.0429	23	07.0709.0372	69	07.0740.0001	17	07.0740.0104	15
07.0703.0430	23	07.0709.0374	57	07.0740.0002	17	07.0740.0105	15
07.0703.0431	23	07.0709.0377	59, 71	07.0740.0003	17	07.0740.0106	15
07.0703.0433	23, 147, 149	07.0709.0386	65	07.0740.0004	17	07.0740.0107	15
07.0703.0434	23	07.0709.0422	53	07.0740.0005	15, 17, 21	07.0740.0116	19
07.0703.0435	23	07.0709.0424	61	07.0740.0006	15, 17, 21	07.0740.0117	15, 19
07.0703.0440	23	07.0709.0426	57, 69	07.0740.0007	17	07.0740.0118	21
07.0703.0441	19	07.0709.0430	73	07.0740.0009	15, 17	07.0740.0119	21
07.0703.0485	113	07.0709.0441	55, 59, 67, 71	07.0740.0010	17	07.0740.0120	21
07.0703.0486	113, 121	07.0709.0443	53	07.0740.0011	17	07.0740.0121	21
07.0703.0487	113	07.0709.0718	53	07.0740.0012	17, 19, 21	07.0740.0122	21
07.0703.0489	19	07.0709.0720	53	07.0740.0013	17, 45	07.0740.0123	21
07.0703.0492	45	07.0709.0721	55, 67	07.0740.0014	15, 17	07.0740.0124	21
07.0703.0522	129	07.0709.0722	57, 69	07.0740.0015	17	07.0740.0125	21
07.0703.0531	19	07.0709.0723	69	07.0740.0016	17, 21	07.0740.0126	21
07.0703.0532	19	07.0709.0724	57, 59, 71	07.0740.0017	17	07.0740.0127	21
07.0703.0535	121	07.0709.0726	59, 71	07.0740.0018	17	07.0740.0128	17, 21
07.0703.0572	23	07.0709.0727	59, 71	07.0740.0020	17	07.0740.0129	21
07.0703.0581	19	07.0709.0847	53	07.0740.0021	17	07.0740.0130	15, 21
07.0703.0614	23	07.0709.0848	53	07.0740.0022	17	07.0740.0132	21
07.0703.0618	23	07.0709.0849	53	07.0740.0024	17	07.0740.0133	21
07.0703.0619	137	07.0709.0851	53	07.0740.0025	17	07.0740.0135	41
07.0703.0620	137	07.0709.0853	53	07.0740.0026	17	07.0740.0136	41
07.0703.0623	137	07.0709.0854	53	07.0740.0027	17	07.0740.0139	19
07.0703.0627	129	07.0709.0855	53	07.0740.0028	15, 17, 21	07.0740.0140	19
07.0703.0629	133	07.0709.0856	53	07.0740.0029	17	07.0740.0141	19
07.0703.0634	129	07.0709.0857	53	07.0740.0030	17	07.0740.0142	19
07.0703.0635	129	07.0709.0858	53	07.0740.0032	15	07.0740.0143	19
07.0703.0636	135	07.0709.0859	53	07.0740.0035	15, 17, 151	07.0740.0144	19
07.0703.0640	121	07.0709.0860	53	07.0740.0037	19	07.0740.0145	19
07.0703.0648	119	07.0709.0861	53	07.0740.0042	19	07.0740.0151	19
07.0703.0649	119	07.0709.0862	53	07.0740.0046	15	07.0740.0152	19
07.0703.0656	121	07.0709.0863	53	07.0740.0047	17	07.0740.0154	19
07.0703.0673	23	07.0709.0864	53	07.0740.0048	17	07.0740.0156	15, 151
07.0705.0084	89	07.0709.0865	53	07.0740.0049	17	07.0740.0157	15, 151
07.0709.0001	63, 75	07.0709.0866	53	07.0740.0050	17, 37	07.0740.0158	15, 151
07.0709.0010	53	07.0709.0867	53	07.0740.0051	17	07.0740.0163	15
07.0709.0011	53	07.0709.0868	53	07.0740.0052	15, 17	07.0740.0169	19
07.0709.0012	53	07.0709.0869	53	07.0740.0054	17	07.0740.0170	45
07.0709.0013	53	07.0709.0870	53	07.0740.0055	17	07.0740.0171	45
07.0709.0057	57, 69	07.0709.0872	53, 125	07.0740.0058	17	07.0740.0192	37
07.0709.0059	57	07.0709.0873	53	07.0740.0059	17	07.0740.0202	15
07.0709.0060	59, 71	07.0709.0880	53	07.0740.0060	17	07.0740.0203	15
07.0709.0061	59, 71	07.0709.0881	53	07.0740.0061	17	07.0740.0206	19
07.0709.0064	59, 71	07.0709.0883	53	07.0740.0062	17, 19	07.0740.0208	19

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
07.0740.0209	15, 151	07.4529.0093	31	09.4618.0813	97	51.0808.5100	37
07.0740.0210	15, 151	07.4529.0102	41	09.4618.0814	97	51.0808.6000	147
07.0740.0211	15, 151	07.4529.0106	33	09.4618.0916	97	51.0808.6900	37
07.0740.0212	15, 151	07.4529.0107	89	09.4618.0917	97	51.0808.7600	45
07.0740.0213	15, 151	07.4529.0108	29	09.4618.0918	97	51.0808.8100	101
07.0740.0214	15, 151	07.4529.0109	93	09.4618.0919	97	51.0808.9000	35
07.0740.0215	15	07.4529.0110	95	09.4618.0920	97	51.0809.3100	37
07.0740.0217	15	07.4529.0111	39, 41	09.4618.0921	97	51.0809.3400	35
07.0740.0218	21	07.4529.0115	41	09.4618.0922	97	51.0809.3900	79
07.0740.0219	21	09.0801.0000	33	09.4618.0923	97	51.0809.4000	77, 79
07.0740.0223	17	09.0801.0001	33, 95	09.4618.0924	97	51.0809.4600	79
07.0740.0227	17	09.0801.0025	95	09.4618.0925	97	51.0809.5700	27
07.0740.0228	17	09.0803.0007	105	09.4618.0926	97	51.0810.2500	105
07.0740.0229	17	09.0803.0008	105	09.4618.0927	97	51.0810.5300	37
07.0740.0230	17	09.0803.0011	147	09.4618.0928	97	51.0810.5500	37
07.0740.0231	17	09.0803.0012	31, 35, 37	09.4618.0933	97	51.0810.7200	141
07.0740.0234	19	09.0803.0016	49	09.4618.0986	97	51.0810.8300	99
07.0740.0235	17	09.0803.0026	27, 81, 153	09.4618.0991	97	51.0810.8400	99
07.0740.0236	17	09.0803.0039	27	09.4618.1001	97	51.0810.8500	99
07.0740.0246	15	09.0803.0043	83, 85, 91	09.4618.1028	97	51.0811.2400	25
07.0740.0247	15	09.0803.0052	149	09.4618.1122	97	51.0811.4019	27
07.0740.0248	15	09.0803.0055	81	09.4618.1124	97	51.0811.4042	27
07.0740.0249	17	09.0803.0068	153	09.4618.1181	97	51.0811.4043	27
07.0740.0250	17	09.0803.0069	147, 153	09.4618.1242	97	51.0811.4044	127
07.0740.0264	49	09.0803.0087	27	09.4618.1251	97	51.0811.4047	107
07.0740.0272	17	09.0803.0125	151	09.4627.0016	51	51.0811.4146	45
07.0740.0273	17	09.0803.0245	101	09.4627.0017	51	51.0811.4147	45
07.0740.0274	17	09.0803.0348	103	09.4629.0000	51	51.0811.4148	45
07.0740.0275	17	09.0803.0351	101	09.4629.0003	51	51.0901.6700	31
07.0740.0276	17	09.0803.0352	35	09.4632.0002	65	51.0901.6900	143
07.0740.0277	17	09.0803.0357	25, 97	09.4632.0061	51	51.0901.7700	89
07.0740.0279	17	09.0803.0360	27	09.4632.0062	51	51.0902.3100	35, 37
07.0740.0359	13	09.0803.0368	37	09.4632.0020	51	51.0902.3200	35
07.0740.0360	13	09.0803.0391	153	09.4635.0014	51	51.0902.3800	29
07.0740.0361	13	09.0803.0395	27	09.4635.0041	51	51.0902.4500	37
07.0740.0363	11	09.0803.0414	35, 37	09.4635.0042	51	51.0902.5400	27
07.0740.0364	11	09.0803.0419	27	09.4636.0014	41	51.1000.4700	27
07.0740.0365	11	09.0803.0501	37	09.4645.0000	105	51.1000.4900	27
07.0740.0366	11	09.0803.0545	115	09.4645.0003	105	51.1300.0100	153
07.0740.0367	11	09.0804.2400	37	09.4645.0022	45	51.1300.0300	153
07.0740.0368	11	09.0804.2500	37	09.4655.0000	105	51.1300.0400	153
07.0740.0369	11	09.0804.2600	37	09.4656.0000	105	51.1300.0500	153
07.0740.0370	11	09.0804.2700	37	09.4661.0002	111	51.1300.5300	81
07.0740.0371	11	09.0804.2800	37	09.4661.0014	35, 111	51.1301.2500	81
07.0740.0372	11	09.0804.2900	37	09.4661.0016	35, 111	52.0900.0200	77
07.0740.0374	15	09.0804.3000	37	09.4670.0001	27	52.1100.7700	37
07.0741.0000	29	09.0804.3100	99	09.4670.0002	101, 111	53.0000.3300	95
07.0741.0001	29, 43	09.0805.0000	99, 101	09.4670.0004	99	53.0100.2400	85
07.0741.0002	43	09.0805.0005	101	09.4670.0006	35	53.0200.0700	85
07.0741.0003	43	09.0805.0018	101, 107	09.4675.0000	139	53.0300.1600	93
07.0741.0004	43	09.0805.0030	111	09.4675.0003	139	53.0400.1200	83
07.0741.0005	43	09.4601.0054	99	09.4675.0007	81	53.0500.0600	89
07.0741.0008	43	09.4604.0000	111	09.4675.0008	81	53.0600.1200	29
07.0741.0009	19	09.4604.0044	107	51.0113.9000	35	53.0700.0300	31
07.0741.0010	19	09.4604.0045	107	51.0200.8400	77	53.0800.1400	33
07.0741.0011	19	09.4604.0047	111	51.0200.8500	79	53.0800.1500	33
07.0741.0012	19	09.4610.0001	19	51.0200.8600	79	53.3000.0400	111
07.0741.0014	19	09.4610.0002	37	51.0400.4700	87	53.3001.0500	89
07.0741.0015	29	09.4610.0028	141	51.0500.1200	33	53.3001.2100	107
07.0741.0016	43	09.4616.0040	97	51.0500.1300	33	53.3001.4200	111
07.0741.0017	19	09.4616.0041	97	51.0600.9000	111	53.3001.6000	103
07.0741.0018	19	09.4616.0100	97	51.0600.9200	35	53.3001.6700	107
07.0741.0019	19	09.4616.0109	97	51.0800.0400	35, 37	53.3001.6704	101
07.0741.0031	29	09.4616.0112	81	51.0800.0600	85	53.3100.0036	103
07.0741.0032	29	09.4616.0122	97	51.0800.2700	27	53.3200.0029	101
07.0741.0033	29	09.4618.0061	97	51.0801.9000	77	53.3301.0002	111
07.0741.0058	43	09.4618.0093	153	51.0801.9100	79	53.3400.9100	85
07.4501.0057	99	09.4618.0171	97	51.0803.0300	85	53.3400.9200	85
07.4501.0084	107	09.4618.0241	97	51.0804.9000	77, 79	53.3402.0300	91
07.4501.0085	107	09.4618.0242	97	51.0805.1500	37	53.3402.0400	91
07.4501.0090	99	09.4618.0243	97	51.0805.1600	35	53.3402.0500	83
07.4501.0098	99	09.4618.0652	97	51.0806.5700	145	53.3402.0600	83
07.4501.0158	99	09.4618.0653	97	51.0806.7400	35	53.3402.0700	49
07.4529.0071	83, 85	09.4618.0776	97	51.0808.0700	45	53.3402.0800	49
07.4529.0072	93, 95	09.4618.0784	97	51.0808.3000	37	54.0000.0001	83
07.4529.0073	83, 85	09.4618.0791	97	51.0808.3100	37	54.0000.0004	85

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
54.0000.0083	81	56.0002.0118	137	56.0021.0085	121	639668	55, 67
54.0000.0096	33	56.0002.0119	137	56.0021.0093	25, 121	639670	55, 67
54.0000.0097	33	56.0002.0124	129	56.0021.0106	121	639671	63, 75
54.0000.0098	33	56.0002.0128	133	56.0023.0017	147	639674	61, 73
54.0000.0099	95	56.0002.0129	133	56.0023.0018	147	639675	61
54.0000.0122	87	56.0002.0132	129	626544	57, 69	639676	61, 73
54.0000.0123	93	56.0002.0133	133	627521	41	639679	61, 73
54.0000.0126	95	56.0002.0134	137	628275	53	639681	61, 73
54.0000.0128	85	56.0002.0141	133, 145	628924	31	639682	61, 73
54.0000.0129	85	56.0002.0142	145	629733	53	639683	61, 73
54.0000.0155	37	56.0002.0144	129	629735	53	639684	69
54.0000.0156	93	56.0002.0145	131	630328	61, 73	639685	69
54.0000.0157	37	56.0002.0146	131	630693	57, 69	639686	69
54.0001.0022	87	56.0002.0149	131	630846	59, 71	639689	73
54.0001.0041	45	56.0002.0150	131	632383	55, 59, 67, 71	639691	73
54.0001.0058	89	56.0002.0153	133, 145	633069	61, 73	639692	73
54.0001.0059	89	56.0002.0154	145	633098	57, 69	639693	73
54.0002.0022	35	56.0002.0164	129	633099	57, 69	639695	61, 73
54.0002.0023	35	56.0002.0165	137	633161	53	639696	73
54.0002.0031	87	56.0002.0169	137	633174	59, 71	639779	53
54.0003.0033	35	56.0002.0181	133	633176	59, 65, 71	639783	53
54.0004.0099	85	56.0002.0196	137	633202	53, 59, 71	639785	53
54.0100.0020	35	56.0002.0205	135	633203	53, 59, 71	639787	53
54.0100.0056	81	56.0002.0230	135	633208	53	639789	53
54.0100.0077	89	56.0002.0247	133	633517	73	639790	53
54.0100.0096	103	56.0002.0248	137	633606	19	639792	53
54.0101.0019	143	56.0002.0249	137	634499	57, 69	639799	53
54.0200.0000	77, 79	56.0002.0250	135	634501	57, 69	639802	53, 57, 69
54.0200.0001	77, 79	56.0002.0294	135	634546	59, 71	639808	53
54.0201.0003	77	56.0002.0622	137	634972	113, 121	639818	53
54.0201.0004	77	56.0002.0631	137	634973	113, 115	639982	121
54.0201.0017	83, 87	56.0005.0000	115	634974	113	640101	85
54.0600.0001	85	56.0005.0002	115	634975	121	640102	85
54.0702.0000	77, 79	56.0005.0005	115	635596	53	640214	59
54.0702.0001	77, 79	56.0005.0009	115	636440	73	640216	59, 71
54.0702.0003	79	56.0005.0010	115	637536	53	640270	63, 75
54.0702.0004	79	56.0006.9202	115	637567	59, 71	640536	83
54.0800.0000	45	56.0008.0012	115	637574	73	640717	69
55.0403.0043	51	56.0009.0002	119	637576	53	640718	59, 71
55.0403.0044	51	56.0009.0003	117	637621	73	640719	71
55.0403.0047	149	56.0010.0005	123	637650	113	640720	59, 71
55.0602.0297	117	56.0010.0034	117	637850	65	640728	59, 71
55.0602.0350	117, 119	56.0010.0035	117	638226	23	640729	59, 71
55.0602.0365	115	56.0010.0039	145, 147, 149	638243	99	640730	59, 71
55.0602.0366	115	56.0010.0041	127	638548	59, 61, 65, 71, 73	640731	73
55.0602.0371	115	56.0010.0042	127	639289	59, 71	640732	73
55.0602.0382	121	56.0010.0050	127	639297	57, 69	640908	59, 71
55.0602.0389	115	56.0010.0051	127	639298	57, 69	640909	59, 71
55.0602.0421	125	56.0010.0052	127	639300	57, 69	641089	57
55.0602.0425	123	56.0010.0053	127	639301	57, 69	641090	57
55.0602.0460	115	56.0010.0054	127	639302	57, 69	641108	63, 75
55.0602.0498	121	56.0010.0055	127	639303	57, 69	641109	63, 75
56.0000.0051	25	56.0010.0056	127	639327	53	901777	73
56.0002.0009	137	56.0010.0057	127	639328	53	902935	93
56.0002.0019	133	56.0012.0017	119	639329	53	96008	19
56.0002.0031	137	56.0012.0024	119	639624	59, 71		
56.0002.0032	145	56.0012.0042	25	639625	59		
56.0002.0040	145	56.0012.0047	53, 125	639630	59, 71		
56.0002.0056	133	56.0012.0062	25	639631	59, 71		
56.0002.0069	133	56.0013.0000	111	639637	59, 71		
56.0002.0071	135	56.0013.0001	35	639639	59, 71		
56.0002.0075	131	56.0013.0006	119	639640	59, 71		
56.0002.0076	133	56.0013.0008	119	639641	59, 71		
56.0002.0079	135	56.0013.0028	119	639642	59, 71		
56.0002.0095	135	56.0013.0036	115	639643	59, 71		
56.0002.0097	135	56.0016.0032	19	639645	59, 71		
56.0002.0100	131	56.0016.0077	25	639646	59, 71		
56.0002.0101	131	56.0017.0032	23, 147, 149	639647	59, 71		
56.0002.0102	137	56.0017.0057	127	639650	57, 69		
56.0002.0103	129	56.0017.0059	23	639651	57, 69		
56.0002.0104	133	56.0021.0023	119	639652	57, 69		
56.0002.0105	129	56.0021.0057	113	639653	57, 69		
56.0002.0108	129	56.0021.0060	121	639657	57, 69		
56.0002.0111	129	56.0021.0068	121	639661	57, 69		
56.0002.0113	133	56.0021.0071	121	639662	57, 69		
56.0002.0117	137	56.0021.0078	121	639664	57, 69		

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

1

1-Way Connector.....129
10-Way Connector.....133
11-Way Mark II Connector.....129
12-Way Connector.....135
12-Way Deutsch Connector.....135
13-Way Mark II Connector.....129
17-Way Mark II Connector.....129
18-Way Connector.....129
1st Telescopic Element.....77

2

2-Way Connector.....133, 135, 137
2-Way Deutsch Connector.....133, 137
21-Way Mark Deutsch Connector.....133
21-Way Mark II Connector.....129
24-Way Connector.....131
24-Way Deutsch Connector.....131
24-Way Deutsch Connector - Type A.....131
2nd Telescopic Element.....79

3

3-Way Connector.....137
3-Way Deutsch Connector.....133
36-Pole Connector.....129
3rd Telescopic Element.....79

4

4-Way Connector.....129, 133
4-Way Deutsch Connector.....133
40-Way Connector - Type A.....131

5

5-Way Mark II Connector.....129

6

6-Pole Connector.....133
6-Way Connector.....129, 133
6-Way Delphi Connector.....133
6-Way Deutsch Connector.....133
6-Way Mark II Connector.....129
606370 pos.10.....49
606370 pos.9.....43
606375 pos.1.....43
606375 pos.2.....93
606376 pos.12.....43
606376 pos.20.....43
606376 pos.26.....111
606379 pos.1.....111
606379 pos.2.....111
606379 pos.3.....111
606379 pos.5.....39
606380 pos.21.....43
606380 pos.23.....111
606407 pos.5.....89
606408 pos.14.....83
606408 pos.17.....43
606418 pos.1.....43

8

8-Way Connector.....135
8-Way Deutsch Connector.....135

9

9-Way Connector.....137
90° 2-Way Connector.....137

A

Accumulator.....49, 95
Adhesive Profile.....17
Air Filter.....107
Air Inlet.....21
Alternator.....99
Alternator Cable.....115
Angle Indicator.....25
Arm.....71
Articulated Tie Rod.....63, 75
Articulation.....105
Axle Case.....59

B

Back Cover Assembly.....11
Back Foam Kit.....11
Back-Up Ring.....61, 73, 83, 85
Ball Bearing.....53
Ball Joint.....31, 93
Ball-Grip.....15, 19, 21
Basic Frame.....35
Battery.....115
BEARING.....59
Bearing.....57, 59, 69, 71
Bevel Gear Set.....57, 69
Bleeder Valve, Long.....61, 73
Block.....85
Boom Functions Control Unit.....121
Boom Work Light.....147
Bracket.....25, 29, 37, 45, 105, 107, 145, 147, 149
Brake Disc.....61, 73
Brake Disc, Intermediate.....61, 73
Bracket.....27
Bubble Level.....19
Bulb.....117, 123, 127, 145, 149
Bushin.....65, 71, 73
BUSHING.....59
Bushing.....15, 17, 19, 29, 31, 33, 59, 65, 71, 77, 79, 83, 87, 89, 95, 151

C

C/C D.....137
C/C D. 10.....137
C/C D. 5,3.....137
C/C D. 5,3 For Wire D. 1-2,5.....137
C/C D. 6 For Wire D. 4.....137
C/C D. 8.....137
Cable.....45, 105
Cable Reel.....147
Cable Terminal.....145
Cap.....19, 53, 59, 61, 65, 71, 73, 151
Card.....113
Cardan Joint Assembly Kit.....51
Cardan Shaft.....51
Cartridge.....107, 111
Case, Differential.....69
Casing.....35
Chain.....81, 147, 153

Clamp.....21, 49, 95, 99, 101, 103, 105, 107, 111, 145, 147
Clutch Disc.....57
Coating.....17
Collar.....85
Compensation Cylinder.....93
Compl. Front Differential Gear.....57
Complete Air Filter.....107
Complete Radiator.....101
Complete Turn Signal.....117
Conic Washer.....35, 37
Connection.....37
Connector.....129, 135, 137, 145
Contact.....19, 119
Control Lever.....19
Control Panel.....23
Control Valve.....29, 43
Conveyor.....101
Cosmetic - Bubble Level.....97
Cosmetic - Burn Hazard.....97
Cosmetic - Burn/Explosion Hazard.....97
Cosmetic - Cabin Fuses & Relays Board.....97
Cosmetic - Capacity of the truck and attachment.....97
Cosmetic - Compartment Access.....97
Cosmetic - Crush Hazard.....97
Cosmetic - Diesel Fuel Cap.....97
Cosmetic - Emergency Manual Controls Of The Main Valve.....97
Cosmetic - Engine Fuses & Relays Board.....97
Cosmetic - Falling Object Hazard.....97
Cosmetic - Genie GTH-4013.AU.2.....97
Cosmetic - GENIE Logo in White.....97
Cosmetic - Guaranteed max sound power level.....97
Cosmetic - Hydraulic Oil.....97
Cosmetic - Lift Point.....97
Cosmetic - Machine data plate.....97
Cosmetic - Maintenance Collar.....97
Cosmetic - Max Capacity.....97
Cosmetic - No Riders.....97
Cosmetic - Parking Brake.....97
Cosmetic - Quick guide and Control Lever.....97
Cosmetic - Re-sequencing the telescopic boom extension.....97
Cosmetic - Rules for machine stability.....97
Cosmetic - Safety pin operation.....97
Cosmetic - Stabilizer Max Pressure.....97
Cosmetic - Tip-over Hazard.....97
Cosmetic - Tyre Pressure.....97
Cosmetic - Upper Door Internal Unlock System.....97
Cosmetic - Use limits close to electric power lines.....97
Cotter Pin.....45
Counterweight.....27
Cover.....19, 53, 55, 59, 67, 71, 111
Cylinder.....31, 53, 63, 75, 85, 89
Cylinder Packing Kit.....85

D

Damper Kit.....11
Dashboard.....19
Dashboard Line.....121
Dented Ball.....53
Deutsch Connector.....135

Diesel Engine.....99
 Diesel Fuel Filter.....99
 Diesel Oil Tank.....35
 Differential.....69
 Differential Case.....57
 Diffuser.....13
 Diode.....121
 Door Stop.....15
 Dowel.....45, 53, 61, 73
 Drilled Screw.....33, 49, 83, 85
 Driver Line.....121
 Driving Mirror.....15, 37, 141
 Dumper.....27

E

Elastic Joint.....99
 Electric Box Base.....115
 Electric Box Cover.....115
 Electrical Fan.....13
 Electrical Line.....125
 Electronic Sensor.....125
 Emergency Button.....19
 End.....33
 Engine Line.....115
 EV Connector.....135
 Exhaust Muffler.....103
 Exhaust Pipe.....103

F

Female Coupling.....89
 Filter.....15, 35, 111
 Filter, Oil, Engine.....99
 Flange.....41, 53, 57, 69, 103
 Flashing Beacon.....123
 Flexible Hose.....29, 31, 33, 39, 41, 43, 47, 49, 83, 85, 89, 91, 93, 95, 109, 111
 Fork.....27, 81, 153
 Fork Coupling Attachment.....87
 Forks Articulation Cylinder.....83
 Frame.....15, 17
 Front Steering Axle.....51
 Front Support.....35, 37
 Fuel Gauge.....35
 Fuse ,7.5A.....113
 Fuse 15A.....115
 Fuse 1A.....121
 Fuse 20A.....121
 Fuse 5A.....113
 Fuse 7.5A.....121
 Fuse Holder.....115, 121
 Fuse, 10A.....113
 Fuse, 15A.....113
 Fuse, 3A.....113
 Fuses Box.....135

G

Gas Cable.....105
 Gas Spring.....37
 Gear.....53
 Gear Box.....51
 Gear, Differential Side.....69
 Glass.....15, 17, 23, 117, 127, 147
 Grate.....15, 37, 101, 143
 Grease Nipple.....17, 29, 31, 33, 45, 59, 65, 71, 77, 87, 93, 95
 Grub Bolt.....53
 Grubscrew.....73
 Guard.....29, 31, 35, 37, 89, 153

Guide.....85
 Gum.....149

H

Half Flange.....47
 Handle.....15, 17, 19, 37
 Handle Kit.....11
 Handwheel Arrangement.....99
 Heater.....13, 21
 Height Adjustment Kit.....11
 Hex Cap.....15, 17, 21
 Hinge.....15, 17, 27, 37
 Hook.....27
 Horn.....117, 119
 Housing.....53, 55, 59, 67, 71, 119
 Hub.....59, 71, 99
 Hydraulic Jack.....139
 Hydraulic Motor.....47
 Hydraulic oil Temperature Indicator.....23

I

Indicator.....107
 Input Shaft.....53
 Input/Output Outriggers Control Unit.....121
 Insulator.....35, 99, 101, 111

J

Joint.....59, 71
 Joint Kit.....29, 31, 33, 39, 41, 43, 47, 63, 75, 83, 89, 93, 95
 Joint, Articulated.....59, 71

K

Key.....17, 23, 27, 81
 Kit.....15

L

Label.....17, 153
 Ladder.....35
 Left Light.....127
 Left Mud-Guard.....35
 Left Stabilizer Cylinder.....33
 Left Support.....99, 127
 Left Wiring Harness Light.....119
 Length Angle Transducer.....25
 Level Indicator.....111, 119
 Lever.....41, 45, 73, 105
 Lever-Fitted Lock.....17
 Lifting Cylinder.....95
 Light.....117, 127, 145
 Light Hose-clamp 22/32.....21
 Loadspeaker Frame.....15
 Lock.....15, 19, 27, 37
 Lock Cable Kit.....25
 Lower Door.....17

M

Magnetic Cap.....53
 Male Coupling.....89
 Manifold.....89, 103, 111
 Manplatform Control Unit.....121
 Max Fuse 30A.....115
 Max Fuse 40A.....115
 Max Fuse 60A.....115
 Max Fuse Holder.....115
 Microswitch.....45

Microswitch Bracket.....45
 Mirror Arm.....15
 Mirror Kit.....15
 Modulus.....43

N

Name Plate.....21, 81
 Negative Battery Cable.....115
 Non-Skid Coating.....17
 Nut.....15, 17, 27, 33, 37, 45, 49, 53, 57, 59, 69, 71, 73, 81, 83, 85, 93, 101, 103, 105, 107, 111
 Nut, DIN439 JAM M16-2.0 P.....59, 71
 Nut, M6.....35, 37, 87, 89, 147

O

O-RING.....61
 O-Ring.....53, 57, 69, 73, 95, 127
 Oil Filter.....111
 Oil Tank.....111
 Output Shaft.....53
 Overload Display.....25
 Overload Sistem Control Box.....25
 Overload System Control Unit.....121
 Overload System Timer.....121

P

Panel.....17, 19
 Paper Piping.....21
 Pedal.....105
 Phonic Wheel.....53
 Pilot Light.....19, 23
 Pin.....17, 27, 33, 35, 37, 45, 57, 59, 69, 71, 81, 83, 85, 87, 89, 93, 95
 Pinion, Differential.....59, 71
 Pipe.....49, 83, 85, 91
 Pipe Fitting.....21, 29, 31, 33, 39, 41, 43, 47, 49, 71, 83, 85, 89, 91, 93, 95, 109, 111
 Piston.....53, 61, 73
 Plain Washer.....27, 29, 35, 37, 45, 49, 85, 89, 95, 99, 101, 103, 107, 111, 119
 Plate.....35, 37, 45, 81, 145, 153
 Plate - Boom Tilting Degree.....97
 Plate - Fork data plate.....97
 Plate - Machine data plate.....97
 Plate - ROPS-FOPS cab type-approval plate.....97
 Plate Support.....27
 Plate, Locking.....59, 71
 Plug.....17, 19, 23, 29, 35, 49, 55, 59, 67, 71, 101, 111, 127
 Plug, Breather.....67
 PlugG ,Breather.....55
 Pommel.....115
 Positive Battery Cable.....115
 Power Steering.....41
 Pressure Switch.....111, 117
 Pressure Transducer.....25
 Pressure Tube.....29, 47
 Protection.....19, 35, 99
 Protection Ring.....53
 Proximity Sensor.....119
 Proximity Switch.....117, 119
 Pulley.....45
 Pump.....41, 47, 49, 111
 Push Button.....19, 45, 119

Part Description Index (continued)

R

Radiator Core.....101
 Ratchet Socket.....139
 Rear Light.....127
 Rear Steering Axle.....51
 Rear Support.....35, 37
 Rear Window Fixing Kit.....151
 Red Fork D.43.....137
 Reduction.....21
 Reduction adapter.....21
 Reduction Bushing.....53
 Reflector.....127
 Reinforcement.....17
 Relais Box.....121
 Relay.....19, 113, 115, 121
 Relay Holder.....115, 121
 Resistor.....115
 Retainer Pipe.....83, 85, 91
 Right Attachment.....35
 Right Light.....127
 Right Mud-Guard.....37
 Right Stabilizer Cylinder.....33
 Right Support.....99, 127
 Right Wiring Harness Light.....119
 Rigid White Faston Cover.....137
 Rim 12".....51
 Rim 20".....51
 Ring Gear.....71
 Ring Gear.....59
 Ring Nut.....57, 69
 Rivet.....19, 81
 Roof Lamp.....15
 Rubber.....15, 17, 21, 151
 Rubber Cap.....53
 Rubber Hose.....21, 99, 101, 107
 Rubber Platform.....17

S

Satellite.....57, 69
 Screw.....15, 17, 19, 21, 25, 27, 29, 31, 33, 35, 37, 39, 41, 45, 47, 49, 53, 57, 59, 61, 63, 69, 71, 73, 75, 77, 79, 81, 83, 85, 87, 89, 91, 93, 95, 99, 101, 103, 105, 107, 111, 117, 119, 127, 149, 151, 153
 Screw TCEI M 6X10 UNI5931 8.8ZN.....145
 Screw TCEI M6X10 UNI5931 8.8ZN 8.8ZN.....147
 Screw TE M 6X16 UNI 5739 8.8 ZN.....27
 Screw TE M 8X25 UNI 5739 8.8 ZN.....27
 Screw TE M10X25 UNI 5739 8.8 ZN.....141
 Screw TE M10X50 UNI 5739 8.8 ZN.....143
 Screw TE M12X25 UNI 5739 8.8 ZN.....143
 Screw TE M8 x 20 8.8 ZN UNI 5737.....147
 Screw TE M8 x 20 LG. 8.8 ZN UNI 5737.....145
 Screw TE M8X25 UNI 5739 8.8 ZN.....147
 Seal.....15, 17, 41, 47, 53, 55, 59, 61, 67, 71, 73, 83, 85, 93, 101, 111, 127
 Seal Ring.....53
 Seal, Differential.....69
 Seal, Differential.....57
 Seal, Planetary.....59, 71
 Seat.....17
 Seat Cover Assembly.....11
 Seat Foam Kit.....11
 Seat Frame Assembly.....11
 Security Dowel.....81
 Security Switch.....19, 125
 Selector.....19, 23

Selector Shaft.....53
 Sensor.....53, 111
 Sheet.....15
 Shim.....53
 Silencer.....103
 Slab Buildibng.....147
 Sleeve.....101, 107, 111
 Sliding Guide.....77, 79
 Sliding Pin.....53
 Snap Ring.....55, 57, 59, 67, 69, 71
 Solenoid.....29, 31, 39, 41, 43, 47
 Solenoid Valve.....31, 39, 41, 47
 Sound-Proof Panel.....37
 Spacer.....15, 57, 59, 69, 73, 77, 143, 151
 Special Clamp.....107
 Speed Lever.....19
 Split Pin.....15, 17, 153
 Spring.....19, 45, 53, 61, 73
 Spring Catch.....147, 153
 Spring Split Pin.....27, 81
 Spring Washer.....25, 27, 29, 35, 37, 45, 47, 49, 77, 79, 85, 89, 95, 99, 101, 103, 111, 117, 119, 149
 Spring washer.....95
 Spring Washer D10.....141, 143
 Spring Washer D12.....143
 Spring washer D6 ZN.....27
 Spring washer D8 UNI 1752.....27
 Stabilizer.....33
 Star Wheel.....51
 Starting Motor.....99
 Starting Switch.....23
 Steering Column.....41
 Steering Set Screw.....41
 Steering Wheel.....41
 Stop.....15, 37
 Stop Belt.....17
 Stop Nut.....15, 17, 21, 27, 35, 37, 45, 93, 95, 99, 111
 Storage Pocket.....15
 Stud.....59, 71
 Sun Visor.....17
 Support.....17, 19, 21, 27, 37, 45, 59, 65, 71, 77, 79, 99, 101, 127, 141
 Support Casing.....37
 Support, Ring Gear.....59, 71
 Suspension Cover Kit.....11
 Swaying Cylinder.....29
 Switch.....19, 23, 147, 149
 Switch Cover.....19
 Switch Glass.....149
 Switch, Selector, 3 Poetion.....23
 Synchronizer.....53

T

Tank.....15
 Tap.....21, 111
 Thermistor.....115
 Thickness.....71, 77, 79
 Threaded Element.....73
 Threaded Plate.....35
 Through Coupling.....15, 83
 Transmission Control Unit.....121
 Trough Coupling.....15
 Turn Signals Lever.....19
 Tyre 20".....51
 Tyre 24".....51

U

Upper Door Complete.....17

V

Valve.....29, 33, 43, 47, 83, 85, 89, 93, 95, 109
 Vent Cap.....53

W

Wacher, Friction.....57
 Washer.....15, 17, 19, 21, 25, 29, 31, 33, 35, 37, 45, 47, 49, 53, 59, 69, 71, 81, 83, 85, 101, 105, 107, 111, 119, 127, 145, 147, 149, 153
 Washer D10.....141, 143
 Washer D12.....143
 Washer D6 ZN.....27
 Washer D8 UNI 6592 ZN.....27
 Washer, Friction.....69
 Weight Adjuster Kit.....11
 Wheel 20".....51
 Wheel 24".....51
 Wheel Aligned Control Unit.....121
 Wheel Stud.....59
 Wheelstud.....49
 Wiper Arm.....15, 151
 Wiper Blade.....15, 151
 Wiper Motor.....15, 151
 Wiring Harness.....117, 119, 123
 Work Light.....149

This Page Intentionally Left Blank

Fitting Cross References

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
12342	6-4 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	42794	1 CR-S	ELBOW,90°,MALE PIPE
13757	4 R6X-S	RUN TEE,SWIVEL NUT,ORFS	42795	BV-0839	BALL VALVE
19685	12-10 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42796	BV-0838	BALL VALVE
22664	12-10 C5OX	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42874	6-8 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
27431	8-12 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	42912	13943-6-4	HOSE END,90° FEMALE SWIVEL,JIC
28678	AS-B-33	SLEEVE,NYLON,1.81" ID	42920	BV-0840	BALL VALVE,90°
39871	6 WETX-WLN-S	UNION,90° BULKHEAD W/NUT,FLARE TUBE	42932	AS-B-17	SLEEVE,NYLON,1.22" ID
39872	4 R5OX-S	RUN TEE,STRAIGHT THREAD	42936	10243-2-4	HOSE END,FEMALE PIPE
39873	6 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42953	1/2 DD-S	ELBOW,90°,FEMALE PIPE
39874	8-6 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42956	6 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS
39875	4-6 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	45349	8 V5OX-S	ELBOW,45°,STRAIGHT THREAD TO FLARE TUBE
39876	6-8 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	45351	4 V5OX-S	ELBOW,45°,STRAIGHT THREAD TO FLARE TUBE
39877	4 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	47223	10343-6-6	HOSE END,MALE,JIC
39878	6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	47419	PS690503-6-6	SWIVEL,90°,STRAIGHT THREAD TO 37° FLARE
39879	4-8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	48750	421-4	HOSE,1/4 INCH ID
39880	6-10 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	48751	481TC-4	HOSE,1/4 INCH ID
39881	4-6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	48752	482TC-4	HOSE,1/4 INCH ID
39882	4-HP5ON-S	PLUG,STRAIGHT THREAD	48753	451TC-6	HOSE,3/8 INCH ID
39883	8-8 FTX-S	CONNECTOR,MALE PIPE TO FLARE TUBE	48754	482TC-6	HOSE,3/8 INCH ID
39885	269HB 12-12	ELBOW,90°,BEADED HOSE BARB TO MALE PIPE	48755	381-6	HOSE,3/8 INCH ID
39886	431-6	HOSE,3/8 INCH ID	48756	451TC-8	HOSE,1/2 INCH ID
39887	540N-2	HOSE,1/8 INCH ID	48757	482TC-8	HOSE,1/2 INCH ID
39888	801-8	HOSE,1/2 INCH ID	48758	381-8	HOSE,1/2 INCH ID
39889	801-12	HOSE,3/4 INCH ID	48759	381-10	HOSE,5/8 INCH ID
39890	10643-6-6	HOSE END,FEMALE SWIVEL,JIC	48760	451TC-10	HOSE,5/8 INCH ID
39891	13943-6-6	HOSE END,90° FEMALE SWIVEL,JIC	48761	482TC-12	HOSE,3/4 INCH ID
39892	13743-6-6	HOSE END,45° FEMALE SWIVEL,JIC	48762	451TC-12	HOSE,3/4 INCH ID
39894	30682-8-8	HOSE END,FEMALE SWIVEL,JIC	48763	772-12	HOSE,3/4 INCH ID
39895	30682-10-12	HOSE END,FEMALE SWIVEL,JIC	48764	881-16	HOSE,1 INCH ID
42286	8-8 CTX-S	ELBOW,90°,MALE PIPE TO FLARE TUBE	48765	772-16	HOSE,1 INCH ID
42756	8-12 CLO-S	ELBOW,90,MALE PIPE TO ORFS	48766	AS-B-15	SLEEVE,NYLON,1.06" ID
42757	8-12 FLO-S	CONNECTOR,MALE PIPE TO ORFS	48767	AS-B-22	SLEEVE,NYLON,1.42" ID
42758	4 JLO-S	UNION TEE,ORFS	48770	881-8	HOSE,1/2 INCH ID
42759	4-4 FLO-S	CONNECTOR,MALE PIPE TO ORFS			
42760	6-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS			
42761	1J143-6-4	HOSE END,90° FEMALE SWIVEL,SEAL LOK			
42762	1J743-6-4	HOSE END,45° FEMALE SWIVEL,SEAL LOK			
42768	1JO43-4-4	HOSE END,MALE,SEAL LOK			
42776	601-8	HOSE,1/2 INCH ID			
42777	1J743-16-16	HOSE END,45° FEMALE SWIVEL,SEAL LOK			
42786	16 CLO-S	ELBOW,90°,MALE PIPE TO ORFS			
42787	16 R6LO-S	RUN TEE,SWIVEL NUT,ORFS			
42788	16-8 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS			
42789	6-6 CLO-S	ELBOW,90°,MALE PIPE TO ORFS			
42790	8-10 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			
42791	3/4 CD-S	ELBOW,90°,MALE TO FEMALE PIPE			
42792	3/4 X 1/2 PTR-S	REDUCER,MALE TO FEMALE PIPE			
42793	1/2 CR-S	ELBOW,90°,MALE PIPE			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
48771	881-10	HOSE, 5/8 INCH ID	48847	13943-12-12	HOSE END, 90° FEMALE SWIVEL, JIC
48772	381-4	HOSE, 1/4 INCH ID	48848	10543-12-12	HOSE END, MALE, STRAIGHT THREAD
48773	AS-B-13	SLEEVE, NYLON, .86" ID	48849	1JC71-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
48800	1JC43-4-4	HOSE END, FEMALE SWIVEL, SEAL LOK	48850	1JS71-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
48801	1J743-4-4	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	48851	1J171-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48802	1J943-4-4	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48852	1J771-12-12	HOSE END, 45° FEMALE SWIVEL, SEAL LOK
48804	1JM43-4-4	HOSE END, MALE, SEAL LOK, NO O-RING	48853	1J971-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48805	10643-4-4	HOSE END, FEMALE SWIVEL, JIC	48854	1JC43-16-16	HOSE END, FEMALE SWIVEL, SEAL LOK
48806	13943-4-4	HOSE END, 90° FEMALE SWIVEL, JIC	48855	1J943-16-16	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48807	1JS43-4-4	HOSE END, FEMALE SWIVEL, SEAL LOK	48856	1J171-16-16	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48808	3JC82-8-8	HOSE END, FEMALE SWIVEL, SEAL LOK	48857	1J971-16-16	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48809	3JC82-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK	48859	1JS43-8-4	HOSE END, FEMALE SWIVEL, SEAL LOK
48810	1JC43-6-4	HOSE END, FEMALE SWIVEL, SEAL LOK	48867	PD36BTL	DIAGNOSTIC NIPPLE, SEAL-LOK SWIVEL
48811	1J943-6-4	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48873	6 PNLO-S	PLUG, TUBE END, ORFS
48812	1JC43-6-6	HOSE END, FEMALE SWIVEL, SEAL LOK	48874	6 PNTX-S	PLUG, FLARE TUBE
48813	1J143-6-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48875	6 R6LO-S	RUN TEE, SWIVEL NUT, ORFS
48814	1J543-6-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48877	4 F5OLO-SW.025	CONNECTOR, STRAIGHT THREAD TO ORFS, W/.025 ORI
48815	1J743-6-6	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	48878	16-12 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS
48816	1J943-6-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48879	8 C6LO-S	ELBOW, 90°, SWIVEL NUT ORFS
48817	1JS43-6-8	HOSE END, FEMALE SWIVEL, SEAL LOK	48880	PD6-285	CAP, DIAGNOSTIC NIPPLE
48818	1J943-8-4	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48881	6 HLO-S	UNION, ORFS
48819	1JC43-8-6	HOSE END, FEMALE SWIVEL, SEAL LOK	48883	8 P5ON-S	PLUG, STRAIGHT THREAD
48820	1J743-8-6	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	48884	8M18F87OMLO-S	CONNECTOR, METRIC, STRAIGHT THREAD TO ORFS
48821	1J943-8-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48885	4 WGTX-WLN-S	CONNECTOR, BULKHEAD, FEMALE PIPE TO FLARE TUBE
48822	1JC43-8-8	HOSE END, FEMALE SWIVEL, SEAL LOK	48886	4 F5OLO-SW/2MM	CONNECTOR, MACHINED STRAIGHT THREAD TO ORFS
48823	1JS43-8-8	HOSE END, FEMALE SWIVEL, SEAL LOK	48887	4 CTX-S	ELBOW, 90°, MALE PIPE TO FLARE TUBE
48824	1J143-8-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48888	10-12 V5OLO-S	ELBOW, 45°, STRAIGHT THREAD TO ORFS
48825	1J543-8-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48890	4 S5OLO-S	BRANCH TEE, STRAIGHT THREAD TO ORFS
48826	1J743-8-8	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	48891	4 S6LO-S	BRANCH TEE, SWIVEL NUT TO ORFS
48827	1J943-8-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48828	1JC43-10-8	HOSE END, FEMALE SWIVEL, SEAL LOK			
48829	1JS43-10-8	HOSE END, FEMALE SWIVEL, SEAL LOK			
48830	1J743-10-8	HOSE END, 45° FEMALE SWIVEL, SEAL LOK			
48831	1J943-10-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48833	1JC43-10-10	HOSE END, FEMALE SWIVEL, SEAL LOK			
48834	1J943-10-10	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48835	1JS43-10-12	HOSE END, FEMALE SWIVEL, SEAL LOK			
48836	1JC43-12-8	HOSE END, FEMALE SWIVEL, SEAL LOK			
48837	1JS43-12-8	HOSE END, FEMALE SWIVEL, SEAL LOK			
48838	1J743-12-8	HOSE END, 45° FEMALE SWIVEL, SEAL LOK			
48839	1J943-12-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48840	1J943-12-10	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48841	1JC43-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK			
48842	1JO43-12-12	HOSE END, MALE, SEAL LOK			
48843	1J143-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48844	1J543-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48845	1J743-12-12	HOSE END, 45° FEMALE SWIVEL, SEAL LOK			
48846	1J943-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
48892	6 C6LO-S	ELBOW,90°,SWIVEL NUT ORFS	48938	8 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48893	6 F5OHAO-S	UNION,STRAIGHT THREAD	48939	8 S6LO-S	BRANCH TEE,SWIVEL NUT TO ORFS
48894	8 WLO-WLNL-S	UNION,BULKHEAD,ORFS	48940	8 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48895	DT-370-MSMO-5	VALVE,CHECK	48941	8-4 TRLO-S	REDUCER,TUBE END TO SWIVEL,ORFS
48896	6 JLO-S	UNION,TEE,ORFS	48942	8-6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48897	DT-750-MSMS-5	VALVE,CHECK	48943	8-6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48898	DT-750-MOMS-5	VALVE,CHECK	48944	8-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48899	DT-620-MOMS-5	VALVE,CHECK	48945	8 FTX-S	CONNECTOR,MALE PIPE TO FLARE TUBE
48900	4-6 F5OLO-SW/.035	CONNECTOR,STRAIGHT THREAD TO ORFS, W/.035 ORI	48946	8-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48902	16-1 AOE4G-S	ELBOW,90° LONG,FEMALE PIPE TO STRAIGHT THREAD	48947	8-12 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48903	1 FF-S	NIPPLE,PIPE	48948	8-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48904	4 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48949	8-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48905	4 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48950	10 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48906	4 R5OLO-S	RUN TEE,STRAIGHT THREAD	48951	10 CC5OLO-S	ELBOW,90° LONG,STRAIGHT THREAD TO ORFS
48907	4 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	48952	10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48908	4 R6LO-S	RUN TEE,SWIVEL NUT,ORFS	48953	10 R5OLO-S	RUN TEE,STRAIGHT THREAD
48909	4 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS	48954	10 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48910	4 GTX-S W/.030	CONNECTOR,FEMALE PIPE TO FLARE TUBE	48955	10 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48911	4-6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48956	10-4 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48912	4-6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48957	10-6 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48913	4-6 F5OLO-SW/.030	CONNECTOR,STRAIGHT THREAD TO ORFS, W/.030 ORI	48958	10-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48914	4-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48959	12 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48915	6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48960	12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48916	6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48961	12 R5OLO-S	RUN TEE,STRAIGHT THREAD
48917	6 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS	48962	12 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48918	6 R5OLO-S	RUN TEE,STRAIGHT THREAD	48963	12 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48919	6 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS	48964	12 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48920	6 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	48965	12 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
48921	6 FLO-S	CONNECTOR,MALE PIPE TO ORFS	48966	12 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48922	6-6 FLO-S	CONNECTOR,MALE PIPE TO ORFS	48967	12 JLO-S	UNION TEE,ORFS
48923	6 P5ON-S	PLUG,STRAIGHT THREAD	48968	12 WLO-WLNL-S	UNION,BULKHEAD,ORFS
48925	6 WELO-S	UNION,90° BULKHEAD,ORFS	48969	12 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48926	6-4 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48970	12 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS
48927	6-4 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48928	6-4 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			
48929	6-8 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS			
48930	6-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48931	6-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48932	8 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS			
48933	8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48934	8 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS			
48935	8 R5OLO-S	RUN TEE,STRAIGHT THREAD			
48936	8 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS			
48937	8 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
48971	12 G5G5JG5-S	TEE,FEMALE STRAIGHT THREAD	49612	PKT02586	O-RING KIT (ORFS FITTINGS)
48972	12 XHL6-S	ADAPTER, 37° MALE TO SWIVEL ORFS	49613	PKT06276	PLUG AND CAP KIT-SERVICE,ORFS
48973	12-1/2 F5OG-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD	49728	10143-12-12	HOSE END, MALE PIPE
48974	12-10 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	49729	16-1 F5OG-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD
48975	12-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	49814	12-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48976	12-16 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	49829	DT-500-MOMF-5	VALVE,CHECK
48977	12-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	49831	881-12	HOSE,3/4 INCH ID
48978	12-16 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	49834	16 JLO-S	UNION TEE,ORFS
48980	12-16 FLO-S	CONNECTOR,MALE PIPE TO ORFS	49838	12-8 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48983	16 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	49840	8 JLO-S	UNION TEE,ORFS
48984	16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	49844	10-8 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48985	16 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	49854	8 P5ON-S	PLUG,STRAIGHT THREAD
48986	16 FLO-S	CONNECTOR,MALE PIPE TO ORFS	49855	1JC43-16-12	HOSE END,FEMALE SWIVEL,SEAL LOK
48988	16 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	49859	4 P5ON-S	PLUG,STRAIGHT THREAD
48989	12 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	49861	4 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS
48990	8 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	49867	12-3/4 F5OG-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD
48991	16-12 FLO-S	CONNECTOR,MALE PIPE TO ORFS	51152	6 R6X-S	RUN TEE,SWIVEL NUT,ORFS
48992	16-12 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	51153	6-4 TRTX-S	REDUCER,TUBE END TO SWIVEL,ORFS
48993	XV501-12	BALL VALVE	51154	4-4 GTX	CONNECTOR,FEMALE PIPE TO FLARE TUBE
48994	XV501-16	BALL VALVE	51264	881-12	HOSE,3/4 INCH ID
48995	XV510P-12	BALL VALVE	51265	8 JLO-S	UNION TEE,ORFS
48996	XV510P-16	BALL VALVE	51508	6 BTX-S	NUT,FLARE TUBE
48997	PD341	DIAGNOSTIC NIPPLE, STRAIGHT THREAD	51580	12-8 TRLO-BL-S	TUBE END REDUCER,ORFS
48998	PD 361	DIAGNOSTIC NIPPLE, STRAIGHT THREAD	51628	6 R6X-S	RUN TEE,SWIVEL NUT,ORFS
48999	DT-500-MOMS-5	VALVE,CHECK	51735	3/8 HHP	PLUG,PIPE THREAD
49201	10 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	51803	1J943-6-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK
49202	1JC43-12-10	HOSE END,FEMALE SWIVEL,SEAL LOK	53023	125HBL-5-4	FITTING,HOSE BARB TO MALE PIPE
49203	10-8 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	53497	PKT02585	O-RING KIT
49205	6 F5OHAO-S	UNION,STRAIGHT THREAD	53499	1JC71-16-16	HOSE END,FEMALE SWIVEL,SEAL LOK
49207	PD34BTL	DIAGNOSTIC NIPPLE,SEAL-LOK SWIVEL	53500	3-904	O-RING,STRAIGHT THREAD,-4
49209	8M18F870MX-S	CONNECTOR,METRIC,STRAIGHT THREAD TO FLARE TUBE	53501	3-906	O-RING,STRAIGHT THREAD,-6
49212	8 WGTX-WLN-S	CONNECTOR,BULKHEAD,FEMALE PIPE TO FLARE TUBE	53502	3-908	O-RING,STRAIGHT THREAD,-8
49213	30682-8-8	HOSE END,FEMALE SWIVEL,JIC	53503	3-910	O-RING,STRAIGHT THREAD,-10
49216	831-8	HOSE,1/2 INCH ID			
49217	33982-8-8	HOSE END,90° FEMALE SWIVEL,JIC			
49219	PS-B-35	SLEEVE,NYLON,2.19" ID			
49418	4-6 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			
49511	DT370-MOMS-5	VALVE,CHECK			
49512	1 DD-S	ELBOW,90°,FEMALE PIPE			
49513	1 FF-S	NIPPLE,PIPE			
49514	10 HP5ON-S	PLUG,STRAIGHT THREAD			
49515	12-16 CLO-S	ELBOW,90°,MALE PIPE TO ORFS			
49517	6 HP5ON-S	PLUG,STRAIGHT THREAD			
49519	16-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
49520	4 VTX-S	ELBOW,45°,MALE PIPE TO FLARE TUBE			
49530	16 C6LO-S	ELBOW,90°,SWIVEL NUT ORFS			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
53535	3-912	O-RING, STRAIGHT THREAD, -12	61083	24 F5OLO-S	CONNECTOR, STRAIGHT THREAD TO ORFS
53536	4-PNLO-S	PLUG, TUBE END, ORFS	61086	20 R5OLO-S	RUN TEE, STRAIGHT THREAD
53537	6 PNLO-S	PLUG, TUBE END, ORFS	61090	24-20 F5OLO-S	CONNECTOR, STRAIGHT THREAD TO ORFS
53538	8 PNLO-S	PLUG, TUBE END, ORFS	61091	1J943 24-24	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
53539	10 PNLO-S	PLUG, TUBE END, ORFS	61093	1J978-12-12	HOSE END, 90° FEMALE SWIVEL, JIC
53540	12 PNLO-S	PLUG, TUBE END, ORFS	61095	1JS43-20-16	HOSE END, FEMALE SWIVEL, SEAL LOK
53946	129HB-5-4	FITTING, 90° HOSE BARB TO MALE PIPE	61100	811-24	HOSE, 1 1/2 INCH ID
53951	8-1/4F5OG-S	ADAPTER, FEMALE PIPE TO STRAIGHT THREAD	61130	1JS43-24-24	HOSE END, FEMALE SWIVEL, SEAL LOK
53980	6 S6LO-S	BRANCH TEE, SWIVEL NUT TO ORFS	61131	1JS78 12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
54132	4 C6LO-S	ELBOW, 90°, SWIVEL NUT ORFS	61132	1J778-12-12	HOSE END, 45° FEMALE SWIVEL, JIC
54135	11343-16-16	HOSE END, MALE SWIVEL, PIPE	61152	139HB-6-4	ELBOW, 45°, BARB TO MALE PIPE
54283	8-10 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS	61251	BV-0750	BALL VALVE
54428	8M18C87OMLO-S	ELBOW, 90° METRIC, STRAIGHT THREAD TO ORFS	61259	4 CC5OLO-S	ELBOW, 90° LONG, STRAIGHT THREAD TO ORFS
54803	FS-F-16-10	SLEEVE, FIRE, .96" ID	61260	20-12 TRLO-BL	REDUCER, TUBE END TO SWIVEL, ORFS
54954	10143-2-4	HOSE END, MALE PIPE	61262	12 C6LO-S	ELBOW, 90°, SWIVEL NUT ORFS
55190	3/8 HP-S	PLUG, PIPE THREAD	61263	20 F5OHAO-S	UNION, STRAIGHT THREAD
55448	8 HLO-S	UNION, ORFS	61264	6-10 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS
55839	6 F65OX-S	CONNECTOR, STRAIGHT THREAD TO 37° SWIVEL	61265	6 WNLO-WLNL-S	UNION, BULKHEAD 45°, ORFS
55968	10 C5OX-S	ELBOW, 90°, STRAIGHT THREAD TO FLARE TUBE	61268	4 WNLO-WLNL-S	UNION, BULKHEAD 45°, ORFS
56003	6 CC5OLO-S	ELBOW, 90° LONG, STRAIGHT THREAD TO ORFS	61269	4 WLO-WLNL-S	UNION, BULKHEAD, ORFS
56166	BV-0837	BALL VALVE, 90°	61272	12 AOEL6	ELBOW, 90°, STRAIGHT THREAD TO ORFS SWIVEL
56188	10143-8-6	HOSE END, MALE PIPE	61316	482TC-16	HOSE, 1 INCH ID
56233	2-011	O-RING, ORFS, -4	61321	6 JLO-S	UNION TEE, ORFS
56234	2-012	O-RING, ORFS, -6	61327	782-12	HOSE, 3/4 INCH ID
56235	2-014	O-RING, ORFS, -8	61328	881-24	HOSE, 1 1/2 INCH ID
56236	2-016	O-RING, ORFS, -10	61336	11943-20-24	HOSE END, 90° FLANGE HEAD
56237	2-018	O-RING, ORFS, -12	61345	12 WJJLO-WLNL-S	RUN TEE, BULKHEAD, ORFS
56238	2-021	O-RING, ORFS, -16	61346	8 WNLO-WLNL-S 4	UNION, BULKHEAD 45°, ORFS
56352	6 WLNL-S	LOCKNUT, BULKHEAD	61569	33782-8-8	HOSE END, 45° FEMALE SWIVEL, JIC
56353	3J782-12-12	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	61610	12 FF5OLO-S	CONNECTOR, LONG, STRAIGHT THREAD TO ORFS
56354	3J982-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	61742	1/8 X 1.5 FFF	NIPPLE, PIPE
56604	10-8 F5OLO-S	CONNECTOR, STRAIGHT THREAD TO ORFS	63426	8 PNTX-S	PLUG, FLARE TUBE
56639	3JC82-10-10	HOSE END, FEMALE SWIVEL, SEAL LOK			
56640	3J982-10-10	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
56655	3JC82-8-10	HOSE END, FEMALE SWIVEL, SEAL LOK			
56676	10-8 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS			
56776	471TC-6	HOSE, 3/8 INCH ID			
56777	471TC-8	HOSE, 1/2 INCH ID			
56789	811-16	HOSE, 1 INCH ID			
57884	3/8 FF	NIPPLE, PIPE			
59335	6 FNL-S	CAP, TUBE END			
59342	4 FNL-S	CAP, TUBE END			
59371	8 HP5ON-S	PLUG, STRAIGHT THREAD			
60653	BV-0751	BALL VALVE			
60806	125HB-3-4	FITTING, HOSE BARB TO MALE PIPE			
61064	5-1/4 F5OG-S	ADAPTER, FEMALE PIPE TO STRAIGHT THREAD			
61079	4 WELO-WLNL-S	UNION, 90° BULKHEAD W/NUT, ORFS			
61080	6 WLO-WLNL-S	UNION, BULKHEAD, ORFS			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
64271	4 WLO-WLNL-S	UNION,BULKHEAD,ORFS	75631	801-6	HOSE,3/8 INCH ID
64272	6 WLO-WLNL-S	UNION,BULKHEAD,ORFS	75654	20 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
65776	8 F65OL-S	CONNECTOR,STRAIGHT THREAD TO ORFS SWIVEL	75655	1J943-20-20	HOSE END,90° FEMALE SWIVEL,SEAL LOK
65880	6001012	O-RING KIT	75656	881-20	HOSE,1-1/4 INCH ID
66154	6 WTX-WLNS	UNION,BULKHEAD,FLARE TUBE	75971	8 F5OHAO-S	UNION,STRAIGHT THREAD
66155	6 WETX-S	UNION,BULKHEAD 90°,FLARE TUBE	77307	1JB43-8-8	HOSE END,BULKHEAD,SEAL LOK
66156	6 WLNL-S	BULKHEAD LOCKNUT	77309	8 WLNL-S	BULKHEAD LOCKNUT
66389	6-8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	77379	8M18C87OMX-S	ELBOW,90° METRIC,STRAIGHT THREAD TO FLARE TUBE
66392	6 R5OX-S	RUN TEE,STRAIGHT THREAD	77703	3J982-8-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK
66396	811-12	HOSE,3/4 INCH ID	77711	801-10	HOSE,5/8 INCH ID
66829	H3174PP	CLAMP,TUBE	77758	12 WNLO-WLNL-S	UNION,BULKHEAD 45°,ORFS
67217	4 KLO-S	UNION,CROSS,ORFS	78091	6 C6X-S	ELBOW,90°,SWIVEL NUT TO FLARE TUBE
67339	10-6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	78684	30582-8-8B	HOSE END,PUSH LOK,MALE
67357	13943-8-6	HOSE END,90° FEMALE SWIVEL,JIC	78852	549-2	HOSE,1/8 INCH ID
67358	10 HP5ON-S	PLUG,STRAIGHT THREAD	78855	10657-4-2	HOSE END,FEMALE SWIVEL,JIC
67371	12 S6LO-S	BRANCH TEE,SWIVEL NUT TO ORFS	79138	PS-B-37	SLEEVE,NYLON,2.38" ID
67498	4 FNL-S	CAP, TUBE END	79476	1JS43-6-8	HOSE END,FEMALE SWIVEL,SEAL LOK
67906	DC-370-F0F0-5	VALVE,CHECK	79847	12-3/4 A0EG-S	ELBOW,90°,STRAIGHT THREAD TO FEMALE PIPE
69316	8 FLO-S	CONNECTOR,MALE PIPE TO ORFS	80044	8 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
69333	H3174PP	CLAMP,HYDRAULIC HOSE	80502	8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
69503	4 F65OX-S	CONNECTOR,STRAIGHT THREAD TO 37° SWIVEL	80503	8 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE
69775	8 FNL-S	CAP, TUBE END	81010	AS-B-27	SLEEVE,NYLON,1.63" ID
71038	1/4X1/4F3HG-S	ADAPTER,CONVERSION	83052	821-6	HOSE,3/8 INCH ID
71196	12-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	83053	821-8	HOSE,1/2 INCH ID
71383	1/4 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	83054	821-12	HOSE,3/4 INCH ID
72270	12FNL-S	CAP, TUBE END	83055	30682-6-6	HOSE END,FEMALE SWIVEL,JIC
73436	60C-4	SLEEVE,COMPRESSION	83056	30682-12-12	HOSE END,FEMALE SWIVEL,JIC
73437	61C-4	NUT,COMPRESSION	83057	33782-6-6	HOSE END,45° FEMALE SWIVEL,JIC
73438	33482-4-4B	HOSE END,PUSH LOK,MALE	83058	33982-6-6	HOSE END,90° FEMALE SWIVEL,JIC
73767	1CD-S	ELBOW,90°,MALE TO FEMALE PIPE	83060	33982-12-12	HOSE END,90° FEMALE SWIVEL,JIC
73768	20-16-F5OG5-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD	83063	13743-4-4	HOSE END,45° FEMALE SWIVEL,JIC
73769	16-20 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
74660	6-8 F42EDMLO-S	CONNECTOR,MALE BSPP TO ORFS			
74661	8-8 F42EDMLO-S	CONNECTOR,MALE BSPP TO ORFS			
75007	4 FLO-S	CONNECTOR,MALE PIPE TO ORFS			
75008	1/8 HP-S	PLUG,PIPE THREAD			
75014	1/2 HP-S	PLUG,PIPE THREAD			
75042	8 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS			
75043	3/4 FF-S	NIPPLE,PIPE			
75254	24 F5OHAO-S	UNION,STRAIGHT THREAD			
75255	12 F5OHAO-S	UNION,STRAIGHT THREAD			
75256	XV506P-24	BALL VALVE			
75574	4 WLNL-S	BULKHEAD LOCKNUT			
75612	8 WJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS			
75613	12-8 F5OG5-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD			
75614	8 CC5OLO-S	ELBOW,90° LONG,STRAIGHT THREAD TO ORFS			
75628	1JB43-4-4	HOSE END,BULKHEAD,SEAL LOK			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description
83064	13743-8-8	HOSE END,45° FEMALE SWIVEL,JIC
83065	13743-12-12	HOSE END,45° FEMALE SWIVEL,JIC
83066	13943-8-8	HOSE END,90° FEMALE SWIVEL,JIC
83067	14143-6-6	HOSE END,90° FEMALE SWIVEL,JIC
83068	14143-8-8	HOSE END,90° FEMALE SWIVEL,JIC
83069	14143-12-12	HOSE END,90° FEMALE SWIVEL,JIC
83070	772-8	HOSE,1/2 INCH ID
83071	10671-8-8	HOSE END,FEMALE SWIVEL,JIC
83072	10671-12-12	HOSE END,FEMALE SWIVEL,JIC
83073	13771-8-8	HOSE END,45° FEMALE SWIVEL,JIC
83074	13771-12-12	HOSE END,45° FEMALE SWIVEL,JIC
83075	13971-8-8	HOSE END,90° FEMALE SWIVEL,JIC
83076	13971-12-12	HOSE END,90° FEMALE SWIVEL,JIC
83077	14171-8-8	HOSE END,90° FEMALE SWIVEL,JIC
83078	14171-12-12	HOSE END,90° FEMALE SWIVEL,JIC
83080	13943-16-16	HOSE END,90° FEMALE SWIVEL,JIC
83103	10671-16-12	HOSE END,FEMALE SWIVEL,JIC
83104	10671-10-12	HOSE END,FEMALE SWIVEL,JIC
83112	1JC71-8-8	HOSE END,FEMALE SWIVEL,SEAL LOK
83113	1JS71-16-12	HOSE END,FEMALE SWIVEL,SEAL LOK
83114	1JS71-10-12	HOSE END,FEMALE SWIVEL,SEAL LOK
83115	1J971-8-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK
83116	1J171-8-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK
83117	1J771-8-8	HOSE END,45° FEMALE SWIVEL,SEAL LOK
83127	1J543-6-8	HOSE END,90° FEMALE SWIVEL,JIC
83128	1JC43-6-8	HOSE END,FEMALE SWIVEL,SEAL LOK
87033	12-6 TRLO-S	REDUCER,TUBE END TO SWIVEL,ORFS
87034	3J782-8-8	HOSE END,45° FEMALE SWIVEL,SEAL LOK
87172	12 HP50N-S	PLUG,STRAIGHT THREAD
87185	8 WNLO-WLNL-S	UNION,BULKHEAD 45°,ORFS
87246	4 C6X-S	ELBOW,90°,SWIVEL NUT TO FLARE TUBE
87679	6 LHP-S	FLANGE SEAL FITTING, MALE
87681	6PLS N0702	BONDED SEAL
88100	SR88100	ADAPTER,OIL DRAIN,GM 3.0L
88311	1JS43-20-20	HOSE END,FEMALE SWIVEL,SEAL LOK
88353	20 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
88474	10081-20	Crimp Shell, 1.25"
88475	1988-20-24	HOSE END,90° FLANGE HEAD
88476	JS88-24-24	HOSE END,FEMALE SWIVEL,SEAL LOK
88477	1JC88-20-20	HOSE END,FEMALE SWIVEL,SEAL LOK
88478	811-20	HOSE,11/4 INCH ID
88936	20-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
88937	20-16 FLO-S	CONNECTOR,MALE PIPE TO ORFS
88938	1JC88-16-16	HOSE END,FEMALE SWIVEL,SEAL LOK
88939	1J988-16-16	HOSE END,90° FEMALE SWIVEL,ORFS
88940	811-16	HOSE,1 INCH ID
88944	1J988-20-20	HOSE END,90° FEMALE SWIVEL,ORFS
89403	16 VLO-S	ELBOW,45°,MALE PIPE TO ORFS

Genie PN	Parker PN	Description
89449	6 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
89489	4 WJMLO-S	BRANCH TEE,BULKHEAD,ORFS
89551	1JB43-6-6	HOSE END,BULKHEAD,SEAL LOK
89552	1JB43-8-8	HOSE END,BULKHEAD,SEAL LOK
89593	20 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
94161	8-8 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
94358	351TC-12	HOSE,3/4 INCH ID
94418	20 FLO-S	CONNECTOR,MALE PIPE TO ORFS
96358	12 TX-S	SLEEVE,FLARE TUBE
96359	12 BTX-S	NUT,FLARE TUBE
96397	8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
96398	12-8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
96402	10343-6-6	HOSE END,MALE,JIC
96407	30382-6-6B	HOSE END,MALE,JIC

California Proposition 65

Warning

The exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Genie North America

Phone 425.881.1800
Toll Free USA and Canada
800.536.1800
Fax 425.883.3475

Genie Australia Pty Ltd.

Phone +61 7 3375 1660
Fax +61 7 3375 1002

Genie China

Phone +86 21 53852570
Fax +86 21 53852569

Genie Malaysia

Phone +65 98 480 775
Fax +65 67 533 544

Genie Japan

Phone +81 3 3453 6082
Fax +81 3 3453 6083

Genie Korea

Phone +82 25 587 267
Fax +82 25 583 910

Genie Brasil

Phone +55 11 41 665 755
Fax +55 11 41 665 754

Genie Holland

Phone +31 183 581 102
Fax +31 183 581 566

Genie Scandinavia

Phone +46 31 575100
Fax +46 31 579020

Genie France

Phone +33 (0)2 37 26 09 99
Fax +33 (0)2 37 26 09 98

Genie Iberica

Phone +34 93 579 5042
Fax +34 93 579 5059

Genie Germany

Phone +49 (0)4202 88520
Fax +49 (0)4202 8852-20

Genie U.K.

Phone +44 (0)1476 584333
Fax +44 (0)1476 584334

Genie Mexico City

Phone +52 55 5666 5242
Fax +52 55 5666 3241

Distributed By:

Parts Manual

GTH-4013 AU.2

from SN 19281

Part No.
645032

Rev A

