



Parts Manual

Serial Number Range

GTH-4010 AU.2

from SN 13967 to 16124

Part No. 645009

Rev B

May 2010

Technical Publications

Genie has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy. Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement.

All communications will be carefully considered for future printings of this and all other manuals.

Contact Us:



A TEREX BRAND

www.genieindustries.com


e-mail: awp.techpub@terex.com

The technical data contained in this document is indicative and not binding, insofar as TEREXLIFT S.r.l reserves the right to make modifications and improvements to its products at any time in order to enhance the quality thereof.

57.0407.8000 Rev 0 March 2006
First Edition, First Printing

Chassis serial number

(The chassis serial number is punched on the front right part of the chassis side member)

**Machine data plate**

(On machines destined for the Italian market, the machine data plate is installed in the driving cab, on the right, and is well-visible when the door is opened. On the machines destined for foreign markets, the data plate is applied on the front right side of the chassis)

TEREXLIFT s.r.l.	
ZONA INDUSTRIALE - 06019 UMBERTIDE (PG) - ITALY Tel. +39 075 941.811 Fax +39 075 941.53.82	
MODELLO - MODEL - MODELE - TYP - MODELO	
ANNO DI COSTRUZIONE - YEAR OF CONSTRUCTION - ANNEE DE CONSTRUCTION BAUJAHR - AÑO DE FABRICACIÓN	
MATRICOLA - SERIAL N. - N. DE SERIE - FZ-IDENT NR. - NO. DE SERIE	
PESO MAX ASSALE ANT. - MAX FRONT AXLE WEIGHT - POIDS MAX ESSIEU AVANT ZUL. ACHSLAST VO. N. ST VZO - PESO MAX EJE ANTERIOR	kg
PESO MAX ASSALE POST. - MAX REAR AXLE WEIGHT - POIDS MAX ESSIEU ARRIERE ZUL. ACHSLAST HI. N. ST VZO - PESO MAX EJE POSTERIOR	kg
PESO TOTALE - TOTAL WEIGHT - POIDS TOTAL - ZUL. GESAMTGEWICHT N. ST VZO PESO TOTAL	kg
MATRICOLA MOTORE TERMICO - ENGINE SERIAL N. - N. MOTEUR THERMIQUE FABRIK NR. DIESEL MOTOR - NO. DE SERIE MOTOR TERMICO	
POTENZA MOTORE TERMICO - ENGINE POWER - PUISSANCE MOTEUR MOTORLEISTUNG - POTENCIA MOTOR	kW
CARICO STATICO VERT. GANCIO DI TRAINO-MAX.VERTICAL LOAD ON THE COUPLING HOOK-EFFORT VERTICAL MAXIMAL SUR LE CROCHET D'ATTELAGE MAXIMALE STUTZLASTBEANSPRUCHUNG DES ZUGHAKENS IN VERTIKALER RICHTUNG- ESFUERZO VERTICAL SOBRE EL GANCHO DE TRACCION	kg
MASSA MAX. RIMORCHIABILE - MAX.DRAWBAR PULL AT THE COUPLING HOOK EFFORT THE TRACTION - MAXI AU CROCHET D'ATTELAGE-MAXIMALE ZUGBEANSPRUCHUNG AM ZUGHAKEN-MAXIMO ESFUERZO DE TRACCION EN EL GANCHO DE TRACCION	kg
OMOLOGAZIONE	
FABBRICATO IN ITALIA - MADE IN ITALY	CE

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genieindustries.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genieindustries.com.

How to Read Your Serial Number.....	3
Parts Stocking List.....	7
How to Order Parts.....	8
Service Parts Fax Order Form.....	9

Electronic Version

Click on any page number to view the figure.

100 Cab and Control Place Unit

101.1 604858 Cab - View 1.....	10
102.1 604859 Cab - View 2 (to serial number 15663).....	14
103.1 604859 Cab - View 2 (from serial number 15664).....	16
104.1 604860 Dashboard.....	18
105.1 604861 Cab Heater.....	20
106.1 604873 Overload Warning System.....	22
107.1 604875 Instruments And Lights Panel.....	24

200 Frame Unit

201.1 604857 Hydraulic System - Outriggers.....	26
202.1 604876 Frame.....	28
203.1 604877 Rear Frame Unit (to serial number 14873)....	30
204.1 604877 Rear Frame Unit (from serial number 14874).....	32
205.1 604900 Label - Name Plate.....	34
206.1 604901 Label - Name Plate.....	36

300 Transmission Unit

301.1 604863 Transmission And Wheels.....	38
302.1 604867 Hydraulic System - Gear Box.....	40
303.1 604868 Power Steering System.....	42
304.1 604872 Hydraulic System - Transmission.....	44
305.1 604878 Hydraulic System - Service Brake.....	46
306.1 604879 Hydraulic System - Parking Brake.....	48
307.1 604880 Front Axle - Differential Case.....	50
308.1 604881 Front Axle - Differential Gear.....	52
309.1 604882 Front Axle - Steering Axle.....	54
310.1 604883 Front Axle - Brake.....	56
311.1 604884 Front Axle - Reduction Gear.....	58
312.1 604885 Front Axle - Steering Cylinder.....	60
313.1 604886 Rear Axle - Differential Case.....	62
314.1 604887 Rear Axle - Differential Gear.....	64
315.1 604888 Rear Axle - Steering Axle.....	66
316.1 604889 Rear Axle - Brake.....	68
317.1 604890 Rear Axle - Steering Cylinder.....	70
318.1 604891 Front Axle - Support.....	72

400 Telescopic Boom Unit

401.1 604856 Forks.....	74
402.1 604892 Arm.....	76
403.1 604893 Hydraulic System - Tilting.....	78
404.1 604894 Hydraulic System - Boom Extension.....	80
405.1 604895 Hydraulic System - Auxiliary Circuit.....	82
406.1 604896 Hydraulic System - Fork Balancing.....	84
407.1 604897 Hydraulic System - Implement Locking.....	86
408.1 604898 Hydraulic System - Lifting (to serial number 15145).....	88
409.1 604898 Hydraulic System - Lifting (from serial number 15146).....	90
410.1 604899 Coupling Unit.....	92

500 Diesel Engine Unit

501.1 604864 Diesel Engine - Hydraulic Pump.....	94
502.1 604865 Diesel Engine - Engine Cooling System.....	96
503.1 604866 Diesel Engine - Exhaust System - Accelerator (to serial number 15378).....	98
504.1 604866 Diesel Engine - Exhaust System - Accelerator (from serial number 15379).....	100
505.1 604869 Hydraulic System - Oil Cooler.....	102
506.1 604871 Suction System Hydraulic Pumps.....	104

600 Electric Installation Unit

601.1 604862 Fuse Box.....	106
602.1 604870 Electric Installation.....	108
603.1 604874 Electric Installation.....	110

Indices

Part Number Index.....	112
Part Description Index.....	116

Cross References

Fittings Cross Reference.....	?
-------------------------------	---

This Page Intentionally Left Blank

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

The following parts are required to perform maintenance procedures as outlined in the GTH 4010 AU.2 Operator's and Service Manuals.

Description	Part No.
Diesel Fuel Filter.....	07.4501.0068
Engine Oil Filter.....	07.4501.0067
Hydraulic Oil Filter Cartridge	07.0700.0000
Oil Filter Immersed in the Tank.....	09.4604.0004
Engine Air Filter Primary Cartridge	640885
Engine Air Filter Secondary Cartridge	07.0700.0041

Used Varnishes

Description	Type
Terex Grey	RAL 7012
Terex White	RAL 1013
Terex Matte Black for Cylinders.....	RAL 9005
Genie Blue.....	
Genie Grey	
Genie Mat Black for Cylinders	RAL 9005

Manuals

Terexlift offers the following support documents for these models:

Title	Part No.
Genie GTH 4010 AU.2 Operator's Manual, 1 st edition (English)	57.0006.2200

Part list abbreviations

ZN	Zinc-plated
RNFT	Reinforced
FLNG	Flanged
PSNT	Heavy type
OC	Eye
PSRT	Through-coupling
CNTF	Hole centre

How To Order Parts

Please be prepared with the following information when ordering replacement parts for your Genie product:

- ☒ Machine model number
- ☒ Machine serial number
- ☒ Genie part number
- ☒ Part description and quantity
- ☒ Purchase order number
- ☒ "Ship to" address
- ☒ Desired method of shipment
- ☒ Name and telephone number of the authorized
Genie Distributor in your area

Use the Service Parts Fax Order Form on the next page and fax your order to our Parts Department.

If you don't know the name of your authorized distributor, or if your area is not currently serviced by an authorized distributor, please call Genie Industries.

Machine Information

Model

Serial Number

Date of Purchase

Authorized Genie Distributor

Phone Number

Genie North America

Telephone (425) 556-6551

Toll Free (877) 367-5606 in U.S.A. and Canada

Fax (425) 556-8659

Genie UK

Parts Telephone (44) (0) 1476 584352

Parts Fax (44) (0) 1476 584340

Genie Australia

Parts Telephone (617) 03375 1660

Parts Fax (617) 03375 1002

Genie France

Parts Telephone (33) (0) 237 26 09 99

Parts Fax (33) (0) 237 31 50 10

Genie Germany

Parts Telephone (49) (0) 4202 885223

Parts Fax (49) (0) 4202 885225

Genie Scandinavia

Parts Telephone (46) (31) 3409612

Parts Fax (46) (31) 3409613

Genie Iberica

Parts Telephone (34) (93) 5795042

Genie Brazil

Parts Telephone (55) (114) 1665755

Parts Fax (55) (114) 1665754

Genie Japan

Parts Telephone (81) (33) 4536082


Parts Fax (81) (33) 4536083

Genie China

Parts Telephone (86) (215) 3852570

Parts Fax (86) (215) 3852569

101.1 604858 Cab - View 1




Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0066	Filter.....	1	40	07.0740.0097	Arm.....	2
2	07.0740.0067	Grate.....	1	41	07.0740.0098	Tank.....	1
3	07.0740.0068	Ball-Grip.....	2	42	07.0740.0099	Glass.....	1
4	07.0740.0069	Seal.....	1	43	07.0740.0100	Stop.....	1
5	07.0740.0070	Sheet.....	1	44	07.0740.0101	Guard.....	1
6	07.0740.0026	Washer.....	12	45	07.0740.0102	Washer.....	1
7	07.0740.0071	Screw.....	18	46	07.0740.0103	Nut.....	1
8	07.0740.0072	Wiper Motor.....	1	47	07.0740.0104	Door Stop.....	1
9	07.0740.0073	Glass.....	1	48	07.0740.0105	Screw.....	3
10	07.0740.0074	Glass.....	1	49	07.0740.0106	Seal.....	1
11	07.0740.0075	Glass.....	1	50	07.0740.0028	Hex Cap.....	6
11	07.0740.0246	Glass.....	1	51	07.0740.0006	Washer.....	10
12	07.0740.0052	Seal.....	1,5	52	07.0740.0005	Stop Nut.....	3
13	07.0740.0076	Handle.....	2	53	07.0740.0107	Frame.....	1
14	07.0740.0217	Split Pin.....	2	54	07.0740.0178	Support.....	1
15	07.0740.0078	Hinge.....	2	55	07.0740.0114	Lock.....	1
16	07.0740.0079	Screw.....	7	56	07.0740.0115	Bracket.....	1
17	07.0740.0046	Stop Nut.....	7	57	07.0740.0116	Screw.....	4
18	07.0740.0014	Hex Cap.....	7	58	07.0740.0117	Washer.....	4
19	07.0740.0080	Rubber.....	2	59	07.0740.0247	Kit.....	1
20	07.0740.0081	Washer.....	3	60	07.0740.0202	Driving Mirror.....	1
21	07.0740.0082	Loadspeaker Frame.....	2	61	07.0740.0157	Wiper Blade.....	1
22	07.0740.0083	Screw.....	8	62	07.0740.0158	Wiper Motor.....	1
23	07.0740.0084	Roof Lamp.....	1	63	07.0740.0210	Rubber.....	1
24	07.0740.0064	Screw.....	2	64	07.0740.0211	Spacer.....	1
25	07.0740.0085	Glass.....	1	65	07.0740.0212	Screw.....	2
26	07.0740.0009	Rubber.....	3	66	07.0740.0213	Bushing.....	2
27	07.0740.0086	Rubber.....	1	67	07.0740.0214	Rubber.....	2
28	07.0740.0032	Washer.....	1	68	07.0740.0035	Rubber.....	2
29	07.0740.0087	Glass.....	1	69	07.0740.0215	Spacer.....	2
30	07.0740.0088	Wiper Arm.....	1	70	07.0740.0156	Wiper Arm.....	1
31	07.0740.0089	Wiper Blade.....	1	71	07.0740.0209	Kit.....	1
32	07.0740.0090	Through Coupling.....	1	72	07.0740.0156	Wiper Arm.....	1
33	07.0740.0091	Seal.....	1,5	73	07.0740.0163	Screw.....	2
34	07.0740.0092	Lock.....	1	74	07.0740.0117	Bushing.....	2
35	07.0740.0012	Washer.....	16	75	07.0740.0248	Wiper Blade.....	1
36	07.0740.0093	Storage Pocket.....	1	76	07.0740.0016	Rubber.....	2
37	07.0740.0094	Screw.....	4	77	51.0901.6900	Grate.....	1
38	07.0740.0095	Screw.....	4	78	01.0001.0094	Screw.....	2
39	07.0740.0096	Stop Nut.....	2	79	01.0001.0071	Spring Washer.....	2

101.1 604858 Cab - View 1
(continued)

Item	Part No.	Description	Qty.
80	09.0803.0359	Magnet.....	1
81	09.0803.0358	Rope.....	1
82	01.0031.0056	Washer.....	2
83	01.0001.0505	Screw.....	2
84	01.0001.0072	Spring Washer.....	2
85	01.0031.0057	Washer.....	2

This Page Intentionally Left Blank


102.1 604859 Cab - View 2 (to serial number 15663)



102.1 604859 Cab - View 2 (to serial number 15663)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0000	Dowel.....	3	41	07.0740.0063	Washer.....	2
2	07.0740.0001	Split Pin.....	3	42	07.0740.0064	Screw.....	2
3	07.0740.0002	Grease Nipple.....	5	43	07.0740.0065	Clip.....	1
4	07.0740.0003	Seat.....	1	44	07.0740.0060	Screw.....	1
5	07.0740.0004	Screw.....	1	45	07.0740.0016	Washer.....	1
6	07.0740.0005	Stop Nut.....	1	46	07.0740.0062	Washer.....	1
7	07.0740.0006	Washer.....	1	47	07.0740.0027	Plug.....	4
8	07.0740.0007	Screw.....	4	48	07.0740.0028	Hex Cap.....	1
9	07.0740.0008	Support.....	1	49	07.0740.0179	Lower Door.....	1
10	07.0740.0009	Rubber.....	2	50	07.0740.0180	Upper Door.....	1
11	07.0740.0010	Support.....	1	51	07.0740.0029	Handle.....	1
12	07.0740.0011	Screw.....	2	52	07.0740.0030	Pin.....	1
13	07.0740.0001	Washer.....	9	53	07.0740.0031	Hex Cap.....	2
14	07.0740.0013	Stop Nut.....	2	54	07.0740.0014	Hex Cap.....	6
15	07.0740.0014	Hex Cap.....	2	55	07.0740.0047	Label.....	1
16	07.0740.0015	Rubber.....	1	56	07.0740.0032	Washer.....	1
17	07.0740.0016	Washer.....	1	58	07.0740.0233	Washer.....	2
18	07.0740.0017	Nut.....	1	60	07.0740.0222	Washer.....	3
19	07.0740.0018	Non-Skid Coating.....	0,7	61	07.0740.0223	Washer.....	6
20	07.0740.0235	Rubber Platform.....	1	62	07.0740.0039	Handle.....	1
21	07.0740.0020	Coating.....	1	63	07.0740.0224	Hinge.....	2
22	07.0740.0021	Coating.....	1	64	07.0740.0041	Glass.....	1
23	07.0740.0022	Adhesive Profile.....	2	65	07.0740.0225	Screw.....	2
24	07.0740.0054	Stop Belt.....	1	66	07.0740.0226	Screw.....	1
25	07.0740.0024	Support.....	1	67	07.0740.0227	Screw.....	2
26	07.0740.0025	Screw.....	2	68	07.0740.0045	Stop Nut.....	2
27	07.0740.0026	Washer.....	2	69	07.0740.0046	Stop Nut.....	3
28	07.0740.0048	Seal.....	1	70	07.0740.0228	Rubber.....	6
29	07.0740.0049	Seal.....	1	71	07.0703.0125	Key.....	1
30	07.0740.0050	Handle.....	1	72	07.0740.0229	Reinforcement.....	1
31	07.0740.0051	Lever-Fitted Lock.....	1	73	07.0740.0230	Seal.....	1
32	07.0740.0052	Seal.....	3,5	74	07.0740.0232	Bushing.....	2
33	07.0740.0053	Lock.....	1	75	07.0740.0231	Plug.....	1
34	07.0740.0035	Bushing.....	1				
35	07.0740.0055	Bushing.....	1				
36	07.0740.0056	Frame.....	1				
37	07.0740.0057	Glass.....	1				
38	07.0740.0058	Seal.....	1				
39	07.0740.0059	Screw.....	2				
40	07.0740.0061	Nut.....	2				


103.1 604859 Cab - View 2 (from serial number 15664)



103.1 604859 Cab - View 2 (from serial number 15664)


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0740.0000	Pin.....	3	41	07.0740.0063	Washer.....	2
2	07.0740.0001	Split Pin.....	3	42	07.0740.0128	Screw.....	4
3	07.0740.0002	Grease Nipple.....	3	43	07.0740.0009	Rubber.....	1
4	07.0740.0003	Seat.....	1	44	07.0740.0060	Screw.....	1
5	07.0740.0004	Screw.....	2	45	07.0740.0231	Plug.....	1
6	07.0740.0005	Stop Nut.....	2	46	07.0740.0062	Washer.....	1
7	07.0740.0006	Washer.....	2	47	07.0740.0027	Plug.....	4
8	07.0740.0007	Screw.....	4	48	07.0740.0028	Hex Cap.....	2
9	07.0740.0275	Screw.....	4	49	07.0740.0250	Lower Door.....	1
10	07.0740.0274	Coating.....	1	50	07.0740.0277	Upper Door Complete.....	1
11	07.0740.0010	Support.....	1	51	07.0740.0029	Handle.....	1
12	07.0740.0011	Screw.....	2	52	07.0740.0030	Pin.....	1
13	07.0740.0012	Washer.....	4	53	07.0740.0228	Rubber.....	6
14	07.0740.0013	Stop Nut.....	2	54	07.0740.0227	Screw.....	2
15	07.0740.0014	Hex Cap.....	8	55	07.0740.0047	Label.....	1
16	07.0740.0015	Rubber.....	1	56	07.0740.0041	Glass.....	1
17	07.0740.0016	Washer.....	2	57	07.0703.0125	Key.....	1
18	07.0740.0017	Nut.....	1	58	07.0740.0230	Seal.....	1
19	07.0740.0018	Non-Skid Coating.....	0,7	59	07.0740.0229	Reinforcement.....	1
20	07.0740.0235	Rubber Platform.....	1	61	07.0740.0223	Washer.....	6
21	07.0740.0020	Coating.....	1	62	07.0740.0272	Handle.....	1
22	07.0740.0021	Coating.....	1	63	07.0740.0276	Hinge.....	2
23	07.0740.0022	Adhesive Profile.....	1				
24	07.0740.0054	Stop Belt.....	1				
25	07.0740.0024	Support.....	1				
26	07.0740.0025	Screw.....	2				
27	07.0740.0026	Washer.....	6				
28	07.0740.0048	Seal.....	1				
29	07.0740.0049	Seal.....	1				
30	07.0740.0050	Handle.....	1				
31	07.0740.0051	Lever-Fitted Lock.....	1				
32	07.0740.0052	Seal.....	3,5				
33	07.0740.0273	Panel.....	1				
34	07.0740.0035	Bushing.....	1				
35	07.0740.0055	Bushing.....	1				
36	07.0740.0249	Frame.....	1				
37	07.0740.0236	Sun Visor.....	1				
38	07.0740.0058	Seal.....	1				
39	07.0740.0059	Screw.....	2				
40	07.0740.0061	Nut.....	2				

104.1 604860 Dashboard




Item	Part No.	Description	Qty.
1	07.0740.0139	Dashboard.....	1
2	07.0740.0220	Dashboard.....	1
3	07.0740.0141	Lock.....	1
4	07.0740.0142	Cover.....	1
5	07.0740.0116	Screw.....	15
6	07.0740.0117	Washer.....	15
7	07.0740.0037	Washer.....	3
8	07.0740.0143	Cover.....	1
9	07.0740.0144	Screw.....	3
10	07.0740.0145	Washer.....	3
11	09.4610.0001	Bubble Level.....	1
12	07.0740.0154	Spring.....	3
13	07.0703.0490	Glass.....	1
14	07.0703.0494	Switch.....	2
15	07.0703.0418	Speed Lever.....	1
16	07.0703.0417	Turn Signals Lever.....	1
17	07.0703.0420	Security Switch.....	1
18	07.0740.0062	Rivet.....	3
19	07.0703.0441	Emergency Button.....	1
20	07.0703.0423	Plug.....	1
21	07.0740.0152	Ball-Grip.....	1
22	07.0703.0489	Plug.....	6
23	07.0703.0532	Contact.....	1
24	07.0703.0531	Contact.....	1
25	07.0740.0201	Lock.....	1
26	07.0703.0017	Glass.....	1

105.1 604861 Cab Heater



Item	Part No.	Description	Qty.
1	07.0740.0119	Heater.....	1
2	07.0740.0120	Paper Piping.....	0,75
3	07.0740.0120	Paper Piping.....	0,65
4	07.0740.0120	Paper Piping.....	1,55
5	07.0740.0120	Paper Piping.....	0,33
6	07.0740.0120	Paper Piping.....	0,32
7	07.0740.0120	Paper Piping.....	0,4
8	07.0740.0121	Pipe Fitting.....	1
9	07.0740.0122	Rubber Hose.....	6
10	07.0740.0122	Rubber Hose.....	0,8
11	07.0740.0122	Rubber Hose.....	5
12	07.0740.0123	Clamp.....	4
13	07.0740.0124	Screw.....	4
14	07.0740.0125	Air Inlet.....	5
15	07.0740.0126	Reduction.....	5
16	07.0740.0127	Clamp.....	8
17	07.0740.0128	Screw.....	2
18	07.0740.0129	Air Inlet.....	1
19	07.0740.0006	Washer.....	1
20	07.0740.0005	Stop Nut.....	1
21	07.0740.0028	Hex Cap.....	1
22	07.0740.0120	Ball-Grip.....	1
24	07.0740.0118	Screw.....	2
25	07.0740.0016	Washer.....	2
26	07.0740.0132	Support.....	1
27	07.0740.0012	Washer.....	2
28	07.0740.0071	Screw.....	2
29	07.0740.0133	Rubber.....	2
30	07.0740.0218	Tap.....	1
31	07.0740.0219	Name Plate.....	1


106.1 604873 Overload Warning System



106.1 604873 Overload Warning System

Item	Part No.	Description	Qty.
1	56.0016.0022	Display.....	1
2	09.0802.0018	Load Cell.....	1
3	09.0803.0225	Screw.....	2
4	09.0803.0226	Washer.....	2
5	55.0602.0129	Wiring Harness.....	1
6	01.4032.0002	Spring Washer.....	2
7	01.0001.0156	Screw.....	2


107.1 604875 Instruments And Lights Panel



107.1 604875 Instruments And Lights Panel

Item	Part No.	Description	Qty.
1	07.0703.0424	Board With Led'S.....	1
2	07.0703.0425	Indicator.....	1
3	07.0703.0613	Indicator.....	1
4	07.0703.0427	Indicator.....	1
5	07.0703.0029	Starting Switch.....	1
6	07.0703.0428	Hour Meter.....	1
7	638226	SWITCH,SELECTOR,3 POSITION.....	1
8	07.0703.0429	Selector.....	1
9	07.0703.0430	Switch.....	1
10	07.0703.0007	Glass.....	1
11	07.0703.0431	Switch.....	1
12	07.0703.0032	Glass.....	1
13	07.0703.0423	Plug.....	3
14	07.0703.0432	Glass.....	1
15	07.0703.0433	Switch.....	1
16	07.0703.0434	Glass.....	1
17	07.0703.0435	Switch.....	1
18	07.0703.0010	Glass.....	1
19	07.0703.0011	Control Panel.....	1
20	07.0703.0125	Key.....	1
21	07.0703.0572	Switch.....	1


201.1 604857 Hydraulic System - Outriggers



201.1 604857 Hydraulic System - Outriggers


Item	Part No.	Description	Qty.
1	51.0500.0900	Stabilizer.....	2
2	51.0500.0100	Road Pad.....	2
3	54.0000.0146	Pin.....	4
4	54.0000.0008	Pin.....	2
5	54.0000.0145	Pin.....	2
6	53.0800.0400	Cylinder.....	1
7	09.0801.0000	Bushing.....	4
8	53.0800.0500	Cylinder.....	1
9	640537	Joint Kit.....	2
10	04.0607.0163	Pipe Fitting.....	8
11	04.4239.0007	Valve.....	2
12	09.0801.0021	Bushing.....	4
13	04.0605.0319	Flexible Hose.....	4
14	01.0001.0308	Screw.....	2
15	56.0012.0009	Proximity Switch.....	2
16	01.0023.0055	Nut.....	2

202.1 604876 Frame



Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	51.0108.0000	Frame.....	1	41	01.4006.0016	Screw.....	3
2	51.0800.0400	Plate.....	2	42	09.0803.0012	Spring Washer.....	12
3	01.4001.0000	Screw.....	8	43	51.0800.1000	Support.....	1
4	01.0031.0062	Plain Washer.....	8	44	01.0023.0053	Nut, M6.....	12
5	01.4023.0000	Stop Nut.....	8	45	01.4032.0003	Spring Washer.....	12
6	51.0806.7200	Support.....	2	46	09.4610.0011	Cylinder.....	1
7	09.0803.0177	Mud-Guard.....	2	47	51.0810.2800	Support.....	1
8	07.0726.0065	Hatch.....	1	48	51.0807.4200	Support.....	1
9	51.0800.1100	Support.....	1	49	01.0001.0306	Screw.....	6
10	52.1100.6200	Guard.....	1	50	01.0031.0301	Plain Washer.....	12
11	51.0902.5800	Guard.....	1	51	09.0803.0011	Spring Washer.....	8
12	09.0803.0005	Handle.....	1	52	01.4006.0004	Screw.....	8
13	51.0901.5500	Guard.....	1	53	01.0023.0055	Stop Nut.....	10
14	09.0803.0245	Seal.....	2,1	54	01.4032.0007	Plain Washer.....	4
15	09.4610.0002	Driving Mirror.....	1	55	01.0001.1493	Screw.....	8
16	51.0901.8100	Guard.....	1	56	01.4032.0006	Plain Washer.....	16
17	51.0901.8700	Guard.....	1	57	01.0001.0657	Screw.....	4
18	09.4670.0006	Insulator.....	4	58	01.0031.0061	Plain Washer.....	4
19	01.0001.0357	Screw.....	8	59	01.4001.0001	Screw.....	4
20	01.4031.0001	Plain Washer.....	4	60	01.0023.0060	Stop Nut.....	4
21	54.0100.0020	Protection.....	4				
22	01.0031.0058	Plain Washer.....	8				
23	01.0023.0057	Stop Nut.....	16				
24	09.4670.0004	Insulator.....	4				
25	01.0001.0356	Screw.....	16				
26	01.0023.0055	Stop Nut.....	16				
27	01.4001.0012	Screw.....	4				
28	01.4032.0004	Plain Washer.....	32				
29	07.0726.0083	Hatch.....	1				
30	09.0803.0023	Lock.....	1				
31	09.0803.0024	Hook (Latch).....	1				
32	09.0803.0000	Hinge.....	2				
33	01.0001.0256	Screw.....	22				
34	01.0031.0299	Plain Washer.....	10				
35	01.0023.0054	Stop Nut.....	21				
36	51.0805.1600	Support.....	2				
37	09.0803.0178	Mud-Guard.....	2				
38	01.0006.0033	Screw.....	8				
39	01.0031.0055	Washer.....	43				
40	01.0001.0156	Screw.....	8				


203.1 604877 Rear Frame Unit (to serial number 14873)



203.1 604877 Rear Frame Unit (to serial number 14873)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	09.0805.0000	Rubber Hose.....	3	42	01.0031.0055	Washer.....	10
2	04.0227.0051	Clamp.....	4	43	01.0001.0353	Screw.....	4
3	09.0805.0000	Rubber Hose.....	0,6	44	01.0031.0301	Spring Washer.....	4
4	51.0807.5500	Bracket.....	1	45	01.0001.0256	Screw.....	2
5	01.4001.0018	Screw.....	2	46	53.3301.0002	Seal.....	1
6	01.4032.0006	Spring Washer.....	6	47	01.0001.0905	Screw.....	2
7	51.0800.3800	Tie Rod.....	1	48	51.1000.4100	Counterweight.....	1
8	01.0001.0651	Screw.....	2	49	01.0001.0503	Screw.....	1
9	01.0031.0059	Washer.....	2	50	51.1000.3000	Counterweight.....	2
10	54.0000.0027	Pin.....	1	51	01.0001.1119	Screw.....	3
11	09.0803.0026	Spring Split Pin.....	1				
12	51.0901.9600	Guard.....	1				
13	09.0803.0278	Hinge.....	2				
14	09.0803.0002	Handle.....	1				
15	01.0003.0203	Screw.....	2				
16	01.0031.0299	Plain Washer.....	2				
17	01.0023.0054	Nut.....	2				
18	51.0806.8200	Rod.....	1				
19	51.0600.2200	Diesel Oil Tank.....	1				
20	01.0001.0254	Screw.....	1				
21	09.0803.0013	Clip.....	1				
22	01.0001.0204	Screw.....	1				
24	01.0003.0110	Screw.....	4				
25	01.0031.0054	Plain Washer.....	8				
26	09.4670.0000	Retainer.....	1				
27	01.0001.0154	Screw.....	1				
28	01.0031.0054	Washer.....	1				
29	09.0805.0000	Rubber Hose.....	3				
30	09.4661.0010	Plug.....	1				
31	56.0013.0001	Fuel Gauge.....	1				
32	01.4001.0006	Screw.....	6				
33	01.0023.0053	Nut, M6.....	4				
34	51.1000.0500	Left Counterweight.....	1				
35	51.1000.0600	Right Counterweight.....	1				
36	01.0023.0055	Stop Nut.....	1				
37	01.0001.0556	Screw.....	2				
38	01.0023.0053	Nut, M6.....	2				
39	01.0031.0058	Plain Washer.....	6				
40	51.0807.5500	Support.....	1				
41	54.0101.0002	Spacer.....	1				


204.1 604877 Rear Frame Unit (from serial number 14874)



204.1 604877 Rear Frame Unit (from serial number 14874)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	09.0805.0000	Rubber Hose.....	3	41	01.0001.0007	Screw.....	2
2	04.0227.0051	Clamp.....	4	42	01.0023.0054	Stop Nut.....	2
3	09.0805.0000	Rubber Hose.....	0,6	43	01.0001.0086	Screw.....	2
4	01.0032.0054	Spring Washer.....	2	44	09.4661.0021	Airinlet.....	1
5	01.4001.0018	Screw.....	2	45	09.4661.0022	Chain.....	1
6	01.4032.0006	Spring Washer.....	6	46	06.0442.0103	Washer.....	1
7	51.0800.3800	Tie Rod.....	1	47	04.0220.0055	Plug.....	1
8	01.0001.0651	Screw.....	2	48	01.0001.0905	Screw.....	2
9	01.0031.0059	Washer.....	2	49	51.1000.4100	Counterweight.....	1
10	54.0000.0027	Pin.....	1	50	01.0001.0503	Screw.....	1
11	09.0803.0026	Spring Split Pin.....	1	51	51.1000.3000	Counterweight.....	2
12	51.0901.9600	Guard.....	1	52	01.0001.1119	Screw.....	3
13	09.0803.0278	Hinge.....	2				
14	09.0803.0002	Handle.....	1				
15	01.0003.0203	Screw.....	2				
16	01.0031.0299	Plain Washer.....	2				
17	01.0023.0054	Nut.....	2				
18	51.0806.8200	Rod.....	1				
19	51.0600.4300	Diesel Oil Tank.....	1				
20	01.0001.0254	Screw.....	1				
21	09.0803.0013	Clip.....	1				
22	01.0001.0204	Screw.....	1				
23	04.4227.0006	Clamp.....	1				
24	01.0003.0110	Screw.....	4				
25	01.0031.0054	Plain Washer.....	8				
26	09.4670.0000	Retainer.....	1				
27	01.0001.0154	Screw.....	1				
28	01.0031.0054	Washer.....	1				
29	09.0805.0000	Rubber Hose.....	3				
30	09.4661.0020	Plug.....	1				
31	56.0013.0001	Fuel Gauge.....	1				
32	01.4001.0006	Screw.....	6				
33	01.0023.0053	Nut, M6.....	4				
34	51.1000.0500	Left Counterweight.....	1				
35	51.1000.0600	Right Counterweight.....	1				
36	01.0023.0055	Stop Nut.....	1				
37	01.0001.0556	Screw.....	2				
38	01.0023.0053	Nut, M6.....	2				
39	01.0031.0058	Plain Washer.....	6				
40	01.0031.0295	Plain Washer.....	6				



205.1 604900 Label - Name Plate



205.1 604900 Label - Name Plate

Item	Part No.	Description	Qty.
1	09.4618.0242	Label.....	1
2	09.4618.0289	Label.....	2
3	09.4618.0243	Label.....	1
4	09.4612.0212	Label.....	2
5	09.4618.0227	Label.....	1
6	09.4618.0540	Label.....	1
7	09.4618.0657	Label.....	1
8	09.4618.0010	Label.....	1
9	09.4618.0261	Label.....	4
10	09.4618.0022	Label.....	1
11	09.4618.0034	Label.....	1
12	09.4616.0040	Label.....	1
13	09.4618.0230	Label.....	-
14	09.4618.0241	Label.....	1
15	09.4618.0288	Label.....	2
16	09.4618.0361	Label.....	2
17	09.4618.0563	Label.....	1
18	09.4618.0271	Label.....	1


206.1 604901 Label - Name Plate



206.1 604901 Label - Name Plate

Item	Part No.	Description	Qty.
1	09.4616.0230	Label.....	1
2	09.4618.0068	Name Plate.....	1
3	09.4618.0053	Name Plate.....	1
4	09.4618.0652	Label.....	1
5	09.4618.0030	Label.....	1
6	09.4618.0026	Label.....	1


301.1 604863 Transmission And Wheels



301.1 604863 Transmission And Wheels

Item	Part No.	Description	Qty.
1	09.4632.0016	Rear Axle.....	1
2	09.4632.0058	Front Axle.....	1
3	09.4635.0024	Cardan Shaft.....	1
4	07.0738.0000	Star Wheel.....	2
5	09.4635.0014	Cardan Joint Assembly Kit.....	4
6	55.0403.0047	Wheel.....	4
7	09.4629.0019	Rim.....	4
8	09.4627.0017	Tyre.....	4
9	09.4635.0039	Cardan Shaft.....	1
10	01.4001.0011	Screw.....	6
11	01.0031.0057	Plain Washer.....	6
12	01.0023.0056	Stop Nut.....	6
13	56.0013.0015	Proximity Switch.....	1


302.1 604867 Hydraulic System - Gear Box



302.1 604867 Hydraulic System - Gear Box

Item	Part No.	Description	Qty.
1	04.0607.0114	Pipe Fitting.....	4
2	04.0605.0177	Flexible Hose from SN 15377.....	2
3	04.4240.0046	Solenoid Valve to SN 15378.....	1
3	04.4240.0053	Solenoid Valve.....	1
4	07.0728.0007	Solenoid.....	2
5	07.0728.0006	Joint Kit.....	1
6	01.0001.0257	Screw to SN 15378.....	2
6	01.0003.0210	Screw from SN 15377.....	2
7	01.0031.0055	Spring Washer.....	2
8		604872 pos. 59	
9	04.0607.0153	Pipe Fitting.....	2
10	04.0607.0117	Pipe Fitting.....	1
11	04.0605.0272	Flexible Hose.....	1
12	04.0600.0013	Pipe Fitting.....	1
13	06.0442.0105	Washer.....	1


303.1 604868 Power Steering System



303.1 604868 Power Steering System

Item	Part No.	Description	Qty.
1	07.0740.0135	Steering Wheel.....	1
2	07.0740.0136	Steering Column.....	1
3	01.0001.0256	Screw.....	4
4	01.0032.0054	Washer.....	4
5	01.0001.0355	Screw.....	4
6	01.0032.0055	Washer.....	4
7	09.4636.0014	Power Steering.....	1
8	07.0728.0007	Solenoid.....	2
9	04.0607.0110	Pipe Fitting.....	2
10	04.0605.0310	Flexible Hose.....	1
11	04.0607.0117	Pipe Fitting.....	4
12	992989	SEAL KIT.....	1
13	01.0003.0210	Screw.....	2
14	04.4240.0044	Solenoid Valve.....	1
15	04.0607.0137	Pipe Fitting.....	4
16	01.4032.0003	Spring Washer.....	2
17	04.0605.0311	Flexible Hose.....	1
18	04.0605.0323	Flexible Hose.....	1
19	04.0605.0254	Flexible Hose.....	1
20	04.0605.0255	Flexible Hose.....	1
21	07.0728.0006	Joint Kit.....	1


304.1 604872 Hydraulic System - Transmission



304.1 604872 Hydraulic System - Transmission

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	04.4224.0000	Tap.....	1	41	01.0003.0157	Screw.....	2
2	06.0442.0111	Washer.....	1	42	04.0607.0103	Pipe Fitting.....	4
3	04.0600.0057	Pipe Fitting.....	1	43	04.4235.0023	Hydraulic Motor.....	1
4	04.0600.0042	Pipe Fitting.....	1	44	01.0031.0059	Plain Washer.....	4
5	06.0442.0109	Washer.....	2	45	04.0607.0129	Pipe Fitting.....	1
6	07.0701.0007	Solenoid.....	2	46	07.0701.0196	Solenoid Valve.....	1
7	07.0700.0000	Cartridge.....	1	47	04.0607.0104	Pipe Fitting.....	1
8	07.0700.0001	Indicator.....	1	48	04.0607.0114	Pipe Fitting.....	3
9	04.0600.0044	Pipe Fitting.....	1	49	01.4032.0007	Spring Washer.....	1
10	04.0602.0490	Flexible Hose.....	1	50	04.0605.0315	Flexible Hose.....	1
11	04.0600.0045	Pipe Fitting.....	1	51	04.0600.0068	Pipe Fitting.....	1
12	04.0600.0053	Sleeve.....	1	52	06.0442.0055	Plain Washer.....	1
13	04.0607.0127	Pipe Fitting.....	1	53	04.4210.0003	Pressure Tube.....	1
14	04.0605.0195	Flexible Hose.....	1	54	51.0806.3000	Support.....	1
15	04.0607.0143	Pipe Fitting.....	1	55	01.0031.0299	Plain Washer.....	4
16	04.0600.0159	Pipe Fitting.....	2	56	01.4031.0004	Plain Washer.....	4
17	04.0600.0021	Pipe Fitting.....	1	57	01.0001.0256	Screw.....	2
18	06.0401.0214	Seal.....	2	58	01.4032.0003	Spring Washer.....	2
19	04.4223.0004	Flange.....	4	59	04.0605.0252	Flexible Hose.....	1
20	01.4032.0004	Washer.....	8	60	04.0607.0120	Pipe Fitting.....	1
21	01.0003.0257	Screw.....	8	61	04.0607.0119	Pipe Fitting.....	1
22	04.4229.0035	Flexible Hose.....	1				
23	06.0401.0219	Seal.....	2				
24	04.4223.0003	Half Flange.....	4				
25	04.4229.0034	Flexible Hose.....	1				
26	04.0605.0204	Flexible Hose.....	1				
27	01.0001.0401	Screw.....	8				
28	01.4032.0005	Washer.....	8				
29	01.0001.0651	Screw.....	4				
30	04.0605.0222	Flexible Hose.....	1				
31	04.0607.0105	Pipe Fitting.....	2				
32	04.0600.0050	Pipe Fitting.....	1				
33	04.4210.0004	Pressure Tube.....	2				
34	04.0600.0038	Pipe Fitting.....	1				
35	04.4239.0013	Valve.....	1				
36	04.0605.0597	Flexible Hose.....	1				
37	04.0607.0107	Pipe Fitting.....	2				
38	04.0605.0209	Flexible Hose.....	1				
39	09.4604.0001	Complete Filter.....	1				
40	09.0803.0043	Retainer Pipe.....	1				

305.1 604878 Hydraulic System - Service Brake



305.1 604878 Hydraulic System - Service Brake

Item	Part No.	Description	Qty.
1	05.4309.0004	Pump.....	1
2	01.0003.0155	Screw.....	1
3	05.4329.0001	Pressure Switch.....	1
4	05.4329.0002	Pressure Switch.....	1
5	01.0001.1465	Screw.....	2
6	01.0023.0054	Nut.....	2
7	05.0401.0000	Pipe Fitting.....	2
8	06.0442.0054	Washer.....	8
9	06.0442.0055	Washer.....	12
10	05.0400.0000	Flexible Hose.....	4
11	09.0803.0016	Clamp.....	1
12	53.3401.7700	Pipe.....	1
13	04.0605.0312	Flexible Hose.....	1
14	05.0401.0003	Drilled Screw.....	10
15	04.0601.0003	Pipe Fitting.....	2
16	04.0607.0245	Flexible Hose.....	2
17	04.0607.0114	Pipe Fitting.....	2
18	53.3400.0600	Pipe.....	1
19	05.4329.0000	Accumulator.....	2
20	05.0401.0005	Pipe Fitting.....	4
21	05.0401.0001	Pipe Fitting.....	6
22	04.0607.0156	Pipe Fitting.....	1
23	04.0605.0113	Flexible Hose.....	1
24	04.0607.0137	Pipe Fitting.....	2
25	04.0605.0370	Flexible Hose.....	1
26	04.0600.0166	Pipe Fitting.....	2
27	04.0607.0137	Pipe Fitting.....	1
28	06.0442.0057	Washer.....	2

This exploded view diagram illustrates the assembly of a bicycle rear wheel. The components are numbered as follows:


- 1-4:** Rear fender assembly, including the fender body (1), mounting bracket (2), and screws (3, 4).
- 5-7:** Rear axle components, including the axle (5), axle nuts (6), and axle washers (7).
- 8-13:** Rear wheel hub and spokes, including the hub (8), spokes (9, 10, 11, 12, 13), and spoke nipples (14).
- 15-17:** Rear wheel rim and tire, including the rim (15), tire (16), and tire valve (17).
- 18-20:** Rear wheel mounting hardware, including the mounting bracket (18), mounting screws (19), and mounting nuts (20).
- 21:** Rear wheel axle nut.
- 22-23:** Rear wheel mounting bracket and mounting screws.

The diagram shows the rear wheel assembly (8-13) being mounted to the frame (21) using the mounting bracket (18) and screws (19). The rear fender (1-4) is shown being mounted to the rear wheel assembly using the mounting bracket (18) and screws (19). The rear axle (5) is shown being inserted into the hub (8) and secured with axle nuts (6) and washers (7). The tire (16) is shown being mounted to the rim (15) using the tire valve (17).

306.1 604879 Hydraulic System - Parking Brake

Item	Part No.	Description	Qty.
1	05.4315.0000	Lever.....	1
2	07.0740.0063	Washer.....	4
3	07.0740.0026	Plain Washer.....	7
4	07.0740.0095	Screw.....	4
5	09.4645.0022	Cable.....	2
6	07.0703.0492	Proximity Switch.....	1
7	900130	Snap Ring.....	2
8	07.0740.0177	Cotter Pin.....	2
9	07.0740.0170	Pin.....	1
10	07.0740.0171	Pulley.....	1
11	07.0740.0174	Screw.....	1
12	07.0740.0172	Support.....	1
13	07.0740.0011	Screw.....	1
14	07.0740.0013	Stop Nut.....	2
15	07.0740.0173	Plate.....	1
16	07.0740.0175	Washer.....	2
17	51.0808.7600	Support.....	1
18	54.0001.0000	Pin.....	2
19	02.0117.0053	Grease Nipple.....	2
20	01.0023.0056	Stop Nut.....	2
21	54.0800.0000	Spring.....	2
22	01.4032.0009	Spring Washer.....	1
23	01.0001.0902	Screw.....	1


307.1 604880 Front Axle - Differential Case



307.1 604880 Front Axle - Differential Case

Item	Part No.	Description	Qty.
1	632383	Seal.....	3
2	639668	COVER.....	1
3	07.0709.0439	Housing.....	1
4	07.0709.0084	Plug.....	1
5	639670	PLUG,BREATHER.....	1
7	07.0709.0113	Plug.....	1
8	07.0709.0371	Plug.....	1
9	07.0709.0441	Snap Ring.....	1

308.1 604881 Front Axle - Differential Gear




*28: Position kit = 6+17+18+19+20+21+27+29

308.1 604881 Front Axle - Differential Gear

Item	Part No.	Description	Qty.
1	633202	BEARING.....	1
2	640207	Stud.....	8
3	640206	Nut.....	8
4	639633	SEAL.....	1
5	639650	Screw.....	4
6	639651	Snap Ring.....	4
7	07.0709.0441	Snap Ring.....	1
8	630693	Ring Nut.....	1
9	639828	Spacer.....	1
10	639300	SPACER.....	1
10	639301	SPACER.....	1
10	639302	SPACER.....	1
10	639303	SPACER.....	1
11	634499	SPACER.....	1
11	634501	SPACER.....	1
11	639297	SPACER.....	1
11	639298	SPACER.....	1
12	626544	BEARING.....	2
13	07.0709.0216	Bevel Gear Set.....	1
14	639657	Screw.....	2
15	626544	BEARING.....	2
17	641090	Differential Side Gear.....	2
18	07.0709.0373	Differential Pinion.....	4
19	639660	Pin.....	4
20	639661	Snap Ring.....	4
21	639662	WASHER,FRICTION.....	4
23	07.0709.0057	Screw.....	12
24	639664	Ring Nut.....	2
27	641089	Differential Case.....	1
28	07.0709.0374	Differential.....	1
29	07.0709.0059	Disc.....	2


309.1 604882 Front Axle - Steering Axle



309.1 604882 Front Axle - Steering Axle

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	633174	Nut.....	2	44	639646	Snap Ring.....	2
2	640718	Screw.....	2	45	07.0709.0104	Screw.....	4
3	640214	Arm.....	2	46	634546	NUT,DIN439 JAM M16-2.0 P.....	4
4	07.0709.0377	Screw.....	32	49	639647	PLATE,LOCKING.....	2
6	640720	Bushin.....	2	50	07.0709.0365	Screw.....	4
7	630846	SEAL,PLANETARY.....	2	53	07.0709.0119	Stud.....	8
8	633202	BEARING.....	2	54	07.0709.0070	Nut.....	8
9	633203	Snap Ring.....	2	56	07.0709.0071	Washer.....	8
10	640216	Seal.....	2	57	640728	Thickness.....	2
11	639624	Joint.....	2	57	640729	Thickness.....	2
12	639289	Bushing.....	1	57	640730	Thickness.....	2
13	07.0709.0124	Bushing.....	2	58	07.0709.0072	Grease Nipple.....	2
14	640909	Screw.....	8	60	07.0709.0073	Support.....	2
15	07.0709.0060	Cover.....	2	65	07.0709.0219	Housing.....	1
16	638548	CAP.....	4	66	07.0709.0121	Housing.....	1
17	633176	GREASE NIPPLE.....	2				
18	07.0709.0061	Pin.....	2				
19	640908	Pin.....	2				
20	639630	SEAL.....	2				
21	639631	JOINT,ARTICULATED.....	2				
22	07.0709.0101	Housing.....	1				
23	07.0709.0215	Seal.....	2				
25	07.0709.0371	Plug.....	2				
26	07.0709.0113	Plug.....	4				
27	07.0709.0102	Housing.....	1				
28	07.0709.0205	Seal.....	2				
29	639637	Bearing.....	4				
30	07.0709.0117	Pipe Fitting.....	16				
31	07.0709.0064	Hub.....	2				
32	632383	Seal.....	2				
33	639639	RING GEAR.....	2				
34	639640	SUPPORT,RING GEAR.....	2				
35	639641	Snap Ring.....	8				
36	639642	PINION,DIFFERENTIAL.....	8				
37	639643	Bearing.....	8				
38	07.0709.0118	Nut.....	16				
40	07.0709.0065	Screw.....	4				
41	07.0709.0103	Support.....	2				
42	639645	Stud.....	16				
43	637567	Nut.....	16				

310.1 604883 Front Axle - Brake




*14: Position Kit = 4+5+6+7+8+9

310.1 604883 Front Axle - Brake

Item	Part No.	Description	Qty.
1	639674	Brake Disc.....	6
2	639675	Screw.....	6
3	07.0709.0106	Spring.....	6
4	07.0709.0424	Piston.....	2
5	639676	Spring.....	6
6	639679	Back-Up Ring.....	2
7	639695	O-RING.....	2
8	639681	Back-Up Ring.....	2
9	639682	SEAL.....	2
10	639683	BRAKE DISC,INTERMEDIATE.....	8
11	630328	BLEEDER VALVE, LONG.....	2
12	638548	CAP.....	2
13	633069	DOWEL.....	2
14	07.0709.0074	Piston.....	2


311.1 604884 Front Axle - Reduction Gear



311.1 604884 Front Axle - Reduction Gear

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	639799	O-RING.....	1	40	639816	O-RING.....	1
2	639779	PLUG,BREATHER.....	1	41	639809	ROD.....	1
3	639789	Cover.....	1	42	639810	O-RING.....	1
4	639790	Seal.....	1	43	639815	Piston.....	1
5	629327	Thickness.....	1	44	639781	O-RING.....	1
5	629733	SHIM,THICKNESS.....	1	45	639814	PLATE,COVER.....	1
5	629735	SHIM,THICKNESS.....	1	47	639813	Selector Shaft.....	1
5	639328	SHIM.....	1	48	639811	SLIDING GUIDE.....	2
5	639329	SHIM.....	1	49	639812	Selector Fork.....	1
6	633202	BEARING.....	1	50	637584	WASHER,SEALING.....	1
7	639782	COVER.....	1	52	637536	SEAL RING.....	1
9	639784	Bearing.....	1	53	633161	RING/SEAL.....	1
10	639797	SPLIT PIN.....	2	56	633202	BEARING.....	1
11	639785	Dowel.....	2	57	637577	SEAL.....	1
12	640196	Housing.....	1	58	639800	Cover.....	1
13	639787	Screw.....	12	59	07.0709.0079	Flange.....	1
14	637574	SEAL.....	1	60	639802	Nut.....	1
16	639818	Washer.....	1	61	07.0709.0440	Sheet.....	1
17	07.0709.0422	Screw.....	1	65	633109	Spring Washer.....	12
18	640198	Spacer.....	1	71	639819	SHAFT.....	1
19	639792	SCREW.....	2	72	639820	Gear.....	1
21	639793	Sheet.....	1	73	639821	Gear.....	1
22	639794	Bearing.....	4				
23	640199	Shaft.....	1				
24	639796	SLEEVE.....	1				
25	639778	SCREW.....	2				
26	639798	Sheet.....	1				
27	628275	PLUG,MAGNETIC.....	1				
28	639791	Spacer.....	1				
29	07.0709.0442	Security Switch.....	1				
30	637582	Rubber Protection.....	1				
31	635594	SCREW.....	1				
32	635596	Spring.....	1				
33	07.0709.0443	Bearing.....	1				
34	07.0709.0327	Sphere.....	1				
35	639803	SCREW.....	1				
36	639804	O-RING.....	1				
37	639807	Seal.....	2				
38	639780	Cylinder.....	1				
39	639808	Plug.....	2				


312.1 604885 Front Axle - Steering Cylinder



312.1 604885 Front Axle - Steering Cylinder

Item	Part No.	Description	Qty.
1	639671	Screw.....	4
4	07.0709.0001	Cylinder.....	1
5	07.0709.0075	Articulated Tie Rod.....	2
8	640270	Joint Kit.....	1


313.1 604886 Rear Axle - Differential Case



313.1 604886 Rear Axle - Differential Case

Item	Part No.	Description	Qty.
1	632383	Seal.....	3
2	639668	COVER.....	1
3	640715	Housing.....	1
4	07.0709.0055	Cover.....	1
5	639670	PLUG,BREATHER.....	1
7	07.0709.0113	Plug.....	1
8	07.0709.0371	Plug.....	1


314.1 604887 Rear Axle - Differential Gear



314.1 604887 Rear Axle - Differential Gear

Item	Part No.	Description	Qty.
1	639352	O-RING.....	1
2	639300	SPACER.....	1
2	639301	SPACER.....	1
2	639302	SPACER.....	1
2	639303	SPACER.....	1
3	07.0709.0372	Bevel Gear Set.....	1
4	633099	Bearing.....	2
5	639664	Ring Nut.....	2
6	639650	Screw.....	4
7	639657	Screw.....	2
8	07.0709.0057	Screw.....	12
9	639684	WASHER.....	2
10	639685	GEAR,DIFFERENTIAL SIDE.....	2
11	639660	Pin.....	4
12	639661	Snap Ring.....	4
13	639662	WASHER,FRICTION.....	4
14	639659	GEAR,SATELLITE.....	4
15	639686	CASE,DIFFERENTIAL.....	1
16	626544	BEARING.....	2
17	634499	SPACER.....	1
17	634501	SPACER.....	1
17	639297	SPACER.....	1
17	639298	SPACER.....	1
18	639653	Spacer.....	1
19	630693	Ring Nut.....	1
20	633098	SEAL,DIFFERENTIAL.....	1
22	07.0709.0426	Flange.....	1
23	639802	Nut.....	1
24	639651	Snap Ring.....	4
25	640717	Differential.....	1

315.1 604888 Rear Axle - Steering Axle




*65: Position Kit = 22+12

*66: Position Kit = 27+12

315.1 604888 Rear Axle - Steering Axle

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	633174	Nut.....	2	44	639646	Snap Ring.....	2
2	640718	Screw.....	2	45	07.0709.0104	Screw.....	4
3	640719	Arm.....	2	46	634546	NUT,DIN439 JAM M16-2.0 P.....	4
4	07.0709.0377	Screw.....	32	49	639647	PLATE,LOCKING.....	2
6	640720	Bushin.....	2	50	633204	SNAP RING (CIRCLIP).....	2
7	630846	SEAL,PLANETARY.....	2	53	07.0709.0119	Stud.....	8
8	633202	BEARING.....	2	54	07.0709.0070	Nut.....	8
9	633203	Snap Ring.....	2	56	07.0709.0071	Washer.....	8
10	640216	Seal.....	2	57	640728	Thickness.....	1
11	639624	Joint.....	2	57	640729	Thickness.....	1
12	639289	Bushing.....	2	57	640730	Thickness.....	1
13	07.0709.0124	Bushing.....	2	58	07.0709.0072	Grease Nipple.....	2
14	640909	Screw.....	12	60	07.0709.0105	Support.....	2
15	07.0709.0060	Cover.....	2	65	07.0709.0219	Housing.....	1
16	638548	CAP.....	4	66	07.0709.0121	Housing.....	1
17	633176	GREASE NIPPLE.....	2	72	07.0709.0365	Screw.....	4
18	07.0709.0061	Pin.....	2				
19	640908	Pin.....	2				
20	639630	SEAL.....	2				
21	639631	JOINT,ARTICULATED.....	2				
22	07.0709.0101	Housing.....	1				
23	07.0709.0215	Seal.....	2				
25	07.0709.0371	Plug.....	2				
26	07.0709.0113	Plug.....	4				
27	07.0709.0102	Housing.....	1				
28	07.0709.0205	Seal.....	2				
29	639637	Bearing.....	4				
30	07.0709.0117	Pipe Fitting.....	16				
31	07.0709.0064	Hub.....	2				
32	632383	Seal.....	2				
33	639639	RING GEAR.....	2				
34	639640	SUPPORT,RING GEAR.....	2				
35	639641	Snap Ring.....	8				
36	639642	PINION,DIFFERENTIAL.....	8				
37	639643	Bearing.....	8				
38	07.0709.0118	Nut.....	16				
40	07.0709.0065	Screw.....	4				
41	07.0709.0103	Support.....	2				
42	639645	Stud.....	16				
43	637567	Nut.....	16				

316.1 604889 Rear Axle - Brake




*36: Position Kit = 15+16+17+18+22+23+24

*37: Position Kit = 15+17+18+22+23+24+26

316.1 604889 Rear Axle - Brake

Item	Part No.	Description	Qty.
1	639689	Lever.....	1
2	630328	BLEEDER VALVE, LONG.....	2
3	638548	CAP.....	2
4	901777	Screw.....	6
5	637574	SEAL.....	2
6	07.0709.0122	Bushin.....	2
7	639691	GRUBSCREW.....	2
8	636440	Nut.....	2
10	639692	Lever.....	2
11	630280	Spacer.....	2
12	637511	Screw.....	2
13	639683	BRAKE DISC, INTERMEDIATE.....	10
14	639693	Screw.....	6
15	07.0709.0106	Spring.....	3
16	640731	Piston.....	1
17	639679	Back-Up Ring.....	1
18	639695	O-RING.....	1
19	633069	DOWEL.....	2
20	639696	Lever.....	1
21	639676	Spring.....	6
22	637621	THREADED ELEMENT.....	2
23	639681	Back-Up Ring.....	1
24	639682	SEAL.....	1
25	639674	Brake Disc.....	8
26	640732	Piston.....	1
36	07.0709.0081	Piston.....	1
37	07.0709.0082	Piston.....	1
38	07.0709.0123	Seal.....	2


317.1 604890 Rear Axle - Steering Cylinder



317.1 604890 Rear Axle - Steering Cylinder

Item	Part No.	Description	Qty.
1	639671	Screw.....	4
4	07.0709.0001	Cylinder.....	1
5	07.0709.0075	Articulated Tie Rod.....	2
8	640270	Joint Kit.....	1


318.1 604891 Front Axle - Support



318.1 604891 Front Axle - Support


Item	Part No.	Description	Qty.
1	07.0709.0218	Bushin.....	4
2	637850	Bushing.....	2
3	07.0709.0386	Support.....	2
4	633176	GREASE NIPPLE.....	2
5	638548	CAP.....	2
6	07.0709.0387	Support.....	2

401.1 604856 Forks




Item	Part No.	Description	Qty.
1	51.1300.5300	Plate.....	1
2	51.1301.2500	Fork.....	2
3	54.0000.0083	Pin.....	1
4	54.0100.0056	Washer.....	1
5	01.0001.0409	Screw.....	1
6	01.0023.0056	Nut.....	1
7	09.0803.0055	Chain.....	0,45
8	09.0803.0026	Spring Split Pin.....	2
9	07.0726.0051	Pin.....	2
10	01.4041.0005	Security Dowel.....	2

402.1 604892 Arm



Item	Part No.	Description	Qty.
1	51.0200.7000	1st Telescopic Element.....	1
2	54.0702.0000	Sliding Guide.....	6
3	54.0200.0001	Bushing.....	8
4	54.0702.0001	Sliding Guide.....	4
5	51.0801.9000	Support.....	2
6	01.4032.0004	Spring Washer.....	16
7	01.0001.0357	Screw.....	12
8	01.0001.0304	Screw.....	4
9	54.0201.0003	Bushing.....	2
10	52.0900.0200	Spacer.....	2
11	54.0201.0004	Bushing.....	2
12	02.0117.0101	Grease Nipple.....	1
13	54.0200.0000	Bushing.....	10
14	01.0001.0353	Screw.....	2
15	54.0702.0004	Sliding Guide.....	2
16	01.4006.0005	Screw.....	4
17	01.0003.0203	Screw.....	4
18	54.0702.0005	Sliding Guide.....	2
19	51.0200.7100	2nd Telescopic Element.....	1
20	01.4032.0003	Spring Washer.....	4
21	51.0804.9000	Thickness.....	6
22	51.0809.4000	Thickness.....	4
23	51.0809.3900	Thickness.....	2
24	51.0806.3800	Thickness.....	2
25	07.0803.0357	Indicator.....	1
26	01.0003.0153	Screw.....	2


403.1 604893 Hydraulic System - Tilting



403.1 604893 Hydraulic System - Tilting

Item	Part No.	Description	Qty.
1	04.0607.0141	Pipe Fitting.....	1
2	09.0803.0043	Retainer Pipe.....	10
3	04.0605.0354	Flexible Hose.....	1
4	53.3401.7900	Pipe.....	1
5	01.0003.0157	Screw.....	20
6	06.0442.0103	Washer.....	2
7	54.0201.0017	Bushing.....	2
8	04.4239.0000	Valve.....	1
9	53.0400.1000	Forks Articulation Cylinder.....	1
10	640536	Joint Kit.....	1
11	54.0000.0143	Pin.....	1
12	04.0214.0035	Drilled Screw.....	1
13	07.4529.0073	Back-Up Ring.....	1
14	07.4529.0071	Seal.....	1
15	01.0001.0314	Screw.....	1
16	01.0023.0055	Nut.....	1
17		604896 pos. 14	
18	01.0001.0306	Screw.....	4
19	53.3400.7800	Pipe.....	1


404.1 604894 Hydraulic System - Boom Extension



404.1 604894 Hydraulic System - Boom Extension

Item	Part No.	Description	Qty.
1	53.0100.2100	Cylinder.....	1
2	07.4529.0114	Cylinder Packing Kit.....	1
3		Screw.....	2
4	54.0702.0028	Sliding Guide.....	2
5	54.0003.0101	Pin.....	1
6	01.4032.0003	Washer.....	1
7	01.0031.0299	Spring Washer.....	1
8	01.0001.0254	Screw.....	1
9	04.0605.0326	Flexible Hose.....	2
10	04.0607.0111	Pipe Fitting.....	2
11	07.4529.0073	Back-Up Ring.....	2
12	07.4529.0071	Seal.....	2
13	01.4003.0002	Screw.....	4
14	04.4239.0001	Valve.....	1
15	01.0023.0054	Nut.....	2
16	01.0001.0310	Screw.....	1
17	54.0000.0142	Pin.....	1
18	01.0023.0055	Nut.....	1
19	53.3401.8600	Pipe.....	1
20	53.3401.8500	Pipe.....	1
21	09.0803.0043	Clamp.....	2
24	01.0003.0157	Screw.....	2


405.1 604895 Hydraulic System - Auxiliary Circuit



405.1 604895 Hydraulic System - Auxiliary Circuit

Item	Part No.	Description	Qty.
1	01.0003.0164	Screw.....	12
2	04.0607.0163	Pipe Fitting.....	2
3	09.0803.0043	Retainer Pipe.....	10
4	01.0003.0157	Screw.....	8
5	04.0605.0414	Flexible Hose.....	1
6	04.0605.0413	Flexible Hose.....	2
7	53.3401.8000	Pipe.....	1
8	53.3401.8100	Pipe.....	1


406.1 604896 Hydraulic System - Fork Balancing



406.1 604896 Hydraulic System - Fork Balancing

Item	Part No.	Description	Qty.
1	04.0605.0320	Flexible Hose.....	2
2	07.0704.0075	Solenoid.....	1
3	04.0605.0261	Flexible Hose.....	2
4	04.0607.0122	Pipe Fitting.....	2
5	04.0607.0111	Pipe Fitting.....	8
6	04.4239.0003	Valve.....	1
7	07.4529.0072	Seal.....	2
8	53.0300.1500	Cylinder.....	1
9	636455	Joint Kit.....	1
10	02.0117.0119	Grease Nipple.....	2
11	54.0000.0132	Pin.....	1
12	54.0000.0123	Pin.....	1
13	04.4239.0004	Valve.....	2
14	04.0605.0260	Flexible Hose.....	2
15	635574	End Piece.....	1
16	03.0000.0005	End Piece.....	1
17	01.4001.0008	Screw.....	2
18	01.0023.0055	Stop Nut.....	2
19	01.0031.0055	Plain Washer.....	4
20	04.4236.0049	Valve.....	1
21	01.4001.0034	Screw.....	4
22	01.4032.0003	Spring Washer.....	4
23	07.0704.0155	Valve.....	1
24	07.0704.0154	Valve.....	2


407.1 604897 Hydraulic System - Implement Locking



407.1 604897 Hydraulic System - Implement Locking

Item	Part No.	Description	Qty.
1	53.3001.0500	Manifold.....	1
2	04.0600.0019	Pipe Fitting.....	1
3	04.0600.0087	Pipe Fitting.....	2
4	04.4210.0008	Female Coupling.....	2
5	04.4210.0007	Male Coupling.....	2
6	04.0607.0141	Pipe Fitting.....	2
7	04.0607.0110	Pipe Fitting.....	2
8	04.0605.0308	Flexible Hose.....	2
9	04.0607.0114	Pipe Fitting.....	3
10	01.0001.0156	Screw.....	2
11	04.0607.0112	Pipe Fitting.....	1
12	04.0605.0114	Flexible Hose.....	1
13	04.0605.0113	Flexible Hose.....	1
14	04.0605.0112	Flexible Hose.....	1
15	04.0607.0131	Pipe Fitting.....	1
16	01.4032.0002	Spring Washer.....	2
17		604895 pos. 5	
18	53.0500.0400	Cylinder.....	1
19	01.0031.0054	Plain Washer.....	2
20	01.0001.0355	Screw.....	4
21	01.0032.0055	Washer.....	4
22	01.0031.0301	Washer.....	4
23	54.0001.0001	Pin.....	2
24	04.0600.0081	Pipe Fitting.....	1
25	04.4239.0002	Valve.....	1
26	04.0607.0132	Pipe Fitting.....	1
27	01.0031.0299	Plain Washer.....	3
28	639395	Joint Kit.....	1
29	51.0901.8200	Guard.....	1
30	01.0001.0254	Screw.....	3
31	01.4032.0003	Spring Washer.....	3
32	04.0607.0163	Pipe Fitting.....	2


408.1 604898 Hydraulic System - Lifting (to serial number 15145)



408.1 604898 Hydraulic System - Lifting (to serial number 15145)

Item	Part No.	Description	Qty.
1	04.4236.0050	Control Valve.....	1
2	04.0607.0111	Pipe Fitting.....	2
3	54.0000.0013	Pin.....	1
4	02.0117.0101	Grease Nipple.....	2
5	04.0605.0321	Flexible Hose.....	2
6	04.0607.0111	Pipe Fitting.....	2
7	04.0600.0016	Pipe Fitting.....	1
8	04.4239.0005	Valve.....	1
9	53.0000.2700	Cylinder.....	1
10	07.4529.0110	Joint Kit.....	1
11	09.0801.0016	Bushing.....	4
12	54.0000.0126	Pin.....	1
13	07.4529.0072	Seal.....	2
14	04.0220.0055	Plug.....	2
15	51.0807.5400	Bracket.....	1
16	51.0807.5200	Bracket.....	2
17	09.0803.0275	Lever.....	2
18	07.0704.0157	Proximity Switch.....	2
19	09.0803.0276	Control Lever.....	1
20	09.0704.0159	Bellow.....	1
21	07.0704.0042	Valve.....	1
22	07.0704.0156	Valve.....	1
23	01.0001.0209	Screw.....	2
24	01.0031.0055	Washer.....	12
25	06.0442.0103	Washer.....	2
26	01.0023.0054	Nut.....	6
27	01.0001.0505	Screw.....	1
28	01.4032.0005	Spring Washer.....	1
29	07.0704.0106	Proximity Switch.....	1
30	07.0704.0158	Proximity Switch.....	2
31	07.0704.0112	Push Button.....	1
32	07.0704.0110	Push Button.....	1
33	07.0704.0111	Cap.....	1
34	01.0023.0056	Stop Nut.....	1
35	01.0001.0413	Screw.....	1
36	07.0704.0055	Solenoid.....	1
37	01.0001.0254	Screw.....	2
38	01.0001.0207	Screw.....	2
41	09.0803.0238	Lever.....	1
42	07.0704.0162	Block.....	1



409.1 604898 Hydraulic System - Lifting (from serial number 15146)



409.1 604898 Hydraulic System - Lifting (from serial number 15146)


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	01.4236.0050	Control Valve.....	1	41	09.0803.0238	Lever.....	1
2	04.0607.0111	Pipe Fitting.....	2	42	07.0704.0162	Block.....	1
3	54.0000.0013	Pin.....	1				
4	02.0117.0101	Grease Nipple.....	2				
5	04.0605.0321	Flexible Hose.....	2				
6	04.0607.0111	Pipe Fitting.....	2				
7	04.0600.0016	Pipe Fitting.....	1				
8	04.4239.0005	Valve.....	1				
9	53.0000.2700	Cylinder.....	1				
10	07.4529.0110	Joint Kit.....	1				
11	09.0801.0016	Bushing.....	4				
12	54.0000.0126	Pin.....	1				
13	07.4529.0072	Seal.....	2				
14	04.0220.0055	Plug.....	2				
15	07.0704.0164	Seal.....	5				
16	51.0809.8400	Bracket.....	2				
17	09.0803.0275	Lever.....	2				
18	07.0704.0157	Proximity Switch.....	2				
19	09.0803.0276	Control Lever.....	1				
20	09.0704.0159	Bellow.....	1				
21	07.0704.0042	Valve.....	1				
22	07.0704.0156	Valve.....	1				
23	01.0001.0207	Screw.....	3				
24	01.0031.0055	Plain Washer.....	3				
25	06.0442.0103	Washer.....	2				
26	01.0032.0054	Spring Washer.....	3				
27	01.0001.0505	Screw.....	1				
28	01.4032.0005	Spring Washer.....	1				
29	07.0704.0106	Proximity Switch.....	1				
30	07.0704.0158	Proximity Switch.....	2				
31	07.0704.0112	Push Button.....	1				
32	07.0704.0110	Push Button.....	1				
33	07.0704.0111	Cap.....	1				
34	01.0023.0056	Stop Nut.....	1				
35	01.0001.0413	Screw.....	1				
36	07.0704.0055	Solenoid.....	1				
37	01.0001.0304	Screw.....	2				
38	01.0032.0055	Spring Washer.....	2				
39	01.0031.0056	Plain Washer.....	2				
40	09.0804.1700	Panel.....	1				

410.1 604899 Coupling Unit



Item	Part No.	Description	Qty.
1	51.0400.2600	Fork Coupling Attachment.....	1
2	01.0031.0054	Plain Washer.....	4
3	01.0023.0053	Nut, M6.....	4
4	01.0001.0104	Screw.....	4
5	54.0201.0017	Bushing.....	2
6	54.0002.0030	Pin.....	1
7	54.0002.0031	Pin.....	1
8	02.0117.0101	Grease Nipple.....	1
9	02.4102.0001	Cotter Pin.....	1
10	54.0000.0077	Pin.....	1
11	54.0001.0022	Pin.....	2


501.1 604864 Diesel Engine - Hydraulic Pump



501.1 604864 Diesel Engine - Hydraulic Pump

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	01.4001.0012	Screw.....	4	41	01.4001.0024	Screw.....	4
2	01.0031.0058	Washer.....	6	42	07.0722.0053	Flange.....	1
3	51.0806.7500	Support.....	1				
4	01.0031.0301	Plain Washer.....	2				
5	01.4032.0004	Spring Washer.....	2				
6	01.0001.0358	Screw.....	2				
7	01.0001.0356	Screw.....	32				
8	09.4670.0004	Insulator.....	4				
9	01.0023.0055	Nut.....	16				
10	09.0804.0100	Handwheel Arrangement.....	1				
11	01.0023.0057	Nut.....	6				
12	641124	Elastic Joint.....	1				
13	01.0032.0057	Washer.....	9				
14	07.4501.0067	Oil Filter.....	1				
15	01.0031.0099	Plain Washer.....	1				
16	01.4032.0007	Spring Washer.....	1				
17	01.0003.0405	Screw.....	1				
18	04.4238.0033	Pump.....	1				
19	640125	Protection.....	1				
20	04.4238.0030	Pump.....	1				
21	01.0032.0055	Plain Washer.....	8				
22	634981	HUB.....	1				
23	999058	WASHER.....	1				
24	07.4501.0068	Diesel Oil Filter.....	1				
25	01.0001.0357	Screw.....	1				
26	09.4601.0029	Diesel Engine.....	1				
27	54.0100.0066	Pulley.....	1				
28	01.0003.0262	Screw.....	8				
29	09.0804.1000	Snap Ring.....	1				
30	09.0804.1200	Half-Joint.....	1				
31	09.0804.0900	Elastic Joint.....	1				
32	01.0003.0208	Screw.....	6				
33	09.0804.1100	Half-Joint.....	1				
34	51.0806.1600	Support.....	1				
35	01.4032.0006	Spring Washer.....	4				
36	02.4102.0004	Split Pin.....	2				
37	51.0806.1800	Support.....	1				
38	01.0001.0402	Screw.....	2				
39	01.0001.0606	Screw.....	4				
40	01.0023.0056	Nut.....	2				


502.1 604865 Diesel Engine - Engine Cooling System



502.1 604865 Diesel Engine - Engine Cooling System

Item	Part No.	Description	Qty.
1	01.0001.0209	Screw.....	1
2	01.4031.0004	Plain Washer.....	1
3	09.4670.0001	Rubber.....	1
4	09.0803.0245	Seal.....	1,4
5	53.3200.0022	Complete Radiator.....	1
6	01.0031.0298	Plain Washer.....	3
7	04.0607.0130	Pipe Fitting.....	2
8	01.0001.0254	Screw.....	1
9	04.0605.0215	Flexible Hose.....	1
10	04.0605.0216	Flexible Hose.....	1
11	01.4032.0003	Spring Washer.....	1
12	01.0031.0055	Plain Washer.....	2
13	07.0712.0046	Radiator Core.....	1
14	07.0712.0047	Conveyor.....	1
15	09.4670.0002	Insulator.....	1
16	51.0806.8900	Bracket.....	1
17	01.0023.0054	Nut.....	1
18	01.0031.0301	Plain Washer.....	1
19	01.0023.0055	Nut.....	1
20	07.0712.0006	Guard.....	1
21	07.0712.0048	Fan.....	1
22	01.0001.0158	Screw.....	2
23	01.4032.0002	Spring Washer.....	3
24	01.0001.0154	Screw.....	1
25	53.3302.0017	Insulation.....	1


503.1 604866 Diesel Engine - Exhaust System - Accelerator (to serial number 15378)



503.1 604866 Diesel Engine - Exhaust System - Accelerator (to serial number 15378)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	09.4655.0000	Lever.....	4	42	640885	Cartridge.....	1
2	09.4656.0000	Pedal.....	1	43	53.3001.1100	Manifold.....	1
3	07.4501.0060	Precleaner.....	1	44	09.0805.0057	Rubber Hose.....	1
4	04.0227.0067	Clamp.....	3	45	01.0023.0053	Nut, M6.....	1
5	09.0805.0054	Rubber Hose.....	1	46	01.0001.0158	Screw.....	1
6	09.0803.0008	Articulation.....	1	47	01.0001.0254	Screw.....	3
7	04.4227.0000	Clamp.....	2	48	01.4032.0003	Washer.....	3
8	07.4501.0061	Proximity Switch.....	1	49	04.0227.0067	Clamp.....	2
9	01.0001.0256	Screw.....	4	50	53.3001.1800	Tube.....	1
10	01.0031.0299	Plain Washer.....	4	51	09.0803.0259	Sheath.....	1
11	09.0805.0058	Rubber Hose.....	1	52	51.0807.5700	Support.....	1
12	01.0001.0357	Screw.....	1	53	09.4645.0003	Gas Cable.....	1
13	01.0031.0056	Washer.....	2	54	09.0803.0007	Clamp.....	2
14	01.0023.0055	Nut.....	1	55	01.0001.1438	Screw.....	2
15	04.4227.0007	Retainer Pipe.....	1	56	01.0023.0052	Stop Nut.....	2
16	01.0006.0049	Screw.....	2				
17	53.3100.0020	Exhaust Muffler.....	1				
18	01.4032.0003	Nut.....	4				
19	09.0803.0109	Collar.....	1				
20	09.0805.0053	Rubber Hose.....	1				
21	01.0001.0506	Screw.....	2				
22	01.4032.0005	Spring Washer.....	2				
23	51.0900.1500	Guard.....	1				
24	01.0031.0301	Plain Washer.....	2				
25	01.4032.0004	Spring Washer.....	2				
26	01.4001.0015	Screw.....	2				
27	55.0208.0030	Manifold.....	1				
28	01.0031.0057	Plain Washer.....	2				
29	51.0807.5900	Support.....	1				
30	09.4645.0000	Cable.....	1				
31	07.4501.0042	Clamp.....	2				
32	07.4501.0041	Cartridge.....	1				
33	09.4604.0039	Complete Air Filter.....	1				
35	51.0806.2800	Bracket.....	1				
36	09.0803.0251	Spring.....	1				
37	51.0806.2700	Bracket.....	1				
38	07.0723.0194	Rubber Hose.....	0,1				
39	01.0023.0054	Nut.....	1				
40	51.0901.9500	Guard.....	1				
41	04.0227.0051	Clamp.....	2				


504.1 604866 Diesel Engine - Exhaust System - Accelerator (from serial number 15379)



504.1 604866 Diesel Engine - Exhaust System - Accelerator (from serial number 15379)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	09.4655.0000	Lever.....	4	42	640885	Cartridge.....	1
2	09.4656.0000	Pedal.....	1	43	53.3001.1100	Manifold.....	1
3	07.4501.0060	Precleaner.....	1	44	09.0805.0057	Rubber Hose.....	1
4	04.0227.0067	Clamp.....	3	45	01.0023.0053	Nut, M6.....	1
5	09.0805.0054	Rubber Hose.....	1	46	01.0001.0158	Screw.....	1
6	09.0803.0008	Articulation.....	1	47	01.0001.0254	Screw.....	3
7	04.4227.0000	Clamp.....	2	48	01.4032.0003	Washer.....	3
8	07.4501.0061	Proximity Switch.....	1	49	04.0227.0067	Clamp.....	2
9	01.0001.0256	Screw.....	4	50	53.3001.1800	Tube.....	1
10	01.0031.0299	Plain Washer.....	4	51	09.0803.0259	Sheath.....	1
11	09.0805.0058	Rubber Hose.....	1	52	51.0807.5700	Support.....	1
12	01.0001.0357	Screw.....	1	53	09.4645.0003	Gas Cable.....	1
13	01.0031.0056	Washer.....	2	54	09.0803.0007	Clamp.....	2
14	01.0023.0055	Nut.....	1	55	01.0001.1438	Screw.....	2
15	04.4227.0007	Retainer Pipe.....	1	56	01.0023.0052	Stop Nut.....	2
16	01.0006.0049	Screw.....	2	57	09.0803.0027	Rain Protector.....	1
17	53.3100.0033	Exhaust Muffler.....	1				
18	01.4032.0003	Nut.....	4				
19	09.0803.0109	Collar.....	1				
20	09.0805.0053	Rubber Hose.....	1				
21	01.0001.0506	Screw.....	2				
22	01.4032.0005	Spring Washer.....	2				
23	51.0900.1500	Guard.....	1				
24	01.0031.0301	Plain Washer.....	2				
25	01.4032.0004	Spring Washer.....	2				
26	01.4001.0015	Screw.....	2				
27	55.0208.0030	Manifold.....	1				
28	01.0031.0057	Plain Washer.....	2				
29	51.0807.5900	Support.....	1				
30	09.4645.0000	Cable.....	1				
31	07.4501.0042	Clamp.....	2				
32	07.4501.0041	Cartridge.....	1				
33	09.4604.0039	Complete Air Filter.....	1				
35	51.0806.2800	Bracket.....	1				
36	09.0803.0251	Spring.....	1				
37	51.0806.2700	Bracket.....	1				
38	07.0723.0194	Rubber Hose.....	0,1				
39	01.0023.0054	Nut.....	1				
40	51.0901.9500	Guard.....	1				
41	04.0227.0051	Clamp.....	2				


505.1 604869 Hydraulic System - Oil Cooler



505.1 604869 Hydraulic System - Oil Cooler

Item	Part No.	Description	Qty.
1	51.0600.4000	Oil Tank.....	1
2	07.0726.0044	Cover.....	1
3	53.3301.0002	Seal.....	1
4	01.0031.0299	Washer.....	12
5	01.0023.0054	Nut.....	12
6	56.0013.0000	Transmitter.....	1
7	06.0442.0103	Washer.....	2
8	04.0600.0046	Pipe Fitting.....	2
9	04.4239.0013	Valve.....	1
10	09.0803.0232	Insulator.....	2
11	04.0607.0120	Pipe Fitting.....	1
12	04.0607.0119	Pipe Fitting.....	1
13	01.0031.0301	Plain Washer.....	4
14	01.0023.0055	Nut.....	4
15	04.0605.0276	Flexible Hose.....	1
16	04.0607.0107	Pipe Fitting.....	1
17	04.0605.0316	Flexible Hose.....	1
18	04.0605.0279	Flexible Hose.....	1
19	04.0607.0130	Pipe Fitting.....	2
20	06.0442.0105	Washer.....	1
21	04.0600.0013	Pipe Fitting.....	1
22	04.4210.0006	Pressure Tube.....	1



506.1 604871 Suction System Hydraulic Pumps



506.1 604871 Suction System Hydraulic Pumps


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	09.4661.0016	Filter.....	1	42	04.0607.0112	Pipe Fitting.....	3
2	09.4661.0002	Level Indicator.....	1	43	04.4239.0082	Valve.....	1
3	06.0401.0842	Seal.....	1	44	01.0031.0054	Plain Washer.....	2
4	53.3000.1300	Manifold.....	1	45	01.0023.0053	Nut, M6.....	2
5	01.4032.0002	Spring Washer.....	6	46	04.0605.0369	Flexible Hose.....	1
6	01.0001.0156	Screw.....	6	47	56.0013.0028	Level Indicator.....	1
7	09.0805.0007	Rubber Hose.....	0,3	48		604878 pos. 13	
8	04.0227.0144	Clamp.....	2	49	04.0605.0314	Flexible Hose.....	1
9	53.3001.0700	Manifold.....	1	50	01.4032.0003	Spring Washer.....	2
10	09.4661.0014	Plug.....	1	51		604878 pos. 23	
11	01.0001.0154	Pipe Fitting.....	1	52	01.0001.0254	Screw.....	2
13	04.0220.0051	Plug.....	1	53	01.0031.0299	Plain Washer.....	2
14	06.0442.0101	Washer.....	1	54	07.0730.0039	Pipe Fitting.....	1
15	06.0442.0103	Washer.....	1	55	07.0730.0040	Pipe Fitting.....	1
16	04.0220.0055	Plug.....	1				
17	06.0442.0111	Washer.....	1				
18	04.0607.0235	Flexible Hose.....	1				
19	04.0605.0194	Flexible Hose.....	1				
20	01.0001.1482	Screw.....	2				
21	01.4031.0003	Plain Washer.....	4				
22	01.0023.0056	Nut.....	2				
23	09.4604.0004	Filter.....	1				
24	04.4224.0000	Tap.....	1				
25	04.0600.0055	Pipe Fitting.....	1				
26	04.0607.0147	Pipe Fitting.....	1				
27	04.0605.0206	Flexible Hose.....	1				
28	04.4223.0000	Pipe Fitting.....	1				
29	626804	Seal.....	1				
30	01.0001.0355	Screw.....	3				
31	01.0031.0056	Washer.....	3				
32	04.0607.0142	Pipe Fitting.....	1				
33	04.0607.0107	Pipe Fitting.....	1				
34	04.0607.0148	Pipe Fitting.....	2				
35	04.0607.0111	Pipe Fitting.....	4				
36	04.0607.0107	Pipe Fitting.....	1				
37	04.0605.0317	Flexible Hose.....	1				
38	04.0605.0309	Flexible Hose.....	1				
39		604878 pos. 25					
40	04.0607.0122	Pipe Fitting.....	3				
41	04.0605.0269	Flexible Hose.....	1				

601.1 604862 Fuse Box




Item	Part No.	Description	Qty.
1	637650	FUSE,3A.....	2
2	07.0703.0193	Fuse.....	1
3	634972	FUSE,7.5A.....	4
4	634974	FUSE,10A.....	15
5	634973	FUSE,15A.....	5
6	07.0703.0485	Relay.....	14
7	07.0703.0487	Relay.....	1
8	56.0021.0062	Housing.....	1
9	56.0021.0040	Relay.....	1

602.1 604870 Electric Installation



Item	Part No.	Description	Qty.
1	55.0602.0235	Wiring Harness.....	1
2	55.0602.0233	Wiring Harness.....	1
3	55.0602.0237	Wiring Harness.....	1
4	55.0602.0233	Wiring Harness.....	1
5	55.0602.0234	Wiring Harness.....	1
6	55.0602.0205	Wiring Harness.....	1
7	55.0602.0231	Wiring Harness.....	1
8	55.0602.0239	Wiring Harness.....	1
9	55.0602.0238	Wiring Harness.....	1
10	55.0601.0046	Wiring Harness.....	1

603.1 604874 Electric Installation



Item	Part No.	Description	Qty.
1	07.0703.0096	Removing Battery.....	1
2	56.0008.0002	Battery.....	1
3	07.0703.0306	Bulb.....	2
4	07.0703.0321	Bulb.....	1
5	56.0009.0003	Horn.....	1
6	56.0010.0005	Pivoting Beacon.....	1
7	07.0703.0319	Bulb.....	2
8	07.0703.0310	Glass.....	2
9	07.0703.0302	Complete Turn Signal.....	1
10	56.0009.0009	Horn.....	1
11	56.0010.0006	Light.....	1
12	56.0010.0004	Light.....	1
13	51.0804.8700	Support.....	1
14	56.0010.0007	Light.....	1
15	56.0010.0000	Light.....	1
16	56.0010.0001	Light.....	1
17	07.0703.0535	Relay.....	1
18	07.0703.0177	Bracket.....	1
19	637513	Relay.....	1
20	07.0703.0060	Fuse.....	1
21	07.0703.0061	Fuse.....	1
22	07.0703.0058	Connector.....	2
23	07.0703.0176	Pull Box.....	1
24	07.0703.0066	Stuffing Box.....	1
25	07.4501.0059	Relay.....	1
26	07.0703.0304	Bulb.....	2
27	07.0703.0305	Bulb.....	2
28	07.0703.0306	Bulb.....	2
29	07.0703.0309	Complete Turn Signal.....	1

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
01.0001.0007	33	01.0031.0055	29, 31, 41, 85,	04.0600.0057	45	04.0607.0163	27, 83, 87
01.0001.0071	11-12		89, 91, 97	04.0600.0068	45	04.0607.0235	105
01.0001.0072	12	01.0031.0056	12, 91, 99, 101,	04.0600.0081	87	04.0607.0245	47
01.0001.0086	33		105	04.0600.0087	87	04.4210.0003	45
01.0001.0094	11-12	01.0031.0057	12, 39, 99, 101	04.0600.0159	45	04.4210.0004	45
01.0001.0104	93	01.0031.0058	29, 31, 33, 95	04.0600.0166	47	04.4210.0006	103
01.0001.0154	31, 33, 97, 105	01.0031.0059	31, 33, 45	04.0601.0003	47	04.4210.0007	87
01.0001.0156	23, 29, 87, 105	01.0031.0061	29	04.0602.0490	45	04.4210.0008	87
01.0001.0158	97, 99, 101	01.0031.0062	29	04.0605.0112	87	04.4223.0000	105
01.0001.0204	31, 33	01.0031.0099	95	04.0605.0113	47, 87	04.4223.0003	45
01.0001.0207	89, 91	01.0031.0295	33	04.0605.0114	87	04.4223.0004	45
01.0001.0209	89, 97	01.0031.0298	97	04.0605.0177	41	04.4224.0000	45, 105
01.0001.0254	31, 33, 81, 87,	01.0031.0299	29, 31, 33, 45,	04.0605.0194	105	04.4227.0000	99, 101
	89, 97, 99, 101,		81, 87, 99, 101,	04.0605.0195	45	04.4227.0006	33
	105		103, 105	04.0605.0204	45	04.4227.0007	99, 101
01.0001.0256	29, 31, 43, 45,	01.0031.0301	29, 31, 87, 95,	04.0605.0206	105	04.4229.0034	45
	99, 101		97, 99, 101, 103	04.0605.0209	45	04.4229.0035	45
01.0001.0257	41	01.0032.0054	33, 43, 91	04.0605.0215	97	04.4235.0023	45
01.0001.0304	77, 91	01.0032.0055	43, 87, 91, 95	04.0605.0216	97	04.4236.0049	85
01.0001.0306	29, 79	01.0032.0057	95	04.0605.0222	45	04.4236.0050	89
01.0001.0308	27	01.4001.0000	29	04.0605.0252	45	04.4238.0030	95
01.0001.0310	81	01.4001.0001	29	04.0605.0254	43	04.4238.0033	95
01.0001.0314	79	01.4001.0006	31, 33	04.0605.0255	43	04.4239.0000	79
01.0001.0353	31, 77	01.4001.0008	85	04.0605.0260	85	04.4239.0001	81
01.0001.0355	43, 87, 105	01.4001.0011	39	04.0605.0261	85	04.4239.0002	87
01.0001.0356	29, 95	01.4001.0012	29, 95	04.0605.0269	105	04.4239.0003	85
01.0001.0357	29, 77, 95, 99,	01.4001.0015	99, 101	04.0605.0272	41	04.4239.0004	85
	101	01.4001.0018	31, 33	04.0605.0276	103	04.4239.0005	89, 91
01.0001.0358	95	01.4001.0024	95	04.0605.0279	103	04.4239.0007	27
01.0001.0401	45	01.4001.0034	85	04.0605.0308	87	04.4239.0013	45, 103
01.0001.0402	95	01.4003.0002	81	04.0605.0309	105	04.4239.0082	105
01.0001.0409	75	01.4006.0004	29	04.0605.0310	43	04.4240.0044	43
01.0001.0413	89, 91	01.4006.0005	77	04.0605.0311	43	04.4240.0046	41
01.0001.0503	31, 33	01.4006.0016	29	04.0605.0312	47	04.4240.0053	41
01.0001.0505	12, 89, 91	01.4023.0000	29	04.0605.0314	105	05.0400.0000	47
01.0001.0506	99, 101	01.4031.0001	29	04.0605.0315	45	05.0401.0000	47
01.0001.0556	31, 33	01.4031.0003	105	04.0605.0316	103	05.0401.0001	47
01.0001.0606	95	01.4031.0004	45, 97	04.0605.0317	105	05.0401.0003	47
01.0001.0651	31, 33, 45	01.4032.0002	23, 87, 97, 105	04.0605.0319	27	05.0401.0005	47
01.0001.0657	29	01.4032.0003	29, 43, 45, 77,	04.0605.0320	85	05.4309.0004	47
01.0001.0902	49		81, 85, 87, 97,	04.0605.0321	89, 91	05.4315.0000	49
01.0001.0905	31, 33		99, 101, 105	04.0605.0323	43	05.4329.0000	47
01.0001.1119	31, 33	01.4032.0004	29, 45, 77, 95,	04.0605.0326	81	05.4329.0001	47
01.0001.1438	99, 101		99, 101	04.0605.0354	79	05.4329.0002	47
01.0001.1465	47	01.4032.0005	45, 89, 91, 99,	04.0605.0369	105	06.0401.0214	45
01.0001.1482	105		101	04.0605.0370	47	06.0401.0219	45
01.0001.1493	29	01.4032.0006	29, 31, 33, 95	04.0605.0413	83	06.0401.0842	105
01.0003.0110	31, 33	01.4032.0007	29, 45, 95	04.0605.0414	83	06.0442.0054	47
01.0003.0153	77	01.4032.0009	49	04.0605.0597	45	06.0442.0055	45, 47
01.0003.0155	47	01.4041.0005	75	04.0607.0103	45	06.0442.0057	47
01.0003.0157	45, 79, 81, 83	01.4236.0050	91	04.0607.0104	45	06.0442.0101	105
01.0003.0164	83	02.0117.0053	49	04.0607.0105	45	06.0442.0103	33, 79, 89, 91,
01.0003.0203	31, 33, 77	02.0117.0101	77, 89, 91, 93	04.0607.0107	45, 103, 105		103, 105
01.0003.0208	95	02.0117.0119	85	04.0607.0110	43, 87	06.0442.0105	41, 103
01.0003.0210	41, 43	02.4102.0001	93	04.0607.0111	81, 85, 89, 91,	06.0442.0109	45
01.0003.0257	45	02.4102.0004	95		105	06.0442.0111	45, 105
01.0003.0262	95	03.0000.0005	85	04.0607.0112	87, 105	07.0700.0000	45
01.0003.0405	95	04.0214.0035	79	04.0607.0114	41, 45, 47, 87	07.0700.0001	45
01.0006.0033	29	04.0220.0051	105	04.0607.0117	41, 43	07.0701.0007	45
01.0006.0049	99, 101	04.0220.0055	33, 89, 91, 105	04.0607.0119	45, 103	07.0701.0196	45
01.0023.0052	99, 101	04.0227.0051	31, 33, 99, 101	04.0607.0120	45, 103	07.0703.0007	25
01.0023.0053	29, 31, 33, 93,	04.0227.0067	99, 101	04.0607.0122	85, 105	07.0703.0010	25
	99, 101, 105	04.0227.0144	105	04.0607.0127	45	07.0703.0011	25
01.0023.0054	29, 31, 33, 47,	04.0600.0013	41, 103	04.0607.0129	45	07.0703.0017	19
	81, 89, 97, 99,	04.0600.0016	89, 91	04.0607.0130	97, 103	07.0703.0029	25
	101, 103	04.0600.0019	87	04.0607.0131	87	07.0703.0032	25
01.0023.0055	27, 29, 31, 33,	04.0600.0021	45	04.0607.0132	87	07.0703.0058	111
	79, 81, 85, 95,	04.0600.0038	45	04.0607.0137	43, 47	07.0703.0060	111
	97, 99, 101, 103	04.0600.0042	45	04.0607.0141	79, 87	07.0703.0061	111
01.0023.0056	39, 49, 75, 89,	04.0600.0044	45	04.0607.0142	105	07.0703.0066	111
	91, 95, 105	04.0600.0045	45	04.0607.0143	45	07.0703.0096	111
01.0023.0057	29, 95	04.0600.0046	103	04.0607.0147	105	07.0703.0125	15, 17, 25
01.0023.0060	29	04.0600.0050	45	04.0607.0148	105	07.0703.0176	111
01.0031.0054	31, 33, 87, 93,	04.0600.0053	45	04.0607.0153	41	07.0703.0177	111
	105	04.0600.0055	105	04.0607.0156	47	07.0703.0193	107

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
07.0703.0302	111	07.0709.0119	55, 67	07.0740.0041	15, 17	07.0740.0127	21
07.0703.0304	111	07.0709.0121	55, 67	07.0740.0045	15	07.0740.0128	17, 21
07.0703.0305	111	07.0709.0122	69	07.0740.0046	11-12, 15	07.0740.0129	21
07.0703.0306	111	07.0709.0123	69	07.0740.0047	15, 17	07.0740.0132	21
07.0703.0309	111	07.0709.0124	55, 67	07.0740.0048	15, 17	07.0740.0133	21
07.0703.0310	111	07.0709.0205	55, 67	07.0740.0049	15, 17	07.0740.0135	43
07.0703.0319	111	07.0709.0215	55, 67	07.0740.0050	15, 17	07.0740.0136	43
07.0703.0321	111	07.0709.0216	53	07.0740.0051	15, 17	07.0740.0139	19
07.0703.0417	19	07.0709.0218	73	07.0740.0052	11-12, 15, 17	07.0740.0141	19
07.0703.0418	19	07.0709.0219	55, 67	07.0740.0053	15	07.0740.0142	19
07.0703.0420	19	07.0709.0327	59	07.0740.0054	15, 17	07.0740.0143	19
07.0703.0423	19, 25	07.0709.0365	55, 67	07.0740.0055	15, 17	07.0740.0144	19
07.0703.0424	25	07.0709.0371	51, 55, 63, 67	07.0740.0056	15	07.0740.0145	19
07.0703.0425	25	07.0709.0372	65	07.0740.0057	15	07.0740.0152	19
07.0703.0427	25	07.0709.0373	53	07.0740.0058	15, 17	07.0740.0154	19
07.0703.0428	25	07.0709.0374	53	07.0740.0059	15, 17	07.0740.0156	11-12
07.0703.0429	25	07.0709.0377	55, 67	07.0740.0060	15, 17	07.0740.0157	11-12
07.0703.0430	25	07.0709.0386	73	07.0740.0061	15, 17	07.0740.0158	11-12
07.0703.0431	25	07.0709.0387	73	07.0740.0062	15, 17, 19	07.0740.0163	11-12
07.0703.0432	25	07.0709.0422	59	07.0740.0063	15, 17, 49	07.0740.0170	49
07.0703.0433	25	07.0709.0424	57	07.0740.0064	11-12, 15	07.0740.0171	49
07.0703.0434	25	07.0709.0426	65	07.0740.0065	15	07.0740.0172	49
07.0703.0435	25	07.0709.0439	51	07.0740.0066	11-12	07.0740.0173	49
07.0703.0441	19	07.0709.0440	59	07.0740.0067	11-12	07.0740.0174	49
07.0703.0485	107	07.0709.0441	51, 53	07.0740.0068	11-12	07.0740.0175	49
07.0703.0487	107	07.0709.0442	59	07.0740.0069	11-12	07.0740.0177	49
07.0703.0489	19	07.0709.0443	59	07.0740.0070	11-12	07.0740.0178	11-12
07.0703.0490	19	07.0712.0006	97	07.0740.0071	11-12, 21	07.0740.0179	15
07.0703.0492	49	07.0712.0046	97	07.0740.0072	11-12	07.0740.0180	15
07.0703.0494	19	07.0712.0047	97	07.0740.0073	11-12	07.0740.0201	19
07.0703.0531	19	07.0712.0048	97	07.0740.0074	11-12	07.0740.0202	11-12
07.0703.0532	19	07.0722.0053	95	07.0740.0075	11-12	07.0740.0209	11-12
07.0703.0535	111	07.0723.0194	99, 101	07.0740.0076	11-12	07.0740.0210	11-12
07.0703.0572	25	07.0726.0044	103	07.0740.0078	11-12	07.0740.0211	11-12
07.0703.0613	25	07.0726.0051	75	07.0740.0079	11-12	07.0740.0212	11-12
07.0704.0042	89, 91	07.0726.0065	29	07.0740.0080	11-12	07.0740.0213	11-12
07.0704.0055	89, 91	07.0726.0083	29	07.0740.0081	11-12	07.0740.0214	11-12
07.0704.0075	85	07.0728.0006	41, 43	07.0740.0082	11-12	07.0740.0215	11-12
07.0704.0106	89, 91	07.0728.0007	41, 43	07.0740.0083	11-12	07.0740.0217	11-12
07.0704.0110	89, 91	07.0730.0039	105	07.0740.0084	11-12	07.0740.0218	21
07.0704.0111	89, 91	07.0730.0040	105	07.0740.0085	11-12	07.0740.0219	21
07.0704.0112	89, 91	07.0738.0000	39	07.0740.0086	11-12	07.0740.0220	19
07.0704.0154	85	07.0740.0000	15, 17	07.0740.0087	11-12	07.0740.0222	15
07.0704.0155	85	07.0740.0001	15, 17	07.0740.0088	11-12	07.0740.0223	15, 17
07.0704.0156	89, 91	07.0740.0002	15, 17	07.0740.0089	11-12	07.0740.0224	15
07.0704.0157	89, 91	07.0740.0003	15, 17	07.0740.0090	11-12	07.0740.0225	15
07.0704.0158	89, 91	07.0740.0004	15, 17	07.0740.0091	11-12	07.0740.0226	15
07.0704.0162	89, 91	07.0740.0005	11-12, 15, 17, 21	07.0740.0092	11-12	07.0740.0227	15, 17
07.0704.0164	91	07.0740.0006	11-12, 15, 17, 21	07.0740.0093	11-12	07.0740.0228	15, 17
07.0709.0001	61, 71	07.0740.0007	15, 17	07.0740.0094	11-12	07.0740.0229	15, 17
07.0709.0055	63	07.0740.0008	15	07.0740.0095	11-12, 49	07.0740.0230	15, 17
07.0709.0057	53, 65	07.0740.0009	11-12, 15, 17	07.0740.0096	11-12	07.0740.0231	15, 17
07.0709.0059	53	07.0740.0010	15, 17	07.0740.0097	11-12	07.0740.0232	15
07.0709.0060	55, 67	07.0740.0011	15, 17, 49	07.0740.0098	11-12	07.0740.0233	15
07.0709.0061	55, 67	07.0740.0012	11-12, 17, 21	07.0740.0099	11-12	07.0740.0235	15, 17
07.0709.0064	55, 67	07.0740.0013	15, 17, 49	07.0740.0100	11-12	07.0740.0236	17
07.0709.0065	55, 67	07.0740.0014	11-12, 15, 17	07.0740.0101	11-12	07.0740.0246	11-12
07.0709.0070	55, 67	07.0740.0015	15, 17	07.0740.0102	11-12	07.0740.0247	11-12
07.0709.0071	55, 67	07.0740.0016	11-12, 15, 17, 21	07.0740.0103	11-12	07.0740.0248	11-12
07.0709.0072	55, 67	07.0740.0017	15, 17	07.0740.0104	11-12	07.0740.0249	17
07.0709.0073	55	07.0740.0018	15, 17	07.0740.0105	11-12	07.0740.0250	17
07.0709.0074	57	07.0740.0020	15, 17	07.0740.0106	11-12	07.0740.0272	17
07.0709.0075	61, 71	07.0740.0021	15, 17	07.0740.0107	11-12	07.0740.0273	17
07.0709.0079	59	07.0740.0022	15, 17	07.0740.0114	11-12	07.0740.0274	17
07.0709.0081	69	07.0740.0024	15, 17	07.0740.0115	11-12	07.0740.0275	17
07.0709.0082	69	07.0740.0025	15, 17	07.0740.0116	11-12, 19	07.0740.0276	17
07.0709.0084	51	07.0740.0026	11-12, 15, 17, 49	07.0740.0117	11-12, 19	07.0740.0277	17
07.0709.0101	55, 67	07.0740.0027	15, 17	07.0740.0118	21	07.0803.0357	77
07.0709.0102	55, 67	07.0740.0028	11-12, 15, 17, 21	07.0740.0119	21	07.4501.0041	99, 101
07.0709.0103	55, 67	07.0740.0029	15, 17	07.0740.0120	21	07.4501.0042	99, 101
07.0709.0104	55, 67	07.0740.0030	15, 17	07.0740.0121	21	07.4501.0059	111
07.0709.0105	67	07.0740.0031	15	07.0740.0122	21	07.4501.0060	99, 101
07.0709.0106	57, 69	07.0740.0032	11-12, 15	07.0740.0123	21	07.4501.0061	99, 101
07.0709.0113	51, 55, 63, 67	07.0740.0035	11-12, 15, 17	07.0740.0124	21	07.4501.0067	95
07.0709.0117	55, 67	07.0740.0037	19	07.0740.0125	21	07.4501.0068	95
07.0709.0118	55, 67	07.0740.0039	15	07.0740.0126	21	07.4529.0071	79, 81

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
07.4529.0072	85, 89, 91	09.4618.0289	35	51.0901.9600	31, 33	55.0602.0235	109
07.4529.0073	79, 81	09.4618.0361	35	51.0902.5800	29	55.0602.0237	109
07.4529.0110	89, 91	09.4618.0540	35	51.1000.0500	31, 33	55.0602.0238	109
07.4529.0114	81	09.4618.0563	35	51.1000.0600	31, 33	55.0602.0239	109
09.0704.0159	89, 91	09.4618.0652	37	51.1000.3000	31, 33	56.0008.0002	111
09.0801.0000	27	09.4618.0657	35	51.1000.4100	31, 33	56.0009.0003	111
09.0801.0016	89, 91	09.4627.0017	39	51.1300.5300	75	56.0009.0009	111
09.0801.0021	27	09.4629.0019	39	51.1301.2500	75	56.0010.0000	111
09.0802.0018	23	09.4632.0016	39	52.0900.0200	77	56.0010.0001	111
09.0803.0000	29	09.4632.0058	39	52.1100.6200	29	56.0010.0004	111
09.0803.0002	31, 33	09.4635.0014	39	53.0000.2700	89, 91	56.0010.0005	111
09.0803.0005	29	09.4635.0024	39	53.0100.2100	81	56.0010.0006	111
09.0803.0007	99, 101	09.4635.0039	39	53.0300.1500	85	56.0010.0007	111
09.0803.0008	99, 101	09.4636.0014	43	53.0400.1000	79	56.0012.0009	27
09.0803.0011	29	09.4645.0000	99, 101	53.0500.0400	87	56.0013.0000	103
09.0803.0012	29	09.4645.0003	99, 101	53.0800.0400	27	56.0013.0001	31, 33
09.0803.0013	31, 33	09.4645.0022	49	53.0800.0500	27	56.0013.0015	39
09.0803.0016	47	09.4655.0000	99, 101	53.3000.1300	105	56.0013.0028	105
09.0803.0023	29	09.4656.0000	99, 101	53.3001.0500	87	56.0016.0022	23
09.0803.0024	29	09.4661.0002	105	53.3001.0700	105	56.0021.0040	107
09.0803.0026	31, 33, 75	09.4661.0010	31	53.3001.1100	99, 101	56.0021.0062	107
09.0803.0027	101	09.4661.0014	105	53.3001.1800	99, 101	626544	53, 65
09.0803.0043	45, 79, 81, 83	09.4661.0016	105	53.3100.0020	99	626804	105
09.0803.0055	75	09.4661.0020	33	53.3100.0033	101	628275	59
09.0803.0109	99, 101	09.4661.0021	33	53.3200.0022	97	629327	59
09.0803.0177	29	09.4661.0022	33	53.3301.0002	31, 103	629733	59
09.0803.0178	29	09.4670.0000	31, 33	53.3302.0017	97	629735	59
09.0803.0225	23	09.4670.0001	97	53.3400.0600	47	630280	69
09.0803.0226	23	09.4670.0002	97	53.3400.7800	79	630328	57, 69
09.0803.0232	103	09.4670.0004	29, 95	53.3401.7700	47	630693	53, 65
09.0803.0238	89, 91	09.4670.0006	29	53.3401.7900	79	630846	55, 67
09.0803.0245	29, 97	51.0108.0000	29	53.3401.8000	83	632383	51, 55, 63, 67
09.0803.0251	99, 101	51.0200.7000	77	53.3401.8100	83	633069	57, 69
09.0803.0259	99, 101	51.0200.7100	77	53.3401.8500	81	633098	65
09.0803.0275	89, 91	51.0400.2600	93	53.3401.8600	81	633099	65
09.0803.0276	89, 91	51.0500.0100	27	54.0000.0008	27	633109	59
09.0803.0278	31, 33	51.0500.0900	27	54.0000.0013	89, 91	633161	59
09.0803.0358	12	51.0600.2200	31	54.0000.0027	31, 33	633174	55, 67
09.0803.0359	12	51.0600.4000	103	54.0000.0077	93	633176	55, 67, 73
09.0804.0100	95	51.0600.4300	33	54.0000.0083	75	633202	53, 55, 59, 67
09.0804.0900	95	51.0800.0400	29	54.0000.0123	85	633203	55, 67
09.0804.1000	95	51.0800.1000	29	54.0000.0126	89, 91	633204	67
09.0804.1100	95	51.0800.1100	29	54.0000.0132	85	634499	53, 65
09.0804.1200	95	51.0800.3800	31, 33	54.0000.0142	81	634501	53, 65
09.0804.1700	91	51.0801.9000	77	54.0000.0143	79	634546	55, 67
09.0805.0000	31, 33	51.0804.8700	111	54.0000.0145	27	634972	107
09.0805.0007	105	51.0804.9000	77	54.0000.0146	27	634973	107
09.0805.0053	99, 101	51.0805.1600	29	54.0001.0000	49	634974	107
09.0805.0054	99, 101	51.0806.1600	95	54.0001.0001	87	634981	95
09.0805.0057	99, 101	51.0806.1800	95	54.0001.0022	93	635574	85
09.0805.0058	99, 101	51.0806.2700	99, 101	54.0002.0030	93	635594	59
09.4601.0029	95	51.0806.2800	99, 101	54.0002.0031	93	635596	59
09.4604.0001	45	51.0806.3000	45	54.0003.0101	81	636440	69
09.4604.0004	105	51.0806.3800	77	54.0100.0020	29	636455	85
09.4604.0039	99, 101	51.0806.7200	29	54.0100.0056	75	637511	69
09.4610.0001	19	51.0806.7500	95	54.0100.0066	95	637513	111
09.4610.0002	29	51.0806.8200	31, 33	54.0101.0002	31	637536	59
09.4610.0011	29	51.0806.8900	97	54.0200.0000	77	637567	55, 67
09.4612.0212	35	51.0807.4200	29	54.0200.0001	77	637574	59, 69
09.4616.0040	35	51.0807.5200	89	54.0201.0003	77	637577	59
09.4616.0230	37	51.0807.5400	89	54.0201.0004	77	637582	59
09.4618.0010	35	51.0807.5500	31	54.0201.0017	79, 93	637584	59
09.4618.0022	35	51.0807.5700	99, 101	54.0702.0000	77	637621	69
09.4618.0026	37	51.0807.5900	99, 101	54.0702.0001	77	637650	107
09.4618.0030	37	51.0808.7600	49	54.0702.0004	77	637850	73
09.4618.0034	35	51.0809.3900	77	54.0702.0005	77	638226	25
09.4618.0053	37	51.0809.4000	77	54.0702.0028	81	638548	55, 57, 67, 69, 73
09.4618.0068	37	51.0809.8400	91	54.0800.0000	49	639289	55, 67
09.4618.0227	35	51.0810.2800	29	55.0208.0030	99, 101	639297	53, 65
09.4618.0230	35	51.0900.1500	99, 101	55.0403.0047	39	639298	53, 65
09.4618.0241	35	51.0901.5500	29	55.0601.0046	109	639300	53, 65
09.4618.0242	35	51.0901.6900	11-12	55.0602.0129	23	639301	53, 65
09.4618.0243	35	51.0901.8100	29	55.0602.0205	109	639302	53, 65
09.4618.0261	35	51.0901.8200	87	55.0602.0231	109	639303	53, 65
09.4618.0271	35	51.0901.8700	29	55.0602.0233	109	639328	59
09.4618.0288	35	51.0901.9500	99, 101	55.0602.0234	109	639329	59

Part Number	Page	Part Number	Page
639352	65	639819	59
639395	87	639820	59
639624	55, 67	639821	59
639630	55, 67	639828	53
639631	55, 67	640125	95
639633	53	640196	59
639637	55, 67	640198	59
639639	55, 67	640199	59
639640	55, 67	640206	53
639641	55, 67	640207	53
639642	55, 67	640214	55
639643	55, 67	640216	55, 67
639645	55, 67	640270	61, 71
639646	55, 67	640536	79
639647	55, 67	640537	27
639650	53, 65	640715	63
639651	53, 65	640717	65
639653	65	640718	55, 67
639657	53, 65	640719	67
639659	65	640720	55, 67
639660	53, 65	640728	55, 67
639661	53, 65	640729	55, 67
639662	53, 65	640730	55, 67
639664	53, 65	640731	69
639668	51, 63	640732	69
639670	51, 63	640885	99, 101
639671	61, 71	640908	55, 67
639674	57, 69	640909	55, 67
639675	57	641089	53
639676	57, 69	641090	53
639679	57, 69	641124	95
639681	57, 69	900130	49
639682	57, 69	901777	69
639683	57, 69	992989	43
639684	65	999058	95
639685	65		
639686	65		
639689	69		
639691	69		
639692	69		
639693	69		
639695	57, 69		
639696	69		
639778	59		
639779	59		
639780	59		
639781	59		
639782	59		
639784	59		
639785	59		
639787	59		
639789	59		
639790	59		
639791	59		
639792	59		
639793	59		
639794	59		
639796	59		
639797	59		
639798	59		
639799	59		
639800	59		
639802	59, 65		
639803	59		
639804	59		
639807	59		
639808	59		
639809	59		
639810	59		
639811	59		
639812	59		
639813	59		
639814	59		
639815	59		
639816	59		
639818	59		

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

- 1**
1st Telescopic Element.....77
- 2**
2nd Telescopic Element.....77
- 6**
604872 pos. 59.....41
604878 pos. 13.....105
604878 pos. 23.....105
604878 pos. 25.....105
604895 pos. 5.....87
604896 pos. 14.....79
- A**
Accumulator.....47
Adhesive Profile.....15, 17
Air Inlet.....21
Airinlet.....33
Arm.....11–12, 55, 67
Articulated Tie Rod.....61, 71
Articulation.....99, 101
- B**
Back-Up Ring.....57, 69, 79, 81
Ball-Grip.....11–12, 19, 21
Battery.....111
BEARING.....53, 55, 59, 65, 67
Bearing.....55, 59, 65, 67
Bellow.....89, 91
Bevel Gear Set.....53, 65
BLEEDER VALVE, LONG.....57, 69
Block.....89, 91
Board With Led'S.....25
Bracket.....11–12, 31, 89, 91, 97, 99, 101, 111
Brake Disc.....57, 69
BRAKE DISC, INTERMEDIATE.....57, 69
Bubble Level.....19
Bulb.....111
Bushin.....55, 67, 69, 73
Bushing.....11–12, 15, 17, 27, 55, 67, 73, 77, 79, 89, 91, 93
- C**
Cable.....49, 99, 101
CAP.....55, 57, 67, 69, 73
Cap.....89, 91
Cardan Joint Assembly Kit.....39
Cardan Shaft.....39
Cartridge.....45, 99, 101
CASE, DIFFERENTIAL.....65
Chain.....33, 75
Clamp.....21, 31, 33, 47, 81, 99, 101, 105
Clip.....15, 31, 33
Coating.....15, 17
Collar.....99, 101
Complete Air Filter.....99, 101
Complete Filter.....45
Complete Radiator.....97
Complete Turn Signal.....111
Connector.....111
Contact.....19
Control Lever.....89, 91
Control Panel.....25
Control Valve.....89, 91
Conveyor.....97
Cotter Pin.....49, 93
Counterweight.....31, 33
COVER.....51, 59, 63
Cover.....19, 55, 59, 63, 67, 103
Cylinder.....27, 29, 59, 61, 71, 81, 85, 87, 89, 91
Cylinder Packing Kit.....81
- D**
Dashboard.....19
Diesel Engine.....95
Diesel Oil Filter.....95
Diesel Oil Tank.....31, 33
Differential.....53, 65
Differential Case.....53
Differential Pinion.....53
Differential Side Gear.....53
Disc.....53
Display.....23
Door Stop.....11–12
DOWEL.....57, 69
Dowel.....15, 59
Drilled Screw.....47, 79
Driving Mirror.....11–12, 29
- E**
Elastic Joint.....95
Emergency Button.....19
End Piece.....85
Exhaust Muffler.....99, 101
- F**
Fan.....97
Female Coupling.....87
Filter.....11–12, 105
Flange.....45, 59, 65, 95
Flexible Hose.....27, 41, 43, 45, 47, 79, 81, 83, 85, 87, 89, 91, 97, 103, 105
Flexible Hose from SN 15377.....41
Fork.....75
Fork Coupling Attachment.....93
Forks Articulation Cylinder.....79
Frame.....11–12, 15, 17, 29
Front Axle.....39
Fuel Gauge.....31, 33
Fuse.....107, 111
FUSE, 10A.....107
FUSE, 15A.....107
FUSE, 3A.....107
FUSE, 7.5A.....107
- G**
Gas Cable.....99, 101
Gear.....59
GEAR, DIFFERENTIAL SIDE.....65
GEAR, SATELLITE.....65
Glass.....11–12, 15, 17, 19, 25, 111
Grate.....11–12
GREASE NIPPLE.....55, 67, 73
Grease Nipple.....15, 17, 49, 55, 67, 77, 85, 89, 91, 93
GRUBSCREW.....69
Guard.....11–12, 29, 31, 33, 87, 97, 99, 101
- H**
Half Flange.....45
Half-Joint.....95
Handle.....11–12, 15, 17, 29, 31, 33
Handwheel Arrangement.....95
Hatch.....29
Heater.....21
Hex Cap.....11–12, 15, 17, 21
Hinge.....11–12, 15, 17, 29, 31, 33
Hook (Latch).....29
Horn.....111
Hour Meter.....25
Housing.....51, 55, 59, 63, 67, 107
HUB.....95
Hub.....55, 67
Hydraulic Motor.....45
- I**
Indicator.....25, 45, 77
Insulation.....97
Insulator.....29, 95, 97, 103
- J**
Joint.....55, 67
Joint Kit.....27, 41, 43, 61, 71, 79, 85, 87, 89, 91
JOINT, ARTICULATED.....55, 67
- K**
Key.....15, 17, 25
Kit.....11–12
- L**
Label.....15, 17, 35, 37
Left Counterweight.....31, 33
Level Indicator.....105
Lever.....49, 69, 89, 91, 99, 101
Lever-Fitted Lock.....15, 17
Light.....111
Load Cell.....23
Loadspeaker Frame.....11–12
Lock.....11–12, 15, 19, 29
Lower Door.....15, 17
- M**
Magnet.....12
Male Coupling.....87
Manifold.....87, 99, 101, 105
Mud-Guard.....29
- N**
Name Plate.....21, 37
Non-Skid Coating.....15, 17
Nut.....11–12, 15, 17, 27, 31, 33, 47, 53, 55, 59, 65, 67, 69, 75, 79, 81, 89, 95, 97, 99, 101, 103, 105
Nut, M6.....29, 31, 33, 93, 99, 101, 105
NUT, DIN439 JAM M16-2.0 P.....55, 67
- O**
O-RING.....57, 59, 65, 69
Oil Filter.....95
Oil Tank.....103

P

Panel.....17, 91
 Paper Piping.....21
 Pedal.....99, 101
 Pin.....15, 17, 27, 31, 33, 49, 53, 55, 65, 67, 75,
 79, 81, 85, 87, 89, 91, 93
 PINION,DIFFERENTIAL.....55, 67
 Pipe.....47, 79, 81, 83
 Pipe Fitting.....21, 27, 41, 43, 45, 47, 55, 67, 79,
 81, 83, 85, 87, 89, 91, 97, 103, 105
 Piston.....57, 59, 69
 Pivoting Beacon.....111
 Plain Washer.....29, 31, 33, 39, 45, 49, 85, 87,
 91, 93, 95, 97, 99, 101, 103, 105
 Plate.....29, 49, 75
 PLATE,COVER.....59
 PLATE,LOCKING.....55, 67
 Plug.....15, 17, 19, 25, 31, 33, 51, 55, 59, 63,
 67, 89, 91, 105
 PLUG,BREATHING.....51, 59, 63
 PLUG,MAGNETIC.....59
 Power Steering.....43
 Precleaner.....99, 101
 Pressure Switch.....47
 Pressure Tube.....45, 103
 Protection.....29, 95
 Proximity Switch.....27, 39, 49, 89, 91, 99, 101
 Pull Box.....111
 Pulley.....49, 95
 Pump.....47, 95
 Push Button.....89, 91

R

Radiator Core.....97
 Rain Protector.....101
 Rear Axle.....39
 Reduction.....21
 Reinforcement.....15, 17
 Relay.....107, 111
 Removing Battery.....111
 Retainer.....31, 33
 Retainer Pipe.....45, 79, 83, 99, 101
 Right Counterweight.....31, 33
 Rim.....39
 RING GEAR.....55, 67
 Ring Nut.....53, 65
 RING/SEAL.....59
 Rivet.....19
 Road Pad.....27
 ROD.....59
 Rod.....31, 33
 Roof Lamp.....11-12
 Rope.....12
 Rubber.....11-12, 15, 17, 21, 97
 Rubber Hose.....21, 31, 33, 99, 101, 105
 Rubber Platform.....15, 17
 Rubber Protection.....59

S

SCREW.....59
 Screw.....11-12, 15, 17, 19, 21, 23, 27, 29, 31,
 33, 39, 43, 45, 47, 49, 53, 55, 57, 59, 61, 65,
 67, 69, 71, 75, 77, 79, 81, 83, 85, 87, 89, 91,
 93, 95, 97, 99, 101, 105
 Screw from SN 15377.....41
 Screw to SN 15378.....41
 SEAL.....53, 55, 57, 59, 67, 69

Seal.....11-12, 15, 17, 29, 31, 45, 51, 55, 59,
 63, 67, 69, 79, 81, 85, 89, 91, 97, 103, 105
 SEAL KIT.....43
 SEAL RING.....59
 SEAL,DIFFERENTIAL.....65
 SEAL,PLANETARY.....55, 67
 Seat.....15, 17
 Security Dowel.....75
 Security Switch.....19, 59
 Selector.....25
 Selector Fork.....59
 Selector Shaft.....59
 SHAFT.....59
 Shaft.....59
 Sheath.....99, 101
 Sheet.....11-12, 59
 SHIM.....59
 SHIM,THICKNESS.....59
 SLEEVE.....59
 Sleeve.....45
 SLIDING GUIDE.....59
 Sliding Guide.....77, 81
 Snap Ring.....49, 51, 53, 55, 65, 67, 95
 SNAP RING (CIRCLIP).....67
 Solenoid.....41, 43, 45, 85, 89, 91
 Solenoid Valve.....41, 43, 45
 Solenoid Valve to SN 15378.....41
 SPACER.....53, 65
 Spacer.....11-12, 31, 53, 59, 65, 69, 77
 Speed Lever.....19
 Sphere.....59
 SPLIT PIN.....59
 Split Pin.....11-12, 15, 17, 95
 Spring.....19, 49, 57, 59, 69, 99, 101
 Spring Split Pin.....31, 33, 75
 Spring Washer.....11-12, 23, 29, 31, 33, 41, 43,
 45, 49, 59, 77, 81, 85, 87, 89, 91, 95, 97, 99,
 101, 105
 Stabilizer.....27
 Star Wheel.....39
 Starting Switch.....25
 Steering Column.....43
 Steering Wheel.....43
 Stop.....11-12
 Stop Belt.....15, 17
 Stop Nut.....11-12, 15, 17, 21, 29, 31, 33, 39,
 49, 85, 89, 91, 99, 101
 Storage Pocket.....11-12
 Stud.....53, 55, 67
 Stuffing Box.....111
 Sun Visor.....17
 Support.....11-12, 15, 17, 21, 29, 31, 45, 49,
 55, 67, 73, 77, 95, 99, 101, 111
 SUPPORT,RING GEAR.....55, 67
 Switch.....19, 25
 SWITCH,SELECTOR,3 POSITION.....25

T

Tank.....11-12
 Tap.....21, 45, 105
 Thickness.....55, 59, 67, 77
 THREADED ELEMENT.....69
 Through Coupling.....11-12
 Tie Rod.....31, 33
 Transmitter.....103
 Tube.....99, 101
 Turn Signals Lever.....19
 Tyre.....39

U

Upper Door.....15
 Upper Door Complete.....17

V

Valve.....27, 45, 79, 81, 85, 87, 89, 91, 103, 105

W

WASHER.....65, 95
 Washer.....11-12, 15, 17, 19, 21, 23, 29, 31,
 33, 41, 43, 45, 47, 49, 55, 59, 67, 75, 79, 81,
 87, 89, 91, 95, 99, 101, 103, 105
 WASHER,FRICTION.....53, 65
 WASHER,SEALING.....59
 Wheel.....39
 Wiper Arm.....11-12
 Wiper Blade.....11-12
 Wiper Motor.....11-12
 Wiring Harness.....23, 109

This Page Intentionally Left Blank

California Proposition 65

Warning

The exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Genie North America

Phone 425.881.1800
Toll Free USA and Canada
800.536.1800
Fax 425.883.3475

Genie Australia Pty Ltd.

Phone +61 7 3375 1660
Fax +61 7 3375 1002

Genie China

Phone +86 21 53852570
Fax +86 21 53852569

Genie Malaysia

Phone +65 98 480 775
Fax +65 67 533 544

Genie Japan

Phone +81 3 3453 6082
Fax +81 3 3453 6083

Genie Korea

Phone +82 25 587 267
Fax +82 25 583 910

Genie Brasil

Phone +55 11 41 665 755
Fax +55 11 41 665 754

Genie Holland

Phone +31 183 581 102
Fax +31 183 581 566

Genie Scandinavia

Phone +46 31 575100
Fax +46 31 579020

Genie France

Phone +33 (0)2 37 26 09 99
Fax +33 (0)2 37 26 09 98

Genie Iberica

Phone +34 93 579 5042
Fax +34 93 579 5059

Genie Germany

Phone +49 (0)4202 88520
Fax +49 (0)4202 8852-20

Genie U.K.

Phone +44 (0)1476 584333
Fax +44 (0)1476 584334

Genie Mexico City

Phone +52 55 5666 5242
Fax +52 55 5666 3241

Distributed By:

Parts Manual

GTH-4010 AU.2

from SN 13967 to 16124

Part No.
645009

Rev B

