



Parts Manual

Serial Number Range

GTH-6622

from SN 10816 to 18723

Part No. 645011

Rev B

April 2010

Technical Publications

Terexlift has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Terexlift policy. Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Terexlift of errors and send in suggestions for improvement. All communications will be carefully considered for future printings of this and all other manuals.

Contact Us:



www.genieindustries.com
e-mail: awp.techpub@terex.com

The technical data contained in this document is indicative and not binding, insofar as TEREXLIFT S.r.l reserves the right to make modifications and improvements to its products at any time in order to enhance the quality thereof.


57.0407.5000 Rev A December 2004
First Edition, First Printing

 Printed on recycled paper

Printed in Italy

Chassis serial number

(The chassis serial number is punched on the front right part of the chassis side member)

**Machine data plate**

(On machines destined for the Italian market, the machine data plate is installed in the driving cab, on the right, and is well-visible when the door is opened. On the machines destined for foreign markets, the data plate is applied on the front right side of the chassis)

TEREX^{LIFT} s.r.l.	
ZONA INDUSTRIALE - 06019 UMBERTIDE (PG) - ITALY Tel. +39 075 941.811 Fax +39 075 941.53.82	
MODELLO - MODEL - MODELE - TYP - MODELO	
ANNO DI COSTRUZIONE - YEAR OF CONSTRUCTION - ANNEE DE CONSTRUCTION BAUJAHR - AÑO DE FABRICACIÓN	
MATRICOLA - SERIAL N. - N. DE SERIE - FZ.-IDENT NR. - NO. DE SERIE	
PESO MAX ASSALE ANT. - MAX FRONT AXLE WEIGHT - POIDS MAX ESSIEU AVANT ZUL. ACHSLAST VO. N. ST VZO - PESO MAX EJE ANTERIOR	kg
PESO MAX ASSALE POST. - MAX REAR AXLE WEIGHT - POIDS MAX ESSIEU ARRIERE ZUL. ACHSLAST HI. N. ST VZO - PESO MAX EJE POSTERIOR	kg
PESO TOTALE - TOTAL WEIGHT - POIDS TOTAL - ZUL. GESAMTGEWICHT N. ST VZO PESO TOTAL	kg
MATRICOLA MOTORE TERMICO - ENGINE SERIAL N. - N. MOTEUR THERMIQUE FABRIK NR. DIESEL MOTOR - NO. DE SERIE MOTOR TERMICO	
POTENZA MOTORE TERMICO - ENGINE POWER - PUISSANCE MOTEUR MOTORLEISTUNG - POTENCIA MOTOR	kW
CARICO STATICO VERT. GANCIO DI TRAINO-MAX.VERTICAL LOAD ON THE COUPLING HOOK-EFFORT VERTICAL MAXIMAL SUR LE CROCHET D'ATTELAGE MAXIMALE STUTZLASTBEANSPRUCHUNG DES ZUGHAKENS IN VERTIKALER RICHTUNG- ESFUERZO VERTICAL SOBRE EL GANCHO DE TRACCION	kg
MASSA MAX. RIMORCHIABILE - MAX.DRAWBAR PULL AT THE COUPLING HOOK EFFORT THE TRACTION - MAXI AU CROCHET D'ATTelage-MAXIMALE ZUGBEANSPRUCHUNG AM ZUGHAKEN-MAXIMO ESFUERZO DE TRACCION EN EL GANCHO DE TRACCION	kg
OMOLOGAZIONE	
FABBRICATO IN ITALIA - MADE IN ITALY	
CE	

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genieindustries.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genieindustries.com.

How to Read Your Serial Number.....	3
Parts Stocking List.....	7
How to Order Parts.....	8
Service Parts Fax Order Form.....	9

Electronic Version

Click on any page number to view the figure.

100 Cab and Control Place Unit

101.1 04.4236.0045 Control Valve.....	10
102.1 04.4237.0010 Control Lever.....	12
103.1 04.4240.0042 Solenoid Valve.....	14
104.1 604750 Dashboard.....	16
105.1 604751 Cab.....	18
106.1 604752 Cab Heater.....	20
107.1 604766 Hydraulic System.....	22
108.1 604767 Hydraulic System - Pilotages.....	24
109.1 604787 Cab - Door And Glasses.....	26

200 Frame Unit

201.1 604753 Frame.....	28
202.1 604754 Rear Frame Unit.....	30
203.1 604774 Label - Name Plate.....	32
204.1 604775 Label - Name Plate.....	34

300 Transmission Unit

301.1 604757 Transmission And Wheels.....	36
302.1 604761 Hydraulic System - Negative Brake.....	38
303.1 604762 Power Steering System.....	40
304.1 604765 Hydraulic System - Transmission.....	42
305.1 604776 Differential Case.....	44
306.1 604777 Front Differential Gear.....	46
307.1 604778 Front Steering Axle.....	48
308.1 604779 Brake.....	50
309.1 604780 Reduction Gear.....	52
310.1 604781 Steering Cylinder.....	54
311.1 604782 Differential Case.....	56
312.1 604783 Rear Differential Gear.....	58
313.1 604784 Rear Steering Axle.....	60
314.1 604785 Steering Cylinder.....	62
315.1 604786 Support.....	64

400 Telescopic Boom Unit

401.1 604755 Arm.....	66
402.1 604756 Forks.....	68
403.1 604768 Hydraulic System - Implement Locking.....	70

404.1 604769 Hydraulic System - Fork Balancing.....	72
405.1 604770 Hydraulic System - Lifting And Boom Extension.....	74
406.1 604771 Hydraulic System - Auxiliary Circuits.....	76

500 Diesel Engine Unit

501.1 604758 Diesel Engine - Hydraulic Pump.....	78
502.1 604759 Diesel Engine - Engine Cooling System.....	80
503.1 604760 Diesel Engine - Suction - Exhaust - Accelerator (to SN 15882).....	82
504.1 604760 Diesel Engine - Suction - Exhaust - Accelerator (from SN 15883).....	84
505.1 604763 Hydraulic System - Tank And Exchanger.....	86
506.1 604764 Suction System - Facilities Pump.....	88

600 Electric Installation Unit

601.1 604772 Electric Installation.....	90
602.1 604773 Fuse Holding Box.....	92

Indices

Part Number Index.....	94
Part Description Index.....	98

Cross References

Fittings Cross Reference.....	100
-------------------------------	-----

This Page Intentionally Left Blank

Notes

[illegible]

Required Parts

The following parts are required to perform maintenance procedures as outlined in the GTH 6622 Operator's and Service Manuals.

Description	Part No.
Diesel Fuel Filter.....	07.4501.0068
Engine Oil Filter.....	07.4501.0067
Hydraulic Oil Filter Cartridge	07.0700.0000
Engine Internal Air Filter	640885
Engine Exsternal Air Filter	07.4501.0041
Oil Filter Immersed in the Tank.....	09.4604.0004

Used Varnishes

Description	Type
Terex Grey	RAL 7012
Terex White	RAL 1013
Terex Matte Black for Cylinders.....	RAL 9005
Genie Blue	
Genie Grey	
Genie Mat Black for Cylinders.....	RAL 9005

Manuals

Terexlift offers the following support documents for these models:

Title	Part No.
Genie GTH 6622 Operator's Manual, 1 st edition.....	57.0005.8200
Genie GTH 6622 Service Manual, 2 nd edition.....	57.4401.2200

Part list abbreviations

ZN	Zinc-plated
RNFT	Reinforced
FLNG	Flanged
PSNT	Heavy type
OC	Eye
PSRT	Through-coupling
CNTF	Hole centre

How To Order Parts

Please be prepared with the following information when ordering replacement parts for your Genie product:

- ☒ Machine model number
- ☒ Machine serial number
- ☒ Genie part number
- ☒ Part description and quantity
- ☒ Purchase order number
- ☒ "Ship to" address
- ☒ Desired method of shipment
- ☒ Name and telephone number of the authorized
Genie Distributor in your area

Use the Service Parts Fax Order Form on the next page and fax your order to our Parts Department.

If you don't know the name of your authorized distributor, or if your area is not currently serviced by an authorized distributor, please call Genie Industries.

Machine Information

Model

Serial Number

Date of Purchase

Authorized Genie Distributor

Phone Number

Genie North America

Telephone (425) 556-6551

Toll Free (877) 367-5606 in U.S.A. and Canada

Fax (425) 556-8659

Genie UK

Parts Telephone (44) (0) 1476 584352

Parts Fax (44) (0) 1476 584340

Genie Australia

Parts Telephone (617) 03375 1660

Parts Fax (617) 03375 1002

Genie France

Parts Telephone (33) (0) 237 26 09 99

Parts Fax (33) (0) 237 31 50 10

Genie Germany

Parts Telephone (49) (0) 4202 885223

Parts Fax (49) (0) 4202 885225

Genie Scandinavia

Parts Telephone (46) (31) 3409612

Parts Fax (46) (31) 3409613

Genie Iberica

Parts Telephone (34) (93) 5795042

Genie Brazil

Parts Telephone (55) (114) 1665755

Parts Fax (55) (114) 1665754

Genie Japan

Parts Telephone (81) (33) 4536082


Parts Fax (81) (33) 4536083

Genie China

Parts Telephone (86) (215) 3852570


Parts Fax (86) (215) 3852569

101.1 04.4236.0045 Control Valve




Item	Part No.	Description	Qty.
1	07.0704.0038	Valve.....	2
2	07.0704.0145	Plug.....	2
3	07.0704.0113	Cap Kit.....	4
4	07.0704.0033	Cursor.....	1
5	07.0704.0034	Cursor.....	2
6	07.0704.0035	Cursor.....	1
7	07.0704.0045	Plug.....	1
8	01.0023.0054	Stop Nut.....	3
9	01.0031.0055	Washer.....	6
10	01.0001.0209	Screw.....	3
11	07.0704.0042	Valve.....	1
12	07.0704.0032	Control Valve.....	1
13	07.0704.0144	Plug.....	4

102.1 04.4237.0010 Control Lever




Item	Part No.	Description	Qty.
1	07.0704.0133	Control Lever.....	1
2	07.0704.0118	Red Pushbutton Cap.....	1
3	07.0704.0117	Push Button.....	2
4	07.0704.0119	Yellow Pushbutton Cap.....	1
5	07.0704.0134	Protection.....	1
6	07.0704.0136	Articulation.....	1
7	07.0704.0138	Cursor.....	4
8	07.0704.0137	Body.....	1
9	07.0704.0169	Flange.....	1

103.1 04.4240.0042 Solenoid Valve




Item	Part No.	Description	Qty.
1	07.0704.0037	Plug.....	1
2	07.0704.0046	Control Valve.....	1
3	07.0704.0146	Cursor.....	1
4	07.0704.0040	Spring Kit.....	1
5	01.0023.0054	Stop Nut.....	2
6	01.0031.0055	Washer.....	4
7	01.0001.0206	Screw.....	2
8	07.0704.0143	Solenoid.....	2
9	07.0704.0049	Solenoid Tube Kit.....	1

104.1 604750 Dashboard




Item	Part No.	Description	Qty.
1	52.1200.1100	Plug.....	1
2	52.1200.0700	Dashboard.....	1
3	52.1200.3900	Dashboard.....	1
4	52.1200.3800	Dashboard.....	1
5	52.1200.3700	Dashboard.....	1
6	07.0703.0472	Starting Switch.....	1
7	641065	Selector.....	1
8	07.0703.0087	Switch.....	2
9	07.0703.0455	Glass.....	1
10	07.0703.0089	Plug.....	2
11	56.0016.0073	Indicator.....	1
12	641053	Hour Meter.....	1
13	56.0016.0072	Indicator.....	1
14	07.0703.0479	Speed Lever.....	1
15	07.0703.0458	Glass.....	1
16	07.0703.0473	Glass.....	1
17	07.0703.0459	Glass.....	1
18	07.0703.0457	Pilot Light.....	1
19	640495	Dashboard.....	1
20	640496	Right Dashboard.....	1
21	640497	Left Dashboard.....	1
22	07.0703.0477	Glass.....	1
23	07.0703.0056	Guard.....	1
24	07.0723.0074	Washer.....	18
25	07.0723.0039	Screw.....	18
26	07.0703.0476	Switch.....	2
27	07.0723.0039	Screw.....	-
28	07.0723.0074	Washer.....	-
29	07.0723.0104	Retainer.....	-
30	07.0703.0052	FRAME, SWITCH.....	8
31	07.0703.0113	Name Plate.....	1
32	07.0703.0474	Glass.....	1
33	07.0723.0104	Retainer.....	1
34	07.0723.0192	Air Inlet.....	3
35	07.0703.0206	Pilot Light.....	1
36	07.0703.0610	Glass.....	1
37	07.0703.0077	Glass.....	1
38	07.0703.0088	Switch.....	1
39	07.0703.0611	Switch.....	1

105.1 604751 Cab




Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0723.0198	Grate.....	1	41	01.0031.0299	Plain Washer.....	2
2	07.0723.0049	Seal.....	2	42	07.0723.0283	Grate.....	1
3	07.0723.0169	Screw.....	2	43	07.0723.0147	Coating.....	1
4	07.0723.0170	Washer.....	7	44	07.0723.0187	External Sound-Proofing.....	1
5	07.0723.0096	Rubber.....	2	45	07.0723.0138	Bracket.....	1
6	07.0723.0171	Rubber.....	2	46	07.0723.0162	Screw.....	2
7	07.0723.0168	Glass.....	1	47	09.4610.0025	Shock Absorber.....	1
8	07.0723.0148	Coating.....	1	48	07.0723.0352	Support.....	1
9	07.0723.0024	Driving Mirror.....	1	49	01.0001.0010	Screw.....	4
10	07.0723.0142	Level Gauge.....	1	50	01.0031.0299	Plain Washer.....	8
11	07.0703.0508	Pvc Back.....	1	51	01.0023.0064	Stop Nut.....	8
12	641009	Coating.....	1	52	01.0003.0944	Screw.....	4
13	07.0723.0196	Guard.....	1				
14	07.0723.0039	Screw.....	19				
15	07.0723.0074	Washer.....	19				
16	07.0723.0011	Roof Lamp.....	1				
17	07.0723.0197	Seal.....	4				
18	07.0723.0145	Coating.....	1				
19	07.0723.0146	Coating.....	1				
20	07.0723.0150	Coating.....	1				
21	09.4610.0024	Seat.....	1				
22	51.1100.0014	Frame.....	1				
23	07.0723.0186	External Sound-Proofing.....	1				
24	07.0723.0055	Plug.....	1				
25	07.0723.0054	Plug.....	2				
26	07.0723.0214	Lock.....	1				
27	07.0740.0347	Rubber Platform.....	1				
28	07.0703.0509	Seat.....	1				
29	07.0723.0215	Plug.....	8				
30	07.0723.0076	Washer.....	4				
31	07.0723.0040	Screw.....	2				
32	07.0723.0217	Guard.....	1				
33	07.0703.0465	Safety Belt.....	1				
34	07.0723.0111	Washer.....	2				
35	07.0723.0173	Washer.....	2				
36	09.4610.0003	Driving Mirror.....	1				
37	01.0001.0503	Screw.....	2				
38	01.4032.0005	Spring Washer.....	2				
39	01.0031.0057	Plain Washer.....	2				
40	01.0001.0252	Screw.....	2				

106.1 604752 Cab Heater



Item	Part No.	Description	Qty.
1	07.0723.0191	Lock.....	1
2	640985	Heater.....	2
3	07.0723.0010	Air Inlet.....	2
4	07.0723.0192	Air Inlet.....	3
5	04.0227.0051	Clamp.....	6
6	640990	Paper Piping.....	1,5
7	04.4227.0000	Clamp.....	2
8	07.0723.0193	Tap.....	1
9	07.0723.0194	Rubber Hose.....	3,5
10	07.0723.0194	Rubber Hose.....	1,8
11	07.0723.0194	Rubber Hose.....	2,0
12	01.0023.0053	Nut, M6.....	1
13	07.0723.0108	Air Inlet.....	1
14	07.0723.0109	Screw.....	6
15	01.0031.0054	Washer.....	2
16	07.0723.0159	Lock.....	1
17	04.0600.0080	Pipe Fitting.....	2
18	04.0600.0161	Pipe Fitting.....	2
19	04.0600.0162	Knurled Coupling.....	2
20	06.0442.0057	Plain Washer.....	2
21	07.0723.0149	Filter.....	1
22	07.0723.0090	Ball-Grip.....	1
23	07.0723.0076	Washer.....	1


107.1 604766 Hydraulic System



107.1 604766 Hydraulic System

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	01.0023.0054	Nut.....	3	38	07.4529.0028	Joint Kit.....	1
2	51.0808.6000	Bracket.....	1	39	07.0704.0128	Solenoid.....	1
3	06.0442.0054	Washer.....	1	40	04.4225.0005	Valve.....	1
4	01.0001.0256	Screw.....	1	41	04.0607.0140	Pipe Fitting.....	1
5	04.4210.0016	Pressure Tube.....	1	42	04.0600.0031	Pipe Fitting.....	1
6	04.0605.0507	Flexible Hose.....	1	43	53.3001.0800	Manifold.....	1
7	04.0607.0114	Pipe Fitting.....	6	44	04.0605.0232	Flexible Hose.....	1
8	04.0600.0159	Pipe Fitting.....	2	45	04.0605.0252	Flexible Hose.....	1
9	04.4227.0003	Clamp.....	1	46	06.0442.0101	Washer.....	1
10	01.0001.0206	Screw.....	3	48	04.0600.0160	Pipe Fitting.....	1
11	04.0605.0280	Flexible Hose.....	1	49	04.0605.0277	Flexible Hose.....	1
12	01.0031.0055	Washer.....	6	50	04.0605.0213	Flexible Hose.....	1
13	04.0607.0113	Pipe Fitting.....	11	51	04.0220.0051	Plug.....	1
14	04.0605.0271	Flexible Hose.....	1	52	04.0220.0059	Plug.....	1
15	04.0607.0131	Pipe Fitting.....	1	53	53.3000.1100	Conveyor.....	1
16	04.0605.0235	Flexible Hose.....	1	54	06.0442.0105	Washer.....	2
17	06.0442.0105	Washer.....	1	55	04.0600.0013	Pipe Fitting.....	1
18	04.0600.0013	Pipe Fitting.....	1	56	04.0607.0117	Pipe Fitting.....	1
19	06.0442.0102	Washer.....	3	57	04.0607.0139	Pipe Fitting.....	1
20	04.0600.0025	Pipe Fitting.....	1	58	04.0605.0193	Flexible Hose.....	1
21	01.0001.0254	Screw.....	2	60	04.0607.0115	Pipe Fitting.....	1
22	01.4032.0003	Washer.....	2	61	04.0605.0267	Flexible Hose.....	1
23	51.0806.3500	Support.....	1				
24	01.0001.0106	Screw.....	2				
25	04.0605.0179	Flexible Hose from SN 15088.....	1				
25	04.0605.0583	Flexible Hose to SN 15089.....	1				
26	04.0600.0021	Pipe Fitting.....	2				
27	04.4239.0019	Valve.....	1				
28	01.0023.0053	Nut, M6.....	2				
29	04.0607.0140	Pipe Fitting.....	2				
30	04.0605.0185	Flexible Hose.....	1				
31	04.0605.0178	Flexible Hose.....	1				
32	04.0605.0178	Flexible Hose from SN 15088.....	1				
32	04.0605.0582	Flexible Hose to SN 15089.....	1				
33	04.0605.0179	Flexible Hose from SN 15088.....	1				
33	04.0605.0583	Flexible Hose to SN 15089.....	1				
34	04.0605.0178	Flexible Hose.....	1				
35	04.4239.0032	Pipe Fitting.....	1				
36	04.4240.0015	Valve.....	1				
37	04.0607.0112	Pipe Fitting.....	2				


108.1 604767 Hydraulic System - Pilotages



108.1 604767 Hydraulic System - Pilotages

Item	Part No.	Description	Qty.
1	04.4210.0024	Pipe Fitting.....	10
2	04.0607.0114	Pipe Fitting.....	7
3	04.0605.0224	Flexible Hose.....	1
4	04.0605.0242	Flexible Hose.....	1
5	04.0605.0269	Flexible Hose.....	1
6	04.0605.0180	Flexible Hose from SN 15088.....	1
6	04.0605.0587	Flexible Hose to SN 15089.....	1
7	04.0605.0269	Flexible Hose.....	1
8	04.0605.0180	Flexible Hose from SN 15088.....	1
8	04.0605.0587	Flexible Hose to SN 15089.....	1
9	04.0605.0220	Flexible Hose.....	1
10	04.0605.0270	Flexible Hose.....	1
11	04.0605.0211	Flexible Hose from SN 15088.....	1
11	04.0605.0584	Flexible Hose to SN 15089.....	1
12	04.0607.0112	Pipe Fitting.....	1
13	04.4240.0042	Solenoid Valve.....	1
14	04.4236.0045	Control Valve.....	1
15	04.4237.0010	Control Lever.....	1


109.1 604787 Cab - Door And Glasses



109.1 604787 Cab - Door And Glasses


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0723.0174	Seal.....	1	40	07.0723.0057	Screw.....	3
2	07.0723.0169	Screw.....	2	41	07.0723.0137	Screw.....	4
3	07.0723.0170	Washer.....	8	42	07.0723.0156	Handle.....	1
4	07.0723.0096	Rubber.....	2	43	07.0723.0188	Lock.....	1
5	07.0723.0171	Rubber.....	2	44	07.0723.0287	Frame.....	1
6	07.0723.0045	Key.....	1	45	07.0723.0157	Handle.....	1
7	07.0723.0163	Glass.....	1	46	07.0723.0291	Glass.....	1
8	07.0723.0190	Seal.....	1	47	07.0723.0341	Lower Door.....	1
9	07.0723.0176	Screw.....	2	48	640996	Plate.....	1
10	07.0723.0134	Plain Washer.....	6	49	07.0723.0173	Washer.....	4
11	07.0723.0177	Screw.....	4	50	07.0723.0175	Screw.....	5
12	07.0723.0179	Rubber.....	4	51	07.0723.0140	Stop Belt.....	1
13	07.0723.0152	Seal.....	1	52	07.0723.0165	Glass.....	1
14	07.0723.0289	Frame.....	1	53	07.0723.0219	Glass.....	1
15	07.0723.0161	Pin.....	4	54	07.0723.0223	Rubber.....	1
16	07.0723.0343	Hinge.....	6	55	07.0723.0220	Seal.....	1
17	07.0723.0154	Seal.....	6	56	07.0723.0221	Wiper Motor.....	1
18	07.0723.0288	Glass.....	1	57	07.0723.0228	Guard.....	1
19	640995	Hook..... Latch	1	58	07.0723.0202	Washer.....	2
20	07.0703.0088	Switch.....	1	59	07.0723.0135	Nut.....	1
21	07.0703.0077	Glass.....	1	60	07.0723.0232	Washer.....	1
22	07.0723.0290	Seal.....	1	61	07.0723.0231	Nut.....	1
23	07.0723.0182	Screw.....	1	62	07.0723.0230	Spacer.....	1
24	07.0723.0340	Upper Door.....	1	63	07.0723.0227	Pipe Fitting.....	1
25	641042	Glass Stop.....	16	64	07.0723.0229	Switch.....	1
26	07.0723.0236	Stop Pad.....	2	65	07.0723.0233	Screw.....	2
27	07.0723.0237	Screw.....	1	66	07.0723.0036	Wiper Arm.....	1
28	07.0723.0164	Lever.....	2	67	641004	Tank.....	1
29	07.0723.0144	Door Stop.....	1	68	07.0723.0224	Sprayer.....	1
30	07.0723.0342	Hinge.....	4	69	07.0723.0225	Washer.....	2
31	07.0723.0190	Seal.....	1	70	07.0723.0037	Wiper Blade.....	1
32	07.0723.0166	Left Side Glass.....	1	71	07.0723.0222	Label.....	1
33	07.0723.0185	Screw.....	3	72	07.0723.0133	Screw.....	1
34	641027	Seal.....	1	73	07.0723.0226	Rubber Hose.....	1
35	641020	Bushin.....	2	74	07.0723.0337	Block.....	1
36	07.0723.0152	Seal.....	1	75	07.0723.0345	Busching.....	8
37	641019	Handle.....	2	76	07.0723.0076	Washer.....	8
38	641024	Stop.....	2	77	07.0723.0040	Screw.....	8
39	07.0723.0172	Plate.....	1				

201.1 604753 Frame



Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	51.0111.2000	Frame.....	1	40	01.0001.0156	Screw.....	8
2	51.0805.1900	Plate.....	2	41	01.4006.0016	Screw.....	3
3	01.4001.0057	Screw.....	4	42	09.0803.0012	Spring Washer.....	12
4	01.0031.0063	Plain Washer.....	4	43	01.0001.0257	Screw.....	2
5	01.0023.0062	Stop Nut.....	4	44	01.0023.0053	Nut, M6.....	12
6	51.0806.6900	Support.....	2	45	01.4032.0003	Spring Washer.....	6
7	09.0803.0265	Mud-Guard.....	2	46	09.4610.0011	Cylinder.....	1
8	07.0726.0065	Hatch.....	1	47	51.0902.6000	Plate.....	1
9	51.0806.8600	Support.....	1	48	07.0726.0083	Lock.....	1
10	52.1100.7200	Guard.....	1	49	07.0726.0083	Hatch.....	1
11	51.0902.5800	Guard.....	1	50	01.0003.0203	Screw.....	3
12	09.0803.0005	Handle.....	1	51	54.0702.0014	Sliding Guide.....	1
13	51.0901.5500	Guard.....	1	52	01.4001.0023	Screw.....	2
14	09.0803.0245	Seal.....	2,1	53	51.0806.8700	Support.....	1
15	09.4610.0003	Driving Mirror.....	1	54	01.4032.0007	Spring Washer.....	2
16	51.0902.5600	Guard.....	1				
17	51.0902.5900	Guard.....	1				
18	07.0723.0004	Insulator.....	4				
19	01.0001.0659	Screw.....	4				
20	54.0100.0002	Washer.....	2				
21	54.0100.0017	Washer.....	4				
22	01.4031.0001	Washer.....	4				
23	01.0023.0058	Stop Nut.....	4				
24	09.4670.0004	Insulator.....	4				
25	01.0001.0356	Screw.....	16				
26	01.0023.0055	Nut.....	16				
27	01.4001.0012	Screw.....	4				
28	01.0031.0058	Washer.....	4				
29	01.0023.0057	Nut.....	4				
30	09.0803.0244	Lock.....	1				
31	09.0803.0024	Hook..... Latch	1				
32	09.0803.0000	Hinge.....	2				
33	01.0001.0256	Screw.....	10				
34	01.0031.0299	Plain Washer.....	10				
35	01.0023.0054	Stop Nut.....	21				
36	51.0806.7000	Support.....	2				
37	09.0803.0264	Mud-Guard.....	2				
38	01.0006.0033	Screw.....	8				
39	01.0031.0055	Washer.....	36				


202.1 604754 Rear Frame Unit



202.1 604754 Rear Frame Unit

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	09.0805.0000	Rubber Hose.....	3	41	54.0101.0002	Spacer.....	1
2	04.0227.0051	Clamp.....	4	42	01.0031.0055	Washer.....	10
3	09.0805.0000	Rubber Hose.....	0,6	43	01.0031.0056	Plain Washer.....	2
4	51.0806.8100	Bracket.....	1	44	01.0001.0356	Screw.....	1
5	01.4001.0018	Screw.....	2	45	53.3301.0002	Seal.....	1
6	01.4032.0006	Spring Washer.....	6	46	01.0023.0053	Nut, M6.....	1
7	51.0800.3800	Tie Rod.....	1	47	01.4006.0001	Screw.....	2
8	01.0001.0702	Screw.....	2	48	01.0031.0058	Plain Washer.....	6
9	01.4032.0007	Washer.....	2	49	51.1000.2900	Counterweight from SN 14634.....	1
10	54.0000.0027	Pin.....	1	49	51.1000.4500	Counterweight to SN 14635.....	1
11	09.0803.0026	Spring Split Pin.....	1	50	01.4001.0063	Screw.....	2
12	51.0902.8000	Guard.....	1	51	01.4032.0007	Spring Washer.....	2
13	09.0803.0025	Hinge.....	2				
14	09.0803.0002	Handle.....	1				
15	01.0003.0203	Screw.....	2				
16	01.0031.0299	Plain Washer.....	2				
17	01.0023.0054	Nut.....	2				
18	51.0806.8200	Rod.....	1				
19	51.0600.2200	Diesel Oil Tank.....	1				
20	01.0001.0254	Screw.....	1				
21	09.0803.0013	Clip.....	1				
22	01.0001.0204	Screw.....	1				
23	01.0023.0054	Nut.....	10				
24	06.0442.0103	Washer.....	1				
25	04.0220.0055	Plug.....	1				
26	09.4670.0000	Retainer.....	1				
27	01.0001.0158	Screw.....	1				
28	01.0031.0054	Washer.....	5				
29	09.0805.0000	Rubber Hose.....	3				
30	09.4661.0010	Plug.....	1				
31	56.0013.0001	Fuel Gauge.....	1				
32	01.4001.0006	Screw.....	6				
33	01.0023.0056	Nut.....	1				
34	51.1000.3800	Left Counterweight.....	1				
35	51.1000.3700	Right Counterweight.....	1				
36	01.0023.0055	Stop Nut.....	1				
37	01.0001.0556	Screw.....	2				
38	01.0023.0053	Nut, M6.....	1				
39	01.0001.0156	Screw.....	1				
40	04.4227.0006	Clamp.....	1				


203.1 604774 Label - Name Plate



203.1 604774 Label - Name Plate

Item	Part No.	Description	Qty.
1	97673	DECAL,DANGER,NO RIDERS.....	1
2	09.4618.0639	Label.....	1
3	09.4618.0642	Label.....	1
4	97667	DECAL,WARN,BURN HAZARD.....	2
5	97664	DECAL,WARN,CRUSH HAZ MOVING PT.....	5
6	97671	DECAL,DANGER,EXPLSION/BURN HAZ.....	1
7	97675	DECAL,WARN,EXPLSION/BURN HAZ.....	2
8	09.4618.0010	Label.....	1
9	09.4618.0071	Label.....	4
10	09.4618.0205	Label.....	1
11	97674	DECAL,DANGER,CRUSH HAZARD.....	1
12	82558	Label.....	1
13	09.4618.0109	Label.....	1
14	09.4618.0640	Label.....	1
15	97688	DECAL,EMERGENCY EXIT HANDLE.....	1
16	97676	DECAL,DANGER,ELECTRICAL HAZARD.....	1
17	97668	DECAL,WARN,OVERTURN HAZARD.....	1
18	97665	DECAL,WARN,WEAR SEAT BELT.....	1
19	97670	DECAL,DANGER,CRUSH HAZARD.....	1
20	97672	DECAL,DANGER,CRUSH HAZARD.....	1
21	97666	DECAL,WARN,READ MANUAL.....	1
22	97669	DECAL,WARN,FALLING OBJECT HAZ.....	1
23	09.4618.0641	Label.....	1


Diagram illustrating the operator's seat and control panel. The seat is labeled 1, the seat belt is labeled 2, the left control lever is labeled 3, the right control lever is labeled 4, and the instrument cluster is labeled 5. An inset shows a 'HYDRAULIC OIL' level gauge and a '671-1000 CAPACITY CHART'.



204.1 604775 Label - Name Plate

Item	Part No.	Description	Qty.
1	09.4616.0101	Name Plate.....	1
2	09.4618.0109	Label.....	1
3	09.4618.0646	Label.....	1
4	09.4618.0389	Label.....	1
5	09.4616.0051	Label.....	1


301.1 604757 Transmission And Wheels



301.1 604757 Transmission And Wheels

Item	Part No.	Description	Qty.
1	09.4632.0045	Rear Axle.....	1
2	09.4632.0044	Front Axle.....	1
3	09.4635.0036	Cardan Shaft.....	1
4	07.0738.0002	Star Wheel.....	2
5	09.4635.0014	Cardan Joint Assembly Kit.....	4
6	55.0403.0051	Wheel.....	4
7	09.4629.0020	Rim.....	4
8	09.4627.0016	Tyre.....	4


302.1 604761 Hydraulic System - Negative Brake



302.1 604761 Hydraulic System - Negative Brake

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	04.0605.0251	Flexible Hose.....	1	41	07.0730.0017	Pin.....	1
2	04.0607.0114	Pipe Fitting.....	9	42	01.4032.0002	Spring Washer.....	1
3	07.4529.0033	Joint Kit.....	1	43	09.0803.0175	Clamp.....	2
4	04.0605.0178	Flexible Hose.....	1	44	04.0605.0268	Flexible Hose.....	1
5	07.0728.0005	Solenoid.....	3	45	04.4240.0036	Valve.....	1
6	04.4239.0071	Valve.....	1	46	04.4227.0006	Bracket.....	1
7	01.0001.0154	Screw.....	1	47	01.0031.0055	Plain Washer.....	1
8	640636	Joint Kit.....	1	48	04.0607.0115	Pipe Fitting.....	1
9	04.0605.0217	Flexible Hose.....	1	49	01.0001.0356	Screw.....	1
10	05.4309.0002	Oil Tank.....	1	50	01.4003.0016	Screw.....	4
11	04.0227.0054	Clamp.....	2	51		603847 pos. 61	
12	09.0805.0000	Rubber Hose.....	1	52	04.0605.0177	Flexible Hose.....	2
13	09.0803.0088	Knurled Coupling.....	1	53	04.0607.0153	Pipe Fitting.....	2
14	05.4309.0001	Pump.....	1	54	04.4240.0035	Valve.....	1
15	04.0607.0149	Pipe Fitting.....	1	55	04.0607.0146	Pipe Fitting.....	1
16	04.4210.0016	Pressure Tube.....	1	56	56.0012.0027	Sensure Switch.....	1
17	05.0401.0007	Drilled Screw.....	1				
18	05.4329.0003	Pressure Switch.....	1				
19	05.0400.0011	Flexible Hose.....	1				
20	04.0401.0003	Screw.....	2				
21	06.0442.0055	Plain Washer.....	7				
22	06.0442.0102	Plain Washer.....	2				
23	04.0600.0159	Pipe Fitting.....	1				
24	04.0600.0021	Pipe Fitting.....	1				
25	04.4240.0000	Block.....	2				
26	01.0003.0110	Screw.....	8				
27		603847 pos. 45					
28	07.0730.0019	Pedal.....	1				
29	01.0001.0252	Screw.....	2				
30	01.4032.0003	Spring Washer.....	7				
31	01.0001.0254	Screw.....	4				
32	01.0031.0299	Plain Washer.....	4				
33	634728	Screw.....	4				
34	04.0220.0053	Plug.....	1				
35	01.0023.0052	Nut.....	8				
36	06.0442.0054	Washer.....	1				
37	07.0730.0013	Bushing.....	2				
38	07.0730.0014	Lever.....	1				
39	07.0730.0025	Support.....	1				
40	07.0730.0023	Spring.....	1				


303.1 604762 Power Steering System



303.1 604762 Power Steering System

Item	Part No.	Description	Qty.
1	09.4636.0008	Steering Wheel.....	1
2	07.0703.0116	Steering Column.....	1
3	01.0001.0256	Screw.....	4
4	01.0032.0054	Washer.....	4
5	01.0001.0355	Screw.....	4
6	01.0032.0055	Washer.....	4
7	09.4636.0003	Power Steering.....	1
7	09.4636.0012	Power Steering.....	1
8	06.0442.0057	Washer.....	1
9	04.0607.0110	Pipe Fitting.....	2
10	04.0605.0199	Flexible Hose.....	1
11	04.0607.0117	Pipe Fitting.....	4
12	06.0442.0102	Washer.....	4
13	04.4240.0000	Plate.....	1
14	04.4240.0037	Solenoid Valve.....	1
15	04.0607.0137	Pipe Fitting.....	5
16	04.0600.0052	Pipe Fitting.....	1
17	04.0605.0253	Flexible Hose.....	1
18	04.0605.0264	Flexible Hose.....	1
19	04.0605.0254	Flexible Hose.....	1
20	04.0605.0255	Flexible Hose.....	1
21	07.4529.0033	Joint Kit.....	1
22	07.0728.0005	Solenoid.....	1
23	992989	SEAL KIT.....	1
24	07.0703.0589	Connector.....	1
25	04.0600.0163	Pipe Fitting.....	1


304.1 604765 Hydraulic System - Transmission



304.1 604765 Hydraulic System - Transmission


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	04.4224.0002	Tap.....	1	41	01.0003.0157	Screw.....	2
2	06.0442.0111	Washer.....	1	42	04.0607.0103	Pipe Fitting.....	4
3	04.0600.0057	Pipe Fitting.....	1	43	04.4235.0023	Hydraulic Motor.....	1
4	04.0600.0042	Pipe Fitting.....	1	44	01.0031.0059	Plain Washer.....	4
5	06.0442.0109	Washer.....	2	45	04.0607.0129	Pipe Fitting.....	1
6	07.0701.0007	Solenoid.....	2	46	04.0605.0167	Flexible Hose.....	1
7	07.0700.0000	Cartridge.....	1	47	04.0607.0104	Pipe Fitting.....	1
8	07.0700.0001	Indicator.....	1	48	04.0607.0114	Pipe Fitting.....	1
9	04.0600.0044	Pipe Fitting.....	1	49	04.4239.0032	Valve.....	1
10	04.0602.0490	Flexible Hose.....	1	50	06.0442.0102	Washer.....	1
11	04.0600.0045	Pipe Fitting.....	1	51	04.0600.0068	Pipe Fitting.....	1
12	04.0600.0053	Sleeve.....	1	52	06.0442.0055	Plain Washer.....	1
13	04.0607.0127	Pipe Fitting.....	1	53	04.0600.0165	Pipe Fitting.....	1
14	04.0605.0195	Flexible Hose.....	1	54	51.0806.3000	Support.....	1
15	04.0607.0143	Pipe Fitting.....	1	55	01.0031.0299	Plain Washer.....	4
16	04.0600.0159	Pipe Fitting.....	1	56	01.4031.0004	Plain Washer.....	4
17	04.0600.0021	Pipe Fitting.....	1	57	01.0001.0256	Screw.....	2
18	06.0401.0214	Seal.....	2	58	01.4032.0003	Spring Washer.....	2
19	04.4223.0004	Flange.....	4	59	04.0600.0160	Pipe Fitting.....	1
20	01.4032.0004	Washer.....	8	60	06.0442.0054	Plain Washer.....	1
21	01.0003.0257	Screw.....	8				
22	04.4229.0035	Flexible Hose.....	1				
23	06.0401.0219	Seal.....	2				
24	04.4223.0003	Half Flange.....	4				
25	04.4229.0034	Flexible Hose.....	1				
26	04.0605.0204	Flexible Hose.....	1				
27	01.0001.0401	Screw.....	8				
28	01.4032.0005	Washer.....	8				
29	01.0001.0651	Screw.....	4				
30	04.0605.0222	Flexible Hose.....	1				
31	04.0607.0105	Pipe Fitting.....	1				
32	04.0600.0050	Pipe Fitting.....	1				
33	04.4210.0016	Pressure Tube.....	2				
34	04.0600.0038	Pipe Fitting.....	1				
35	04.4239.0013	Valve.....	1				
36		603847 pos. 50					
37	04.0607.0107	Pipe Fitting.....	2				
38	04.0605.0209	Flexible Hose.....	1				
39	09.4604.0001	Complete Filter.....	1				
40	09.0803.0043	Retainer Pipe.....	1				

305.1 604776 Differential Case



Item	Part No.	Description	Qty.
1	633204	SNAP RING (CIRCLIP).....	1
2	07.0709.0084	Plug.....	1
3	07.0709.0232	Plug.....	1
4	07.0709.0358	Housing.....	1


306.1 604777 Front Differential Gear



306.1 604777 Front Differential Gear

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	640207	Stud.....	8	23	07.0709.0357	Sphere.....	1
2	640206	Nut.....	8	24	07.0709.0300	Snap Ring.....	1
3	07.0709.0174	Bearing.....	2	25	07.0709.0301	Clutch Disc.....	8
4	07.0709.0716	Seal.....	1	27	07.0709.0302	Snap Ring.....	1
5	07.0709.0359	Spacer.....	1	28	07.0709.0306	Bearing.....	1
6	634391	SHIM,THICKNESS.....	1	29	07.0709.0305	Clutch Disc.....	7
6	634392	SHIM,THICKNESS.....	1	30	07.0709.0304	Bushin.....	1
6	634393	SHIM,THICKNESS.....	1	31	07.0709.0307	Snap Ring.....	1
7	07.0709.0236	Ring.....	1	32	07.0709.0308	Spacer.....	1
7	07.0709.0237	Ring.....	1	33	639637	Bearing.....	1
7	07.0709.0238	Ring.....	1	34	07.0709.0309	Thickness.....	1
7	07.0709.0239	Ring.....	1	34	07.0709.0310	Thickness.....	1
7	07.0709.0240	Ring.....	1	34	07.0709.0311	Thickness.....	1
7	07.0709.0241	Ring.....	1	35	07.0709.0303	Snap Ring.....	1
7	07.0709.0242	Ring.....	1	36	633202	BEARING.....	1
7	07.0709.0243	Ring.....	1	39	633946	Bushing.....	1
7	07.0709.0244	Ring.....	1	41	07.0709.0320	Clutch Disc.....	1
7	07.0709.0245	Ring.....	1				
7	07.0709.0246	Ring.....	1				
7	07.0709.0247	Ring.....	1				
7	07.0709.0248	Ring.....	1				
7	07.0709.0249	Ring.....	1				
7	07.0709.0250	Ring.....	1				
8	07.0709.0717	Ring Nut.....	1				
9	07.0709.0360	Bevel Gear Set.....	1				
10	07.0709.0160	Screw.....	12				
11	07.0709.0257	Thickness.....	1				
11	07.0709.0258	Thickness.....	1				
11	07.0709.0259	Thickness.....	1				
11	07.0709.0260	Thickness.....	1				
12	633529	BEARING.....	1				
13	07.0709.0297	Differential Case.....	1				
15	07.0709.0298	Differential Side Gear.....	1				
16	633568	PINION GEAR.....	1				
17	633533	WASHER.....	4				
18	07.0709.0253	Pin.....	2				
19	07.0709.0254	Dowel.....	3				
20	07.0709.0255	Pin.....	1				
21	07.0709.0256	Star Wheel.....	1				
22	07.0709.0299	Differential Side Gear.....	1				


307.1 604778 Front Steering Axle



307.1 604778 Front Steering Axle


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0709.0261	Seal.....	2	40	07.0709.0280	Nut.....	16
2	639670	PLUG,BREATHER.....	1	41	07.0709.0281	Stud.....	16
3	07.0709.0262	Screw.....	16	42	07.0709.0171	Bearing.....	4
4	07.0709.0361	Arm.....	1	43	07.0709.0282	Hub.....	2
5	07.0709.0264	Bushing.....	4	45	07.0709.0119	Stud.....	8
6	07.0709.0265	Seal.....	4	46	07.0709.0071	Washer.....	8
7	07.0709.0362	Joint.....	2	47	07.0709.0070	Nut.....	8
8	07.0709.0267	Pin.....	2	48	07.0709.0284	Support.....	2
9	633176	GREASE NIPPLE.....	4	50	07.0709.0364	Arm.....	1
10	638548	CAP.....	4	51	07.0709.0323	Screw.....	16
11	07.0709.0057	Screw.....	12	52	07.0709.0365	Screw.....	4
12	07.0709.0268	Thickness.....	2				
12	07.0709.0290	Thickness.....	2				
12	07.0709.0291	Thickness.....	2				
13	07.0709.0269	Seal.....	2				
14	07.0709.0124	Bushing.....	2				
15	07.0709.0270	Articulation.....	2				
16	07.0709.0271	Pin.....	2				
17	634546	NUT,DIN439 JAM M16-2.0 P.....	4				
18	07.0709.0104	Screw.....	4				
19	07.0709.0272	Housing.....	1				
20	07.0709.0273	Housing.....	1				
21	07.0709.0274	Plug.....	1				
22	07.0709.0363	Seal.....	2				
23	07.0709.0117	Pipe Fitting.....	16				
24	07.0709.0118	Nut.....	16				
25	632383	Seal.....	2				
26	639646	Snap Ring.....	2				
27	639639	RING GEAR.....	2				
28	07.0709.0275	Support.....	2				
29	07.0709.0276	Sheet.....	2				
30	07.0709.0277	Ring.....	2				
31	07.0709.0278	Snap Ring.....	2				
32	639641	Snap Ring.....	6				
33	639642	PINION,DIFFERENTIAL.....	6				
34	639643	Bearing.....	6				
36	07.0709.0113	Plug.....	2				
37	07.0709.0065	Screw.....	4				
38	07.0709.0321	Support.....	2				
39	07.0709.0279	Washer.....	2				

308.1 604779 Brake



Item	Part No.	Description	Qty.
1	07.0709.0324	Brake Disc.....	6
2	07.0709.0325	Brake Disc.....	6
3	07.0709.0326	Bushin.....	1
4	07.0709.0327	Sphere.....	1
5	07.0709.0328	Spacer.....	1
6	629733	SHIM,THICKNESS.....	2
6	629735	SHIM,THICKNESS.....	2
6	639327	SHIM.....	2
6	639329	SHIM.....	2
7	07.0709.0329	Brake Disc.....	1
8	07.0709.0330	Split Pin.....	2
9	07.0709.0331	Piston.....	1
10	07.0709.0332	Seal.....	1
11	632070	Screw.....	1
12	630328	BLEEDER VALVE,LONG.....	2
13	638548	CAP.....	2
14	07.0709.0333	Back-Up Ring.....	1
15	07.0709.0334	Seal.....	1
16	07.0709.0335	Back-Up Ring.....	1
17	07.0709.0336	Snap Ring.....	2
18	07.0709.0337	Spring.....	1
19	07.0709.0338	Back-Up Ring.....	2
20	07.0709.0339	Seal.....	4
21	07.0709.0254	Dowel.....	1
22	07.0709.0340	Piston.....	1
23	07.0709.0341	Seal.....	3
24	07.0709.0342	Pin.....	3
25	07.0709.0343	Seal.....	1
26	07.0709.0344	Seal.....	1
27	07.0709.0345	Piston.....	1
28	07.0709.0346	Spring.....	2
29	07.0709.0347	Ring Nut.....	1
30	07.0709.0348	Screw.....	2
31	07.0709.0034	Seal.....	2
32	07.0709.0349	Spacer.....	2
33	07.0709.0350	Security Dowel.....	1
34	07.0709.0351	Sealing Washer.....	2
35	07.0709.0352	Screw.....	2


309.1 604780 Reduction Gear



309.1 604780 Reduction Gear

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	639799	O-RING.....	1	42	639810	O-RING.....	1
2	639779	PLUG,BREATHER.....	1	43	639815	Piston.....	1
3	639789	Cover.....	1	44	639781	O-RING.....	1
4	639790	Seal.....	1	45	639814	PLATE,COVER.....	1
5	629327	Thickness.....	1	47	639813	Selector Shaft.....	1
5	629733	SHIM,THICKNESS.....	1	48	639811	SLIDING GUIDE.....	2
5	639328	SHIM.....	1	49	639812	Selector Fork.....	1
5	639329	SHIM.....	1	50	637584	WASHER,SEALING.....	1
6	633202	BEARING.....	1	52	637536	SEAL RING.....	1
7	639782	COVER.....	1	53	633161	RING/SEAL.....	1
9	639784	Bearing.....	1	55	56.0013.0015	Proximity Switch.....	1
10	639797	SPLIT PIN.....	2	56	633208	Plug.....	1
11	639785	Dowel.....	2	57	637577	SEAL.....	1
12	640196	Housing.....	1	58	639800	Cover.....	1
13	639787	Screw.....	12	59	07.0709.0079	Flange.....	1
14	637574	SEAL.....	1	60	639802	Nut.....	1
16	07.0709.0357	Sealing Washer.....	1	61	639916	Sheet.....	1
18	640198	Spacer.....	1	65	633109	Spring Washer.....	12
19	639792	SCREW.....	2	66	07.0709.367	Shaft.....	1
21	639793	Sheet.....	1	67	07.0709.368	Gear.....	1
22	639794	Bearing.....	4	68	07.0709.369	Gear.....	1
23	07.0709.0366	Shaft.....	1				
24	639796	SLEEVE.....	1				
25	639778	SCREW.....	2				
26	639798	Sheet.....	1				
27	628275	PLUG,MAGNETIC.....	1				
28	639791	Spacer.....	1				
29	07.0709.0356	Security Switch.....	1				
30	637582	Rubber Protection.....	1				
31	635594	SCREW.....	1				
32	635596	Spring.....	1				
33	07.0709.0184	Bearing.....	1				
34	07.0709.0327	Sphere.....	1				
35	639803	SCREW.....	1				
36	639804	O-RING.....	1				
37	639807	Seal.....	2				
38	639780	Cylinder.....	1				
39	639808	Plug.....	2				
40	639816	O-RING.....	1				
41	639809	ROD.....	1				


310.1 604781 Steering Cylinder



310.1 604781 Steering Cylinder


Item	Part No.	Description	Qty.
1	07.0709.0285	Cylinder.....	1
2	634397	O-RING.....	2
3	07.0709.0370	Articulated Tie Rod.....	2
4	07.0709.0134	Screw.....	4
5	07.0709.0417	Joint Kit.....	1

311.1 604782 Differential Case



Item	Part No.	Description	Qty.
1	633204	SNAP RING (CIRCLIP).....	1
2	07.0709.0080	Plug.....	1
3	07.0709.0232	Plug.....	1


312.1 604783 Rear Differential Gear



312.1 604783 Rear Differential Gear

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	633160	Nut.....	1	24	07.0709.0258	Thickness.....	2
2	07.0709.0388	Flange.....	1	24	07.0709.0259	Thickness.....	2
3	633098	SEAL,DIFFERENTIAL.....	1	24	07.0709.0260	Thickness.....	2
4	07.0709.0174	Bearing.....	2	25	630694	Screw.....	8
5	07.0709.0234	Spacer.....	1				
6	633110	O-RING.....	1				
7	07.0709.0235	Sheet.....	1				
8	633574	Spacer.....	1				
9	07.0709.0236	Ring.....	1				
9	07.0709.0237	Ring.....	1				
9	07.0709.0238	Ring.....	1				
9	07.0709.0239	Ring.....	1				
9	07.0709.0240	Ring.....	1				
9	07.0709.0241	Ring.....	1				
9	07.0709.0242	Ring.....	1				
9	07.0709.0243	Ring.....	1				
9	07.0709.0244	Ring.....	1				
9	07.0709.0245	Ring.....	1				
9	07.0709.0246	Ring.....	1				
9	07.0709.0247	Ring.....	1				
9	07.0709.0248	Ring.....	1				
9	07.0709.0249	Ring.....	1				
9	07.0709.0250	Ring.....	1				
10	634392	SHIM,THICKNESS.....	1				
10	634393	SHIM,THICKNESS.....	1				
10	634403	Thickness.....	1				
11	07.0709.0389	Bevel Gear Set.....	1				
12	633529	BEARING.....	2				
13	07.0709.0160	Screw.....	12				
14	07.0709.0252	Differential Case.....	1				
15	633531	WASHER.....	2				
16	633944	Differential Side Gear.....	2				
17	633533	WASHER.....	4				
18	633568	PINION GEAR.....	4				
19	07.0709.0253	Pin.....	2				
20	07.0709.0254	Dowel.....	3				
21	07.0709.0255	Pin.....	1				
22	07.0709.0256	Star Wheel.....	1				
23	633569	Cover.....	1				
24	07.0709.0257	Thickness.....	2				


313.1 604784 Rear Steering Axle



313.1 604784 Rear Steering Axle


Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	07.0709.0261	Seal.....	1	40	07.0709.0280	Nut.....	16
2	639670	PLUG,BREATHER.....	1	41	07.0709.0281	Stud.....	16
3	07.0709.0262	Screw.....	16	42	07.0709.0171	Bearing.....	4
4	07.0709.0390	Arm.....	1	43	07.0709.0282	Hub.....	2
5	07.0709.0264	Bushing.....	4	44	07.0709.0392	Arm.....	1
6	07.0709.0265	Seal.....	4	45	07.0709.0119	Stud.....	8
7	07.0709.0391	Joint.....	2	46	07.0709.0071	Washer.....	8
8	07.0709.0267	Pin.....	2	47	07.0709.0070	Nut.....	8
9	633176	GREASE NIPPLE.....	4	48	07.0709.0284	Support.....	2
10	638548	CAP.....	4	52	07.0709.0365	Screw.....	4
11	07.0709.0057	Screw.....	12				
12	07.0709.0268	Thickness.....	2				
12	07.0709.0290	Thickness.....	2				
12	07.0709.0291	Thickness.....	2				
13	07.0709.0269	Seal.....	2				
14	07.0709.0124	Bushing.....	2				
15	07.0709.0270	Articulation.....	2				
16	07.0709.0271	Pin.....	2				
17	634546	NUT,DIN439 JAM M16-2.0 P.....	4				
18	07.0709.0104	Screw.....	4				
19	07.0709.0272	Housing.....	1				
20	07.0709.0273	Housing.....	1				
21	07.0709.0274	Plug.....	1				
22	07.0709.0363	Seal.....	2				
23	07.0709.0117	Pipe Fitting.....	16				
24	07.0709.0118	Nut.....	16				
25	632383	Seal.....	2				
26	639646	Snap Ring.....	2				
27	639639	RING GEAR.....	2				
28	07.0709.0275	Support.....	2				
29	07.0709.0276	Sheet.....	2				
30	07.0709.0277	Ring.....	2				
31	07.0709.0278	Snap Ring.....	2				
32	639641	Snap Ring.....	6				
33	639642	PINION,DIFFERENTIAL.....	6				
34	639643	Bearing.....	6				
36	07.0709.0113	Plug.....	2				
37	07.0709.0065	Screw.....	4				
38	07.0709.0321	Support.....	2				
39	07.0709.0279	Washer.....	2				

314.1 604785 Steering Cylinder




314.1 604785 Steering Cylinder

Item	Part No.	Description	Qty.
1	07.0709.0285	Cylinder.....	1
2	634397	O-RING.....	2
3	07.0709.0370	Articulated Tie Rod.....	2
4	07.0709.0134	Screw.....	4
5	07.0709.0417	Joint Kit.....	1




Item	Part No.	Description	Qty.
1	07.0709.0218	Bushin.....	4
2	07.0709.0287	Bushing.....	2
3	07.0709.0288	Support.....	2
4	633176	GREASE NIPPLE.....	2
5	638548	CAP.....	2
6	07.0709.0289	Support.....	2

401.1 604755 Arm




Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	51.0201.0000	Basic Arm.....	1	41	51.0806.3800	Thickness.....	2
2	51.0201.0100	Arm.....	1	42	01.0003.0944	Screw.....	1
3	54.0201.0007	Bushing.....	2	43	01.0031.0055	Washer.....	1
4	54.0003.0027	Pin.....	1	44	01.0019.0104	Nut.....	1
5	01.4001.0012	Screw.....	1	45	51.0804.8400	Needle For Inclinator.....	1
6	01.0023.0057	Nut.....	1				
7	54.0000.0115	Pin.....	1				
8	01.0001.0209	Screw.....	2				
9	01.0023.0054	Nut.....	2				
10	54.0002.0014	Pin.....	1				
11	02.0117.0101	Grease Nipple.....	1				
12	54.0000.0117	Pin.....	1				
13	01.4001.0003	Screw.....	1				
14	01.0023.0056	Nut.....	1				
15	54.0003.0026	Pin.....	1				
16	54.0702.0013	Sliding Guide.....	2				
17	54.0002.0026	Pin.....	1				
18	01.0001.0310	Screw.....	2				
19	01.0023.0055	Nut.....	2				
20	54.0001.0030	Pin.....	1				
21	54.0201.0009	Bushing.....	2				
22	54.0702.0000	Sliding Guide.....	4				
23	54.0200.0001	Bushing.....	12				
24	01.0001.0110	Screw.....	4				
25	01.0032.0055	Washer.....	16				
26	01.0001.0357	Screw.....	8				
27	01.0001.0356	Screw.....	8				
28	54.0200.0000	Bushing.....	6				
29	54.0702.0001	Sliding Guide.....	2				
30	54.0702.0002	Sliding Guide.....	2				
31	01.0001.0088	Screw.....	2				
32	54.0702.0005	Sliding Guide.....	2				
33	01.0003.0203	Screw.....	2				
34	01.0001.0254	Screw.....	1				
35	01.0032.0054	Washer.....	1				
36	09.0803.0062	Washer.....	6				
37	51.0806.6100	Sliding Block Holder.....	2				
38	51.0809.3900	Thickness.....	2				
39	51.0804.9000	Thickness.....	6				
40	51.0809.4000	Thickness.....	2				

402.1 604756 Forks



Item	Part No.	Description	Qty.
1	51.1301.4300	Plate.....	1
2	51.1301.2400	Fork from SN 14786.....	2
2	51.1301.4400	Fork to SN 14787.....	2
3	54.0000.0068	Pin.....	1
4	54.0100.0027	Washer.....	2
5	01.0001.0409	Screw.....	1
6	01.0023.0056	Stop Nut.....	1


403.1 604768 Hydraulic System - Implement Locking



403.1 604768 Hydraulic System - Implement Locking

Item	Part No.	Description	Qty.
1	53.3001.0500	Manifold.....	1
2	04.0600.0019	Pipe Fitting.....	1
3	04.0600.0087	Pipe Fitting.....	2
4	04.4210.0019	Female Coupling.....	2
5	04.4210.0018	Male Coupling.....	2
6	04.0607.0141	Pipe Fitting.....	2
7	04.0607.0110	Pipe Fitting.....	2
8	04.0605.0278	Flexible Hose.....	2
9	04.0607.0114	Pipe Fitting.....	3
10	01.0001.0156	Screw.....	2
11	04.0607.0112	Pipe Fitting.....	1
12	04.0605.0114	Flexible Hose.....	1
13	04.0605.0113	Flexible Hose.....	1
14	04.0605.0112	Flexible Hose.....	1
15	04.0607.0131	Pipe Fitting.....	1
16	01.4032.0002	Spring Washer.....	2
17	01.0023.0053	Nut, M6.....	1
18	53.0500.0400	Cylinder.....	1
19	01.0001.0104	Screw.....	1
20	01.0001.0355	Screw.....	4
21	01.0032.0055	Washer.....	4
22	01.0031.0301	Washer.....	4
23	54.0001.0001	Pin.....	2
24	51.0400.0300	Fork Coupling Attachment.....	1
25	04.4239.0002	Valve.....	1
26	04.0607.0132	Pipe Fitting.....	1
27	54.0001.0022	Pin.....	1
28	639395	Joint Kit.....	1
29	51.0903.1500	Guard.....	1
30	01.0001.0254	Screw.....	3
31	01.4032.0003	Spring Washer.....	3
32	01.0031.0299	Plain Washer.....	3
33	04.0600.0081	Pipe Fitting.....	1
34	01.0031.0054	Plain Washer.....	2
35	04.0607.0163	Pipe Fitting.....	2


404.1 604769 Hydraulic System - Fork Balancing



404.1 604769 Hydraulic System - Fork Balancing

Item	Part No.	Description	Qty.
1	01.0031.0061	Washer.....	1
2	04.0607.0111	Pipe Fitting.....	4
3	09.0803.0061	Plate.....	1
4	04.0605.0257	Flexible Hose.....	1
5	04.0605.0257	Flexible Hose.....	1
6	04.0607.0126	Pipe Fitting.....	2
7	04.4239.0051	Valve.....	1
8	04.4239.0004	Valve.....	2
9	53.3401.3100	Pipe.....	1
10	04.0607.0114	Pipe Fitting.....	1
11		603847 pos. 49	
12	53.0300.1300	Cylinder.....	1
13	04.0607.0124	Pipe Fitting.....	2
14	54.0002.0013	Pin.....	1
15	01.0001.0211	Screw.....	1
16	01.0023.0054	Nut.....	1
17	04.0605.0260	Flexible Hose.....	2
18	53.3401.3200	Pipe.....	1
19	09.0803.0043	Clamp.....	4
20	01.0003.0157	Screw.....	8
21	01.0001.0257	Screw.....	1
22	04.0605.0248	Flexible Hose.....	1
23	04.0607.0141	Pipe Fitting.....	2
24	04.4239.0052	Valve.....	1
25	53.0400.0800	Cylinder.....	1
26	04.0605.0097	Flexible Hose.....	2
27	54.0002.0025	Pin.....	1
28	01.0001.0310	Screw.....	1
29	01.0023.0055	Nut.....	1
30	639992	Joint Kit.....	1
31	07.0721.0019	Ball Joint.....	2
32	07.0721.0042	Snap Ring.....	4
33	635965	SEAL KIT,CYLINDER.....	1
34	07.0705.0085	Joint Kit.....	4
35	54.0201.0008	Bushing.....	2
36	09.0803.0060	Clamp.....	1
37	07.4501.0105	Seal.....	2


405.1 604770 Hydraulic System - Lifting And Boom Extension



405.1 604770 Hydraulic System - Lifting And Boom Extension

Item	Part No.	Description	Qty.
1	09.0803.0043	Clamp.....	4
2	04.0607.0111	Pipe Fitting.....	5
3	04.0607.0109	Pipe Fitting.....	1
4	04.0605.0259	Flexible Hose.....	2
5	04.0607.0138	Pipe Fitting.....	1
6	04.4239.0005	Valve.....	1
7	53.0000.2300	Lifting Jack.....	1
8	04.0607.0124	Pipe Fitting.....	2
9	54.0000.0116	Pin.....	1
10	01.4001.0003	Screw.....	1
11	01.0023.0056	Nut.....	1
12	04.0605.0257	Flexible Hose.....	1
13	04.0605.0258	Flexible Hose.....	1
14	53.3401.2800	Pipe.....	1
15	53.3401.2700	Pipe.....	1
16	01.0003.0157	Screw.....	8
17	01.0031.0061	Washer.....	2
18	07.4529.0091	Joint Kit.....	1
19	04.0600.0087	Pipe Fitting.....	2
20	04.4239.0005	Valve.....	1
21	53.0100.1600	Extension Cylinder.....	1
22	04.0605.0260	Flexible Hose.....	2
23	54.0201.0011	Bushing.....	4
24	639993	Joint Kit.....	1
25	07.4529.0072	Seal.....	4


406.1 604771 Hydraulic System - Auxiliary Circuits



406.1 604771 Hydraulic System - Auxiliary Circuits

Item	Part No.	Description	Qty.
1	01.0001.0256	Washer.....	2
2	04.0607.0111	Pipe Fitting.....	2
3	01.0031.0055	Washer.....	2
4	04.0605.0256	Flexible Hose.....	1
5	04.0605.0256	Flexible Hose.....	1
6	53.3401.2900	Pipe.....	1
7	09.0803.0043	Clamp.....	4
8	01.0003.0157	Screw.....	8
9	01.0001.0257	Screw.....	1
10	04.0605.0249	Flexible Hose.....	1
11	04.0607.0124	Pipe Fitting.....	2
12	04.0605.0260	Flexible Hose.....	2
13	04.4227.0016	Bracket.....	1
14	09.0803.0060	Clamp.....	1
15	53.3401.3000	Pipe.....	1
16	01.0031.0061	Washer.....	2
17	09.0803.0061	Plate.....	1


501.1 604758 Diesel Engine - Hydraulic Pump



501.1 604758 Diesel Engine - Hydraulic Pump

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	01.4001.0012	Screw.....	4	41	01.4001.0024	Screw.....	4
2	01.0031.0058	Washer.....	6				
3	51.0806.7500	Support.....	1				
4	01.0031.0301	Plain Washer.....	2				
5	01.4032.0004	Spring Washer.....	2				
6	01.0001.0358	Screw.....	2				
7	01.0001.0356	Screw.....	32				
8	09.4670.0004	Insulator.....	4				
9	01.0023.0055	Nut.....	16				
10	09.0804.0100	Handwheel Arrangement.....	1				
11	01.0023.0057	Nut.....	6				
12	641124	Elastic Joint.....	1				
13	01.0032.0057	Washer.....	9				
14	07.4501.0067	Oil Filter.....	1				
15	01.0031.0099	Plain Washer.....	1				
16	01.4032.0007	Spring Washer.....	1				
17	01.0003.0405	Screw.....	1				
18	04.4238.0033	Pump.....	1				
19	640125	Protection.....	1				
20	04.4238.0030	Pump.....	1				
21	01.0032.0055	Plain Washer.....	8				
22	634981	HUB.....	1				
23	999058	WASHER.....	1				
24	07.4501.0068	Diesel Oil Filter.....	1				
25	01.0001.0357	Screw.....	1				
26	09.4601.0029	Diesel Engine.....	1				
27	54.0100.0066	Pulley.....	1				
28	01.0003.0262	Screw.....	8				
29	09.0804.1000	Snap Ring.....	1				
30	09.0804.1200	Half-Joint.....	1				
31	09.0804.0900	Elastic Joint.....	1				
32	01.0003.0208	Screw.....	6				
33	09.0804.1100	Half-Joint.....	1				
34	51.0806.1600	Support.....	1				
35	01.4032.0006	Spring Washer.....	4				
36	02.4102.0004	Split Pin.....	2				
37	51.0806.1800	Support.....	1				
38	01.0001.0402	Screw.....	2				
39	01.0001.0606	Screw.....	4				
40	01.0023.0056	Nut.....	2				


502.1 604759 Diesel Engine - Engine Cooling System



502.1 604759 Diesel Engine - Engine Cooling System

Item	Part No.	Description	Qty.
1	01.0001.0209	Screw.....	1
2	01.4031.0004	Plain Washer.....	1
3	09.4670.0001	Rubber.....	1
4	09.0803.0245	Seal.....	1,4
5	53.3200.0022	Complete Radiator.....	1
6	01.0031.0298	Plain Washer.....	3
7	04.0607.0130	Pipe Fitting.....	2
8	01.0001.0254	Screw.....	1
9	04.0605.0215	Flexible Hose.....	1
10	04.0605.0216	Flexible Hose.....	1
11	01.4032.0003	Spring Washer.....	1
12	01.0031.0055	Plain Washer.....	2
13	07.0712.0046	Radiator Core.....	1
14	07.0712.0047	Conveyor.....	1
15	09.4670.0002	Insulator.....	1
16	51.0806.8900	Bracket.....	1
17	01.0023.0054	Nut.....	1
18	01.0031.0301	Plain Washer.....	1
19	01.0023.0055	Nut.....	1
20	07.0712.0006	Guard.....	1
21	07.0712.0048	Fan.....	1
22	01.0001.0158	Screw.....	2
23	01.4032.0002	Spring Washer.....	3
24	01.0001.0154	Screw.....	1
25	53.3302.0017	Insulation.....	1


503.1 604760 Diesel Engine - Suction - Exhaust - Accelerator (to SN 15882)



503.1 604760 Diesel Engine - Suction - Exhaust - Accelerator (to SN 15882)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	01.4006.0001	Screw.....	4	39	01.0023.0054	Nut.....	1
2	09.4656.0007	Pedal.....	1	40	53.3001.1200	Rubber Hose.....	1
2	09.4656.0009	Pedal.....	1	41	04.0227.0051	Clamp.....	2
3	07.4501.0060	Precleaner.....	1	42	07.4501.0041	Cartridge.....	1
4	04.0227.0067	Clamp.....	3	43	09.0803.0064	Retainer Pipe.....	1
5	09.0805.0054	Rubber Hose.....	1	44	51.0809.1800	Bracket.....	1
6	09.0803.0008	Articulation.....	1	45	01.0031.0054	Plain Washer.....	6
7	04.4227.0000	Clamp.....	2	46	01.0023.0053	Nut, M6.....	4
8	07.4501.0061	Proximity Switch.....	1	47	01.0003.0157	Screw.....	2
9	01.0001.0256	Screw.....	4	48	01.0003.0159	Screw.....	2
10	01.0031.0299	Plain Washer.....	4				
11	09.0805.0058	Rubber Hose.....	1				
12	01.0001.0357	Screw.....	1				
13	01.0031.0056	Washer.....	2				
14	01.0023.0055	Nut.....	1				
15	04.4227.0007	Retainer Pipe.....	1				
16	01.0006.0049	Screw.....	2				
17	53.3100.0020	Exhaust Muffler.....	1				
18	01.4032.0003	Nut.....	4				
19	09.0803.0109	Collar.....	2				
20	09.0805.0053	Rubber Hose.....	1				
21	01.0001.0506	Screw.....	2				
22	01.4032.0005	Spring Washer.....	2				
23	01.0001.0158	Screw.....	1				
24	01.0023.0053	Nut, M6.....	1				
25	09.0805.0057	Rubber Hose.....	1				
26	53.3001.1100	Manifold.....	1				
27	53.3001.1000	Manifold.....	1				
28	01.0031.0057	Plain Washer.....	2				
29	51.0806.2400	Support.....	1				
30	09.4645.0024	Cable.....	1				
30	09.4645.0028	Cable.....	1				
31	07.4501.0042	Clamp.....	2				
32	640885	Cartridge.....	1				
33	09.4604.0039	Complete Air Filter.....	1				
34	04.4227.0001	Clamp.....	1				
35	51.0806.2800	Bracket.....	1				
36	09.0803.0251	Spring.....	1				
37	51.0806.2700	Bracket.....	1				
38	07.0723.0194	Rubber Hose.....	0,1				


504.1 604760 Diesel Engine - Suction - Exhaust - Accelerator (from SN 15883)



504.1 604760 Diesel Engine - Suction - Exhaust - Accelerator (from SN 15883)

Item	Part No.	Description	Qty.	Item	Part No.	Description	Qty.
1	01.4006.0001	Screw.....	4	39	01.0023.0054	Nut.....	1
2	09.4656.0007	Pedal.....	1	40	53.3001.1200	Rubber Hose.....	1
2	09.4656.0009	Pedal.....	1	41	04.0227.0051	Clamp.....	2
3	07.4501.0060	Precleaner.....	1	42	07.4501.0041	Cartridge.....	1
4	04.0227.0067	Clamp.....	3	43	09.0803.0064	Retainer Pipe.....	1
5	09.0805.0054	Rubber Hose.....	1	44	51.0809.1800	Bracket.....	1
6	09.0803.0008	Articulation.....	1	45	01.0031.0054	Plain Washer.....	6
7	04.4227.0000	Clamp.....	2	46	01.0023.0053	Nut, M6.....	4
8	07.4501.0061	Proximity Switch.....	1	47	01.0003.0157	Screw.....	2
9	01.0001.0256	Screw.....	4	48	01.0003.0159	Screw.....	2
10	01.0031.0299	Plain Washer.....	4	49	09.0803.0027	Rain Protector.....	1
11	09.0805.0058	Rubber Hose.....	1				
12	01.0001.0357	Screw.....	1				
13	01.0031.0056	Washer.....	2				
14	01.0023.0055	Nut.....	1				
15	04.4227.0007	Retainer Pipe.....	1				
16	01.0006.0049	Screw.....	2				
17	53.3100.0033	Exhaust Muffler.....	1				
18	01.4032.0003	Nut.....	4				
19	09.0803.0109	Collar.....	2				
20	09.0805.0053	Rubber Hose.....	1				
21	01.0001.0506	Screw.....	2				
22	01.4032.0005	Spring Washer.....	2				
23	01.0001.0158	Screw.....	1				
24	01.0023.0053	Nut, M6.....	1				
25	09.0805.0057	Rubber Hose.....	1				
26	53.3001.1100	Manifold.....	1				
27	53.3001.1000	Manifold.....	1				
28	01.0031.0057	Plain Washer.....	2				
29	51.0806.2400	Support.....	1				
30	09.4645.0024	Cable.....	1				
30	09.4645.0028	Cable.....	1				
31	07.4501.0042	Clamp.....	2				
32	640885	Cartridge.....	1				
33	09.4604.0039	Complete Air Filter.....	1				
34	04.4227.0001	Clamp.....	1				
35	51.0806.2800	Bracket.....	1				
36	09.0803.0251	Spring.....	1				
37	51.0806.2700	Bracket.....	1				
38	07.0723.0194	Rubber Hose.....	0,1				


505.1 604763 Hydraulic System - Tank And Exchanger



505.1 604763 Hydraulic System - Tank And Exchanger

Item	Part No.	Description	Qty.
1	51.0600.3100	Oil Tank.....	1
2	07.0726.0044	Cover.....	1
3	53.3301.0002	Seal.....	1
4	01.0031.0299	Washer.....	10
5	01.0023.0054	Nut.....	10
6	56.0013.0000	Transmitter.....	1
7	06.0442.0103	Washer.....	2
8	04.0600.0046	Pipe Fitting.....	4
9	04.4239.0013	Valve.....	1
10	04.0605.0263	Flexible Hose.....	1
11	04.0607.0120	Pipe Fitting.....	2
12	04.0607.0119	Pipe Fitting.....	2
13	04.0600.0009	Pipe Fitting.....	1
14	04.0600.0041	Pipe Fitting.....	1
15	04.0600.0038	Pipe Fitting.....	1
16	04.0607.0107	Pipe Fitting.....	2
17	04.0605.0273	Flexible Hose.....	1
18	04.0605.0279	Flexible Hose.....	1
19	04.0607.0130	Pipe Fitting.....	2
20	04.4239.0012	Valve.....	1
21	04.0605.0276	Flexible Hose.....	1
22	01.0001.0359	Screw.....	2
23	01.4032.0004	Spring Washer.....	2
24	01.0031.0301	Plain Washer.....	2
25	09.0803.0232	Insulator.....	2


506.1 604764 Suction System - Facilities Pump



506.1 604764 Suction System - Facilities Pump


Item	Part No.	Description	Qty.
1	09.4661.0016	Filter.....	1
2	09.4661.0002	Level Indicator.....	1
3	06.0401.0842	Seal.....	1
4	53.3000.1300	Manifold.....	1
5	01.4032.0002	Spring Washer.....	6
6	01.0001.0156	Screw.....	6
7	09.0805.0007	Rubber Hose.....	0,3
8	04.0227.0144	Clamp.....	2
9	53.3001.0700	Manifold.....	1
10	09.4661.0014	Plug.....	1
11	04.0607.0121	Pipe Fitting.....	1
12	01.0031.0298	Washer.....	2
13	04.0220.0051	Plug.....	1
14	06.0442.0101	Washer.....	1
15	06.0442.0103	Washer.....	1
16	04.0220.0055	Plug.....	1
17	06.0442.0111	Washer.....	1
18	04.0605.0262	Flexible Hose.....	1
19	04.0605.0265	Flexible Hose.....	1
20	01.0001.1482	Screw.....	2
21	01.0031.0151	Plain Washer.....	4
22	01.0023.0056	Nut.....	2
23	09.4604.0004	Filter.....	1
24	04.4224.0002	Tap.....	1
25	09.0806.0019	Pipe Fitting.....	1
26	04.0607.0147	Pipe Fitting.....	1
27	04.0605.0206	Flexible Hose.....	1
28	04.4223.0000	Pipe Fitting.....	1
29	626804	Seal.....	1
30	01.0001.0355	Screw.....	3
31	01.0031.0056	Washer.....	3
32	04.0607.0142	Pipe Fitting.....	1
33	04.0607.0119	Pipe Fitting.....	1
34	04.0607.0113	Pipe Fitting.....	2
35	04.0607.0111	Pipe Fitting.....	3
36	04.0607.0107	Pipe Fitting.....	1
37	04.0605.0266	Flexible Hose.....	1
38	04.0605.0198	Flexible Hose.....	1

601.1 604772 Electric Installation



Item	Part No.	Description	Qty.
1	55.0602.0158	Wiring Harness.....	1
2	56.0008.0003	Battery.....	1
3	55.0602.0015	Cable.....	1
4	55.0602.0014	Cable.....	1
5	56.0009.0003	Horn.....	1
6	07.4501.0059	Relay.....	1
8	07.0703.0060	Fuse.....	2
9	07.0703.0178	Relay.....	1
10	07.0703.0177	Bracket.....	1
11	07.0703.0176	Pull Box.....	1
12	07.0703.0058	Connector.....	2
13	55.0600.0069	Wiring Harness.....	1
14	07.0703.0066	Stuffing Box.....	1
15	55.0601.0041	Wiring Harness.....	1
16	07.0703.0064	Relay Holder.....	1
17	55.0605.0306	Parking Brake Kit.....	1

602.1 604773 Fuse Holding Box



Item	Part No.	Description	Qty.
1	07.0703.0081	Fuse.....	2
2	07.0703.0080	Fuse.....	6
3	634972	FUSE,7.5A.....	2
4	07.0703.0079	Fuse.....	4
5	634973	FUSE,15A.....	1
6	07.0703.0179	Relay.....	4
7	641135	Housing.....	1

Part Number Index

The Part Number Index is a numeric index of all part numbers included in this manual. The index shows what page(s) the part is used on.

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
01.0001.0010	19	01.0031.0299	19, 29, 31, 39, 43, 71, 83, 85, 87	04.0605.0195	43	04.0607.0139	23
01.0001.0088	67	01.0031.0301	71, 79, 81, 87	04.0605.0198	89	04.0607.0140	23
01.0001.0104	71	01.0032.0054	41, 67	04.0605.0199	41	04.0607.0141	71, 73
01.0001.0106	23	01.0032.0055	41, 67, 71, 79	04.0605.0204	43	04.0607.0142	89
01.0001.0110	67	01.0032.0057	79	04.0605.0206	89	04.0607.0143	43
01.0001.0154	39, 81	01.4001.0003	67, 75	04.0605.0209	43	04.0607.0146	39
01.0001.0156	29, 31, 71, 89	01.4001.0006	31	04.0605.0211	25	04.0607.0147	89
01.0001.0158	31, 81, 83, 85	01.4001.0012	29, 67, 79	04.0605.0213	23	04.0607.0149	39
01.0001.0204	31	01.4001.0018	31	04.0605.0215	81	04.0607.0153	39
01.0001.0206	15, 23	01.4001.0023	29	04.0605.0216	81	04.0607.0163	71
01.0001.0209	11, 67, 81	01.4001.0024	79	04.0605.0217	39	04.4210.0016	23, 39, 43
01.0001.0211	73	01.4001.0057	29	04.0605.0220	25	04.4210.0018	71
01.0001.0252	19, 39	01.4001.0063	31	04.0605.0222	43	04.4210.0019	71
01.0001.0254	23, 31, 39, 67, 71, 81	01.4003.0016	39	04.0605.0224	25	04.4210.0024	25
01.0001.0256	23, 29, 41, 43, 77, 83, 85	01.4006.0001	31, 83, 85	04.0605.0232	23	04.4223.0000	89
01.0001.0257	29, 73, 77	01.4006.0016	29	04.0605.0235	23	04.4223.0003	43
01.0001.0310	67, 73	01.4031.0001	29	04.0605.0242	25	04.4223.0004	43
01.0001.0355	41, 71, 89	01.4031.0004	43, 81	04.0605.0248	73	04.4224.0002	43, 89
01.0001.0356	29, 31, 39, 67, 79	01.4032.0002	39, 71, 81, 89	04.0605.0249	77	04.4225.0005	23
01.0001.0357	67, 79, 83, 85	01.4032.0003	23, 29, 39, 43, 71, 81, 83, 85	04.0605.0251	39	04.4227.0000	21, 83, 85
01.0001.0358	79	01.4032.0004	43, 79, 87	04.0605.0252	23	04.4227.0001	83, 85
01.0001.0359	87	01.4032.0005	19, 43, 83, 85	04.0605.0253	41	04.4227.0003	23
01.0001.0401	43	01.4032.0006	31, 79	04.0605.0254	41	04.4227.0006	31, 39
01.0001.0402	79	01.4032.0007	29, 31, 79	04.0605.0255	41	04.4227.0007	83, 85
01.0001.0409	69	02.0117.0101	67	04.0605.0256	77	04.4227.0016	77
01.0001.0503	19	02.4102.0004	79	04.0605.0257	73, 75	04.4229.0034	43
01.0001.0506	83, 85	04.0220.0051	23, 89	04.0605.0258	75	04.4229.0035	43
01.0001.0556	31	04.0220.0053	39	04.0605.0259	75	04.4235.0023	43
01.0001.0606	79	04.0220.0055	31, 89	04.0605.0260	73, 75, 77	04.4236.0045	25
01.0001.0651	43	04.0220.0059	23	04.0605.0262	89	04.4237.0010	25
01.0001.0659	29	04.0227.0051	21, 31, 83, 85	04.0605.0263	87	04.4238.0030	79
01.0001.0702	31	04.0227.0054	39	04.0605.0264	41	04.4238.0033	79
01.0001.1482	89	04.0227.0067	83, 85	04.0605.0265	89	04.4239.0002	71
01.0003.0110	39	04.0227.0144	89	04.0605.0266	89	04.4239.0004	73
01.0003.0157	43, 73, 75, 77, 83, 85	04.0401.0003	39	04.0605.0267	23	04.4239.0005	75
01.0003.0159	83, 85	04.0600.0009	87	04.0605.0268	39	04.4239.0012	87
01.0003.0203	29, 31, 67	04.0600.0013	23	04.0605.0269	25	04.4239.0013	43, 87
01.0003.0208	79	04.0600.0019	71	04.0605.0270	25	04.4239.0019	23
01.0003.0257	43	04.0600.0021	23, 39, 43	04.0605.0271	23	04.4239.0032	23, 43
01.0003.0262	79	04.0600.0025	23	04.0605.0273	87	04.4239.0051	73
01.0003.0405	79	04.0600.0031	23	04.0605.0276	87	04.4239.0052	73
01.0003.0944	19, 67	04.0600.0038	43, 87	04.0605.0277	23	04.4239.0071	39
01.0006.0033	29	04.0600.0041	87	04.0605.0278	71	04.4240.0000	39, 41
01.0006.0049	83, 85	04.0600.0042	43	04.0605.0279	87	04.4240.0015	23
01.0019.0104	67	04.0600.0044	43	04.0605.0280	23	04.4240.0035	39
01.0023.0052	39	04.0600.0045	43	04.0605.0507	23	04.4240.0036	39
01.0023.0053	21, 23, 29, 31, 71, 83, 85	04.0600.0046	87	04.0605.0582	23	04.4240.0037	41
01.0023.0054	11, 15, 23, 29, 31, 67, 73, 81, 83, 85, 87	04.0600.0050	43	04.0605.0583	23	04.4240.0042	25
01.0023.0055	29, 31, 67, 73, 79, 81, 83, 85	04.0600.0052	41	04.0605.0584	25	05.0400.0011	39
01.0023.0056	31, 67, 69, 75, 79, 89	04.0600.0053	43	04.0605.0587	25	05.0401.0007	39
01.0023.0057	29, 67, 79	04.0600.0057	43	04.0607.0103	43	05.4309.0001	39
01.0023.0058	29	04.0600.0068	43	04.0607.0104	43	05.4309.0002	39
01.0023.0062	29	04.0600.0080	21	04.0607.0105	43	05.4329.0003	39
01.0023.0064	19	04.0600.0081	71	04.0607.0107	43, 87, 89	06.0401.0214	43
01.0031.0054	21, 31, 71, 83, 85	04.0600.0087	71, 75	04.0607.0109	75	06.0401.0219	43
01.0031.0055	11, 15, 23, 29, 31, 39, 67, 77, 81	04.0600.0159	23, 39, 43	04.0607.0110	41, 71	06.0401.0842	89
01.0031.0056	31, 83, 85, 89	04.0600.0160	23, 43	04.0607.0111	73, 75, 77, 89	06.0442.0054	23, 39, 43
01.0031.0057	19, 83, 85	04.0600.0161	21	04.0607.0112	23, 25, 71	06.0442.0055	39, 43
01.0031.0058	29, 31, 79	04.0600.0162	21	04.0607.0113	23, 89	06.0442.0057	21, 41
01.0031.0059	43	04.0600.0163	41	04.0607.0114	23, 25, 39, 43, 71, 73	06.0442.0101	23, 89
01.0031.0061	73, 75, 77	04.0600.0165	43	04.0607.0115	23, 39	06.0442.0102	23, 39, 41, 43
01.0031.0063	29	04.0602.0490	43	04.0607.0117	23, 41	06.0442.0103	31, 87, 89
01.0031.0099	79	04.0605.0097	73	04.0607.0119	87, 89	06.0442.0105	23
01.0031.0151	89	04.0605.0112	71	04.0607.0120	87	06.0442.0109	43
01.0031.0298	81, 89	04.0605.0113	71	04.0607.0121	89	06.0442.0111	43, 89
		04.0605.0114	71	04.0607.0124	73, 75, 77	07.0700.0000	43
		04.0605.0167	43	04.0607.0126	73	07.0701.0007	43
		04.0605.0177	39	04.0607.0127	43	07.0703.0052	17
		04.0605.0178	23, 39	04.0607.0129	43	07.0703.0056	17
		04.0605.0179	23	04.0607.0130	81, 87	07.0703.0058	91
		04.0605.0180	25	04.0607.0131	23, 71	07.0703.0060	91
		04.0605.0185	23	04.0607.0132	71	07.0703.0064	91
		04.0605.0193	23	04.0607.0137	41	07.0703.0066	91
				04.0607.0138	75	07.0703.0077	17, 27

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
07.0703.0079	93	07.0709.0232	45, 57	07.0709.0328	51	07.0723.0134	27
07.0703.0080	93	07.0709.0234	59	07.0709.0329	51	07.0723.0135	27
07.0703.0081	93	07.0709.0235	59	07.0709.0330	51	07.0723.0137	27
07.0703.0087	17	07.0709.0236	47, 59	07.0709.0331	51	07.0723.0138	19
07.0703.0088	17, 27	07.0709.0237	47, 59	07.0709.0332	51	07.0723.0140	27
07.0703.0089	17	07.0709.0238	47, 59	07.0709.0333	51	07.0723.0142	19
07.0703.0113	17	07.0709.0239	47, 59	07.0709.0334	51	07.0723.0144	27
07.0703.0116	41	07.0709.0240	47, 59	07.0709.0335	51	07.0723.0145	19
07.0703.0176	91	07.0709.0241	47, 59	07.0709.0336	51	07.0723.0146	19
07.0703.0177	91	07.0709.0242	47, 59	07.0709.0337	51	07.0723.0147	19
07.0703.0178	91	07.0709.0243	47, 59	07.0709.0338	51	07.0723.0148	19
07.0703.0179	93	07.0709.0244	47, 59	07.0709.0339	51	07.0723.0149	21
07.0703.0206	17	07.0709.0245	47, 59	07.0709.0340	51	07.0723.0150	19
07.0703.0455	17	07.0709.0246	47, 59	07.0709.0341	51	07.0723.0152	27
07.0703.0457	17	07.0709.0247	47, 59	07.0709.0342	51	07.0723.0154	27
07.0703.0458	17	07.0709.0248	47, 59	07.0709.0343	51	07.0723.0156	27
07.0703.0459	17	07.0709.0249	47, 59	07.0709.0344	51	07.0723.0157	27
07.0703.0465	19	07.0709.0250	47, 59	07.0709.0345	51	07.0723.0159	21
07.0703.0472	17	07.0709.0252	59	07.0709.0346	51	07.0723.0161	27
07.0703.0473	17	07.0709.0253	47, 59	07.0709.0347	51	07.0723.0162	19
07.0703.0474	17	07.0709.0254	47, 51, 59	07.0709.0348	51	07.0723.0163	27
07.0703.0476	17	07.0709.0255	47, 59	07.0709.0349	51	07.0723.0164	27
07.0703.0477	17	07.0709.0256	47, 59	07.0709.0350	51	07.0723.0165	27
07.0703.0479	17	07.0709.0257	47, 59	07.0709.0351	51	07.0723.0166	27
07.0703.0508	19	07.0709.0258	47, 59	07.0709.0352	51	07.0723.0168	19
07.0703.0509	19	07.0709.0259	47, 59	07.0709.0356	53	07.0723.0169	19, 27
07.0703.0589	41	07.0709.0260	47, 59	07.0709.0357	47, 53	07.0723.0170	19, 27
07.0703.0610	17	07.0709.0261	49, 61	07.0709.0358	45	07.0723.0171	19, 27
07.0703.0611	17	07.0709.0262	49, 61	07.0709.0359	47	07.0723.0172	27
07.0704.0032	11	07.0709.0264	49, 61	07.0709.0360	47	07.0723.0173	19, 27
07.0704.0033	11	07.0709.0265	49, 61	07.0709.0361	49	07.0723.0174	27
07.0704.0034	11	07.0709.0267	49, 61	07.0709.0362	49	07.0723.0175	27
07.0704.0035	11	07.0709.0268	49, 61	07.0709.0363	49, 61	07.0723.0176	27
07.0704.0037	15	07.0709.0269	49, 61	07.0709.0364	49	07.0723.0177	27
07.0704.0038	11	07.0709.0270	49, 61	07.0709.0365	49, 61	07.0723.0179	27
07.0704.0040	15	07.0709.0271	49, 61	07.0709.0366	53	07.0723.0182	27
07.0704.0042	11	07.0709.0272	49, 61	07.0709.0370	55, 63	07.0723.0185	27
07.0704.0045	11	07.0709.0273	49, 61	07.0709.0388	59	07.0723.0186	19
07.0704.0046	15	07.0709.0274	49, 61	07.0709.0389	59	07.0723.0187	19
07.0704.0049	15	07.0709.0275	49, 61	07.0709.0390	61	07.0723.0188	27
07.0704.0113	11	07.0709.0276	49, 61	07.0709.0391	61	07.0723.0190	27
07.0704.0117	13	07.0709.0277	49, 61	07.0709.0392	61	07.0723.0191	21
07.0704.0118	13	07.0709.0278	49, 61	07.0709.0417	55, 63	07.0723.0192	17, 21
07.0704.0119	13	07.0709.0279	49, 61	07.0709.0716	47	07.0723.0193	21
07.0704.0128	23	07.0709.0280	49, 61	07.0709.0717	47	07.0723.0194	21, 83, 85
07.0704.0133	13	07.0709.0281	49, 61	07.0709.367	53	07.0723.0196	19
07.0704.0134	13	07.0709.0282	49, 61	07.0709.368	53	07.0723.0197	19
07.0704.0136	13	07.0709.0284	49, 61	07.0709.369	53	07.0723.0198	19
07.0704.0137	13	07.0709.0285	55, 63	07.0712.0006	81	07.0723.0202	27
07.0704.0138	13	07.0709.0287	65	07.0712.0046	81	07.0723.0214	19
07.0704.0143	15	07.0709.0288	65	07.0712.0047	81	07.0723.0215	19
07.0704.0144	11	07.0709.0289	65	07.0712.0048	81	07.0723.0217	19
07.0704.0145	11	07.0709.0290	49, 61	07.0721.0019	73	07.0723.0219	27
07.0704.0146	15	07.0709.0291	49, 61	07.0721.0042	73	07.0723.0220	27
07.0704.0169	13	07.0709.0297	47	07.0723.0004	29	07.0723.0221	27
07.0705.0085	73	07.0709.0298	47	07.0723.0010	21	07.0723.0222	27
07.0709.0034	51	07.0709.0299	47	07.0723.0011	19	07.0723.0223	27
07.0709.0057	49, 61	07.0709.0300	47	07.0723.0024	19	07.0723.0224	27
07.0709.0065	49, 61	07.0709.0301	47	07.0723.0036	27	07.0723.0225	27
07.0709.0070	49, 61	07.0709.0302	47	07.0723.0037	27	07.0723.0226	27
07.0709.0071	49, 61	07.0709.0303	47	07.0723.0039	17, 19	07.0723.0227	27
07.0709.0079	53	07.0709.0304	47	07.0723.0040	19, 27	07.0723.0228	27
07.0709.0080	57	07.0709.0305	47	07.0723.0045	27	07.0723.0229	27
07.0709.0084	45	07.0709.0306	47	07.0723.0049	19	07.0723.0230	27
07.0709.0104	49, 61	07.0709.0307	47	07.0723.0054	19	07.0723.0231	27
07.0709.0113	49, 61	07.0709.0308	47	07.0723.0055	19	07.0723.0232	27
07.0709.0117	49, 61	07.0709.0309	47	07.0723.0057	27	07.0723.0233	27
07.0709.0118	49, 61	07.0709.0310	47	07.0723.0074	17, 19	07.0723.0236	27
07.0709.0119	49, 61	07.0709.0311	47	07.0723.0076	19, 21, 27	07.0723.0237	27
07.0709.0124	49, 61	07.0709.0320	47	07.0723.0090	21	07.0723.0283	19
07.0709.0134	55, 63	07.0709.0321	49, 61	07.0723.0096	19, 27	07.0723.0287	27
07.0709.0160	47, 59	07.0709.0323	49	07.0723.0104	17	07.0723.0288	27
07.0709.0171	49, 61	07.0709.0324	51	07.0723.0108	21	07.0723.0289	27
07.0709.0174	47, 59	07.0709.0325	51	07.0723.0109	21	07.0723.0290	27
07.0709.0184	53	07.0709.0326	51	07.0723.0111	19	07.0723.0291	27
07.0709.0218	65	07.0709.0327	51, 53	07.0723.0133	27	07.0723.0337	27

Part Number Index (continued)

Part Number	Page	Part Number	Page	Part Number	Page	Part Number	Page
07.0723.0340	27	09.4618.0010	33	51.1301.4400	69	56.0016.0073	17
07.0723.0341	27	09.4618.0071	33	52.1100.7200	29	626804	89
07.0723.0342	27	09.4618.0109	33, 35	52.1200.0700	17	628275	53
07.0723.0343	27	09.4618.0205	33	52.1200.1100	17	629327	53
07.0723.0345	27	09.4618.0389	35	52.1200.3700	17	629733	51, 53
07.0723.0352	19	09.4618.0639	33	52.1200.3800	17	629735	51
07.0726.0044	87	09.4618.0640	33	52.1200.3900	17	630328	51
07.0726.0065	29	09.4618.0641	33	53.0000.2300	75	630694	59
07.0726.0083	29	09.4618.0642	33	53.0100.1600	75	632070	51
07.0728.0005	39, 41	09.4618.0646	35	53.0300.1300	73	632383	49, 61
07.0730.0013	39	09.4627.0016	37	53.0400.0800	73	633098	59
07.0730.0014	39	09.4629.0020	37	53.0500.0400	71	633109	53
07.0730.0017	39	09.4632.0044	37	53.3000.1100	23	633110	59
07.0730.0019	39	09.4632.0045	37	53.3000.1300	89	633160	59
07.0730.0023	39	09.4635.0014	37	53.3001.0500	71	633161	53
07.0730.0025	39	09.4635.0036	37	53.3001.0700	89	633176	49, 61, 65
07.0738.0002	37	09.4636.0003	41	53.3001.0800	23	633202	47, 53
07.0740.0347	19	09.4636.0008	41	53.3001.1000	83, 85	633204	45, 57
07.4501.0041	83, 85	09.4636.0012	41	53.3001.1100	83, 85	633208	53
07.4501.0042	83, 85	09.4645.0024	83, 85	53.3001.1200	83, 85	633529	47, 59
07.4501.0059	91	09.4645.0028	83, 85	53.3100.0020	83	633531	59
07.4501.0060	83, 85	09.4656.0007	83, 85	53.3100.0033	85	633533	47, 59
07.4501.0061	83, 85	09.4656.0009	83, 85	53.3200.0022	81	633568	47, 59
07.4501.0067	79	09.4661.0002	89	53.3301.0002	31, 87	633569	59
07.4501.0068	79	09.4661.0010	31	53.3302.0017	81	633574	59
07.4501.0105	73	09.4661.0014	89	53.3401.2700	75	633944	59
07.4529.0028	23	09.4661.0016	89	53.3401.2800	75	633946	47
07.4529.0033	39, 41	09.4670.0000	31	53.3401.2900	77	634391	47
07.4529.0072	75	09.4670.0001	81	53.3401.3000	77	634392	47, 59
07.4529.0091	75	09.4670.0002	81	53.3401.3100	73	634393	47, 59
09.0803.0000	29	09.4670.0004	29, 79	53.3401.3200	73	634397	55, 63
09.0803.0002	31	51.0111.2000	29	54.0000.0027	31	634403	59
09.0803.0005	29	51.0201.0000	67	54.0000.0068	69	634546	49, 61
09.0803.0008	83, 85	51.0201.0100	67	54.0000.0115	67	634728	39
09.0803.0012	29	51.0400.0300	71	54.0000.0116	75	634972	93
09.0803.0013	31	51.0600.2200	31	54.0000.0117	67	634973	93
09.0803.0024	29	51.0600.3100	87	54.0001.0001	71	634981	79
09.0803.0025	31	51.0800.3800	31	54.0001.0022	71	635594	53
09.0803.0026	31	51.0804.8400	67	54.0001.0030	67	635596	53
09.0803.0027	85	51.0804.9000	67	54.0002.0013	73	635965	73
09.0803.0043	43, 73, 75, 77	51.0805.1900	29	54.0002.0014	67	637536	53
09.0803.0060	73, 77	51.0806.1600	79	54.0002.0025	73	637574	53
09.0803.0061	73, 77	51.0806.1800	79	54.0002.0026	67	637577	53
09.0803.0062	67	51.0806.2400	83, 85	54.0003.0026	67	637582	53
09.0803.0064	83, 85	51.0806.2700	83, 85	54.0003.0027	67	637584	53
09.0803.0088	39	51.0806.2800	83, 85	54.0100.0002	29	638548	49, 51, 61, 65
09.0803.0109	83, 85	51.0806.3000	43	54.0100.0017	29	639327	51
09.0803.0175	39	51.0806.3500	23	54.0100.0027	69	639328	53
09.0803.0232	87	51.0806.3800	67	54.0100.0066	79	639329	51, 53
09.0803.0244	29	51.0806.6100	67	54.0101.0002	31	639395	71
09.0803.0245	29, 81	51.0806.6900	29	54.0200.0000	67	639637	47
09.0803.0251	83, 85	51.0806.7000	29	54.0200.0001	67	639639	49, 61
09.0803.0264	29	51.0806.7500	79	54.0201.0007	67	639641	49, 61
09.0803.0265	29	51.0806.8100	31	54.0201.0008	73	639642	49, 61
09.0804.0100	79	51.0806.8200	31	54.0201.0009	67	639643	49, 61
09.0804.0900	79	51.0806.8600	29	54.0201.0011	75	639646	49, 61
09.0804.1000	79	51.0806.8700	29	54.0702.0000	67	639670	49, 61
09.0804.1100	79	51.0806.8900	81	54.0702.0001	67	639778	53
09.0804.1200	79	51.0808.6000	23	54.0702.0002	67	639779	53
09.0805.0000	31, 39	51.0809.1800	83, 85	54.0702.0005	67	639780	53
09.0805.0007	89	51.0809.3900	67	54.0702.0013	67	639781	53
09.0805.0053	83, 85	51.0809.4000	67	54.0702.0014	29	639782	53
09.0805.0054	83, 85	51.0901.5500	29	55.0403.0051	37	639784	53
09.0805.0057	83, 85	51.0902.5600	29	55.0600.0069	91	639785	53
09.0805.0058	83, 85	51.0902.5800	29	55.0601.0041	91	639787	53
09.0806.0019	89	51.0902.5900	29	55.0602.0014	91	639789	53
09.4601.0029	79	51.0902.6000	29	55.0602.0015	91	639790	53
09.4604.0001	43	51.0902.8000	31	55.0602.0158	91	639791	53
09.4604.0004	89	51.0903.1500	71	55.0605.0306	91	639792	53
09.4604.0039	83, 85	51.1000.2900	31	56.0008.0003	91	639793	53
09.4610.0003	19, 29	51.1000.3700	31	56.0009.0003	91	639794	53
09.4610.0011	29	51.1000.3800	31	56.0012.0027	39	639796	53
09.4610.0024	19	51.1000.4500	31	56.0013.0000	87	639797	53
09.4610.0025	19	51.1100.0014	19	56.0013.0001	31	639798	53
09.4616.0051	35	51.1301.2400	69	56.0013.0015	53	639799	53
09.4616.0101	35	51.1301.4300	69	56.0016.0072	17	639800	53

Part Number Page

639802	53
639803	53
639804	53
639807	53
639808	53
639809	53
639810	53
639811	53
639812	53
639813	53
639814	53
639815	53
639816	53
639916	53
639992	73
639993	75
640125	79
640196	53
640198	53
640206	47
640207	47
640495	17
640496	17
640497	17
640636	39
640885	83, 85
640985	21
640990	21
640995	27
640996	27
641004	27
641009	19
641019	27
641020	27
641024	27
641027	27
641042	27
641053	17
641065	17
641124	79
641135	93
82558	33
97664	33
97665	33
97666	33
97667	33
97668	33
97669	33
97670	33
97671	33
97672	33
97673	33
97674	33
97675	33
97676	33
97688	33
992989	41
999058	79

Part Description Index

The Part Description Index is an alphabetical index of all part descriptions included in this manual. The index shows what page(s) the part is used on.

6 603847 pos. 45.....39 603847 pos. 49.....73 603847 pos. 50.....43 603847 pos. 61.....39	DECAL,WARN,BURN HAZARD.....33 DECAL,WARN,CRUSH HAZ MOVING PT.....33 DECAL,WARN,EXPLSION/BURN HAZ.....33 DECAL,WARN,FALLING OBJECT HAZ.....33 DECAL,WARN,OVERTURN HAZARD.....33 DECAL,WARN,READ MANUAL.....33 DECAL,WARN,WEAR SEAT BELT.....33 Diesel Engine.....79 Diesel Oil Filter.....79 Diesel Oil Tank.....31 Differential Case.....47, 59 Differential Side Gear.....47, 59 Door Stop.....27 Dowel.....47, 51, 53, 59 Drilled Screw.....39 Driving Mirror.....19, 29	Hub.....49, 61 Hydraulic Motor.....43 I Indicator.....17, 43 Insulation.....81 Insulator.....29, 79, 81, 87
A Air Inlet.....17, 21 Arm.....49, 61, 67 Articulated Tie Rod.....55, 63 Articulation.....13, 49, 61, 83, 85	E Elastic Joint.....79 Exhaust Muffler.....83, 85 Extension Cylinder.....75 External Sound-Proofing.....19	J Joint.....49, 61 Joint Kit.....23, 39, 41, 55, 63, 71, 73, 75
B Back-Up Ring.....51 Ball Joint.....73 Ball-Grip.....21 Basic Arm.....67 Battery.....91 BEARING.....47, 53, 59 Bearing.....47, 49, 53, 59, 61 Bevel Gear Set.....47, 59 BLEEDER VALVE, LONG.....51 Block.....27, 39 Body.....13 Bracket.....19, 23, 31, 39, 77, 81, 83, 85, 91 Brake Disc.....51 Busching.....27 Bushin.....27, 47, 51, 65 Bushing.....39, 47, 49, 61, 65, 67, 73, 75	F Fan.....81 Female Coupling.....71 Filter.....21, 89 Flange.....13, 43, 53, 59 Flexible Hose.....23, 25, 39, 41, 43, 71, 73, 75, 77, 81, 87, 89 Flexible Hose from SN 15088.....23, 25 Flexible Hose to SN 15089.....23, 25 Fork Coupling Attachment.....71 Fork from SN 14786.....69 Fork to SN 14787.....69 Frame.....19, 27, 29 FRAME, SWITCH.....17 Front Axle.....37 Fuel Gauge.....31 Fuse.....91, 93 FUSE, 15A.....93 FUSE, 7.5A.....93	K Key.....27 Knurled Coupling.....21, 39 L Label.....27, 33, 35 Left Counterweight.....31 Left Dashboard.....17 Left Side Glass.....27 Level Gauge.....19 Level Indicator.....89 Lever.....27, 39 Lifting Jack.....75 Lock.....19, 21, 27, 29 Lower Door.....27
C Cable.....83, 85, 91 CAP.....49, 51, 61, 65 Cap Kit.....11 Cardan Joint Assembly Kit.....37 Cardan Shaft.....37 Cartridge.....43, 83, 85 Clamp.....21, 23, 31, 39, 73, 75, 77, 83, 85, 89 Clip.....31 Clutch Disc.....47 Coating.....19 Collar.....83, 85 Complete Air Filter.....83, 85 Complete Filter.....43 Complete Radiator.....81 Connector.....41, 91 Control Lever.....13, 25 Control Valve.....11, 15, 25 Conveyor.....23, 81 Counterweight from SN 14634.....31 Counterweight to SN 14635.....31 COVER.....53 Cover.....53, 59, 87 Cursor.....11, 13, 15 Cylinder.....29, 53, 55, 63, 71, 73	G Gear.....53 Glass.....17, 19, 27 Glass Stop.....27 Grate.....19 GREASE NIPPLE.....49, 61, 65 Grease Nipple.....67 Guard.....17, 19, 27, 29, 31, 71, 81	M Male Coupling.....71 Manifold.....23, 71, 83, 85, 89 Mud-Guard.....29 N Name Plate.....17, 35 Needle For Inclinator.....67 Nut.....23, 27, 29, 31, 39, 47, 49, 53, 59, 61, 67, 73, 75, 79, 81, 83, 85, 87, 89 Nut, M6.....21, 23, 29, 31, 71, 83, 85 NUT, DIN439 JAM M16-2.0 P.....49, 61
D Dashboard.....17 DECAL,DANGER,CRUSH HAZARD.....33 DECAL,DANGER,ELECTRICAL HAZARD.....33 DECAL,DANGER,EXPLSION/BURN HAZ.....33 DECAL,DANGER,NO RIDERS.....33 DECAL,EMERGENCY EXIT HANDLE.....33	H Half Flange.....43 Half-Joint.....79 Handle.....27, 29, 31 Handwheel Arrangement.....79 Hatch.....29 Heater.....21 Hinge.....27, 29, 31 Hook.....27, 29 Horn.....91 Hour Meter.....17 Housing.....45, 49, 53, 61, 93 HUB.....79	O O-RING.....53, 55, 59, 63 Oil Filter.....79 Oil Tank.....39, 87 P Paper Piping.....21 Parking Brake Kit.....91 Pedal.....39, 83, 85 Pilot Light.....17 Pin.....27, 31, 39, 47, 49, 51, 59, 61, 67, 69, 71, 73, 75 PINION GEAR.....47, 59 PINION, DIFFERENTIAL.....49, 61 Pipe.....73, 75, 77 Pipe Fitting.....21, 23, 25, 27, 39, 41, 43, 49, 61, 71, 73, 75, 77, 81, 87, 89 Piston.....51, 53 Plain Washer.....19, 21, 27, 29, 31, 39, 43, 71, 79, 81, 83, 85, 87, 89 Plate.....27, 29, 41, 69, 73, 77 PLATE, COVER.....53

Plug.....11, 15, 17, 19, 23, 31, 39, 45, 49, 53,
57, 61, 89
PLUG,BREATHER.....49, 53, 61
PLUG,MAGNETIC.....53
Power Steering.....41
Precleaner.....83, 85
Pressure Switch.....39
Pressure Tube.....23, 39, 43
Protection.....13, 79
Proximity Switch.....53, 83, 85
Pull Box.....91
Pulley.....79
Pump.....39, 79
Push Button.....13
Pvc Back.....19

R

Radiator Core.....81
Rain Protector.....85
Ratainer Pipe.....83, 85
Rear Axle.....37
Red Pushbutton Cap.....13
Relay.....91, 93
Relay Holder.....91
Retainer.....17, 31
Retainer Pipe.....43, 83, 85
Right Counterweight.....31
Right Dashboard.....17
Rim.....37
Ring.....47, 49, 59, 61
RING GEAR.....49, 61
Ring Nut.....47, 51
RING/SEAL.....53
ROD.....53
Rod.....31
Roof Lamp.....19
Rubber.....19, 27, 81
Rubber Hose.....21, 27, 31, 39, 83, 85, 89
Rubber Platform.....19
Rubber Protection.....53

S

Safety Belt.....19
SCREW.....53
Screw.....11, 15, 17, 19, 21, 23, 27, 29, 31, 39,
41, 43, 47, 49, 51, 53, 55, 59, 61, 63, 67, 69,
71, 73, 75, 77, 79, 81, 83, 85, 87, 89
SEAL.....53
Seal.....19, 27, 29, 31, 43, 47, 49, 51, 53, 61,
73, 75, 81, 87, 89
SEAL KIT.....41
SEAL KIT,CYLINDER.....73
SEAL RING.....53
SEAL,DIFFERENTIAL.....59
Sealing Washer.....51, 53
Seat.....19
Security Dowel.....51
Security Switch.....53
Selector.....17
Selector Fork.....53
Selector Shaft.....53
Sensure Switch.....39
Shaft.....53
Sheet.....49, 53, 59, 61
SHIM.....51, 53
SHIM,THICKNESS.....47, 51, 53, 59
Shock Absorber.....19
SLEEVE.....53

Sleeve.....43
Sliding Block Holder.....67
SLIDING GUIDE.....53
Sliding Guide.....29, 67
Snap Ring.....47, 49, 51, 61, 73, 79
SNAP RING (CIRCLIP).....45, 57
Solenoid.....15, 23, 39, 41, 43
Solenoid Tube Kit.....15
Solenoid Valve.....25, 41
Spacer.....27, 31, 47, 51, 53, 59
Speed Lever.....17
Sphere.....47, 51, 53
SPLIT PIN.....53
Split Pin.....51, 79
Sprayer.....27
Spring.....39, 51, 53, 83, 85
Spring Kit.....15
Spring Split Pin.....31
Spring Washer.....19, 29, 31, 39, 43, 53, 71, 79,
81, 83, 85, 87, 89
Star Wheel.....37, 47, 59
Starting Switch.....17
Steering Column.....41
Steering Wheel.....41
Stop.....27
Stop Belt.....27
Stop Nut.....11, 15, 19, 29, 31, 69
Stop Pad.....27
Stud.....47, 49, 61
Stuffing Box.....91
Support.....19, 23, 29, 39, 43, 49, 61, 65, 79,
83, 85
Switch.....17, 27

T

Tank.....27
Tap.....21, 43, 89
Thickness.....47, 49, 53, 59, 61, 67
Tie Rod.....31
Transmitter.....87
Tyre.....37

U

Upper Door.....27

V

Valve.....11, 23, 39, 43, 71, 73, 75, 87

W

WASHER.....47, 59, 79
Washer.....11, 15, 17, 19, 21, 23, 27, 29, 31,
39, 41, 43, 49, 61, 67, 69, 71, 73, 75, 77, 79,
83, 85, 87, 89
WASHER,SEALING.....53
Wheel.....37
Wiper Arm.....27
Wiper Blade.....27
Wiper Motor.....27
Wiring Harness.....91

Y

Yellow Pushbutton Cap.....13

Fitting Cross References

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
12342	6-4 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	42794	1 CR-S	ELBOW,90°,MALE PIPE
13757	4 R6X-S	RUN TEE,SWIVEL NUT,ORFS	42795	BV-0839	BALL VALVE
19685	12-10 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42796	BV-0838	BALL VALVE
22664	12-10 C5OX	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42874	6-8 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
27431	8-12 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	42912	13943-6-4	HOSE END,90° FEMALE SWIVEL,JIC
28678	AS-B-33	SLEEVE,NYLON,1.81" ID	42920	BV-0840	BALL VALVE,90°
39871	6 WETX-WLN-S	UNION,90° BULKHEAD W/NUT,FLARE TUBE	42932	AS-B-17	SLEEVE,NYLON,1.22" ID
39872	4 R5OX-S	RUN TEE,STRAIGHT THREAD	42936	10243-2-4	HOSE END,FEMALE PIPE
39873	6 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42953	1/2 DD-S	ELBOW,90°,FEMALE PIPE
39874	8-6 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	42956	6 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS
39875	4-6 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	45349	8 V5OX-S	ELBOW,45°,STRAIGHT THREAD TO FLARE TUBE
39876	6-8 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE	45351	4 V5OX-S	ELBOW,45°,STRAIGHT THREAD TO FLARE TUBE
39877	4 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	47223	10343-6-6	HOSE END,MALE,JIC
39878	6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	47419	PS690503-6-6	SWIVEL,90°,STRAIGHT THREAD TO 37° FLARE
39879	4-8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	48750	421-4	HOSE,1/4 INCH ID
39880	6-10 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	48751	481TC-4	HOSE,1/4 INCH ID
39881	4-6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	48752	482TC-4	HOSE,1/4 INCH ID
39882	4-HP5ON-S	PLUG,STRAIGHT THREAD	48753	451TC-6	HOSE,3/8 INCH ID
39883	8-8 FTX-S	CONNECTOR,MALE PIPE TO FLARE TUBE	48754	482TC-6	HOSE,3/8 INCH ID
39885	269HB 12-12	ELBOW,90°,BEADED HOSE BARB TO MALE PIPE	48755	381-6	HOSE,3/8 INCH ID
39886	431-6	HOSE,3/8 INCH ID	48756	451TC-8	HOSE,1/2 INCH ID
39887	540N-2	HOSE,1/8 INCH ID	48757	482TC-8	HOSE,1/2 INCH ID
39888	801-8	HOSE,1/2 INCH ID	48758	381-8	HOSE,1/2 INCH ID
39889	801-12	HOSE,3/4 INCH ID	48759	381-10	HOSE,5/8 INCH ID
39890	10643-6-6	HOSE END,FEMALE SWIVEL,JIC	48760	451TC-10	HOSE,5/8 INCH ID
39891	13943-6-6	HOSE END,90° FEMALE SWIVEL,JIC	48761	482TC-12	HOSE,3/4 INCH ID
39892	13743-6-6	HOSE END,45° FEMALE SWIVEL,JIC	48762	451TC-12	HOSE,3/4 INCH ID
39894	30682-8-8	HOSE END,FEMALE SWIVEL,JIC	48763	772-12	HOSE,3/4 INCH ID
39895	30682-10-12	HOSE END,FEMALE SWIVEL,JIC	48764	881-16	HOSE,1 INCH ID
42286	8-8 CTX-S	ELBOW,90°,MALE PIPE TO FLARE TUBE	48765	772-16	HOSE,1 INCH ID
42756	8-12 CLO-S	ELBOW,90,MALE PIPE TO ORFS	48766	AS-B-15	SLEEVE,NYLON,1.06" ID
42757	8-12 FLO-S	CONNECTOR,MALE PIPE TO ORFS	48767	AS-B-22	SLEEVE,NYLON,1.42" ID
42758	4 JLO-S	UNION TEE,ORFS	48770	881-8	HOSE,1/2 INCH ID
42759	4-4 FLO-S	CONNECTOR,MALE PIPE TO ORFS			
42760	6-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS			
42761	1J143-6-4	HOSE END,90° FEMALE SWIVEL,SEAL LOK			
42762	1J743-6-4	HOSE END,45° FEMALE SWIVEL,SEAL LOK			
42768	1JO43-4-4	HOSE END,MALE,SEAL LOK			
42776	601-8	HOSE,1/2 INCH ID			
42777	1J743-16-16	HOSE END,45° FEMALE SWIVEL,SEAL LOK			
42786	16 CLO-S	ELBOW,90°,MALE PIPE TO ORFS			
42787	16 R6LO-S	RUN TEE,SWIVEL NUT,ORFS			
42788	16-8 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS			
42789	6-6 CLO-S	ELBOW,90°,MALE PIPE TO ORFS			
42790	8-10 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			
42791	3/4 CD-S	ELBOW,90°,MALE TO FEMALE PIPE			
42792	3/4 X 1/2 PTR-S	REDUCER,MALE TO FEMALE PIPE			
42793	1/2 CR-S	ELBOW,90°,MALE PIPE			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
48771	881-10	HOSE, 5/8 INCH ID	48847	13943-12-12	HOSE END, 90° FEMALE SWIVEL, JIC
48772	381-4	HOSE, 1/4 INCH ID	48848	10543-12-12	HOSE END, MALE, STRAIGHT THREAD
48773	AS-B-13	SLEEVE, NYLON, .86" ID	48849	1JC71-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
48800	1JC43-4-4	HOSE END, FEMALE SWIVEL, SEAL LOK	48850	1JS71-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
48801	1J743-4-4	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	48851	1J171-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48802	1J943-4-4	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48852	1J771-12-12	HOSE END, 45° FEMALE SWIVEL, SEAL LOK
48804	1JM43-4-4	HOSE END, MALE, SEAL LOK, NO O-RING	48853	1J971-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48805	10643-4-4	HOSE END, FEMALE SWIVEL, JIC	48854	1JC43-16-16	HOSE END, FEMALE SWIVEL, SEAL LOK
48806	13943-4-4	HOSE END, 90° FEMALE SWIVEL, JIC	48855	1J943-16-16	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48807	1JS43-4-4	HOSE END, FEMALE SWIVEL, SEAL LOK	48856	1J171-16-16	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48808	3JC82-8-8	HOSE END, FEMALE SWIVEL, SEAL LOK	48857	1J971-16-16	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
48809	3JC82-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK	48859	1JS43-8-4	HOSE END, FEMALE SWIVEL, SEAL LOK
48810	1JC43-6-4	HOSE END, FEMALE SWIVEL, SEAL LOK	48867	PD36BTL	DIAGNOSTIC NIPPLE, SEAL-LOK SWIVEL
48811	1J943-6-4	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48873	6 PNLO-S	PLUG, TUBE END, ORFS
48812	1JC43-6-6	HOSE END, FEMALE SWIVEL, SEAL LOK	48874	6 PNTX-S	PLUG, FLARE TUBE
48813	1J143-6-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48875	6 R6LO-S	RUN TEE, SWIVEL NUT, ORFS
48814	1J543-6-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48877	4 F5OLO-SW.025	CONNECTOR, STRAIGHT THREAD TO ORFS, W/.025 ORI
48815	1J743-6-6	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	48878	16-12 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS
48816	1J943-6-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48879	8 C6LO-S	ELBOW, 90°, SWIVEL NUT ORFS
48817	1JS43-6-8	HOSE END, FEMALE SWIVEL, SEAL LOK	48880	PD6-285	CAP, DIAGNOSTIC NIPPLE
48818	1J943-8-4	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48881	6 HLO-S	UNION, ORFS
48819	1JC43-8-6	HOSE END, FEMALE SWIVEL, SEAL LOK	48883	8 P5ON-S	PLUG, STRAIGHT THREAD
48820	1J743-8-6	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	48884	8M18F87OMLO-S	CONNECTOR, METRIC, STRAIGHT THREAD TO ORFS
48821	1J943-8-6	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48885	4 WGTX-WLN-S	CONNECTOR, BULKHEAD, FEMALE PIPE TO FLARE TUBE
48822	1JC43-8-8	HOSE END, FEMALE SWIVEL, SEAL LOK	48886	4 F5OLO-SW/2MM	CONNECTOR, MACHINED STRAIGHT THREAD TO ORFS
48823	1JS43-8-8	HOSE END, FEMALE SWIVEL, SEAL LOK	48887	4 CTX-S	ELBOW, 90°, MALE PIPE TO FLARE TUBE
48824	1J143-8-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48888	10-12 V5OLO-S	ELBOW, 45°, STRAIGHT THREAD TO ORFS
48825	1J543-8-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	48890	4 S5OLO-S	BRANCH TEE, STRAIGHT THREAD TO ORFS
48826	1J743-8-8	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	48891	4 S6LO-S	BRANCH TEE, SWIVEL NUT TO ORFS
48827	1J943-8-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48828	1JC43-10-8	HOSE END, FEMALE SWIVEL, SEAL LOK			
48829	1JS43-10-8	HOSE END, FEMALE SWIVEL, SEAL LOK			
48830	1J743-10-8	HOSE END, 45° FEMALE SWIVEL, SEAL LOK			
48831	1J943-10-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48833	1JC43-10-10	HOSE END, FEMALE SWIVEL, SEAL LOK			
48834	1J943-10-10	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48835	1JS43-10-12	HOSE END, FEMALE SWIVEL, SEAL LOK			
48836	1JC43-12-8	HOSE END, FEMALE SWIVEL, SEAL LOK			
48837	1JS43-12-8	HOSE END, FEMALE SWIVEL, SEAL LOK			
48838	1J743-12-8	HOSE END, 45° FEMALE SWIVEL, SEAL LOK			
48839	1J943-12-8	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48840	1J943-12-10	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48841	1JC43-12-12	HOSE END, FEMALE SWIVEL, SEAL LOK			
48842	1JO43-12-12	HOSE END, MALE, SEAL LOK			
48843	1J143-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48844	1J543-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
48845	1J743-12-12	HOSE END, 45° FEMALE SWIVEL, SEAL LOK			
48846	1J943-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
48892	6 C6LO-S	ELBOW,90°,SWIVEL NUT ORFS	48938	8 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48893	6 F5OHAQ-S	UNION,STRAIGHT THREAD	48939	8 S6LO-S	BRANCH TEE,SWIVEL NUT TO ORFS
48894	8 WLO-WLNL-S	UNION,BULKHEAD,ORFS	48940	8 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48895	DT-370-MSMO-5	VALVE,CHECK	48941	8-4 TRLO-S	REDUCER,TUBE END TO SWIVEL,ORFS
48896	6 JLO-S	UNION,TEE,ORFS	48942	8-6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48897	DT-750-MSMS-5	VALVE,CHECK	48943	8-6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48898	DT-750-MOMS-5	VALVE,CHECK	48944	8-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48899	DT-620-MOMS-5	VALVE,CHECK	48945	8 FTX-S	CONNECTOR,MALE PIPE TO FLARE TUBE
48900	4-6 F5OLO-SW/.035	CONNECTOR,STRAIGHT THREAD TO ORFS, W/.035 ORI	48946	8-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48902	16-1 AOE4G-S	ELBOW,90° LONG,FEMALE PIPE TO STRAIGHT THREAD	48947	8-12 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48903	1 FF-S	NIPPLE,PIPE	48948	8-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48904	4 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48949	8-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48905	4 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48950	10 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48906	4 R5OLO-S	RUN TEE,STRAIGHT THREAD	48951	10 CC5OLO-S	ELBOW,90° LONG,STRAIGHT THREAD TO ORFS
48907	4 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	48952	10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48908	4 R6LO-S	RUN TEE,SWIVEL NUT,ORFS	48953	10 R5OLO-S	RUN TEE,STRAIGHT THREAD
48909	4 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS	48954	10 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48910	4 GTX-S W/.030	CONNECTOR,FEMALE PIPE TO FLARE TUBE	48955	10 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48911	4-6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48956	10-4 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48912	4-6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48957	10-6 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48913	4-6 F5OLO-SW/.030	CONNECTOR,STRAIGHT THREAD TO ORFS, W/.030 ORI	48958	10-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48914	4-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48959	12 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48915	6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48960	12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48916	6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	48961	12 R5OLO-S	RUN TEE,STRAIGHT THREAD
48917	6 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS	48962	12 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48918	6 R5OLO-S	RUN TEE,STRAIGHT THREAD	48963	12 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48919	6 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS	48964	12 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48920	6 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	48965	12 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
48921	6 FLO-S	CONNECTOR,MALE PIPE TO ORFS	48966	12 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48922	6-6 FLO-S	CONNECTOR,MALE PIPE TO ORFS	48967	12 JLO-S	UNION TEE,ORFS
48923	6 P5ON-S	PLUG,STRAIGHT THREAD	48968	12 WLO-WLNL-S	UNION,BULKHEAD,ORFS
48925	6 WELO-S	UNION,90° BULKHEAD,ORFS	48969	12 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48926	6-4 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	48970	12 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS
48927	6-4 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48928	6-4 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			
48929	6-8 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS			
48930	6-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48931	6-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48932	8 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS			
48933	8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
48934	8 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS			
48935	8 R5OLO-S	RUN TEE,STRAIGHT THREAD			
48936	8 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS			
48937	8 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
48971	12 G5G5JG5-S	TEE,FEMALE STRAIGHT THREAD	49612	PKT02586	O-RING KIT (ORFS FITTINGS)
48972	12 XHL6-S	ADAPTER, 37° MALE TO SWIVEL ORFS	49613	PKT06276	PLUG AND CAP KIT-SERVICE,ORFS
48973	12-1/2 F5OG-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD	49728	10143-12-12	HOSE END, MALE PIPE
48974	12-10 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	49729	16-1 F5OG-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD
48975	12-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	49814	12-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48976	12-16 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	49829	DT-500-MOMF-5	VALVE,CHECK
48977	12-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	49831	881-12	HOSE,3/4 INCH ID
48978	12-16 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	49834	16 JLO-S	UNION TEE,ORFS
48980	12-16 FLO-S	CONNECTOR,MALE PIPE TO ORFS	49838	12-8 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48983	16 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS	49840	8 JLO-S	UNION TEE,ORFS
48984	16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	49844	10-8 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48985	16 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	49854	8 P5ON-S	PLUG,STRAIGHT THREAD
48986	16 FLO-S	CONNECTOR,MALE PIPE TO ORFS	49855	1JC43-16-12	HOSE END,FEMALE SWIVEL,SEAL LOK
48988	16 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	49859	4 P5ON-S	PLUG,STRAIGHT THREAD
48989	12 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	49861	4 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS
48990	8 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	49867	12-3/4 F5OG-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD
48991	16-12 FLO-S	CONNECTOR,MALE PIPE TO ORFS	51152	6 R6X-S	RUN TEE,SWIVEL NUT,ORFS
48992	16-12 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	51153	6-4 TRTX-S	REDUCER,TUBE END TO SWIVEL,ORFS
48993	XV501-12	BALL VALVE	51154	4-4 GTX	CONNECTOR,FEMALE PIPE TO FLARE TUBE
48994	XV501-16	BALL VALVE	51264	881-12	HOSE,3/4 INCH ID
48995	XV510P-12	BALL VALVE	51265	8 JLO-S	UNION TEE,ORFS
48996	XV510P-16	BALL VALVE	51508	6 BTX-S	NUT,FLARE TUBE
48997	PD341	DIAGNOSTIC NIPPLE, STRAIGHT THREAD	51580	12-8 TRLO-BL-S	TUBE END REDUCER,ORFS
48998	PD 361	DIAGNOSTIC NIPPLE, STRAIGHT THREAD	51628	6 R6X-S	RUN TEE,SWIVEL NUT,ORFS
48999	DT-500-MOMS-5	VALVE,CHECK	51735	3/8 HHP	PLUG,PIPE THREAD
49201	10 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	51803	1J943-6-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK
49202	1JC43-12-10	HOSE END,FEMALE SWIVEL,SEAL LOK	53023	125HBL-5-4	FITTING,HOSE BARB TO MALE PIPE
49203	10-8 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS	53497	PKT02585	O-RING KIT
49205	6 F5OHAO-S	UNION,STRAIGHT THREAD	53499	1JC71-16-16	HOSE END,FEMALE SWIVEL,SEAL LOK
49207	PD34BTL	DIAGNOSTIC NIPPLE,SEAL-LOK SWIVEL	53500	3-904	O-RING,STRAIGHT THREAD,-4
49209	8M18F870MX-S	CONNECTOR,METRIC,STRAIGHT THREAD TO FLARE TUBE	53501	3-906	O-RING,STRAIGHT THREAD,-6
49212	8 WGTX-WLN-S	CONNECTOR,BULKHEAD,FEMALE PIPE TO FLARE TUBE	53502	3-908	O-RING,STRAIGHT THREAD,-8
49213	30682-8-8	HOSE END,FEMALE SWIVEL,JIC	53503	3-910	O-RING,STRAIGHT THREAD,-10
49216	831-8	HOSE,1/2 INCH ID			
49217	33982-8-8	HOSE END,90° FEMALE SWIVEL,JIC			
49219	PS-B-35	SLEEVE,NYLON,2.19" ID			
49418	4-6 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			
49511	DT370-MOMS-5	VALVE,CHECK			
49512	1 DD-S	ELBOW,90°,FEMALE PIPE			
49513	1 FF-S	NIPPLE,PIPE			
49514	10 HP5ON-S	PLUG,STRAIGHT THREAD			
49515	12-16 CLO-S	ELBOW,90°,MALE PIPE TO ORFS			
49517	6 HP5ON-S	PLUG,STRAIGHT THREAD			
49519	16-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
49520	4 VTX-S	ELBOW,45°,MALE PIPE TO FLARE TUBE			
49530	16 C6LO-S	ELBOW,90°,SWIVEL NUT ORFS			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
53535	3-912	O-RING, STRAIGHT THREAD, -12	61083	24 F5OLO-S	CONNECTOR, STRAIGHT THREAD TO ORFS
53536	4-PNLO-S	PLUG, TUBE END, ORFS	61086	20 R5OLO-S	RUN TEE, STRAIGHT THREAD
53537	6 PNLO-S	PLUG, TUBE END, ORFS	61090	24-20 F5OLO-S	CONNECTOR, STRAIGHT THREAD TO ORFS
53538	8 PNLO-S	PLUG, TUBE END, ORFS	61091	1J943 24-24	HOSE END, 90° FEMALE SWIVEL, SEAL LOK
53539	10 PNLO-S	PLUG, TUBE END, ORFS	61093	1J978-12-12	HOSE END, 90° FEMALE SWIVEL, JIC
53540	12 PNLO-S	PLUG, TUBE END, ORFS	61095	1JS43-20-16	HOSE END, FEMALE SWIVEL, SEAL LOK
53946	129HB-5-4	FITTING, 90° HOSE BARB TO MALE PIPE	61100	811-24	HOSE, 1 1/2 INCH ID
53951	8-1/4F5OG-S	ADAPTER, FEMALE PIPE TO STRAIGHT THREAD	61130	1JS43-24-24	HOSE END, FEMALE SWIVEL, SEAL LOK
53980	6 S6LO-S	BRANCH TEE, SWIVEL NUT TO ORFS	61131	1JS78 12-12	HOSE END, FEMALE SWIVEL, SEAL LOK
54132	4 C6LO-S	ELBOW, 90°, SWIVEL NUT ORFS	61132	1J778-12-12	HOSE END, 45° FEMALE SWIVEL, JIC
54135	11343-16-16	HOSE END, MALE SWIVEL, PIPE	61152	139HB-6-4	ELBOW, 45°, BARB TO MALE PIPE
54283	8-10 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS	61251	BV-0750	BALL VALVE
54428	8M18C87OMLO-S	ELBOW, 90° METRIC, STRAIGHT THREAD TO ORFS	61259	4 CC5OLO-S	ELBOW, 90° LONG, STRAIGHT THREAD TO ORFS
54803	FS-F-16-10	SLEEVE, FIRE, .96" ID	61260	20-12 TRLO-BL	REDUCER, TUBE END TO SWIVEL, ORFS
54954	10143-2-4	HOSE END, MALE PIPE	61262	12 C6LO-S	ELBOW, 90°, SWIVEL NUT ORFS
55190	3/8 HP-S	PLUG, PIPE THREAD	61263	20 F5OHAO-S	UNION, STRAIGHT THREAD
55448	8 HLO-S	UNION, ORFS	61264	6-10 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS
55839	6 F65OX-S	CONNECTOR, STRAIGHT THREAD TO 37° SWIVEL	61265	6 WNLO-WLNL-S	UNION, BULKHEAD 45°, ORFS
55968	10 C5OX-S	ELBOW, 90°, STRAIGHT THREAD TO FLARE TUBE	61268	4 WNLO-WLNL-S	UNION, BULKHEAD 45°, ORFS
56003	6 CC5OLO-S	ELBOW, 90° LONG, STRAIGHT THREAD TO ORFS	61269	4 WLO-WLNL-S	UNION, BULKHEAD, ORFS
56166	BV-0837	BALL VALVE, 90°	61272	12 AOEL6	ELBOW, 90°, STRAIGHT THREAD TO ORFS SWIVEL
56188	10143-8-6	HOSE END, MALE PIPE	61316	482TC-16	HOSE, 1 INCH ID
56233	2-011	O-RING, ORFS, -4	61321	6 JLO-S	UNION TEE, ORFS
56234	2-012	O-RING, ORFS, -6	61327	782-12	HOSE, 3/4 INCH ID
56235	2-014	O-RING, ORFS, -8	61328	881-24	HOSE, 1 1/2 INCH ID
56236	2-016	O-RING, ORFS, -10	61336	11943-20-24	HOSE END, 90° FLANGE HEAD
56237	2-018	O-RING, ORFS, -12	61345	12 WJJLO-WLNL-S	RUN TEE, BULKHEAD, ORFS
56238	2-021	O-RING, ORFS, -16	61346	8 WNLO-WLNL-S 4	UNION, BULKHEAD 45°, ORFS
56352	6 WLNL-S	LOCKNUT, BULKHEAD	61569	33782-8-8	HOSE END, 45° FEMALE SWIVEL, JIC
56353	3J782-12-12	HOSE END, 45° FEMALE SWIVEL, SEAL LOK	61610	12 FF5OLO-S	CONNECTOR, LONG, STRAIGHT THREAD TO ORFS
56354	3J982-12-12	HOSE END, 90° FEMALE SWIVEL, SEAL LOK	61742	1/8 X 1.5 FFF	NIPPLE, PIPE
56604	10-8 F5OLO-S	CONNECTOR, STRAIGHT THREAD TO ORFS	63426	8 PNTX-S	PLUG, FLARE TUBE
56639	3JC82-10-10	HOSE END, FEMALE SWIVEL, SEAL LOK			
56640	3J982-10-10	HOSE END, 90° FEMALE SWIVEL, SEAL LOK			
56655	3JC82-8-10	HOSE END, FEMALE SWIVEL, SEAL LOK			
56676	10-8 C5OLO-S	ELBOW, 90°, STRAIGHT THREAD TO ORFS			
56776	471TC-6	HOSE, 3/8 INCH ID			
56777	471TC-8	HOSE, 1/2 INCH ID			
56789	811-16	HOSE, 1 INCH ID			
57884	3/8 FF	NIPPLE, PIPE			
59335	6 FNL-S	CAP, TUBE END			
59342	4 FNL-S	CAP, TUBE END			
59371	8 HP5ON-S	PLUG, STRAIGHT THREAD			
60653	BV-0751	BALL VALVE			
60806	125HB-3-4	FITTING, HOSE BARB TO MALE PIPE			
61064	5-1/4 F5OG-S	ADAPTER, FEMALE PIPE TO STRAIGHT THREAD			
61079	4 WELO-WLNL-S	UNION, 90° BULKHEAD W/NUT, ORFS			
61080	6 WLO-WLNL-S	UNION, BULKHEAD, ORFS			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
64271	4 WLO-WLNL-S	UNION,BULKHEAD,ORFS	75631	801-6	HOSE,3/8 INCH ID
64272	6 WLO-WLNL-S	UNION,BULKHEAD,ORFS	75654	20 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
65776	8 F65OL-S	CONNECTOR,STRAIGHT THREAD TO ORFS SWIVEL	75655	1J943-20-20	HOSE END,90° FEMALE SWIVEL,SEAL LOK
65880	6001012	O-RING KIT	75656	881-20	HOSE,1-1/4 INCH ID
66154	6 WTX-WLNS	UNION,BULKHEAD,FLARE TUBE	75971	8 F5OHAO-S	UNION,STRAIGHT THREAD
66155	6 WETX-S	UNION,BULKHEAD 90°,FLARE TUBE	77307	1JB43-8-8	HOSE END,BULKHEAD,SEAL LOK
66156	6 WLNL-S	BULKHEAD LOCKNUT	77309	8 WLNL-S	BULKHEAD LOCKNUT
66389	6-8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	77379	8M18C87OMX-S	ELBOW,90° METRIC,STRAIGHT THREAD TO FLARE TUBE
66392	6 R5OX-S	RUN TEE,STRAIGHT THREAD	77703	3J982-8-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK
66396	811-12	HOSE,3/4 INCH ID	77711	801-10	HOSE,5/8 INCH ID
66829	H3174PP	CLAMP,TUBE	77758	12 WNLO-WLNL-S	UNION,BULKHEAD 45°,ORFS
67217	4 KLO-S	UNION,CROSS,ORFS	78091	6 C6X-S	ELBOW,90°,SWIVEL NUT TO FLARE TUBE
67339	10-6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE	78684	30582-8-8B	HOSE END,PUSH LOK,MALE
67357	13943-8-6	HOSE END,90° FEMALE SWIVEL,JIC	78852	549-2	HOSE,1/8 INCH ID
67358	10 HP5ON-S	PLUG,STRAIGHT THREAD	78855	10657-4-2	HOSE END,FEMALE SWIVEL,JIC
67371	12 S6LO-S	BRANCH TEE,SWIVEL NUT TO ORFS	79138	PS-B-37	SLEEVE,NYLON,2.38" ID
67498	4 FNL-S	CAP, TUBE END	79476	1JS43-6-8	HOSE END,FEMALE SWIVEL,SEAL LOK
67906	DC-370-F0F0-5	VALVE,CHECK	79847	12-3/4 A0EG-S	ELBOW,90°,STRAIGHT THREAD TO FEMALE PIPE
69316	8 FLO-S	CONNECTOR,MALE PIPE TO ORFS	80044	8 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
69333	H3174PP	CLAMP,HYDRAULIC HOSE	80502	8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
69503	4 F65OX-S	CONNECTOR,STRAIGHT THREAD TO 37° SWIVEL	80503	8 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE
69775	8 FNL-S	CAP, TUBE END	81010	AS-B-27	SLEEVE,NYLON,1.63" ID
71038	1/4X1/4F3HG-S	ADAPTER,CONVERSION	83052	821-6	HOSE,3/8 INCH ID
71196	12-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS	83053	821-8	HOSE,1/2 INCH ID
71383	1/4 CD45-S	ELBOW,45°,MALE TO FEMALE PIPE	83054	821-12	HOSE,3/4 INCH ID
72270	12FNL-S	CAP, TUBE END	83055	30682-6-6	HOSE END,FEMALE SWIVEL,JIC
73436	60C-4	SLEEVE,COMPRESSION	83056	30682-12-12	HOSE END,FEMALE SWIVEL,JIC
73437	61C-4	NUT,COMPRESSION	83057	33782-6-6	HOSE END,45° FEMALE SWIVEL,JIC
73438	33482-4-4B	HOSE END,PUSH LOK,MALE	83058	33982-6-6	HOSE END,90° FEMALE SWIVEL,JIC
73767	1CD-S	ELBOW,90°,MALE TO FEMALE PIPE	83060	33982-12-12	HOSE END,90° FEMALE SWIVEL,JIC
73768	20-16-F5OG5-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD	83063	13743-4-4	HOSE END,45° FEMALE SWIVEL,JIC
73769	16-20 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
74660	6-8 F42EDMLO-S	CONNECTOR,MALE BSPP TO ORFS			
74661	8-8 F42EDMLO-S	CONNECTOR,MALE BSPP TO ORFS			
75007	4 FLO-S	CONNECTOR,MALE PIPE TO ORFS			
75008	1/8 HP-S	PLUG,PIPE THREAD			
75014	1/2 HP-S	PLUG,PIPE THREAD			
75042	8 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS			
75043	3/4 FF-S	NIPPLE,PIPE			
75254	24 F5OHAO-S	UNION,STRAIGHT THREAD			
75255	12 F5OHAO-S	UNION,STRAIGHT THREAD			
75256	XV506P-24	BALL VALVE			
75574	4 WLNL-S	BULKHEAD LOCKNUT			
75612	8 WJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS			
75613	12-8 F5OG5-S	ADAPTER,FEMALE PIPE TO STRAIGHT THREAD			
75614	8 CC5OLO-S	ELBOW,90° LONG,STRAIGHT THREAD TO ORFS			
75628	1JB43-4-4	HOSE END,BULKHEAD,SEAL LOK			

Fitting Cross References (Continued)

Genie PN	Parker PN	Description	Genie PN	Parker PN	Description
83064	13743-8-8	HOSE END,45° FEMALE SWIVEL,JIC	89449	6 WJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
83065	13743-12-12	HOSE END,45° FEMALE SWIVEL,JIC	89489	4 WJMLO-S	BRANCH TEE,BULKHEAD,ORFS
83066	13943-8-8	HOSE END,90° FEMALE SWIVEL,JIC	89551	1JB43-6-6	HOSE END,BULKHEAD,SEAL LOK
83067	14143-6-6	HOSE END,90° FEMALE SWIVEL,JIC	89552	1JB43-8-8	HOSE END,BULKHEAD,SEAL LOK
83068	14143-8-8	HOSE END,90° FEMALE SWIVEL,JIC	89593	20 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
83069	14143-12-12	HOSE END,90° FEMALE SWIVEL,JIC	94161	8-8 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
83070	772-8	HOSE,1/2 INCH ID	94358	351TC-12	HOSE,3/4 INCH ID
83071	10671-8-8	HOSE END,FEMALE SWIVEL,JIC	94418	20 FLO-S	CONNECTOR,MALE PIPE TO ORFS
83072	10671-12-12	HOSE END,FEMALE SWIVEL,JIC	96358	12 TX-S	SLEEVE,FLARE TUBE
83073	13771-8-8	HOSE END,45° FEMALE SWIVEL,JIC	96359	12 BTX-S	NUT,FLARE TUBE
83074	13771-12-12	HOSE END,45° FEMALE SWIVEL,JIC	96397	8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
83075	13971-8-8	HOSE END,90° FEMALE SWIVEL,JIC	96398	12-8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
83076	13971-12-12	HOSE END,90° FEMALE SWIVEL,JIC	96402	10343-6-6	HOSE END,MALE,JIC
83077	14171-8-8	HOSE END,90° FEMALE SWIVEL,JIC	96407	30382-6-6B	HOSE END,MALE,JIC
83078	14171-12-12	HOSE END,90° FEMALE SWIVEL,JIC			
83080	13943-16-16	HOSE END,90° FEMALE SWIVEL,JIC			
83103	10671-16-12	HOSE END,FEMALE SWIVEL,JIC			
83104	10671-10-12	HOSE END,FEMALE SWIVEL,JIC			
83112	1JC71-8-8	HOSE END,FEMALE SWIVEL,SEAL LOK			
83113	1JS71-16-12	HOSE END,FEMALE SWIVEL,SEAL LOK			
83114	1JS71-10-12	HOSE END,FEMALE SWIVEL,SEAL LOK			
83115	1J971-8-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK			
83116	1J171-8-8	HOSE END,90° FEMALE SWIVEL,SEAL LOK			
83117	1J771-8-8	HOSE END,45° FEMALE SWIVEL,SEAL LOK			
83127	1J543-6-8	HOSE END,90° FEMALE SWIVEL,JIC			
83128	1JC43-6-8	HOSE END,FEMALE SWIVEL,SEAL LOK			
87033	12-6 TRLO-S	REDUCER,TUBE END TO SWIVEL,ORFS			
87034	3J782-8-8	HOSE END,45° FEMALE SWIVEL,SEAL LOK			
87172	12 HP5ON-S	PLUG,STRAIGHT THREAD			
87185	8 WNLO-WLNL-S	UNION,BULKHEAD 45°,ORFS			
87246	4 C6X-S	ELBOW,90°,SWIVEL NUT TO FLARE TUBE			
87679	6 LHP-S	FLANGE SEAL FITTING, MALE			
87681	6PLS N0702	BONDED SEAL			
88100	SR88100	ADAPTER,OIL DRAIN,GM 3.0L			
88311	1JS43-20-20	HOSE END,FEMALE SWIVEL,SEAL LOK			
88353	20 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS			
88474	10081-20	Crimp Shell, 1.25"			
88475	1988-20-24	HOSE END,90° FLANGE HEAD			
88476	JS88-24-24	HOSE END,FEMALE SWIVEL,SEAL LOK			
88477	1JC88-20-20	HOSE END,FEMALE SWIVEL,SEAL LOK			
88478	811-20	HOSE,11/4 INCH ID			
88936	20-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS			
88937	20-16 FLO-S	CONNECTOR,MALE PIPE TO ORFS			
88938	1JC88-16-16	HOSE END,FEMALE SWIVEL,SEAL LOK			
88939	1J988-16-16	HOSE END,90° FEMALE SWIVEL,ORFS			
88940	811-16	HOSE,1 INCH ID			
88944	1J988-20-20	HOSE END,90° FEMALE SWIVEL,ORFS			
89403	16 VLO-S	ELBOW,45°,MALE PIPE TO ORFS			

California Proposition 65

Warning

The exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Genie North America

Phone 425.881.1800
Toll Free USA and Canada
800.536.1800
Fax 425.883.3475

Genie Australia Pty Ltd.

Phone +61 7 3375 1660
Fax +61 7 3375 1002

Genie China

Phone +86 21 53852570
Fax +86 21 53852569

Genie Malaysia

Phone +65 98 480 775
Fax +65 67 533 544

Genie Japan

Phone +81 3 3453 6082
Fax +81 3 3453 6083

Genie Korea

Phone +82 25 587 267
Fax +82 25 583 910

Genie Brasil

Phone +55 11 41 665 755
Fax +55 11 41 665 754

Genie Holland

Phone +31 183 581 102
Fax +31 183 581 566

Genie Scandinavia

Phone +46 31 575100
Fax +46 31 579020

Genie France

Phone +33 (0)2 37 26 09 99
Fax +33 (0)2 37 26 09 98

Genie Iberica

Phone +34 93 579 5042
Fax +34 93 579 5059

Genie Germany

Phone +49 (0)4202 88520
Fax +49 (0)4202 8852-20

Genie U.K.

Phone +44 (0)1476 584333
Fax +44 (0)1476 584334

Genie Mexico City

Phone +52 55 5666 5242
Fax +52 55 5666 3241

Distributed By:

Parts Manual

GTH-6622

from SN 10816 to 18723

Part No.
645011

Rev B

