


235469

T13

TRANSMISSION PARTS BOOK

TH528C SS-636C SS-644C SS-842C



DATE: 8-30-99
CLARK T12000 SERIES
INTERMEDIATE DROP

TEREX HANDLERS


455 N. Superior Ave., Baraga, MI 49908-0248

PH: (906) 353-6676; FAX: (906) 353-7543


INTERNET: <http://www.sqshooter.com>

INDEX


<u>PAGE</u>	<u>DESCRIPTION</u>	<u>DRAWING</u>
1	CONVERTER HOUSING GROUP	P1-1244
2	TRANSMISSION CASE AND PLATE GROUP	P1-1245
3	TORQUE CONVERTER GROUP	P1-1265
4	GEAR GROUP	P1-1247
5	PUMP DRIVE GROUP	P1-1248
6	CHARGING PUMP GROUP	P1-1266
7	REVERSE IDLER GROUP	P1-1250
8	FORWARD AND REVERSE SHAFT GROUP	P1-1251
9	3rd SHAFT GROUP	P1-1252
10	FIRST AND SECOND SHAFT GROUP	P1-1253
11	OUTPUT SHAFT GROUP	P1-1254
12	ELECTRIC CONTROL GROUP	P1-1255
13	DRIVE PLATE GROUP	P1-1256



ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-384	CONVERTER HOUSING	1
2	7-126-385	PLUG (INCLUDES ITEM 3)	4
3	7-126-386	O-RING	4
4	7-126-387	PLUG	1
5	7-126-385	PLUG (INCLUDES ITEM 6)	1
6	7-126-386	O-RING	1
7	7-126-04	PLUG	1
8	7-126-388	SCREW	6
9	7-126-389	SCREW	3
10	7-126-390	SCREW	1
11	7-126-391	LOCKWASHER	10
12	7-126-389	SCREW	13
13	7-126-391	LOCKWASHER	13
14	7-126-393	GASKET	1
15	7-126-392	PLUG	1



ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-394	TRANSMISSION CASE	1
2	7-126-05	BREATHER	1
3	7-126-395	PLUG (INCLUDES ITEM 4)	2
4	7-126-358	O-RING	2
5	7-126-33	PLUG / MAGNETIC DRAIN	1
6	7-126-396	PIN	2
7	7-126-357	GASKET	1
8	7-126-359	RING	1
9	7-126-397	CLIP	1
10	7-126-398	SPACER	1
11	7-126-399	SEAT	1
12	7-126-400	SNAP RING	1
13	7-126-401	POPPET	1
14	7-126-402	SPRING	1
15	7-126-403	WASHER	1
16	7-126-387	PLUG	1
17	7-126-385	PLUG (INCLUDES ITEM 18)	3
18	7-126-386	O-RING	3
19	7-126-387	SCREW	7
20	7-126-388	SCREW	2
21	7-126-391	LOCKWASHER	9
22	7-126-392	TUBE AND SCREEN ASSEMBLY	1
23	7-126-265	FILLER PLUG	1
24	7-126-387	PLUG	1
25	7-126-04	PLUG	1
26	7-126-393	PLUG	1
27	7-126-270	DIPSTICK TUBE	1
28	7-126-394	DIPSTICK ASSEMBLY	1
29	7-126-404	PLUG	2
30	7-126-356	O-RING	2
31	7-126-405	SCREW	2
32	7-126-406	SCREW	1
33	7-126-407	WASHER	1
34	7-126-408	SCREW	1
35	7-126-407	WASHER	1
36	7-126-409	WASHER	1
37	7-126-410	NUT	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-411	STATOR SUPPORT ASSY (INCL. ITEMS 2-3)	1
2	7-126-412	BUSHING	1
3	7-126-413	BEARING	1
4	7-126-414	STATOR SUPPORT PISTON RING	1
5	7-126-415	EXPANDER	1
6	7-126-416	SNAP RING	2
7	7-126-360	SEAL	1
8	7-126-518	TORQUE CONVERTER ASSEMBLY	1
9	7-126-234	TORQUE CONVERTER PLUG	1
10	7-126-233	O-RING	1
11	7-126-277	SNAP RING	1
12	7-126-417	IMPELLER HUB GEAR	1
13	7-126-418	SNAP RING	2
14	7-126-419	WASHER	1
15	7-126-420	BEARING	1
16	7-126-421	OIL DISTRIBUTOR RING	1

DRAWING
NUMBER


P1-1265

TORQUE CONVERTER GROUP
T12000 TRANSMISSION / TH528C SS-636C SS-644C SS-842C


PAGE
NUMBER 3A




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-422	REV CL. GEAR & BRNG ASSY (INCL. ITEMS 2-3)	1
2	7-126-423	BEARING	2
3	7-126-424	SPACER	1
4	7-126-425	FWD CL. GEAR & BRNG ASSY (INCL. ITEMS 5-6)	1
5	7-126-423	BEARING	2
6	7-126-424	SPACER	1
7	7-126-428	3rd CL. GEAR & BRNG ASSY (INCL. ITEM 8)	1
8	7-126-429	BEARING	2
9	7-126-430	1st CL. GEAR & BRNG ASSY (INCL. ITEM 10)	1
10	7-126-423	BEARING	2
11	7-126-432	2nd CL. GEAR & BRNG ASSY (INCL. ITEM 12)	1
12	7-126-423	BEARING	2
13	7-126-427	3rd DRIVEN GEAR	1
14	7-126-426	OUTPUT SHAFT GEAR	1
15	7-126-431	REVERSE IDLER GEAR	1
16	7-126-433	FIRST DRIVEN GEAR	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-434	PUMP DRIVE IDLER GEAR	1
2	7-126-435	BEARING	1
3	7-126-436	PUMP DRIVE GEAR	1
4	7-126-437	PUMP DRIVE IDLER THRUST WASHER	2
5	7-126-438	PUMP DRIVE SHAFT & PIN ASSY (INCL. ITEM 6)	1
6	7-126-439	ROLL PIN	1
7	7-126-440	PUMP DRIVE GEAR BEARING	1
8	7-126-441	PUMP DRIVE GEAR BEARING	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-350	CHARGING PUMP ASSEMBLY	1
2	7-126-349	HYDRAULIC SPIN FILTER ASSEMBLY	1
3	7-126-442	REGULATOR VALVE SLEEVE	1
4	7-126-443	REGULATOR VALVE PISTON	1
5	7-126-444	REGULATOR VALVE SPRING	1
6	7-126-445	PIN	1
7	7-126-446	BALL CHECK VALVE ASSY (INCL. ITEMS 7-11)	1
8	7-126-447	BALL	1
9	7-126-448	CHECK VALVE SPRING	1
10	7-126-449	CHECK VALVE PIN	1
11	7-126-361	O-RING	1
12	7-126-362	CHARGING PUMP GASKET	2
13	7-126-450	PUMP MOUNTING SCREW	4
14	7-126-451	PUMP MOUNTING STUD	1
15	7-126-452	LOCKWASHER	5
16	7-126-453	PUMP MOUNTING STUD	1
17	7-126-391	LOCKWASHER	1
18	7-126-454	NUT	1
19	7-126-410	NUT	1
20	7-126-522	PUMP DRIVE ADAPTOR	1
21	7-126-455	PUMP ADAPTOR	1
22	7-126-521	SPACER PLATE	1
23	7-126-520	O-RING	1
24	7-126-519	SCREW	2
25	7-126-215	LOCKWASHER	2
26	7-126-456	REGULATOR VALVE ASSY (INCL. ITEMS 3-6)	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-457	IDLER & PILOT SHAFT	1
2	7-126-458	IDLER SHAFT SNAP RING	1
3	7-126-459	REVERSE IDLER GEAR BEARING	1
4	7-126-460	THRUST WASHER	1
5	7-126-461	END PLATE	1
6	7-126-462	CAPSCREW	1
7	7-126-463	WASHER	1
8	7-126-464	ROLL PIN	1
9	7-126-431	REVERSE IDLER GEAR	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-465	TURBINE SHAFT DRUM & PLUG ASSY	1
2	7-126-466	OIL DISTRIBUTOR SLEEVE	1
3	7-126-467	RETAINER SCREW	1
4	7-126-468	PISTON RING	3
5	7-126-469	PISTON & SEALS ASSY (INCL. ITEMS 6-7)	2
6	7-126-470	OUTER CLUTCH PISTON SEAL	2
7	7-126-471	INNER CLUTCH PISTON SEAL	2
8	7-126-472	END PLATE	2
9	7-126-473	SNAP RING	2
10	7-126-474	CLUTCH PISTON WEAR PLATE	2
11	7-126-475	DISC SPRING ASSEMBLY	2
12	7-126-476	SNAP RING RETAINER	2
13	7-126-477	SNAP RING	2
14	7-126-478	OUTER DISC (6 FORWARD / 6 REVERSE)	12
15	7-126-479	INNER DISC (6 FORWARD / 6 REVERSE)	12
16	7-126-480	CLUTCH GEAR THRUST BEARING	4
17	7-126-481	WASHER	8
18	7-126-482	REAR TURBINE SHAFT BEARING	1
19		CL. GEAR BRNG (SEE GEAR GROUP)	4
20		CL. GEAR BRNG SPACER (SEE GEAR GROUP)	2
21		REV CLUTCH GEAR (SEE GEAR GROUP)	1
22		FWD CLUTCH GEAR (SEE GEAR GROUP)	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-483	3rd SHAFT, DRUM, & PLUG ASSY	1
2	7-126-484	ROLLER BEARING	1
3	7-126-485	BEARING & SEAL ASSY	1
4	7-126-486	BEARING SUPPORT WASHER	1
5	7-126-487	OIL DISTRIBUTOR SLEEVE	1
6	7-126-488	SCREW	1
7	7-126-468	PISTON RING	2
8	7-126-489	PISTON & SEALS ASSY (INCLUDES ITEMS 9-10)	1
9	7-126-470	OUTER CLUTCH PISTON SEAL	1
10	7-126-471	INNER CLUTCH PISTON SEAL	1
11	7-126-478	OUTER DISC	5
12	7-126-479	INNER DISC	5
13	7-126-472	END PLATE	1
14	7-126-473	SNAP RING	1
15	7-126-474	CLUTCH PISTON WEAR PLATE	1
16	7-126-475	DISC SPRING ASSY (INCL. 5 WASHERS)	1
17	7-126-476	SNAP RING RETAINER	1
18	7-126-477	SNAP RING	1
19	7-126-490	NEEDLE ROLLER THRUST BEARING	2
20	7-126-491	THRUST WASHER	4
21	7-126-492	SNAP RING	3
22	7-126-429	3rd CLUTCH GEAR BEARING (SEE GEAR GROUP)	2
23		3rd CLUTCH GEAR (SEE GEAR GROUP)	1
24		FIRST DRIVE GEAR (SEE GEAR GROUP)	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-493	1st & 2nd SHAFT, DRUM, PLUG, & SEAT ASSY	1
2	7-126-494	ROLLER BEARING	1
3	7-126-485	BEARING & SEAL ASSY	1
4	7-126-468	PISTON RING	2
5	7-126-495	PISTON & SEALS ASSY (INCL. ITEMS 6 & 7)	2
6	7-126-470	OUTER CLUTCH PISTON SEAL	2
7	7-126-471	INNER CLUTCH PISTON SEAL	2
8	7-126-472	END PLATE	2
9	7-126-473	SNAP RING	2
10	7-126-474	CLUTCH PISTON WEAR PLATE	2
11	7-126-475	2nd DISC SPRING ASSY (INCL. 5 WASHERS)	1
12	7-126-496	1st DISC SPRING ASSY (INCL. 7 WASHERS)	1
13	7-126-476	SNAP RING RETAINER	2
14	7-126-477	SNAP RING	2
15	7-126-480	CLUTCH GEAR THRUST BEARING	4
16	7-126-481	CLUTCH GEAR THRUST WASHER	8
17	7-126-497	SNAP RING	2
18	7-126-498	OIL DISTRIBUTOR SLEEVE	1
19	7-126-499	SLEEVE RETAINING SCREW	1
20	7-126-478	OUTER DISC (1st)	10
21	7-126-479	INNER DISC (1st)	10
22	7-126-478	OUTER DISC (2nd)	5
23	7-126-479	INNER DISC (2nd)	5
24	7-126-423	CLUTCH GEAR BEARING (SEE GEAR GROUP)	4
25		1st CLUTCH GEAR (SEE GEAR GROUP)	1
26		2nd CLUTCH GEAR (SEE GEAR GROUP)	1
27		3rd DRIVEN GEAR (SEE GEAR GROUP)	1



ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-500	OUTPUT SHAFT	1
2	7-126-307	OUTPUT SHAFT BEARING	2
3	7-126-368	OIL SEAL SLEEVE	2
4	7-126-366	O-RING	2
5	7-126-367	OUTPUT SHAFT OIL SEAL	2
6	7-126-365	SNAP RING	4
7	7-126-369	SNAP RING	2
8	7-126-364	OUTPUT FLANGE & PLUG ASSY (INCL. ITEM 9)	1
9	7-126-363	FLANGE PLUG	1
10	7-126-426	OUTPUT SHAFT GEAR (SEE GEAR GROUP)	1



ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-382	SOLENOID ASSEMBLY (INCLUDES ITEMS 2-10)	4
2	7-126-380	4-WAY VALVE CARTRIDGE (INCL. ITEMS 3-6)	4
3	7-126-376	O-RING	4
4	7-126-377	O-RING	4
5	7-126-378	O-RING	4
6	7-126-379	O-RING	4
7	7-126-374	O-RING	4
8	7-126-375	SOLENOID COIL (12V)	4
9	7-126-374	O-RING	4
10	7-126-373	NUT	4
11	7-126-501	PROTECTIVE COVER	1
12	7-126-502	SCREW	2
13	7-126-503	LOCKWASHER	2
14	7-126-504	MODULATOR VALVE HOUSING	2
15	7-126-371	O-RING	2
16	7-126-505	INNER SPRING	2
17	7-126-506	MIDDLE SPRING	2
18	7-126-507	OUTER SPRING	2
19	7-126-508	MODULATION VALVE SLEEVE	2
20	7-126-372	O-RING	2
21	7-126-63	PIN	2
22	7-126-509	ACCUMULATOR SPOOL	2
23	7-126-510	REGULATOR SPOOL	2
24	7-126-511	MODULATOR VALVE SPOOL	2
25	7-126-512	SPRING RETAINER	2
26	7-126-513	SPRING SPACER	2
27	7-126-514	UPPER PIN	2
28	7-126-515	LOWER PIN	2
29	7-126-381	SOLENOID BORE PLUG	1
30	7-126-379	O-RING	1
31	7-126-378	O-RING	1
32	7-126-376	O-RING	1



ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-383	DRIVE PLATE ASSY (INCL. IN ITEM 6-N.S.S.)	1
2	7-126-383	DRIVE PLATE (INCL. IN ITEM 6-N.S.S.)	2
3	7-126-60	DRIVE PLATE BACKING RING	1
4	7-126-516	SCREW	6
5	7-126-54	LOCKWASHER	6
6	7-126-383	DRIVE PLATE KIT (INCLUDES ITEMS 1-5)	1