


TRANSMISSION PARTS BOOK

TH528C TH528C TURBO
TH636C TH644C TH842C TH844C



DATE: 3-17-03
CLARK T12000 SERIES
INTERMEDIATE DROP

TEREX HANDLERS


455 N. Superior Ave., Baraga, MI 49908-0790

PH: (906) 353-6675; FAX: (906) 353-7543


INTERNET: <http://www.sqshooter.com>

INDEX


PAGE	DESCRIPTION	DRAWING
1	CONVERTER HOUSING GROUP	P1-1244
2	TRANSMISSION CASE AND PLATE GROUP	P1-1245
3	TORQUE CONVERTER GROUP	P1-1265
4	GEAR GROUP	P1-1247
5	PUMP DRIVE GROUP	P1-1248
6	CHARGING PUMP GROUP	P1-1266
7	REVERSE IDLER GROUP	P1-1250
8	FORWARD AND REVERSE SHAFT GROUP	P1-1251
9	3rd SHAFT GROUP	P1-1252
10	FIRST AND SECOND SHAFT GROUP	P1-1253
11	OUTPUT SHAFT GROUP	P1-1254
12	ELECTRIC CONTROL GROUP	P1-1255
13	DRIVE PLATE GROUP / ALL EXC. TH528C TURBO	P1-1256
14	DRIVE PLATE GROUP / TH528C TURBO ONLY	P1-1791




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-384	CONVERTER HOUSING	1
2	7-126-385	PLUG (INCLUDES ITEM 3)	4
3	7-126-386	O-RING	4
4	7-126-387	PLUG	1
5	7-126-385	PLUG (INCLUDES ITEM 6)	1
6	7-126-386	O-RING	1
7	7-126-04	PLUG	1
8	7-126-388	SCREW	6
9	7-126-389	SCREW	3
10	7-126-390	SCREW	1
11	7-126-391	LOCKWASHER	10
12	7-126-389	SCREW	13
13	7-126-391	LOCKWASHER	13
14	7-126-393	GASKET	1
15	7-126-392	PLUG	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-394	TRANSMISSION CASE	1
2	7-126-05	BREATHER	1
3	7-126-395	PLUG (INCLUDES ITEM 4)	2
4	7-126-358	O-RING	2
5	7-126-33	PLUG / MAGNETIC DRAIN	1
6	7-126-396	PIN	2
7	7-126-357	GASKET	1
8	7-126-359	RING	1
9	7-126-397	CLIP	1
10	7-126-398	SPACER	1
11	7-126-399	SEAT	1
12	7-126-400	SNAP RING	1
13	7-126-401	POPPET	1
14	7-126-402	SPRING	1
15	7-126-403	WASHER	1
16	7-126-387	PLUG	1
17	7-126-385	PLUG (INCLUDES ITEM 18)	3
18	7-126-386	O-RING	3
19	7-126-387	SCREW	7
20	7-126-388	SCREW	2
21	7-126-391	LOCKWASHER	9
22	7-126-392	TUBE AND SCREEN ASSEMBLY	1
23	7-126-265	FILLER PLUG	1
24	7-126-387	PLUG	1
25	7-126-04	PLUG	1
26	7-126-393	PLUG	1
27	7-126-270	DIPSTICK TUBE	1
28	7-126-671	DIPSTICK ASSEMBLY	1
29	7-126-404	PLUG	2
30	7-126-356	O-RING	2
31	7-126-405	SCREW	2
32	7-126-406	SCREW	1
33	7-126-407	WASHER	1
34	7-126-408	SCREW	1
35	7-126-407	WASHER	1
36	7-126-409	WASHER	1
37	7-126-410	NUT	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-411	STATOR SUPPORT ASSY (INCL. ITEMS 2-3)	1
2	7-126-412	BUSHING	1
3	7-126-413	BEARING	1
4	7-126-414	STATOR SUPPORT PISTON RING	1
5	7-126-415	EXPANDER	1
6	7-126-416	SNAP RING	2
7	7-126-360	SEAL	1
8	7-126-518	TORQUE CONVERTER ASSEMBLY	1
9	7-126-234	TORQUE CONVERTER PLUG	1
10	7-126-233	O-RING	1
11	7-126-277	SNAP RING	1
12	7-126-417	IMPELLER HUB GEAR	1
13	7-126-418	SNAP RING	2
14	7-126-419	WASHER	1
15	7-126-420	BEARING	1
16	7-126-421	OIL DISTRIBUTOR RING	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-422	REV CL. GEAR & BRNG ASSY (INCL. ITEMS 2-3)	1
2	7-126-423	BEARING	2
3	7-126-424	SPACER	1
4	7-126-425	FWD CL. GEAR & BRNG ASSY (INCL. ITEMS 5-6)	1
5	7-126-423	BEARING	2
6	7-126-424	SPACER	1
7	7-126-428	3rd CL. GEAR & BRNG ASSY (INCL. ITEM 8)	1
8	7-126-429	BEARING	2
9	7-126-430	1st CL. GEAR & BRNG ASSY (INCL. ITEM 10)	1
10	7-126-423	BEARING	2
11	7-126-432	2nd CL. GEAR & BRNG ASSY (INCL. ITEM 12)	1
12	7-126-423	BEARING	2
13	7-126-427	3rd DRIVEN GEAR	1
14	7-126-426	OUTPUT SHAFT GEAR	1
15	7-126-431	REVERSE IDLER GEAR	1
16	7-126-433	FIRST DRIVEN GEAR	1



ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-434	PUMP DRIVE IDLER GEAR	1
2	7-126-435	BEARING	1
3	7-126-436	PUMP DRIVE GEAR	1
4	7-126-437	PUMP DRIVE IDLER THRUST WASHER	2
5	7-126-438	PUMP DRIVE SHAFT & PIN ASSY (INCL. ITEM 6)	1
6	7-126-439	ROLL PIN	1
7	7-126-440	PUMP DRIVE GEAR BEARING	1
8	7-126-441	PUMP DRIVE GEAR BEARING	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-350	CHARGING PUMP ASSEMBLY	1
2	7-126-349	HYDRAULIC SPIN FILTER ASSEMBLY	1
3	7-126-442	REGULATOR VALVE SLEEVE	1
4	7-126-443	REGULATOR VALVE PISTON	1
5	7-126-444	REGULATOR VALVE SPRING	1
6	7-126-445	PIN	1
7	7-126-446	BALL CHECK VALVE ASSY (INCL. ITEMS 7-11)	1
8	7-126-447	BALL	1
9	7-126-448	CHECK VALVE SPRING	1
10	7-126-449	CHECK VALVE PIN	1
11	7-126-361	O-RING	1
12	7-126-362	CHARGING PUMP GASKET	2
13	7-126-450	PUMP MOUNTING SCREW	4
14	7-126-451	PUMP MOUNTING STUD	1
15	7-126-452	LOCKWASHER	5
16	7-126-453	PUMP MOUNTING STUD	1
17	7-126-391	LOCKWASHER	1
18	7-126-454	NUT	1
19	7-126-410	NUT	1
20	7-126-522	PUMP DRIVE ADAPTOR	1
21	7-126-455	PUMP ADAPTOR	1
22	7-126-521	SPACER PLATE	1
23	7-126-520	O-RING	1
24	7-126-519	SCREW	2
25	7-126-215	LOCKWASHER	2
26	7-126-456	REGULATOR VALVE ASSY (INCL. ITEMS 3-6)	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-457	IDLER & PILOT SHAFT	1
2	7-126-458	IDLER SHAFT SNAP RING	1
3	7-126-459	REVERSE IDLER GEAR BEARING	1
4	7-126-460	THRUST WASHER	1
5	7-126-461	END PLATE	1
6	7-126-462	CAPSCREW	1
7	7-126-463	WASHER	1
8	7-126-464	ROLL PIN	1
9	7-126-431	REVERSE IDLER GEAR	1


This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-465	TURBINE SHAFT DRUM & PLUG ASSY	1
2	7-126-466	OIL DISTRIBUTOR SLEEVE	1
3	7-126-467	RETAINER SCREW	1
4	7-126-468	PISTON RING	3
5	7-126-469	PISTON & SEALS ASSY (INCL. ITEMS 6-7)	2
6	7-126-470	OUTER CLUTCH PISTON SEAL	2
7	7-126-471	INNER CLUTCH PISTON SEAL	2
8	7-126-472	END PLATE	2
9	7-126-473	SNAP RING	2
10	7-126-474	CLUTCH PISTON WEAR PLATE	2
11	7-126-475	DISC SPRING ASSEMBLY	2
12	7-126-476	SNAP RING RETAINER	2
13	7-126-477	SNAP RING	2
14	7-126-478	OUTER DISC (6 FORWARD / 6 REVERSE)	12
15	7-126-479	INNER DISC (6 FORWARD / 6 REVERSE)	12
16	7-126-480	CLUTCH GEAR THRUST BEARING	4
17	7-126-481	WASHER	8
18	7-126-482	REAR TURBINE SHAFT BEARING	1
19		CL. GEAR BRNG (SEE GEAR GROUP)	4
20		CL. GEAR BRNG SPACER (SEE GEAR GROUP)	2
21		REV CLUTCH GEAR (SEE GEAR GROUP)	1
22		FWD CLUTCH GEAR (SEE GEAR GROUP)	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-483	3rd SHAFT, DRUM, & PLUG ASSY	1
2	7-126-484	ROLLER BEARING	1
3	7-126-485	BEARING & SEAL ASSY	1
4	7-126-486	BEARING SUPPORT WASHER	1
5	7-126-487	OIL DISTRIBUTOR SLEEVE	1
6	7-126-488	SCREW	1
7	7-126-468	PISTON RING	2
8	7-126-489	PISTON & SEALS ASSY (INCLUDES ITEMS 9-10)	1
9	7-126-470	OUTER CLUTCH PISTON SEAL	1
10	7-126-471	INNER CLUTCH PISTON SEAL	1
11	7-126-478	OUTER DISC	5
12	7-126-479	INNER DISC	5
13	7-126-472	END PLATE	1
14	7-126-473	SNAP RING	1
15	7-126-474	CLUTCH PISTON WEAR PLATE	1
16	7-126-475	DISC SPRING ASSY (INCL. 5 WASHERS)	1
17	7-126-476	SNAP RING RETAINER	1
18	7-126-477	SNAP RING	1
19	7-126-490	NEEDLE ROLLER THRUST BEARING	2
20	7-126-491	THRUST WASHER	4
21	7-126-492	SNAP RING	3
22	7-126-429	3rd CLUTCH GEAR BEARING (SEE GEAR GROUP)	2
23		3rd CLUTCH GEAR (SEE GEAR GROUP)	1
24		FIRST DRIVE GEAR (SEE GEAR GROUP)	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-493	1st & 2nd SHAFT, DRUM, PLUG, & SEAT ASSY	1
2	7-126-494	ROLLER BEARING	1
3	7-126-485	BEARING & SEAL ASSY	1
4	7-126-468	PISTON RING	2
5	7-126-495	PISTON & SEALS ASSY (INCL. ITEMS 6 & 7)	2
6	7-126-470	OUTER CLUTCH PISTON SEAL	2
7	7-126-471	INNER CLUTCH PISTON SEAL	2
8	7-126-472	END PLATE	2
9	7-126-473	SNAP RING	2
10	7-126-474	CLUTCH PISTON WEAR PLATE	2
11	7-126-475	2nd DISC SPRING ASSY (INCL. 5 WASHERS)	1
12	7-126-496	1st DISC SPRING ASSY (INCL. 7 WASHERS)	1
13	7-126-476	SNAP RING RETAINER	2
14	7-126-477	SNAP RING	2
15	7-126-480	CLUTCH GEAR THRUST BEARING	4
16	7-126-481	CLUTCH GEAR THRUST WASHER	8
17	7-126-497	SNAP RING	2
18	7-126-498	OIL DISTRIBUTOR SLEEVE	1
19	7-126-499	SLEEVE RETAINING SCREW	1
20	7-126-478	OUTER DISC (1st)	10
21	7-126-479	INNER DISC (1st)	10
22	7-126-478	OUTER DISC (2nd)	5
23	7-126-479	INNER DISC (2nd)	5
24	7-126-423	CLUTCH GEAR BEARING (SEE GEAR GROUP)	4
25		1st CLUTCH GEAR (SEE GEAR GROUP)	1
26		2nd CLUTCH GEAR (SEE GEAR GROUP)	1
27		3rd DRIVEN GEAR (SEE GEAR GROUP)	1



ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-500	OUTPUT SHAFT	1
2	7-126-307	OUTPUT SHAFT BEARING	2
3	7-126-368	OIL SEAL SLEEVE	2
4	7-126-366	O-RING	2
5	7-126-367	OUTPUT SHAFT OIL SEAL	2
6	7-126-365	SNAP RING	4
7	7-126-369	SNAP RING	2
8	7-126-364	OUTPUT FLANGE & PLUG ASSY (INCL. ITEM 9)	1
9	7-126-363	FLANGE PLUG	1
10	7-126-426	OUTPUT SHAFT GEAR (SEE GEAR GROUP)	1




ITEM	NUMBER	DESCRIPTION	REQD
1	7-126-382	SOLENOID ASSEMBLY (INCLUDES ITEMS 2-10)	4
2	7-126-380	4-WAY VALVE CARTRIDGE (INCL. ITEMS 3-6)	4
3	7-126-376	O-RING	4
4	7-126-377	O-RING	4
5	7-126-378	O-RING	4
6	7-126-379	O-RING	4
7	7-126-374	O-RING	4
8	7-126-375	SOLENOID COIL (12V)	4
9	7-126-374	O-RING	4
10	7-126-373	NUT	4
11	7-126-501	PROTECTIVE COVER	1
12	7-126-502	SCREW	2
13	7-126-503	LOCKWASHER	2
14	7-126-504	MODULATOR VALVE HOUSING	2
15	7-126-371	O-RING	2
16	7-126-505	INNER SPRING	2
17	7-126-506	MIDDLE SPRING	2
18	7-126-507	OUTER SPRING	2
19	7-126-508	MODULATION VALVE SLEEVE	2
20	7-126-372	O-RING	2
21	7-126-63	PIN	2
22	7-126-509	ACCUMULATOR SPOOL	2
23	7-126-510	REGULATOR SPOOL	2
24	7-126-511	MODULATOR VALVE SPOOL	2
25	7-126-512	SPRING RETAINER	2
26	7-126-513	SPRING SPACER	2
27	7-126-514	UPPER PIN	2
28	7-126-515	LOWER PIN	2
29	7-126-381	SOLENOID BORE PLUG	1
30	7-126-379	O-RING	1
31	7-126-378	O-RING	1
32	7-126-376	O-RING	1



ITEM	NUMBER	DESCRIPTION	REQD
1	N.S.S.	DRIVE PLATE w/ WELD NUTS	1
2	N.S.S.	DRIVE PLATE	2
3	7-126-60	DRIVE PLATE BACKING RING	1
4	7-126-516	SCREW	6
5	7-126-54	LOCKWASHER	6
6	7-126-383	DRIVE PLATE KIT (INCLUDES ITEMS 1-5)	1

N.S.S. = NOT SOLD SEPARATELY



ITEM	NUMBER	DESCRIPTION	REQD
1	N.S.S.	DRIVE PLATE	3
2	7-126-60	DRIVE PLATE BACKING RING	1
3	7-126-516	SCREW	6
4	7-126-54	LOCKWASHER	6
5	7-126-692	DRIVE PLATE KIT (INCLUDES ITEMS 1-4)	1

N.S.S. = NOT SOLD SEPARATELY

